

6-2 [T8A0] BODY ELECTRICAL SYSTEM (CRUISE CONTROL)

8. Diagnostics Chart with Diagnostic Code

8. Diagnostics Chart with Diagnostic Code

A: DIAGNOSTIC CODE LIST

Diagnostic code	Item	Contents of diagnosis	Index No.
11	BRAKE SW/STOP SW	Input signals from brake switch "OFF", stop light switch "ON" (Brake pedal is depressed.)	<Ref. to 6-2 [T8B0].>
12	CLUTCH SW/INHIBITOR SW	Input signals from clutch switch "OFF" (MT), or inhibitor switch "P or N" (AT) [Clutch pedal is depressed (MT), or selector lever is set to P or N position (AT).]	<Ref. to 6-2 [T8C0].>
13	LOW SPEED LIMIT	Low-speed control limiter	<Ref. to 6-2 [T8D0].>
14	CANCEL SW	Input signal from cancel switch (faulty SET/COAST switch or RESUME/ACCEL switch)	<Ref. to 6-2 [T8E0].>
21	VACUUM VALVE	Faulty vacuum valve or valve drive system	<Ref. to 6-2 [T8F0].>
22	VENT 2 VALVE	Faulty vent 2 valve or valve drive system	<Ref. to 6-2 [T8F0].>
23	VENT 1 VALVE	Faulty vent 1 valve or valve drive system	<Ref. to 6-2 [T8F0].>
24	SPEED SENSOR	Faulty vehicle speed sensor 2	<Ref. to 6-2 [T8D0].>
25	CONTROL MODULE	Faulty CPU RAM included in cruise control module	<Ref. to 6-2 [T8G0].>

B: DIAGNOSTIC CODE 11 (BRAKE SWITCH, STOP LIGHT SWITCH)


DIAGNOSIS:

- Failure or disconnection of the stop light switch and brake switch.

TROUBLE SYMPTOM:

- Cruise control cannot be set.

WIRING DIAGRAM:



6-2 [T8B1] BODY ELECTRICAL SYSTEM (CRUISE CONTROL)


8. Diagnostics Chart with Diagnostic Code

8B1 : CHECK BRAKE SWITCH.

- 1) Turn ignition switch to ON.
- 2) Turn cruise control main switch to ON.
- 3) Apply parking brake securely.
- 4) Set select monitor in "Current Data Display & Save" mode.
- 5) Depress the brake pedal and check signals for proper operation.
 - (1) The Stop Lamp Switch shown on the display turns from "OFF" to "ON".
 - (2) The Brake Switch shown on the display turns from "OFF" to "ON".
- 6) Release the brake pedal.
- 7) Remove connector of stop and brake switch.
- 8) Check circuit between brake switch terminal.

Terminals

No. 1 — No. 4: (Brake switch)




- CHECK** : *Is resistance less than 1 Ω ? (When brake pedal is released.)*
- YES** : Go to step 8B2.
- NO** : Replace brake and stop light switch.

8B2 : CHECK BRAKE SWITCH.

Check circuit between brake switch terminal.

Terminals

No. 1 — No. 4: (Brake switch)




- CHECK** : *Is resistance more than 1 M Ω ? (When brake pedal is depressed.)*
- YES** : Go to step 8B3.
- NO** : Replace brake and stop light switch.

8B3 : CHECK STOP LIGHT SWITCH.

Check circuit between stop light switch terminal.

Terminals

No. 2 — No. 3: (Stop light switch)




- CHECK** : *Is resistance more than 1 M Ω ? (When brake pedal is released.)*
- YES** : Go to step 8B4.
- NO** : Replace brake and stop light switch.

8B4 : CHECK STOP LIGHT SWITCH.

Check circuit between stop light switch terminal.

Terminals

No. 2 — No. 3: (Stop light switch)



CHECK : *Is resistance less than 1 Ω ? (When brake pedal is depressed.)*

YES : Replace cruise control module.

NO : Replace brake and stop light switch.

MEMO:

C: DIAGNOSTIC CODE 12 (CLUTCH SWITCH, INHIBITOR SWITCH)


DIAGNOSIS:

- Failure or disconnection of the clutch switch. (MT)
- Failure or disconnection of the inhibitor switch. (AT)

TROUBLE SYMPTOM:

- Cruise control cannot be set.

WIRING DIAGRAM:



S6M0113

6-2 [T8C1] BODY ELECTRICAL SYSTEM (CRUISE CONTROL)


8. Diagnostics Chart with Diagnostic Code

8C1 : CHECK CLUTCH SWITCH. (MT)

- 1) Turn ignition switch to ON.
- 2) Turn cruise control main switch to ON.
- 3) Apply parking brake securely.
- 4) Set select monitor in "Current Data Display & Save" mode.
- 5) Depress the clutch pedal and check signal for proper operation. (MT)
The Clutch/Inhibitor Switch shown on the display turns from "ON" to "OFF".
- 6) Disconnect connector of clutch switch.
- 7) Check continuity of the clutch switch.

Terminals

No. 1 — No. 2:




- CHECK** : Is resistance less than 10 Ω ? (When clutch pedal is released.)
- YES** : Go to step 8C2.
- NO** : Replace clutch switch.

8C2 : CHECK CLUTCH SWITCH. (MT)

Check continuity of the clutch switch.

Terminals

No. 1 — No. 2:




- CHECK** : Is resistance more than 1 M Ω ? (When clutch pedal is depressed.)
- YES** : Replace cruise control module.
- NO** : Replace clutch switch.

8C3 : CHECK INHIBITOR SWITCH. (AT)

- 1) Turn ignition switch to ON.
- 2) Turn cruise control main switch to ON.
- 3) Apply parking brake securely.
- 4) Set select monitor in "Current Data Display & Save" mode.
- 5) Set the selector lever from P or N position to D position and check signal for proper operation. (AT)
The Clutch/Inhibitor Switch shown on the display turns from "ON" to "OFF".
- 6) Set the selector lever to P or N position.
- 7) Disconnect connector of inhibitor switch.
- 8) Check continuity of the inhibitor switch.

Terminals

No. 11 — No. 12:




- CHECK** : Is resistance less than 10 Ω ? (When selector lever is in P or N.)
- YES** : Go to step 8C4.
- NO** : Replace inhibitor switch. Repair inhibitor switch wiring harness.

8C4 : CHECK INHIBITOR SWITCH. (AT)

Check continuity of the inhibitor switch.

Terminals

No. 11 — No. 12:



- CHECK** : *Is resistance more than 1 MΩ? (When selector lever is not in P or N.)*
- YES** : Replace cruise control module.
- NO** : Replace inhibitor switch. Repair inhibitor switch wiring harness.

MEMO:

D: DIAGNOSTIC CODE 13 AND 24 (VEHICLE SPEED SENSOR 2 SYSTEM)


DIAGNOSIS:

- Disconnection or short circuit of vehicle speed sensor 2 system.

TROUBLE SYMPTOM:

- Cruise control cannot be set. (Cancelled immediately.)

WIRING DIAGRAM:



S6M0115

8D1 : CHECK OPERATION OF SPEEDOMETER.

Make sure that speedometer indicates the vehicle speed by driving the vehicle.

CHECK : Does speedometer indicate vehicle speed by driving vehicle?

YES : Go to step 8D2.

NO : Repair combination meter circuit.

8D2 : CHECK INPUT SIGNAL FOR CRUISE CONTROL MODULE.


WARNING:

Be careful not to be caught up by the running wheels.

- 1) Set the vehicle on free roller, or lift-up the vehicle and support with safety stands.
- 2) Set oscilloscope to cruise control module connector terminals.
- 3) Start the engine.
- 4) Shift on the gear position, and keep the vehicle speed at constant.
- 5) Measure signal voltage.

Connector & terminal


(B94) No. 18 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 2 V?
- YES** : Replace cruise control module.
- NO** : Go to step 8D3.

NOTE:

- If the vehicle speed increases, the width of amplitude (W) decreases.




- If oscilloscope is not available, check input signal (vehicle speed signal) by using a select monitor. (Refer to the procedure as described below.)
- Using the select monitor:
 - 1) Set the vehicle on free roller, or lift-up the vehicle and support with safety stands.
 - 2) Turn ignition switch to OFF and set select monitor.

- 3) Turn ignition switch to ON.
- 4) Turn cruise control main switch to ON.
- 5) Set select monitor in "Current Data Display & Save" mode.
- 6) Drive the vehicle at speed greater than 40 km/h (25 MPH).
- 7) Check that vehicle speed indication on select monitor and speedometer are equal.
- When there is a disconnection or short circuit in the harness between the meter and the cruise control module, the indicated value will be 0 to 1.0 km/h (0 to 0.6 MPH).

8D3 : PERFORM A CIRCUIT TEST BETWEEN COMBINATION METER AND CRUISE CONTROL MODULE.


- 1) Turn ignition switch to OFF.
- 2) Remove combination meter.



- 3) Disconnect connector from cruise control module.
- 4) Measure resistance of harness connector between combination meter and cruise control module.

Connector & terminal

(i12) No. 11 — (B94) No. 18:




- CHECK** : Is resistance less than 10 Ω?
- YES** : Go to step 8D4.
- NO** : Repair or replace harness connector.

8D4 : PERFORM A CIRCUIT TEST BETWEEN COMBINATION METER AND CRUISE CONTROL MODULE.

Measure resistance of harness connector between cruise control module and chassis ground to make sure that circuit does not short.

Connector & terminal

(B94) No. 18 (+) — Chassis ground (-):




- CHECK** : Is resistance more than 1 MΩ?
- YES** : Go to step 8D5.
- NO** : Repair or replace harness connector.

8D5 : CHECK VEHICLE SPEED SENSOR 2.

- 1) Disconnect connector from vehicle speed sensor 2.
- 2) Measure resistance between terminals of vehicle speed sensor 2.

Terminals

No. 1 — No. 2:



- CHECK** : Is resistance between 350 and 450 Ω?
- YES** : Go to step 8D6.
- NO** : Replace vehicle speed sensor 2.

8D6 : CHECK VEHICLE SPEED SENSOR 2.

- 1) Set the vehicle on free roller, or lift-up the vehicle and support with safety stands.

WARNING:


Be careful not to be caught up by the running wheels.

- 2) Drive the vehicle at speed greater than 20 km/h (12 MPH).
- 3) Measure voltage between terminals of vehicle speed sensor 2.

NOTE:


Using an oscilloscope:

- (1) Turn ignition switch to OFF.
- (2) Set oscilloscope to vehicle speed sensor 2.
- (3) Drive the vehicle at speed greater than 20 km/h (12 MPH).
- (4) Measure signal voltage.




Terminals

No. 1 — No. 2:



6-2 [T8D6] BODY ELECTRICAL SYSTEM (CRUISE CONTROL)

8. Diagnostics Chart with Diagnostic Code



- CHECK** : *Is voltage more than 2 V?*
- YES** : Repair or replace combination meter circuit.
- NO** : Replace vehicle speed sensor 2.

E: DIAGNOSTIC CODE 14 (SET/COAST SWITCH, RESUME/ACCEL SWITCH, CANCEL SWITCH)


DIAGNOSIS:

- Short circuit inside the SET SW and RESUME SW.

TROUBLE SYMPTOM:

- Cruise control cannot be set. (Cancelled immediately.)


WIRING DIAGRAM:



S6M0123

8E1 : CHECK POWER SUPPLY.


- 1) Turn ignition switch to ON.
- 2) Turn cruise control main switch to ON.
- 3) Set select monitor in "Current Data Display & Save" mode.
- 4) Check signals for proper operation.
 - (1) When pushing the SET/COAST switch:
The SET/COAST switch shown on the display turns from "OFF" to "ON".
 - (2) When pushing the RESUME/ACCEL switch:
The RESUME/ACCEL switch shown on the display turns from "OFF" to "ON".
- 5) Turn ignition switch to OFF.
- 6) Disconnect connector from cruise control command switch.
- 7) Turn ignition switch to ON.
- 8) Measure voltage between cruise control command switch connector and chassis ground.

Terminals**No. 1 (+) — Chassis ground (-):**

- CHECK** : **Is voltage more than 10 V?**
- YES** : Go to step **8E2**.
- NO** : Repair or replace wiring harness between fuse & relay box and cruise control command switch.

8E2 : CHECK THE CRUISE CONTROL COMMAND SWITCH.


- 1) Turn ignition switch to OFF.
- 2) Connect connector of cruise control command switch.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between cruise control command switch connector and chassis ground.

Terminals**No. 2 (+) — Chassis ground (-):**

- CHECK** : **Is voltage more than 10 V? (When SET/COAST switch is ON.)**
- YES** : Go to step **8E3**.
- NO** : Replace cruise control command switch.

8E3 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

Measure voltage between cruise control command switch connector and chassis ground.

Terminals**No. 3 (+) — Chassis ground (-):**


- CHECK** : **Is voltage more than 10 V? (When RESUME/ACCEL switch is ON.)**
- YES** : Go to step **8E4**.
- NO** : Replace cruise control command switch.

8E4 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

Measure voltage between cruise control command switch connector and chassis ground.

Terminals

No. 2 (+) — Chassis ground (-):



CHECK : Is voltage more than 10 V? (When CANCEL switch is ON.)

YES : Go to step 8E5.


NO : Replace cruise control command switch.

8E5 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

Measure voltage between cruise control command switch connector and chassis ground.

Terminals

No. 3 (+) — Chassis ground (-):



CHECK : Is voltage more than 10 V? (When CANCEL switch is ON.)

YES : Go to step 8E6.


NO : Replace cruise control command switch.

8E6 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from cruise control command switch.
- 3) Measure resistance between terminals of cruise control command switch connector (switch side) to check the switch operation.

Terminals

No. 1 — No. 2:



CHECK : Is resistance less than 10 Ω ? (When SET/COAST switch is ON.)

YES : Go to step 8E7.

NO : Replace cruise control command switch.

6-2 [T8E7] BODY ELECTRICAL SYSTEM (CRUISE CONTROL)


8. Diagnostics Chart with Diagnostic Code

8E7 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

Measure resistance between terminals of cruise control command switch connector (switch side) to check the switch operation.

Terminals

No. 1 — No. 2:




- CHECK** : *Is resistance more than 1 M Ω ? (When SET/COAST switch is OFF.)*
- YES** : Go to step 8E8.
- NO** : Replace cruise control command switch.

8E8 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

Measure resistance between terminals of cruise control command switch connector (switch side) to check the switch operation.

Terminals

No. 1 — No. 3:




- CHECK** : *Is resistance less than 10 Ω ? (When RESUME/ACCEL switch is ON.)*
- YES** : Go to step 8E9.
- NO** : Replace cruise control command switch.

8E9 : CHECK THE CRUISE CONTROL COMMAND SWITCH.

Measure resistance between terminals of cruise control command switch connector (switch side) to check the switch operation.

Terminals

No. 1 — No. 3:




- CHECK** : *Is resistance more than 1 M Ω ? (When RESUME/ACCEL switch is OFF.)*
- YES** : Go to step 8E10.
- NO** : Replace cruise control command switch.

8E10 : CHECK HARNESS CONNECTOR BETWEEN CRUISE CONTROL COMMAND SWITCH AND CRUISE CONTROL MODULE.

- 1) Disconnect connector from cruise control module.
- 2) Measure resistance of harness connector between cruise control command switch and cruise control module.

Connector & terminal

No. 2 (command switch) — (B94) No. 6:




- CHECK** : *Is resistance less than 10 Ω ?*
- YES** : Go to step 8E11.
- NO** : Repair or replace wiring harness.

8E11 : CHECK HARNESS CONNECTOR BETWEEN CRUISE CONTROL COMMAND SWITCH AND CRUISE CONTROL MODULE.

Measure resistance of harness connector between cruise control command switch and cruise control module.

Connector & terminal

No. 3 (command switch) — (B94) No. 7:



CHECK

: **Is resistance less than 10 Ω ?**

YES

: Replace cruise control module.

NO

: Repair or replace wiring harness.

MEMO:

F: DIAGNOSTIC CODE 21, 22 AND 23 (VACUUM VALVE, VENT 2 VALVE, VENT 1 VALVE)


DIAGNOSIS:

- Open or poor contact of vacuum valve, vent 2 valve and vent 1 valve.

TROUBLE SYMPTOM:

- Cruise control cannot be set. (Cancels immediately.)

WIRING DIAGRAM:



S6M0128

6-2 [T8F1] BODY ELECTRICAL SYSTEM (CRUISE CONTROL)


8. Diagnostics Chart with Diagnostic Code

8F1 : MEASURE RESISTANCE OF VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE.

- 1) Disconnect connector from actuator.
- 2) Measure resistance of vacuum valve, vent 2 valve and vent 1 valve.

Terminals

No. 2 — No. 3:




- CHECK** : Is resistance less than 22 Ω ?
- YES** : Go to step 8F2.
- NO** : Replace actuator.

8F2 : MEASURE RESISTANCE OF VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE.

Measure resistance of vacuum valve, vent 2 valve and vent 1 valve.

Terminals

No. 2 — No. 1:




- CHECK** : Is resistance less than 55 Ω ?
- YES** : Go to step 8F3.
- NO** : Replace actuator.

8F3 : MEASURE RESISTANCE OF VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE.

Measure resistance of vacuum valve, vent 2 valve and vent 1 valve.

Terminals

No. 2 — No. 4:



- CHECK** : Is resistance less than 55 Ω ?
- YES** : Go to step 8F4.
- NO** : Replace actuator.

8F4 : PERFORM A CIRCUIT TEST IN HARNESS BETWEEN ACTUATOR (VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE) AND CRUISE CONTROL MODULE.

8F5 : PERFORM A CIRCUIT TEST IN HARNESS BETWEEN ACTUATOR (VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE) AND CRUISE CONTROL MODULE.



- 1) Disconnect connector from cruise control module.
- 2) Measure resistance of harness connector between cruise control module, vacuum valve, vent 2 valve and vent 1 valve.

Measure resistance of harness connector between cruise control module, vacuum valve, vent 2 valve and vent 1 valve.

Connector & terminal
(B7) No. 2 — (B94) No. 8:

Connector & terminal

(B7) No. 1 — (B94) No. 1:



- CHECK** : Is resistance less than 10 Ω?
- YES** : Go to step 8F5.
- NO** : Repair or replace wiring harness between actuator and cruise control module.


- CHECK** : Is resistance less than 10 Ω?
- YES** : Go to step 8F6.
- NO** : Repair or replace wiring harness between actuator and cruise control module.

8F6 : PERFORM A CIRCUIT TEST IN HARNESS BETWEEN ACTUATOR (VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE) AND CRUISE CONTROL MODULE.

Measure resistance of harness connector between cruise control module, vacuum valve, vent 2 valve and vent 1 valve.

Connector & terminal

(B7) No. 3 — (B94) No. 11:



CHECK : **Is resistance less than 10 Ω?**

YES : Go to step **8F7**.


NO : Repair or replace wiring harness between actuator and cruise control module.

8F7 : PERFORM A CIRCUIT TEST IN HARNESS BETWEEN ACTUATOR (VACUUM VALVE, VENT 2 VALVE AND VENT 1 VALVE) AND CRUISE CONTROL MODULE.

Measure resistance of harness connector between cruise control module, vacuum valve, vent 2 valve and vent 1 valve.

Connector & terminal

(B7) No. 4 — (B94) No. 2:



CHECK : **Is resistance less than 10 Ω?**

YES : Replace cruise control module.

NO : Repair or replace wiring harness between actuator and cruise control module.

G: DIAGNOSTIC CODE 25 (CRUISE CONTROL MODULE BUILT-IN RELAY, CPU RAM)

DIAGNOSIS:

- Poor welding of built-in relay of cruise control module.
- Failure of built-in CPU RAM of cruise control module.

TROUBLE SYMPTOM:

- Cruise control is canceled and memorized cruise speed is also canceled.
- Once cruise control is canceled, cruise control cannot be set until the ignition switch and cruise control main switch turns OFF, and then turns ON again.

NOTE:

Check input/output signal and vehicle speed signal with select monitor. When signals are in good condition, failure is in cruise control module. (Check power supply and ground conditions of cruise control module.)

9. Diagnostics Chart with Select Monitor

A: FUNCTION MODE

NOTE:

Applicable select monitor cartridge:
No. 24082AA010

Select the "Cruise Control" system using the select monitor and set the "Current Data Display & Save" mode. The following parameters will then appear on the display.

- Vehicle Speed

The current vehicle speed is shown on the display.

- Stop Lamp Switch

When the brake pedal is depressed, the stop lamp switch shown on the display turns from "OFF" to "ON".

- Brake Switch

When the brake pedal is depressed, the brake switch shown on the display turns from "OFF" to "ON".

- "SET/COAST" Switch

When the cruise control command switch is placed in the "SET/COAST" position, the SET/COAST switch shown on the display turns from "OFF" to "ON".

- "RESUME/ACCEL" Switch

When the cruise control command switch is placed in the "RESUME/ACCEL" position, the RESUME/ACCEL switch shown on the display turns from "OFF" to "ON".

- Clutch/Inhibitor Switch

When the clutch pedal is depressed, the clutch/inhibitor switch shown on the display turns from "ON" to "OFF". (MT models)

When the selector lever is moved from the "N" or "P" position to any other position, the clutch/inhibitor switch shown on the display turns from "ON" to "OFF".