


7. Diagnostics for CHECK ENGINE Malfunction Indicator Lamp (MIL)

A: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON.


- **DIAGNOSIS:**
 - The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.
- **TROUBLE SYMPTOM:**
 - When ignition switch is turned ON (engine OFF), MIL does not come on.
- **WIRING DIAGRAM:**




S2M0317

7A1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground.

Connector & terminal**(B84) No. 58 (+) — Chassis ground (—):****CHECK** : *Is the voltage less than 1 V?***YES** : Go to step 7A4.**NO** : Go to step 7A2.**7A2 : CHECK POOR CONTACT.****CHECK** : *Does the MIL come on when shaking or pulling ECM connector and harness?***YES** : Repair poor contact in ECM connector.**NO** : Go to step 7A3.**7A3 : CHECK ECM CONNECTOR.****CHECK** : *Is ECM connector correctly connected?***YES** : Replace ECM.**NO** : Repair connection of ECM connector.**7A4 : CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove combination meter. <Ref. to 6-2 [W8A0].>
- 3) Disconnect connector from ECM and combination meter.
- 4) Measure resistance of harness between ECM and combination meter connector.

Connector & terminal**(B84) No. 58 — (i10) No. 9:****CHECK** : *Is resistance less than 1 Ω?***YES** : Go to step 7A5.**NO** : Repair harness and connector.**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and combination meter connector
- Poor contact in coupling connector (i2)

7A5 : CHECK POOR CONTACT.

Check poor contact in combination meter connector. <Ref. to FOREWORD [T3C1].>


CHECK : *Is there poor contact in combination meter connector?***YES** : Repair poor contact in combination meter connector.**NO** : Go to step 7A6.

7A6 : CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between combination meter connector and chassis ground.

Connector & terminal

(i10) No. 7 (+) — Chassis ground (-):



- CHECK** : **Is voltage more than 10 V?**
- YES** : Go to step **7A7**.
- NO** : Check the following and repair if necessary.

NOTE:

- Broken down ignition relay.
- Blown out fuse (No. 15).
- If replaced fuse (No. 15) blows easily, check the harness for short circuit of harness between fuse (No. 15) and ignition relay connector.
- Open or short circuit in harness between fuse (No. 15) and battery terminal
- Open circuit in harness between fuse (No. 15) and ignition relay connector
- Poor contact in coupling connector (i1 and B108)
- Poor contact in ignition relay connector
- Poor contact in ignition switch connector


7A7 : CHECK POOR CONTACT.

Check poor contact in combination meter connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in combination meter connector?**
- YES** : Repair poor contact in combination meter connector.
- NO** : Replace bulb or combination meter.

B: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF.


- **DIAGNOSIS:**
 - The CHECK ENGINE malfunction indicator lamp (MIL) circuit is shorted.
- **TROUBLE SYMPTOM:**
 - Although MIL comes on when engine runs, trouble code is not shown on Subaru select monitor or OBD-II general scan tool display.
- **WIRING DIAGRAM:**



S2M0317

7B1 : CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Turn ignition switch to ON.



- CHECK** : ***Does the MIL come on?***
- YES** : Repair short circuit in harness between combination meter and ECM connector.
- NO** : Replace ECM.

C: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT BLINK AT A CYCLE OF 3 Hz.


• DIAGNOSIS:

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.
- Test mode connector circuit is in open.

• TROUBLE SYMPTOM:

- When inspection mode, MIL does not blink at a cycle of 3 Hz.


• WIRING DIAGRAM:



S2M0318

7C1 : CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).

- 1) Turn ignition switch to OFF.
- 2) Disconnect test mode connector.
- 3) Turn ignition switch to ON.




- CHECK** : Does the MIL come on?
- YES** : Go to step 7C2.
- NO** : Repair the MIL circuit. <Ref. to 2-7 [T7A0].>

7C2 : CHECK OUTPUT SIGNAL FROM ECM.

Measure voltage between test mode connector and chassis ground.

Connector & terminal
(B75) No. 1 (+) — Chassis ground (-):




- CHECK** : Is voltage less than 1 V?
- YES** : Go to step 7C3.
- NO** : Go to step 7C5.

7C3 : CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and test mode connector.

Connector & terminal
(B84) No. 84 — (B75) No. 1:



- CHECK** : Is resistance less than 1 Ω?
- YES** : Go to step 7C4.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and test mode connector
- Poor contact in coupling connector (B125)


7C4 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM.

7C5 : CHECK GROUND CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between test mode connector and chassis ground.

Connector & terminal**(B76) No. 1 — Chassis ground:**

- CHECK** : ***Is resistance less than 5 Ω?***
- YES** : Repair poor contact in test mode connector.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between test mode and engine grounding terminal
- Poor contact in coupling connector (B22)

D: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 Hz.


● DIAGNOSIS:

- Test mode connector circuit is shorted.

● TROUBLE SYMPTOM:

- Even though test mode connector is disconnected, MIL blinks at a cycle of 3 Hz when ignition switch is turned to ON.

● WIRING DIAGRAM:




S2M0318

7D1 : CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

Connector & terminal

(B84) No. 84 — Chassis ground:



- CHECK** : **Is resistance less than 5 Ω ?**
- YES** : Repair short circuit in harness between ECM and test mode connector.
- NO** : Replace ECM.