


8. Diagnostics for Engine Starting Failure

A: BASIC DIAGNOSTICS CHART

1. Inspection of starter motor circuit. <Ref. to 2-7 [T8B0].>	
	↓
2. Inspection of ECM power supply and ground line. <Ref. to 2-7 [T8C0].>	
	↓
3. Inspection of ignition control system. <Ref. to 2-7 [T8D0].>	
	↓
4. Inspection of fuel pump circuit. <Ref. to 2-7 [T8E0].>	
	↓
5. Inspection of fuel injector circuit. <Ref. to 2-7 [T8F0].>	
	↓
6. Inspection of crankshaft position sensor circuit. <Ref. to 2-7 [T8G0].>	
	↓
7. Inspection of camshaft position sensor circuit. <Ref. to 2-7 [T8H0].>	
	↓
8. Inspection using Subaru select monitor or OBD-II general scan tool <Ref. to 2-7 [T10A0].> or inspection using "9. General Diagnostics Table". <Ref. to 2-7 [T900].>	


B: STARTER MOTOR CIRCUIT**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.
 <Ref. to 2-7 [T3D0] and [T3E0].>


● **WIRING DIAGRAM:**

8B1 : CHECK INPUT SIGNAL FOR STARTER MOTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from starter motor.



- 3) Turn ignition switch to ST.
- 4) Measure power supply voltage between starter motor connector terminal and engine ground.


Connector & terminal**(B14) No. 1 (+) — Engine ground (-):****NOTE:**

- On AT vehicles, place the selector lever in the "P" or "N" position.
- On MT vehicles, depress the clutch pedal.

- (CHECK) : Is the voltage more than 10 V?**
- (YES) : Go to step 8B2.**
- (NO) : Go to step 8B3.**

8B2 : CHECK GROUND CIRCUIT OF STARTER MOTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect terminal from starter motor.



- 3) Measure resistance of ground cable between ground cable terminal and engine ground.

- (CHECK) : Is resistance less than 5 Ω?**
- (YES) : Check starter motor. <Ref. to 6-1 [W100].>**
- (NO) : Repair open circuit of ground cable.**

8B3 : CHECK FUSE (SBF NO. 1).

- 1) Turn ignition switch to OFF.
- 2) Remove SBF No. 1 from main fuse box.
- 3) Measure resistance of fuse.

- (CHECK) : Is resistance less than 1 Ω?**
- (YES) : Go to step 8B4.**
- (NO) : Replace SBF No. 1.**

8B4 : CHECK FUSE (SBF NO. 4).

- 1) Remove SBF No. 4 from main fuse box.
- 2) Measure resistance of fuse.


- (CHECK) : Is resistance less than 1 Ω?**
- (YES) : Go to step 8B5.**
- (NO) : Replace SBF No. 4.**

8B5 : CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.

- 1) Install SBF No. 1 and SBF No. 4 to main fuse box.
- 2) Turn ignition switch to ON.
- 3) Measure power supply voltage between ignition switch connector and chassis ground.

Connector & terminal

(B72) No. 1 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8B6.
- NO** : Repair open circuit in harness between ignition switch and SBF No. 4 connector.

8B6 : CHECK TRANSMISSION TYPE.


- CHECK** : Is transmission type AT?
- YES** : Go to step 8B7.
- NO** : Go to step 8B11.

8B7 : CHECK INHIBITOR SWITCH CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Place the selector lever in the "P" or "N" position.
- 3) Separate transmission harness connector.
- 4) Measure resistance between transmission harness connector receptacle's terminals.

Connector & terminal

(T3) No. 11 — No. 12:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Repair open circuit in harness between starter motor and ignition switch connector.
- NO** : Go to step 8B8.

8B8 : CHECK TRANSMISSION HARNESS.

- 1) Disconnect connector from inhibitor switch.
- 2) Measure resistance of harness between transmission harness and inhibitor switch connector.

Connector & terminal

(T3) No. 11 — (T7) No. 1:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8B9.
- NO** : Repair open circuit in harness between transmission harness and inhibitor switch connector.

8B9 : CHECK TRANSMISSION HARNESS.

Measure resistance of harness between transmission harness and inhibitor switch connector.

Connector & terminal

(T3) No. 12 — (T7) No. 2:



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **8B10**.
- NO** : Repair open circuit in harness between transmission harness and inhibitor switch connector.

8B10 : CHECK POOR CONTACT.

Check poor contact in inhibitor switch connector.
<Ref. to FOREWORD [T3C1].>


- CHECK** : **Is there poor contact in inhibitor switch connector?**
- YES** : Repair poor contact in inhibitor switch connector.
- NO** : Replace inhibitor switch.

8B11 : CHECK STARTER INTERLOCK CIRCUIT.

- 1) Turn ignition switch to "ST".
- 2) Measure voltage between clutch switch connector and chassis ground.

Connector & terminal

(B106) No. 2 (+) — Chassis ground (-):




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Replace starter interlock relay.
- NO** : Go to step **8B12**.

8B12 : CHECK STARTER INTERLOCK CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between clutch switch connector terminals while depressing the clutch pedal.

Connector & terminal

(B106) No. 1 — No. 2:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair open circuit in harness between starter motor and ignition switch connector.
- NO** : Replace clutch switch.

C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.
 <Ref. to 2-7 [T3D0] and [T3E0].>


● WIRING DIAGRAM:



S2M0320

8C1 : CHECK MAIN RELAY.


- 1) Turn the ignition switch to OFF.
- 2) Remove main relay.
- 3) Connect battery to main relay terminals No. 1 and No. 2.
- 4) Measure resistance between main relay terminals.

Terminals**No. 3 — No. 5:**

- CHECK** : Is the resistance less than 10 Ω ?
- YES** : Go to step 8C2.
- NO** : Replace main relay.

8C2 : CHECK MAIN RELAY.


Measure resistance between main relay terminals.

Terminals**No. 4 — No. 6:**

- CHECK** : Is the resistance less than 10 Ω ?
- YES** : Go to step 8C3.
- NO** : Replace main relay.

8C3 : CHECK POWER SUPPLY CIRCUIT OF ECM.


- 1) Install main relay.
- 2) Disconnect connectors from ECM.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage between ECM connector terminals.

Connector & terminal**(B84) No. 1 (+) — No. 19 (-):**

- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C4.
- NO** : Repair open or ground short circuit in harness of power supply circuit.

8C4 : CHECK POWER SUPPLY CIRCUIT OF ECM.

Measure power supply voltage between ECM connector terminals.

Connector & terminal**(B84) No. 2 (+) — No. 19 (-):**


- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C5.
- NO** : Repair open or ground short circuit in harness of power supply circuit.

8C5 : CHECK POWER SUPPLY CIRCUIT OF ECM.

Measure power supply voltage between ECM connector terminals.

Connector & terminal

(B84) No. 39 (+) — No. 19 (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C6.
- NO** : Repair open or ground short circuit in harness of power supply circuit.

8C6 : CHECK GROUND CIRCUIT OF ECM.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 17 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω ?
- YES** : Go to step 8C7.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C7 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 18 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω ?
- YES** : Go to step 8C8.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C8 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Measure resistance of harness between ECM and chassis ground.

(B84) No. 19 — Chassis ground:



CHECK : Is the resistance less than 5 Ω?

YES : Go to step 8C9.


NO : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C9 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 20 — Chassis ground:



CHECK : Is the resistance less than 5 Ω?

YES : Go to step 8C10.


NO : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C10 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 42 — Chassis ground:



CHECK : Is the resistance less than 5 Ω?

YES : Go to step 8C11.


NO : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C11 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 46 — Chassis ground:



CHECK : Is the resistance less than 5 Ω?

YES : Go to step 8C12.


NO : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C12 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 69 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step **8C13**.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C13 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 94 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step **8C14**.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C14 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal


(B84) No. 95 — Chassis ground:



- CHECK** : Is the resistance less than 5 Ω?
- YES** : Check ignition control system. <Ref. to 2-7 [T8D0].>
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

D: IGNITION CONTROL SYSTEM**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.
 <Ref. to 2-7 [T3D0] and [T3E0].>

● WIRING DIAGRAM:

S2M0321


8D1 : CHECK IGNITION SYSTEM FOR SPARKS.

- 1) Remove plug cord cap from each spark plug.
- 2) Install new spark plug on plug cord cap.

CAUTION:

Do not remove spark plug from engine.

- 3) Contact spark plug's thread portion on engine.
- 4) While opening throttle valve fully, crank engine to check that spark occurs at each cylinder.




- CHECK** : **Does spark occur at each cylinder?**
- YES** : Check fuel pump system. <Ref. to 2-7 [T8E0].>
- NO** : Go to step **8D2**.

8D2 : CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ignition coil.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage between ignition coil connector and engine ground.

Connector & terminal

(E12) No. 2 (+) — Engine ground (-):



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **8D3**.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ignition coil and ignition switch connector
- Poor contact in coupling connector (B22)

8D3 : CHECK IGNITION COIL.

Measure resistance between ignition coil terminals to check primary coil.

Terminals

No. 2 — No. 1:




- CHECK** : **Is the resistance between 0.4 and 1.0 Ω ?**
- YES** : Go to step **8D4**.
- NO** : Replace ignition coil.

8D4 : CHECK IGNITION COIL.

Measure resistance between ignition coil terminals to check primary coil.

Terminals

No. 2 — No. 3:



CHECK : *Is the resistance between 0.4 and 1.0 Ω ?*

YES : Go to step **8D5**.


NO : Replace ignition coil.

8D5 : CHECK IGNITION COIL.

Measure resistance between spark plug cord contact portions to check secondary coil.

Terminals

No. 1 — No. 2:



CHECK : *Is the resistance between 10 and 15 Ω ?*

YES : Go to step **8D6**.


NO : Replace ignition coil.

8D6 : CHECK IGNITION COIL.

Measure resistance between spark plug cord contact portions to check secondary coil.

Terminals

No. 3 — No. 4:



CHECK : *Is the resistance between 10 and 15 Ω ?*

YES : Go to step **8D7**.


NO : Replace ignition coil.

8D7 : CHECK HARNESS BETWEEN IGNITOR AND IGNITION COIL CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ignitor.
- 3) Measure resistance of harness between ignitor coil and ignitor connector.

Connector & terminal

(B13) No. 5 — (E12) No. 1:



CHECK : *Is the resistance less than 1 Ω ?*

YES : Go to step **8D8**.


NO : Go to step **8D9**.

8D8 : CHECK HARNESS BETWEEN IGNITOR AND IGNITION COIL CONNECTOR.

Measure resistance of harness between ignition coil and ignitor connector.

Connector & terminal

(B13) No. 6 — (E12) No. 3:



CHECK : *Is the resistance less than 1 Ω?*

YES : Go to step **8D10**.

NO : Go to step **8D9**.

8D9 : CHECK POOR CONTACT.

Check poor contact in coupling connector (B22).
<Ref. to FOREWORD [T3C1].>

CHECK : *Is there poor contact in coupling connector (B22)?*

YES : Repair poor contact in coupling connector (B22).


NO : Repair open circuit in harness between ignition coil and ignitor connector.

8D10 : CHECK INPUT SIGNAL FOR IGNITOR.

Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignitor connector and engine ground.

Connector & terminal:

(B13) No. 1 (+) — Engine ground (-):



CHECK : *Is the voltage more than 10 V?*

YES : Go to step **8D11**.


NO : Replace ignitor.

8D11 : CHECK INPUT SIGNAL FOR IGNITOR.

Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignitor connector and engine ground.

Connector & terminal:

(B13) No. 2 (+) — Engine ground (-):



CHECK : *Is the voltage more than 10 V?*

YES : Go to step **8D12**.


NO : Replace ignitor.

8D12 : CHECK HARNESS OF IGNITOR GROUND CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ignitor and engine ground.

Connector & terminal

(B13) No. 3 — Engine ground:



- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8D13.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ignitor connector and engine grounding terminal
- Poor contact in coupling connector (B22)

8D13 : CHECK HARNESS BETWEEN ECM AND IGNITOR CONNECTOR.

- 1) Disconnect connector from ECM.
- 2) Measure resistance of harness between ECM and ignitor connector.

Connector & terminal

(B84) No. 41 — (B13) No. 1:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8D14.
- NO** : Repair open circuit in harness between ECM and ignitor connector.

8D14 : CHECK HARNESS BETWEEN ECM AND IGNITOR CONNECTOR.

Measure resistance of harness between ECM and ignitor connector.

Connector & terminal

(B84) No. 40 — (B13) No. 2:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8D15.
- NO** : Repair open circuit in harness between ECM and ignitor connector.

8D15 : CHECK HARNESS BETWEEN ECM AND IGNITOR CONNECTOR.

Measure resistance of harness between ECM and ignitor connector.

Connector & terminal

(B84) No. 94 — (B13) No. 3:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8D16.
- NO** : Repair open circuit in harness between ECM and ignitor connector.

8D16 : CHECK HARNESS BETWEEN ECM AND IGNITOR CONNECTOR.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 41 — Chassis ground:




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **8D17**.
- NO** : Repair ground short circuit in harness between ECM and ignitor connector.

8D17 : CHECK HARNESS BETWEEN ECM AND IGNITOR CONNECTOR.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 40 — Chassis ground:



- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **8D18**.
- NO** : Repair ground short circuit in harness between ECM and ignitor connector.


8D18 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>


- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Check fuel pump circuit. <Ref. to 2-7 [T8E0].>

8E2 : CHECK GROUND CIRCUIT OF FUEL PUMP.

- 1) Turn ignition switch to OFF.
- 2) Remove fuel pump access hole lid located on the luggage compartment floor.



- 3) Disconnect connector from fuel pump.
- 4) Measure resistance of harness connector between fuel pump and chassis ground.

Connector & terminal**(R58) No. 4 — Chassis ground:**

- CHECK** : **Is the resistance less than 5 Ω ?**
- YES** : Go to step **8E3**.
- NO** : Repair harness and connector.


NOTE:

In this case, repair the following:

- Open circuit in harness between fuel pump connector and chassis grounding terminal
- Poor contact in coupling connector (R15)

8E3 : CHECK POWER SUPPLY TO FUEL PUMP.

- 1) Turn ignition switch to ON.
- 2) Measure voltage of power supply circuit between fuel pump connector and chassis ground.

Connector & terminal**(R58) No. 1 (+) — Chassis ground (-):**


- CHECK** : **Is the voltage more than 10 V?**
- YES** : Replace fuel pump.
- NO** : Go to step **8E4**.

8E4 : CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between fuel pump and fuel pump relay connector.

Connector & terminal

(R58) No. 1 — (B46) No. 4:



- CHECK** : Is the resistance less than 1 Ω ?
- YES** : Go to step 8E5.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between fuel pump and fuel pump relay connector
- Poor contact in coupling connectors (R67 and B97)

8E5 : CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.

Measure resistance of harness between fuel pump and fuel pump relay connector.

Connector & terminal

(R58) No. 1 — Chassis ground:




- CHECK** : Is the resistance more than 1 M Ω ?
- YES** : Go to step 8E6.
- NO** : Repair ground short circuit in harness between fuel pump and fuel pump relay connector.

8E6 : CHECK FUEL PUMP RELAY.

- 1) Disconnect connector from fuel pump relay.
- 2) Remove fuel pump relay from bracket.
- 3) Connect battery to fuel pump relay connector terminals No. 1 and No. 3.
- 4) Measure resistance between connector terminals of fuel pump relay.

Terminals

No. 2 — No. 4:




- CHECK** : Is the resistance less than 10 Ω ?
- YES** : Go to step 8E7.
- NO** : Replace fuel pump relay.

8E7 : CHECK HARNESS BETWEEN ECM AND FUEL PUMP RELAY CONNECTOR.

- 1) Disconnect connectors from ECM.
- 2) Measure resistance of harness between ECM and fuel pump relay connector.

Connector & terminal

(B84) No. 32 — (B46) No. 3:



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 8E8.
- NO** : Repair open circuit in harness between ECM and fuel pump relay connector.

8E8 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>


- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Check fuel injector circuit. <Ref. to 2-7 [T8F0].>

F: FUEL INJECTOR CIRCUIT**CAUTION:**

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.
<Ref. to 2-7 [T3D0] and [T3E0].>

NOTE:

Check fuel injector circuit. <Ref. to 2-7 [T10AA0].> or <Ref. to 2-7 [T10AE0].>

● **WIRING DIAGRAM:**

S2M0323

G: CRANKSHAFT POSITION SENSOR CIRCUIT


CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES.
<Ref. to 2-7 [T3D0] and [T3E0].>

NOTE:

Check crankshaft position sensor circuit. <Ref. to 2-7 [T10AK0].>

● WIRING DIAGRAM:



S2M0324

H: CAMSHAFT POSITION SENSOR CIRCUIT**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY** and **INSPECTION MODES**.
 <Ref. to 2-7 [T3D0] and [T3E0].>

NOTE:

Check camshaft position sensor circuit. <Ref. to 2-7 [T10AM0].>

● **WIRING DIAGRAM:**