

## 4. Keyless Entry System

### A: PRECAUTION

#### 1. SUPPLEMENTAL RESTRAINT SYSTEM “AIRBAG”

Airbag system wiring harness is routed near the keyless entry control module.

#### CAUTION:

- All airbag system wiring harness and connectors are yellow. Do not use electrical test equipment on these circuits.
- Be careful not to damage airbag system wiring harness when servicing the keyless entry control module.

### B: PRE-INSPECTION

#### 1. POWER DOOR LOCK

**4B11 : CHECK POWER DOOR LOCK.**

Perform lock and unlock with door lock switch.

- CHECK** : *Does the power door lock function normally?*
- YES** : Go to step **4B21**.
- NO** : Repair power door lock.


## 2. TRANSMITTER

**4B21 : CHECK TRANSMITTER BATTERY.**

- 1) Remove battery from transmitter.

#### NOTE:


To prevent static electricity damage to transmitter printed circuit board, touch steel area of building with hand to discharge static electricity carried on body or clothes before disassembling transmitter.



- 2) Measure voltage battery.

#### NOTE:

- Battery discharge occurs during measurement. Complete measurement within 5 seconds.
- During battery voltage measurement, voltage falls more than 1.8 volts during 3 seconds period. Weak battery is indicated. Replace battery.



- CHECK** : *Is the voltage more than 2 V?*
- YES** : Go to step **4B22**.
- NO** : Replace transmitter battery. (Use CR2032 or equivalent.)

**4B22 : CHECK LED OF TRANSMITTER.**

1) Press either the LOCK/ARM or UNLOCK/DISARM button six times to synchronize with the keyless entry control module.

2) Press the LOCK/ARM button.

**CHECK** : *Does the LED blink one time?*

**YES** : Go to step **4B23**.

**NO** : Replace transmitter.

**4B23 : CHECK LED OF TRANSMITTER.**

Keep the LOCK/ARM button pressed.

**CHECK** : *Does the LED blink one time and then turn on?*

**YES** : Go to step **4B24**.

**NO** : Replace transmitter.

**4B24 : CHECK LED OF TRANSMITTER.**

Press the UNLOCK/DISARM button.

**CHECK** : *Does the LED blink one time?*

**YES** : Go to step **4B25**.

**NO** : Replace transmitter.

**4B25 : CHECK LED OF TRANSMITTER.**

Keep the UNLOCK/DISARM button pressed.

**CHECK** : *Does the LED blink two times?*

**YES** : Go to step **4B26**.

**NO** : Replace transmitter.

**4B26 : CHECK POWER DOOR LOCK FUNCTION.**

Perform lock and unlock function of power door lock with transmitter.

**CHECK** : *Does it function normally?*

**YES** : Go to step **4B27**.

**NO** : Replace transmitter.

**4B27 : CHECK ON/OFF SELECT HORN SIGNAL.**

Press the LOCK/ARM or UNLOCK/DISARM button.

**CHECK** : *Does the horn signal chirp?*

**YES** : Go to step **4B28**.

**NO** : Keep both LOCK/ARM and UNLOCK/DISARM buttons pressed for more than 1.5 seconds. Go to step **4B28**.

**4B28 : CHECK ON/OFF SELECT HORN SIGNAL.**

Keep both LOCK/ARM and UNLOCK/DISARM buttons pressed for more than 1.5 seconds.

**CHECK** : *Does the horn signal chirp two times?*

**YES** : Go to step **4B29**.

**NO** : Replace transmitter.

**4B29 : CHECK ON/OFF SELECT HORN SIGNAL.**

Press LOCK/ARM or UNLOCK/DISARM button.

**CHECK** : *Does the horn signal chirp?*

**YES** : Replace transmitter.

**NO** : Go to step **4B210**.

**4B210 : CHECK ON/OFF SELECT HORN SIGNAL.**

Keep both LOCK/ARM and UNLOCK/DISARM buttons pressed for more than 1.5 seconds.

**CHECK** : *Does the horn signal chirp one time?*

**YES** : Go to step **4B211**.

**NO** : Replace transmitter.

**4B211 : CHECK ON/OFF SELECT HORN SIGNAL.**

Press LOCK/ARM and UNLOCK/DISARM button.

**CHECK** : *Does the horn signal chirp?*

**YES** : Go to step **4B212**.

**NO** : Replace transmitter.

**4B212 : CHECK FOR UNCHECKED TRANSMITTER.**

Check for an unchecked transmitter.

- CHECK** : *Does an unchecked transmitter exist?*
- YES** : Check for an unchecked transmitter. Go to step **4B21**.
- NO** : Go to step **4B31**.

**3. FUSE****4B31 : CHECK FUSE.**

Remove and visually check the fuse No. 3 (in fuse box).

- CHECK** : *Is fuse No. 3 blown?*
- YES** : Replace fuse (15 A).
- NO** : Go to step **4B41**.


## 4. POWER SUPPLY CIRCUIT

**4B41 : CHECK POWER SUPPLY CIRCUIT.**

Measure voltage between fuse box connector (B158) and chassis ground.

**Connector & terminal**

**(B158) No. 8 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **4B42**.
- NO** : Repair wiring harness between fuse box and battery.

**4B42 : CHECK POWER SUPPLY CIRCUIT.**

- 1) Disconnect connector from keyless entry control module.
- 2) Measure voltage between keyless entry control module connector (B176) and chassis ground.

**Connector & terminal**

**(B176) No. 3 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **4B51**.
- NO** : Repair wiring harness between keyless entry control module and fuse box.


## 5. GROUND CIRCUIT

**4B51 : CHECK GROUND CIRCUIT.**

Measure resistance between keyless entry control module connector (B176) and chassis ground.


**Connector & terminal**

**(B176) No. 8 (+) — Chassis ground (-):**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **4F11**.
- NO** : Repair wiring harness between keyless entry control module and chassis ground.



C: ELECTRICAL COMPONENTS LOCATION




S6M0450A

- |                                  |                                   |                 |
|----------------------------------|-----------------------------------|-----------------|
| (1) Horn                         | (3) Horn relay (in main fuse box) | (5) Door switch |
| (2) Keyless entry control module | (4) Rear gate latch switch        |                 |

D: SCHEMATIC




S6M0451



S6M0452

## E: CONTROL MODULE I/O SIGNAL



B6M0957

Content	Terminal No.	Measuring condition
Door and rear gate lock actuator (Except driver side)	1 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM button two times.
Door and rear gate lock actuator	2 (OUTPUT)	Battery voltage is present when pressing the transmitter LOCK/ARM button one time.
Power supply (Back-up)	3	Battery voltage is constantly present.
<ul style="list-style-type: none"> <li>Room light</li> <li>Rear gate latch switch</li> </ul>	4 (OUTPUT)	<ul style="list-style-type: none"> <li>0 V is present when pressing the transmitter UNLOCK/DISARM button one time.</li> <li>Battery voltage is present when opening the rear gate.</li> </ul>
Door lock switch	5 (INPUT)	0 V is present when operating the door lock switch.
Door switch	7 (INPUT)	Battery voltage is present when any door is open.
Ground	8	—
Door lock actuator (Driver side)	9 (OUTPUT)	Battery voltage is present when pressing the transmitter UNLOCK/DISARM button one time.
Security control module	10	—
Security control module	11	—
Horn relay	12 (OUTPUT)	0 V is present when pressing the transmitter UNLOCK/DISARM or LOCK/ARM button.
Security control module	13	—
Ignition switch (ON)	14 (INPUT)	Battery voltage is present when ignition switch is turned ON.
Door unlock switch	15 (INPUT)	0 V is present when operating the door lock switch.
Key warning switch	16 (INPUT)	Battery voltage is present when inserting the key into the ignition switch.

## F: DIAGNOSTICS PROCEDURE

## 1. BASIC DIAGNOSTICS PROCEDURE

## 4F11 : CHECK KEYLESS ENTRY FUNCTION.

- 1) Perform pre-inspection.  
<Ref. to 6-2 [T4B0].>
- 2) Remove ignition key from ignition switch.
- 3) Set the room light switch in the middle position.
- 4) Close all doors and the rear gate.
- 5) Press the LOCK/ARM button one time.

**CHECK** : **Do all doors and rear gate lock normally?**

**YES** : Go to step 4F12.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

## 4F12 : CHECK KEYLESS ENTRY FUNCTION.

Check if the horn signal chirps.

**CHECK** : **Does the horn chirp one time?**

**YES** : Go to step 4F13.

**NO** : Go to step 4F21.



**4F13 : CHECK KEYLESS ENTRY FUNCTION.**

Press the UNLOCK/DISARM button one time.

**CHECK** : *Does the driver's door unlock normally?*

**YES** : Go to step 4F14.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F14 : CHECK KEYLESS ENTRY FUNCTION.**

Check if the horn signal chirps.

**CHECK** : *Does the horn chirp two times?*

**YES** : Go to step 4F15.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F15 : CHECK KEYLESS ENTRY FUNCTION.**

Check if the room light is turned on.

**CHECK** : *Does the room light turn on for 30 seconds, and then turn off?*

**YES** : Go to step 4F16.

**NO** : Go to step 4F31.

**4F16 : CHECK KEYLESS ENTRY FUNCTION.**

- 1) Press the LOCK/ARM button one time.
- 2) Press the UNLOCK/DISARM button two times.

**CHECK** : *Do all doors and rear gate unlock normally?*

**YES** : Go to step 4F17.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F17 : CHECK KEYLESS ENTRY FUNCTION.**

Keep the LOCK/ARM button pressed for more than 1.5 seconds.

**CHECK** : *Does the horn sound for 30 seconds, and then turns off?*

**YES** : Go to step 4F18.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F18 : CHECK KEYLESS ENTRY FUNCTION.**

- 1) Keep the LOCK/ARM button pressed for more than 1.5 seconds.

- 2) Horn will sound, and then press the LOCK/ARM button.

**CHECK** : *Does the horn turn off?*

**YES** : Go to step 4F19.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F19 : CHECK KEYLESS ENTRY FUNCTION.**

- 1) Keep the LOCK/ARM button pressed for more than 1.5 seconds.

- 2) Horn will sound, and then press the UNLOCK/DISARM button.

**CHECK** : *Does the horn turn off?*

**YES** : Go to step 4F110.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F110 : CHECK DOOR SWITCH FUNCTION.**

Open the front left door.

**CHECK** : *Does the room light turn on?*

**YES** : Go to step 4F111.

**NO** : Go to step 4F41.

**4F111 : CHECK DOOR SWITCH FUNCTION.**

- 1) Close the front left door.
- 2) Open the front right door.

**CHECK** : *Does the room light turn on?*

**YES** : Go to step 4F112.

**NO** : Go to step 4F41.

**4F112 : CHECK DOOR SWITCH FUNCTION.**

- 1) Close the front right door.
- 2) Open the rear left door.

**CHECK** : *Does the room light turn on?*

**YES** : Go to step 4F113.

**NO** : Go to step 4F41.

**4F113 : CHECK DOOR SWITCH FUNCTION.**

- 1) Close the rear left door.
- 2) Open the rear right door.

**CHECK** : ***Does the room light turn on?***

**YES** : Go to step **4F114**.

**NO** : Go to step **4F41**.

**4F114 : PERFORM PROGRAMMING.****NOTE:**

Finish operation from step 1) through 4) within 45 seconds.

- 1) Sit on the driver's seat and close all doors and the rear gate.
- 2) Open the driver's door.
- 3) Close the driver's door.
- 4) Turn the ignition switch from ON to LOCK ten times in rapid succession (within 15 seconds).

**NOTE:**

Do not start the engine at this time.

- 5) The horn chirps one time to indicate that the system has been in the programming mode.
- 6) Open the driver's door.
- 7) Close the driver's door.
- 8) Press any button on the transmitter that you wish to program into the system.
- 9) Horn will chirp two times to indicate that the transmitter has been programmed.

**NOTE:**

Any additional transmitter can also be programmed at this time. Repeat steps 6) through 9) for an additional transmitter.

- 10) Remove the ignition key from the ignition switch.
- 11) The horn will chirp three times to indicate that the system has exited the programming mode.
- 12) Check the keyless entry system properly operates by operating each transmitter.

**CHECK** : ***Does the transmitter operate normally?***

**YES** : Go to step **4F115**.

**NO** : Go to step **4F51**.

**4F115 : CHECK IGNITION KEY SWITCH.**

- 1) Insert the ignition key to the ignition switch (at LOCK position).
- 2) Perform lock and unlock with transmitter.

**CHECK** : ***Does the power door lock function normally?***

**YES** : Go to step **4F61**.

**NO** : End of basic diagnostics procedure.

2. DIAGNOSTICS ITEM 1

**4F21 : SELECT HORN SIGNAL OPERATION.**


Keep both LOCK/ARM and UNLOCK/DISARM buttons pressed for more than 1.5 seconds.

- CHECK** : *Does the horn chirp one time?*
- YES** : Go to step 4F22.
- NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

**4F22 : CHECK HORN SIGNAL OUTPUT SIGNAL.**

- 1) Disconnect connector from keyless entry control module.
- 2) Measure voltage between keyless entry control module connector (B176) and chassis ground.

**Connector & terminal**  
**(B176) No. 12 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step 4F23.
- NO** : Go to step 4F26.

**4F23 : CHECK HORN RELAY.**

- 1) Remove horn relay from main fuse box.
- 2) Check continuity between horn relay terminals.

**Terminals**  
**No. 1 — No. 2:**




- CHECK** : *Does continuity exist?*
- YES** : Replace horn relay.
- NO** : Go to step 4F24.

**4F24 : CHECK HORN RELAY.**

Check continuity between horn relay terminals.

**Terminals**  
**No. 3 — No. 4:**




- CHECK** : *Does continuity exist?*
- YES** : Go to step 4F25.
- NO** : Replace horn relay.

**4F25 : CHECK HORN RELAY.**

- 1) Connect the battery to horn relay terminals No. 3 and No. 4.
- 2) Check continuity between horn relay terminals.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : **Does continuity exist?**
- YES** : Repair wiring harness of horn circuit.
- NO** : Replace horn relay.

**4F26 : CHECK FUSE.**

Remove and visually check the fuse No. 6 (in main fuse box).


- CHECK** : **Is the fuse No. 6 blown?**
- YES** : Replace fuse (15 A).
- NO** : Go to step **4F27**.

**4F27 : CHECK POWER SUPPLY FOR HORN RELAY.**

- 1) Install horn relay to main fuse box.
- 2) Measure voltage between main fuse box connector (F37) and chassis ground.

**Connector & terminal**

**(F37) No. 4 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **4F28**.
- NO** : Repair wiring harness between main fuse box and battery.

**4F28 : CHECK RESISTANCE BETWEEN HORN RELAY AND KEYLESS ENTRY CONTROL MODULE.**

- 1) Disconnect connector from main fuse box and keyless entry control module.
- 2) Measure resistance between keyless entry control module connector (B176) and main fuse box connector (F37).

**Connector & terminal**

**(B176) No. 12 — (F37) No. 4:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace keyless entry control module. <Ref. to 6-2 [W10A1].>
- NO** : Repair wiring harness between main fuse box and keyless entry control module.

**3. DIAGNOSTICS ITEM 2**

**4F31 : CHECK FUSE.**

Remove and visually check the fuse No. 2 (in main fuse box).

- CHECK** : **Is fuse No. 2 blown?**
- YES** : Replace fuse (15 A).
- NO** : Go to step 4F32.

**4F32 : CHECK ROOM LIGHT BULB.**

Remove and visually check the room light bulb.


- CHECK** : **Is the bulb blown?**
- YES** : Replace bulb.
- NO** : Go to step 4F33.

**4F33 : CHECK ROOM LIGHT SWITCH.**

- 1) Remove room light.
- 2) Measure resistance of room light switch terminal at the middle position.

**Terminals**

**No. 2 — No. 3:**




- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Repair or replace room light.
- NO** : Go to step 4F34.

**4F34 : CHECK POWER SUPPLY FOR ROOM LIGHT.**

- 1) Disconnect connector from room light.
- 2) Open any door.
- 3) Measure voltage between room light connector (R52) and chassis ground.

**Connector & terminal**

**(R52) No. 2 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **4F35**.
- NO** : Repair wiring harness between room light and battery.

**4F35 : CHECK HARNESS CONNECTOR BETWEEN ROOM LIGHT AND KEYLESS ENTRY CONTROL MODULE.**

- 1) Disconnect connector from keyless entry control module.
- 2) Measure resistance between room light connector (R52) and keyless entry control module connector (B176).

**Connector & terminal**

**(R52) No. 1 — (B176) No.4:**




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>
- NO** : Repair wiring harness between room light and keyless entry control module.

4. DIAGNOSTICS ITEM 3

4F41 : CHECK DOOR SWITCH.


1) Remove door switch.



2) Move switch and check continuity between terminals of door switch.

**Terminals**

**No. 1 — Chassis ground**



**CHECK** : Does any fault exist in the door switch?


**YES** : Replace door switch.

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

5. DIAGNOSTICS ITEM 4

4F51 : CHECK IGNITION SWITCH.

1) Remove ignition switch. <Ref. to 6-2 [W3A1].>  
2) Turn ignition key to each position and check continuity between terminals of ignition switch connector.



**CHECK** : Is the ignition switch faulty?

**YES** : Replace ignition switch. <Ref. to 6-2 [W3A1].>

**NO** : Replace keyless entry control module.  
<Ref. to 6-2 [W10A1].>

## 6. DIAGNOSTICS ITEM 5

**4F61 : CHECK FUSE.**


Remove and visually check the fuse No. 6 (in main fuse box).

- CHECK** : *Is fuse No. 6 blown?*  
**YES** : Replace fuse (15 A).  
**NO** : Go to step **4F62**.

**4F62 : CHECK KEYLESS ENTRY CONTROL MODULE.**

- 1) Disconnect connector from keyless entry control module.
- 2) Insert the key to ignition switch (LOCK position).
- 3) Measure voltage between keyless entry control module connector (B176) and chassis ground.

**Connector & terminal**  
**(B176) No. 16 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 10 V?*  
**YES** : Replace keyless entry control module.  
 <Ref. to 6-2 [W10A0].>  
**NO** : Go to step **4F63**.

**4F63 : CHECK HARNESS CONNECTOR BETWEEN BATTERY AND KEY WARNING SWITCH.**

- 1) Disconnect connector from key warning switch.
- 2) Measure voltage between key warning switch connector (B74) and chassis ground.

**Connector & terminal**  
**(B74) No. 2 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 10 V?*  
**YES** : Go to step **4F64**.  
**NO** : Repair wiring harness between battery and key warning switch.

**4F64 : CHECK HARNESS CONNECTOR BETWEEN KEY WARNING SWITCH AND KEYLESS ENTRY CONTROL MODULE.**

Measure resistance between key warning switch connector (B74) and keyless entry control module connector (B176).

**Connector & terminal**  
**(B74) No. 1 — (B176) No. 16:**



- CHECK** : *Is the resistance less than 10 Ω?*  
**YES** : Replace key warning switch.  
**NO** : Repair wiring harness between key warning switch and keyless entry control module.