

## 8. Diagnostics for Engine Starting Failure

### A: BASIC DIAGNOSTICS CHART


1. Inspection of starter motor circuit. <Ref. to 2-7 [T8B0].>	↓
2. Inspection of ECM power supply and ground line. <Ref. to 2-7 [T8C0].>	↓
3. Inspection of ignition control system. <Ref. to 2-7 [T8D0].>	↓
4. Inspection of fuel pump circuit. <Ref. to 2-7 [T8E0].>	↓
5. Inspection of fuel injector circuit. <Ref. to 2-7 [T8F0].>	↓
6. Inspection of crankshaft position sensor circuit. <Ref. to 2-7 [T8G0].>	↓
7. Inspection of camshaft position sensor circuit. <Ref. to 2-7 [T8H0].>	↓
8. Inspection using Subaru Select Monitor or OBD-II general scan tool <Ref. to 2-7 [T10A0].> or inspection using "9. General Diagnostics Table". <Ref. to 2-7 [T900].>	

**B: STARTER MOTOR CIRCUIT**

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




**8B1 : CHECK BATTERY.**

- CHECK** : *Is the voltage more than 12 V?*
- YES** : Go to step **8B2**.
- NO** : Charge or replace battery.

**8B2 : CHECK INPUT SIGNAL FOR STARTER MOTOR.**

1) Turn ignition switch to OFF.

2) Disconnect connector from starter motor.




3) Turn ignition switch to ON.

4) Measure power supply voltage between starter motor connector terminal and engine ground.

**Connector & terminal**

**(B14) No. 1 (+) — Engine ground (-):**



**NOTE:**

- On AT vehicles, place the select lever in the “P” or “N” position.
- On MT vehicles, depress the clutch pedal.

**CHECK** : **Is the voltage more than 10 V?**

**YES** : Go to step 8B3.

**NO** : Go to step 8B4.

**8B3 : CHECK GROUND CIRCUIT OF STARTER MOTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect terminal from starter motor.



3) Measure resistance of ground cable between ground cable terminal and engine ground.

**CHECK** : **Is resistance less than 5 Ω?**

**YES** : Check starter motor. <Ref. to 6-1 [K100].>


**NO** : Repair open circuit of ground cable.

**8B4 : CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.**

- 1) Disconnect connector from ignition switch.
- 2) Measure power supply voltage between ignition switch connector and chassis ground.

**Connector & terminal**

**(B72) No. 1 (+) — Chassis ground (-):**



**CHECK** : **Is the voltage more than 10 V?**

**YES** : Go to step 8B6.


**NO** : Repair open circuit in harness between ignition switch and battery, and check fuse SBF No. 4 and SBF No.1.

**8B5 : CHECK IGNITION SWITCH.**

- 1) Disconnect connector from ignition switch.
- 2) Measure resistance between ignition switch terminals while turning ignition switch to the “ST” position.

**Terminals**

**No. 1 — No. 3:**




**CHECK** : **Is the resistance less than 5 Ω?**

**YES** : Go to step 8B6.


**NO** : Replace ignition switch.

**8B6 : CHECK TRANSMISSION TYPE.****CHECK** : *Is transmission type AT?***YES** : Go to step **8B7**.**NO** : Go to step **8B11**.**8B7 : CHECK INPUT VOLTAGE OF INHIBITOR SWITCH.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from inhibitor switch.
- 3) Connect connector to ignition switch.
- 4) Measure input voltage between inhibitor switch connector terminal and engine ground while turning ignition switch to ST.

**Connector & terminal****(B12) No. 12 (+) — Engine ground (-):****CHECK** : *Is the voltage more than 10 V?***YES** : Go to step **8B8**.**NO** : Repair open or ground short circuit in harness between inhibitor switch and ignition switch.**8B8 : CHECK INHIBITOR SWITCH.**

- 1) Place the select lever in the "P" or "N" position.
- 2) Measure resistance between inhibitor switch terminals.


**Connector & terminal****(T3) No. 11 — No. 12:****CHECK** : *Is the resistance less than 1 Ω?***YES** : Repair open or ground short circuit in harness between inhibitor switch and starter motor.**NO** : Replace inhibitor switch. <Ref. to 3-2 [W2C0].>

**8B9 : CHECK INPUT VOLTAGE OF STARTER INTERLOCK RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from starter interlock relay.
- 3) Connect connector to ignition switch.
- 4) Measure input voltage between starter interlock relay connector and chassis ground while turning ignition switch to ST.

**Connector & terminal**

- (B105) No. 1 (+) — Chassis ground (-):
- (B105) No. 3 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8B10.
- NO** : Repair open or ground short circuit in harness between starter interlock relay and ignition switch.

**8B10 : CHECK STARTER INTERLOCK RELAY.**

- 1) Connect battery to starter interlock relay terminals No. 2 and No. 3.
- 2) Measure resistance between starter interlock relay terminals.

**Terminals**

- No. 1 — No. 4:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8B11.
- NO** : Replace starter interlock relay.

**8B11 : CHECK GROUND CIRCUIT OF CLUTCH SWITCH.**

- 1) Disconnect connector from clutch switch.
- 2) Measure resistance between clutch switch connector and chassis ground.

**Connector & terminal**

- (B106) No. 1 — Chassis ground:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8B12.
- NO** : Repair open circuit of ground cable.

**8B12 : CHECK CLUTCH SWITCH.**

1) Measure resistance between clutch switch terminal while depressing the clutch pedal.

**Terminals**

**No. 1 — No. 2:**




- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **8B13**.
- NO** : Replace clutch switch. <Ref. to 6-2 [T100].>

**8B13 : CHECK CLUTCH SWITCH CIRCUIT.**

1) Connect connector to clutch switch.  
2) Measure resistance between starter interlock relay connector and chassis ground while depressing the clutch pedal.

**Connector & terminal**

**(B105) No. 2 — Chassis ground:**



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Repair open or ground short circuit in harness between starter interlock relay and starter motor.
- NO** : Repair open circuit in harness between starter interlock relay and clutch switch.


**MEMO:**

**C: CONTROL MODULE POWER SUPPLY AND GROUND LINE**

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE. <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




H2M3537

**8C1 : CHECK MAIN RELAY.**

- 1) Turn the ignition switch to OFF.
- 2) Remove main relay.
- 3) Connect battery to main relay terminals No. 1 and No. 2.
- 4) Measure resistance between main relay terminals.

**Terminals**

**No. 3 — No. 5:**



H2M2268


- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step **8C2**.
- NO** : Replace main relay.

**8C2 : CHECK MAIN RELAY.**

Measure resistance between main relay terminals.

**Terminals**

**No. 4 — No. 6:**



H2M2269

- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step **8C3**.
- NO** : Replace main relay.




**8C3 : CHECK GROUND CIRCUIT OF ECM.**

- 1) Disconnect connector from ECM.
- 2) Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**

- (B136) No. 21 — Chassis ground:
- (B136) No. 22 — Chassis ground:
- (B134) No. 27 — Chassis ground:
- (B134) No. 8 — Chassis ground:
- (B134) No. 7 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8C4.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

**8C4 : CHECK INPUT VOLTAGE OF ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

- (B136) No. 9 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C5.
- NO** : Repair open or ground short circuit of power supply circuit.

**8C5 : CHECK INPUT VOLTAGE OF ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

- (B135) No. 7 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C6.
- NO** : Repair open or ground short circuit of power supply circuit.

**8C6 : CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ECM and chassis ground.

**Connector & terminal**

- (B135) No. 19 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 8C7.
- NO** : Repair ground short circuit in harness between ECM connector and main relay connector, then replace ECM.

**8C7 : CHECK OUTPUT VOLTAGE FROM ECM.**

- 1) Connect connector to ECM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
**(B135) No. 19 (+) — Chassis ground (-):**




- CHECK** : Is the voltage more than 10 V?  
**YES** : Go to step 8C8.  
**NO** : Replace ECM.

**8C8 : CHECK INPUT VOLTAGE OF MAIN RELAY.**

Check voltage between main relay connector and chassis ground.

**Connector & terminal**  
**(B47) No. 2 (+) — Chassis ground (-):**




- CHECK** : Is the voltage more than 10 V?  
**YES** : Go to step 8C9.  
**NO** : Repair open circuit in harness between ECM connector and main relay connector.

**8C9 : CHECK GROUND CIRCUIT OF MAIN RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between main relay connector and chassis ground.

**Connector & terminal**  
**(B47) No. 1 — Chassis ground:**




- CHECK** : Is the resistance less than 5 Ω?  
**YES** : Go to step 8C10.  
**NO** : Repair open circuit between main relay and chassis ground.

**8C10 : CHECK INPUT VOLTAGE OF MAIN RELAY.**

Measure voltage between main relay connector and chassis ground.

**Connector & terminal**  
**(B47) No. 5 (+) — Chassis ground (-):**  
**(B47) No. 6 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 10 V?  
**YES** : Go to step 8C11.  
**NO** : Repair open or ground short circuit in harness of power supply circuit.


**8C11 : CHECK INPUT VOLTAGE OF ECM.**

- 1) Connect main relay connector.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 1 (+) — Chassis ground (-):**

**(B136) No. 2 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Check ignition control system. <Ref. to 2-7 [T8D0].>
- NO** : Repair open or ground short circuit in harness between ECM connector and main relay connector.

D: IGNITION CONTROL SYSTEM

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● WIRING DIAGRAM:



B2M3557


**8D1 : CHECK IGNITION SYSTEM FOR SPARKS.**

- 1) Remove plug cord cap from each spark plug.
- 2) Install new spark plug on plug cord cap.

**CAUTION:**

**Do not remove spark plug from engine.**

- 3) Contact spark plug's thread portion on engine.
- 4) While opening throttle valve fully, crank engine to check that spark occurs at each cylinder.




- CHECK** : **Does spark occur at each cylinder?**
- YES** : Check fuel pump system. <Ref. to 2-7 [T8E0].>
- NO** : Go to step **8D2**.

**8D2 : CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL & IGNITOR ASSEMBLY.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ignition coil & ignitor assembly.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage between ignition coil & ignitor assembly connector and engine ground.

**Connector & terminal**

**(E12) No. 2 (+) — Engine ground (-):**



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **8D3**.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ignition coil & ignitor assembly, and ignition switch connector
- Poor contact in coupling connectors (B22)

**8D3 : CHECK HARNESS OF IGNITION COIL & IGNITOR ASSEMBLY GROUND CIRCUIT.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ignition coil & ignitor assembly connector and engine ground.

**Connector & terminal**

**(E12) No. 3 — Engine ground:**



**CHECK** : *Is the resistance between less than 5 Ω?*

**YES** : Go to step **8D4**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ignition coil & ignitor assembly connector and engine grounding terminal


**8D4 : CHECK IGNITION COIL & IGNITOR ASSEMBLY.**

- 1) Remove spark plug cords.
- 2) Measure resistance between spark plug cord contact portions to check secondary coil.

**Terminals**

**No. 1 — No. 2:**

**No. 3 — No. 4:**



**CHECK** : *Is the resistance between 10 and 15 kΩ?*

**YES** : Go to step **8D5**.

**NO** : Replace ignition coil & ignitor assembly.  
<Ref. to 6-1 [W4A0].>


**8D5 : CHECK INPUT SIGNAL FOR IGNITION COIL & IGNITOR ASSEMBLY.**

- 1) Connect connector to ignition coil & ignitor assembly.
- 2) Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil & ignitor assembly connector and engine ground.

**Connector & terminal**

(E12) No. 1 (+) — Engine ground (-):

(E12) No. 4 (+) — Engine ground (-):



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8D6.
- NO** : Replace ignition coil & ignitor assembly. <Ref. to 6-1 [W4A0].>


**8D6 : CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Disconnect connector from ignition coil & ignitor assembly.
- 4) Measure resistance of harness between ECM and ignition coil & ignitor assembly connector.

**Connector & terminal**

(B134) No. 25 — (E12) No. 1:

(B134) No. 26 — (E12) No. 4:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8D7.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and ignition coil & ignitor assembly connector
- Poor contact in coupling connector (B22)


**8D7 : CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.**

Measure resistance of harness between ECM and chassis ground.

**Connector & terminal:**

**(B134) No. 25 — Chassis ground:**

**(B134) No. 26 — Chassis ground:**



- CHECK** : **Is the resistance more than 1 MΩ?**
- YES** : Go to step **8D8**.
- NO** : Repair ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.

**8D8 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Check fuel pump circuit. <Ref. to 2-7 [T8E0].>




MEMO:

**E: FUEL PUMP CIRCUIT**

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



**8E1 : CHECK OPERATING SOUND OF FUEL PUMP.**

Make sure that fuel pump is in operation for two seconds when turning ignition switch to ON.


**NOTE:**

Fuel pump operation can also be executed using Subaru Select Monitor (Function mode: FD01). For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : Does fuel pump produce operating sound?
- YES** : Check fuel injector circuit. <Ref. to 2-7 [T8G0].>
- NO** : Go to step **8E2**.

**8E2 : CHECK GROUND CIRCUIT OF FUEL PUMP.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuel pump access hole lid located on the right rear of luggage compartment floor.




- 3) Disconnect connector from fuel pump.

4) Measure resistance of harness connector between fuel pump and chassis ground.

**Connector & terminal**

**(R58) No. 4 — Chassis ground:**



- CHECK** : *Is the resistance less than 5 Ω?*
- YES** : Go to step 8E3.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between fuel pump connector and chassis grounding terminal
- Poor contact in coupling connector (R67)

**8E3 : CHECK POWER SUPPLY TO FUEL PUMP.**

1) Turn ignition switch to ON.  
2) Measure voltage of power supply circuit between fuel pump connector and chassis ground.

**Connector & terminal**

**(R58) No. 1 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 10 V?*
- YES** : Replace fuel pump. <Ref. to 2-8 [W3A0].>
- NO** : Go to step 8E4.

**8E4 : CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.**

1) Turn ignition switch to OFF.  
2) Measure resistance of harness connector between fuel pump and fuel pump relay.

**Connector & terminal**

**(R58) No. 1 — (B46) No. 4:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 8E5.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between fuel pump connector and chassis grounding terminal
- Poor contact in coupling connectors (R67 and B97)

**8E5 : CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.**

Measure resistance of harness between fuel pump and fuel pump relay connector.

**Connector & terminal**

**(R58) No. 1 — Chassis ground:**




- CHECK** : **Is the resistance more than 1 MΩ?**
- YES** : Go to step **8E6**.
- NO** : Repair short circuit in harness between fuel pump and fuel pump relay connector.

**8E6 : CHECK FUEL PUMP RELAY.**

- 1) Disconnect connectors from fuel pump relay and main relay.
- 2) Remove fuel pump relay and main relay with bracket.
- 3) Connect battery to fuel pump relay connector terminals No. 1 and No. 3.
- 4) Measure resistance between connector terminals of fuel pump relay.

**Terminals**

**No. 2 — No. 4:**




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **8E7**.
- NO** : Replace fuel pump relay. <Ref. to 2-7 [W19A0].>

**8E7 : CHECK HARNESS BETWEEN ECM AND FUEL PUMP RELAY CONNECTOR.**

- 1) Disconnect connectors from ECM.
- 2) Measure resistance of harness between ECM and fuel pump relay connector.

**Connector & terminal**

**(B134) No. 16 — (B46) No. 3:**



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **8E8**.
- NO** : Repair open circuit in harness between ECM and fuel pump relay connector.

**8E8 : CHECK POOR CONTACT.**

Check poor contact in ECM connector.  
<Ref. to FOREWORD [T3C1].>


- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Check fuel injector circuit. <Ref. to 2-7 [T8G0].>

**F: FUEL INJECTOR CIRCUIT**

**CAUTION:**

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE. <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



H2M3539

**8F1 : CHECK OPERATION OF EACH FUEL INJECTOR.**

While cranking the engine, check that each fuel injector emits “operating” sound. Use a sound scope or attach a screwdriver to injector for this check.


- CHECK** : *Is the fuel injector emits “operating” sound?*
- YES** : Check fuel pressure. <Ref. to 2-2 [W7A0].>
- NO** : Go to step **8F2**.

**8F2 : CHECK POWER SUPPLY TO EACH FUEL INJECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from #1 cylinder fuel injector.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage between the fuel injector terminal and engine ground.

**Connector & terminal**

- #1 (E5) No. 2 (+) — Engine ground (-):
- #2 (E16) No. 2 (+) — Engine ground (-):
- #3 (E6) No. 2 (+) — Engine ground (-):
- #4 (E17) No. 2 (+) — Engine ground (-):



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8F3.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between main relay and fuel injector connector
- Poor contact in main relay connector
- Poor contact in coupling connector (B22)
- Poor contact in fuel injector connector

**8F3 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

- 1) Disconnect connector from ECM.
- 2) Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**

**(B134) No. 4 — (B136) No. 2:**



- CHECK** : Is the resistance between 5 and 20 Ω?
- YES** : Go to step 8F4.
- NO** : Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between ECM and fuel injector connector
- Poor contact in coupling connector (B22)

**8F4 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
**(B134) No. 4 — Chassis ground:**




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Repair ground short circuit in harness between ECM and fuel injector connector.
- NO** : Go to step 8F5.

**8F5 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
**(B134) No. 13 — (B136) No. 2:**



- CHECK** : *Is the resistance between 5 and 20 Ω?*
- YES** : Go to step 8F6.
- NO** : Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between ECM and fuel injector connector
- Poor contact in coupling connector (B22)

**8F6 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
**(B134) No. 13 — Chassis ground:**




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Repair ground short circuit in harness between ECM and fuel injector connector.
- NO** : Go to step 8F7.

**8F7 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
**(B134) No. 14 — (B136) No. 2:**



- CHECK** : *Is the resistance between 5 and 20 Ω?*
- YES** : Go to step 8F8.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and fuel injector connector
- Poor contact in coupling connector (B22)



**8F8 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
(B134) No. 14 — Chassis ground:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Repair ground short circuit in harness between ECM and fuel injector connector.
- NO** : Go to step 8F9.

**8F9 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
(B134) No. 15 — (B136) No. 2:



- CHECK** : Is the resistance between 5 and 20 Ω?
- YES** : Go to step 8F10.
- NO** : Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between ECM and fuel injector connector
- Poor contact in coupling connector (B22)

**8F10 : CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.**

Measure resistance of harness between ECM and fuel injector connector.

**Connector & terminal**  
(B134) No. 15 — Chassis ground:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Repair ground short circuit in harness between ECM and fuel injector connector.
- NO** : Go to step 8F11.

**8F11 : CHECK EACH FUEL INJECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between each fuel injector terminals.

**Terminals**  
No. 1 — No. 2:



- CHECK** : Is the resistance between 5 and 20 Ω?
- YES** : Go to step 8F12.
- NO** : Replace faulty fuel injector.

**8F12 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [W3C1].>

**CHECK** : *Is there poor contact in ECM connector?*

**YES** : Repair poor contact in ECM connector.

**NO** : Check crankshaft position sensor circuit. <Ref. to 2-7 [T8G0].>

## **G: CRANKSHAFT POSITION SENSOR CIRCUIT**

### **CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

### **NOTE:**

Check crankshaft position sensor circuit.  
<Ref. to 2-7 [T10AD0].>

## **H: CAMSHAFT POSITION SENSOR CIRCUIT**

### **CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

### **NOTE:**

Check camshaft position sensor circuit.  
<Ref. to 2-7 [T10AF0].>