

9. General Diagnostic Table

A: GENERAL DIAGNOSTICS TABLE WITH NON-CONFORMITY SYMPTOM FOR ENGINE

NOTE:

Malfunction of parts other than those listed is also possible. <Ref. to 2-3 [K100].>

Symptom	Problem parts
1. Engine stalls during idling.	1) Idle air control solenoid valve 2) Intake air temperature and pressure sensor 3) Ignition parts (*1) 4) Engine coolant temperature sensor (*2) 5) Crankshaft position sensor (*3) 6) Camshaft position sensor (*3) 7) Fuel injection parts (*4)
2. Rough idling	1) Idle air control solenoid valve 2) Intake air temperature and pressure sensor 3) Engine coolant temperature sensor (*2) 4) Ignition parts (*1) 5) Air intake system (*5) 6) Fuel injection parts (*4) 7) Throttle position sensor 8) Crankshaft position sensor (*3) 9) Camshaft position sensor (*3) 10) Oxygen sensor 11) Fuel pump and fuel pump relay
3. Engine does not return to idle.	1) Idle air control solenoid valve 2) Engine coolant temperature sensor 3) Accelerator cable (*6) 4) Throttle position sensor 5) Intake air temperature and pressure sensor
4. Poor acceleration	1) Intake air temperature and pressure sensor 2) Throttle position sensor 3) Fuel injection parts (*4) 4) Fuel pump and fuel pump relay 5) Engine coolant temperature sensor (*2) 6) Crankshaft position sensor (*3) 7) Camshaft position sensor (*3) 8) A/C switch and A/C cut relay 9) Engine torque control signal circuit 10) Ignition parts (*1)
5. Engine stalls or engine sags or hesitates at acceleration.	1) Intake air temperature and pressure sensor 2) Engine coolant temperature sensor (*2) 3) Crankshaft position sensor (*3) 4) Camshaft position sensor (*3) 5) Purge control solenoid valve 6) Fuel injection parts (*4) 7) Throttle position sensor 8) Fuel pump and fuel pump relay
6. Surge	1) Intake air temperature and pressure sensor 2) Engine coolant temperature sensor (*2) 3) Crankshaft position sensor (*3) 4) Camshaft position sensor (*3) 5) Fuel injection parts (*4) 6) Throttle position sensor 7) Fuel pump and fuel pump relay

Symptom	Problem parts
7. Spark knock	1) Intake air temperature and pressure sensor 2) Engine coolant temperature sensor 3) Knock sensor 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay
8. After burning in exhaust system	1) Intake air temperature and pressure sensor 2) Engine coolant temperature sensor (*2) 3) Fuel injection parts (*4) 4) Fuel pump and fuel pump relay

*1: Check ignition coil & ignitor assembly and spark plug.

*2: Indicate the symptom occurring only in cold temperatures.

*3: Ensure the secure installation.

*4: Check fuel injector, fuel pressure regulator and fuel filter.

*5: Inspect air leak in air intake system.

*6: Adjust accelerator cable.

B: GENERAL DIAGNOSTICS TABLE WITH NON-CONFORMITY SYMPTOM FOR AUTOMATIC TRANSMISSION

NOTE:

Check general diagnostics table with non-conformity symptom for automatic transmission. <Ref. to 3-2 [T1000].>