

MECHANICAL

ME(SOHC)

| | Page |
|-------------------------------------|-------------|
| 1. General Description | 2 |
| 2. Compression | 23 |
| 3. Idle Speed | 24 |
| 4. Ignition Timing | 25 |
| 5. Intake Manifold Vacuum..... | 26 |
| 6. Engine Oil Pressure | 27 |
| 7. Fuel Pressure | 28 |
| 8. Valve Clearance | 29 |
| 9. Engine Assembly | 32 |
| 10. Engine Mounting | 39 |
| 11. Preparation for Overhaul..... | 40 |
| 12. V-belt..... | 41 |
| 13. Crankshaft Pulley | 43 |
| 14. Belt Cover | 45 |
| 15. Timing Belt Assembly..... | 46 |
| 16. Camshaft Sprocket..... | 51 |
| 17. Crankshaft Sprocket..... | 53 |
| 18. Valve Rocker Assembly | 54 |
| 19. Camshaft..... | 56 |
| 20. Cylinder Head Assembly..... | 60 |
| 21. Cylinder Block | 68 |
| 22. Engine Trouble in General | 89 |
| 23. Engine Noise | 94 |

GENERAL DESCRIPTION

MECHANICAL

1. General Description

A: SPECIFICATIONS

| Model | | 2000 cc | 2500 cc |
|--|---------|--|---|
| | | Type | Horizontally opposed, liquid cooled, 4-cylinder, 4-stroke gasoline engine |
| Valve arrangement | | Belt driven, single over-head camshaft, 4-valve/cylinder | |
| Bore x Stroke | | 92 x 75 (3.62 x 2.95) | 99.5 x 79.0 (3.917 x 3.110) |
| Displacement | | 1,994 (121.67) | 2,457 (150) |
| Compression ratio | | 10.0 | |
| Compression pressure (at 200 — 300 rpm) | | 1,079 — 1,275 (11.0 — 13.0, 156 — 185) | |
| Number of piston rings | | Pressure ring: 2, Oil ring: 1 | |
| Intake valve timing | Opening | 4° BTDC | 1° BTDC |
| | Closing | 48° ABDC | 51° ABDC |
| Exhaust valve timing | Opening | 48° BBDC | 50° BBDC |
| | Closing | 4° ATDC | 6° ATDC |
| Valve clearance | Intake | 0.20±0.02 (0.0079±0.0008) | |
| | Exhaust | 0.25±0.02 (0.0098±0.0008) | |
| Idling speed [At neutral position on MT, or "P" or "N" position on AT] | | 650±100 (No load) 850±100 (A/C switch ON) | |
| Firing order | | 1 → 3 → 2 → 4 | |
| Ignition timing | | 10°±10°/700 | |

NOTE:

STD: Standard I.D.: Inner Diameter O.D.: Outer Diameter US: Undersize OS: Oversize

| | | | | | |
|--|-----------------------------------|---|---|---|---|
| Belt tensioner adjuster | Protrusion of adjuster rod | | 5.2 — 6.2 mm (0.205 — 0.244 in) | | |
| Belt tensioner | Spacer O.D. | | 17.955 — 17.975 mm (0.7069 — 0.7077 in) | | |
| | Tensioner bush I.D. | | 18.00 — 18.08 mm (0.7087 — 0.7118 in) | | |
| | Clearance between spacer and bush | STD | 0.025 — 0.125 mm (0.0010 — 0.0049 in) | | |
| | | Limit | 0.175 mm (0.0069 in) | | |
| Side clearance of spacer | STD | 0.20 — 0.55 mm (0.0079 — 0.0217 in) | | | |
| | Limit | 0.81 mm (0.0319 in) | | | |
| Valve rocker arm | Clearance between shaft and arm | STD | 0.020 — 0.054 mm (0.0008 — 0.0021 in) | | |
| | | Limit | 0.10 mm (0.0039 in) | | |
| Camshaft | Bend limit | | 0.025 mm (0.0010 in) | | |
| | Thrust clearance | STD | 0.030 — 0.090 mm (0.0012 — 0.0035 in) | | |
| | | Limit | 0.11 mm (0.0039 in) | | |
| | Cam lobe height | 2000 cc | Intake | STD | 38.732 — 38.832 mm (1.5249 — 1.5288 in) |
| | | | | Limit | 38.632 mm (1.5209 in) |
| | | | Exhaust | STD | 39.257 — 39.357 mm (1.5455 — 1.5495 in) |
| | | Limit | | 39.157 mm (1.5416 in) | |
| | | 2500 cc | Intake | STD | 39.485 — 39.585 mm (1.5545 — 1.5585 in) |
| | | | | Limit | 39.385 mm (1.5506 in) |
| | Exhaust | | STD | 39.257 — 39.357 mm (1.5455 — 1.5495 in) | |
| | | Limit | 39.157 mm (1.5416 in) | | |
| Camshaft journal O.D. | | 31.928 — 31.945 mm (1.2570 — 1.2577 in) | | | |
| Camshaft journal hole I.D. (Cylinder head) | | 32.000 — 32.018 mm (1.2598 — 1.2605 in) | | | |
| Oil clearance | STD | 0.055 — 0.090 mm (0.0022 — 0.0035 in) | | | |
| | Limit | 0.10 mm (0.0039 in) | | | |

ME(SOHC)-2

GENERAL DESCRIPTION

MECHANICAL

| | | | | | | | |
|--|--|------------------------|---|--|---|---|--|
| Cylinder head | Surface warpage limit (mating with cylinder block) | | | 0.05 mm (0.0020 in) | | | |
| | Surface grinding limit | | | 0.1 mm (0.004 in) | | | |
| | Standard height | | | 97.5 mm (3.84 in) | | | |
| Valve seat | Refacing angle | | | 90° | | | |
| | Contacting width | Intake | STD | 1.1 mm (0.043 in) | | | |
| | | | Limit | 1.8 mm (0.070 in) | | | |
| | | Exhaust | STD | 1.5 mm (0.059 in) | | | |
| Limit | | | 2.2 mm (0.087 in) | | | | |
| Valve guide | Inner diameter | | | 6.000 — 6.012 mm (0.2362 — 0.2367 in) | | | |
| | Protrusion above head | | Intake | 20.0 — 20.5 mm (0.787 — 0.807 in) | | | |
| | | | Exhaust | 16.5 — 17.0 mm (0.650 — 0.669 in) | | | |
| Valve | Head edge thickness | Intake | STD | 1.0 mm (0.039 in) | | | |
| | | | Limit | 0.6 mm (0.024 in) | | | |
| | | Exhaust | STD | 1.2 mm (0.047 in) | | | |
| | | | Limit | 0.6 mm (0.024 in) | | | |
| | Stem diameter | | Intake | 5.950 — 5.965 mm (0.2343 — 0.2348 in) | | | |
| | | | Exhaust | 5.945 — 5.960 mm (0.2341 — 0.2346 in) | | | |
| | Stem oil clearance | | STD | Intake | 0.035 — 0.062 mm (0.0014 — 0.0024 in) | | |
| | | | | Exhaust | 0.040 — 0.067 mm (0.0016 — 0.0026 in) | | |
| | | Limit | — | 0.15 mm (0.0059 in) | | | |
| Overall length | | Intake | 120.6 mm (4.75 in) | | | | |
| | | Exhaust | 121.7 mm (4.79 in) | | | | |
| Valve spring | Free length | | | 54.30 mm (2.1378 in) | | | |
| | Squareness | | | 2.5°, 2.4 mm (0.094 in) | | | |
| | Tension/spring height | | Set | 214 — 246 N (22 — 25 kgf, 48 — 55 lb)/ 45.0 mm (1.772 in) | | | |
| | | | Lift | 526 — 582 N (54 — 59 kgf, 119 — 130 lb)/ 34.7 mm (1.366 in) | | | |
| Cylinder block | Surface warpage limit (mating with cylinder head) | | | 0.05 mm (0.0020 in) | | | |
| | Surface grinding limit | | | 0.1 mm (0.004 in) | | | |
| | Cylinder bore | 2000 cc | STD | A | 92.005 — 92.015 mm (3.6222 — 3.6226 in) | | |
| | | | | B | 91.995 — 92.005 mm (3.6218 — 3.6222 in) | | |
| | | 2500 cc | STD | A | 99.505 — 99.515 mm (3.9175 — 3.9179 in) | | |
| | | | | B | 99.495 — 99.505 mm (3.9171 — 3.9175 in) | | |
| | Taper | | STD | 0.015 mm (0.0006 in) | | | |
| | | | Limit | 0.050 mm (0.0020 in) | | | |
| | Out-of-roundness | | STD | 0.010 mm (0.0004 in) | | | |
| | | | Limit | 0.050 mm (0.0020 in) | | | |
| Piston clearance | | STD | 0.010 — 0.030 mm (0.0004 — 0.0012 in) | | | | |
| | | Limit | 0.050 mm (0.0020 in) | | | | |
| Enlarging (boring) limit | | | 0.5 mm (0.020 in) | | | | |
| Piston | Outer diameter | 2000 cc | STD | A | 91.985 — 91.995 mm (3.6214 — 3.6218 in) | | |
| | | | | B | 91.975 — 91.985 mm (3.6211 — 3.6214 in) | | |
| | | | | | 0.25 mm (0.0098 in) OS | 92.225 — 92.235 mm (3.6309 — 3.6313 in) | |
| | | | | | 0.50 mm (0.0197 in) OS | 92.475 — 92.485 mm (3.6407 — 3.6411 in) | |
| | | 2500 cc | STD | A | 99.485 — 99.495 mm (3.9167 — 3.9171 in) | | |
| | | | | B | 99.475 — 99.485 mm (3.9163 — 3.9167 in) | | |
| | | | | | 0.25 mm (0.0098 in) OS | 99.725 — 99.735 mm (3.9262 — 3.9266 in) | |
| | | 0.50 mm (0.0197 in) OS | 99.975 — 99.985 mm (3.9360 — 3.9364 in) | | | | |
| Standard inner diameter of piston pin hole | | | 23.000 — 23.006 mm (0.9055 — 0.9057 in) | | | | |

GENERAL DESCRIPTION

MECHANICAL

| | | | | | |
|------------------------|--|-------------|--|---------------------------------------|-------------------------------------|
| Piston pin | Outer diameter | | 22.994 — 23.000 mm (0.9053 — 0.9055 in) | | |
| | Standard clearance between piston pin and piston | | 0.004 — 0.008 mm (0.0002 — 0.0003 in) | | |
| | Degree of fit | | Piston pin must be fitted into position with thumb at 20°C (68°F). | | |
| Piston ring | Piston ring gap | Top ring | STD | 0.20 — 0.35 mm (0.0079 — 0.0138 in) | |
| | | | Limit | 1.0 mm (0.039 in) | |
| | | Second ring | 2000 cc | STD | 0.35 — 0.50 mm (0.0138 — 0.0197 in) |
| | | | | Limit | 1.0 mm (0.039 in) |
| | | | 2500 cc | STD | 0.37 — 0.52 mm (0.0146 — 0.0204 in) |
| | | | | Limit | 1.0 mm (0.039 in) |
| | Oil ring | STD | 0.20 — 0.50 mm (0.0079 — 0.0197 in) | | |
| | | Limit | 1.5 mm (0.059 in) | | |
| | Clearance between piston ring and piston ring groove | Top ring | STD | 0.040 — 0.080 mm (0.0016 — 0.0031 in) | |
| | | | Limit | 0.15 mm (0.0059 in) | |
| Second ring | | STD | 0.030 — 0.070 mm (0.0012 — 0.0028 in) | | |
| | | Limit | 0.15 mm (0.0059 in) | | |
| Connecting rod | Bend twist per 100 mm (3.94 in) in length | | Limit | 0.10 mm (0.0039 in) | |
| | Side clearance | | STD | 0.070 — 0.330 mm (0.0028 — 0.0130 in) | |
| | | | Limit | 0.4 mm (0.016 in) | |
| Connecting rod bearing | Oil clearance | 2000 cc | STD | 0.010 — 0.038 mm (0.0004 — 0.0015 in) | |
| | | | Limit | 0.05 mm (0.0020 in) | |
| | | 2500 cc | STD | 0.012 — 0.038 mm (0.0005 — 0.0015 in) | |
| | | | Limit | 0.05 mm (0.0020 in) | |
| | Thickness at center portion | 2000 cc | STD | 1.492 — 1.501 mm (0.0587 — 0.0591 in) | |
| | | | 0.03 mm (0.0012 in) US | 1.510 — 1.513 mm (0.0594 — 0.0596 in) | |
| | | | 0.05 mm (0.0020 in) US | 1.520 — 1.523 mm (0.0598 — 0.0600 in) | |
| | | | 0.25 mm (0.0098 in) US | 1.620 — 1.623 mm (0.0638 — 0.0639 in) | |
| | | 2500 cc | STD | 1.490 — 1.502 mm (0.0587 — 0.0591 in) | |
| | | | 0.03 mm (0.0012 in) US | 1.504 — 1.512 mm (0.0592 — 0.0595 in) | |
| | | | 0.05 mm (0.0020 in) US | 1.514 — 1.522 mm (0.0596 — 0.0599 in) | |
| | | | 0.25 mm (0.0098 in) US | 1.614 — 1.622 mm (0.0635 — 0.0639 in) | |
| Connecting rod bushing | Clearance between piston pin and bushing | | STD | 0 — 0.022 mm (0 — 0.0009 in) | |
| | | | Limit | 0.030 mm (0.0012 in) | |

GENERAL DESCRIPTION

MECHANICAL


| | | | | | | | |
|--------------------|------------------------------|---------------------------------------|------------------------------|---|---|------------------------|---------------------------------------|
| Crankshaft | Bend limit | | 0.035 mm (0.0014 in) | | | | |
| | Crank pin and crank journal | Out-of-roundness | 0.020 mm (0.0008 in) or less | | | | |
| | | Grinding limit | 0.250 mm (0.0098 in) | | | | |
| | Crank pin outer diameter | | STD | 51.984 — 52.000 mm (2.0466 — 2.0472 in) | | | |
| | | | 0.03 mm (0.0012 in) US | 51.954 — 51.970 mm (2.0454 — 2.0461 in) | | | |
| | | | 0.05 mm (0.0020 in) US | 51.934 — 51.950 mm (2.0446 — 2.0453 in) | | | |
| | | | 0.25 mm (0.0098 in) US | 51.734 — 51.750 mm (2.0368 — 2.0374 in) | | | |
| | Crank journal outer diameter | | #1, #3 | STD | 59.992 — 60.008 mm (2.3619 — 2.3625 in) | | |
| | | | | 0.03 mm (0.0012 in) US | 59.962 — 59.978 mm (2.3607 — 2.3613 in) | | |
| | | | | 0.05 mm (0.0020 in) US | 59.942 — 59.958 mm (2.3599 — 2.3605 in) | | |
| | | | | 0.25 mm (0.0098 in) US | 59.742 — 59.758 mm (2.3520 — 2.3527 in) | | |
| | | | #2, #4, #5 | STD | 59.992 — 60.008 mm (2.3619 — 2.3625 in) | | |
| | | | | 0.03 mm (0.0012 in) US | 59.962 — 59.978 mm (2.3607 — 2.3613 in) | | |
| | | | | 0.05 mm (0.0020 in) US | 59.942 — 59.958 mm (2.3599 — 2.3605 in) | | |
| | | | | 0.25 mm (0.0098 in) US | 59.742 — 59.758 mm (2.3520 — 2.3527 in) | | |
| | Thrust clearance | | STD | 0.030 — 0.115 mm (0.0012 — 0.0045 in) | | | |
| | | | Limit | 0.25 mm (0.0098 in) | | | |
| | Oil clearance | | #1 | STD | 0.003 — 0.030 mm (0.0001 — 0.0012 in) | | |
| | | | | Limit | 0.040 mm (0.0016 in) | | |
| | | | #2 | STD | 0.012 — 0.033 mm (0.0005 — 0.0013 in) | | |
| | | | | Limit | 0.045 mm (0.0018 in) | | |
| | | | #3 | STD | 0.003 — 0.030 mm (0.0001 — 0.0012 in) | | |
| | | | | Limit | 0.040 mm (0.0016 in) | | |
| #4 | | | STD | 0.012 — 0.033 mm (0.0005 — 0.0013 in) | | | |
| | | | Limit | 0.045 mm (0.0018 in) | | | |
| #5 | | | STD | 0.010 — 0.031 mm (0.0004 — 0.0012 in) | | | |
| | | | Limit | 0.040 mm (0.0016 in) | | | |
| Crankshaft bearing | | | Crankshaft bearing thickness | | #1, #3 | STD | 1.998 — 2.011 mm (0.0787 — 0.0792 in) |
| | | | | | | 0.03 mm (0.0012 in) US | 2.017 — 2.020 mm (0.0794 — 0.0795 in) |
| | 0.05 mm (0.0020 in) US | 2.027 — 2.030 mm (0.0798 — 0.0799 in) | | | | | |
| | 0.25 mm (0.0098 in) US | 2.127 — 2.130 mm (0.0837 — 0.0839 in) | | | | | |
| | #2, #4, #5 | STD | | | 2.000 — 2.013 mm (0.0787 — 0.0793 in) | | |
| | | 0.03 mm (0.0012 in) US | | | 2.019 — 2.022 mm (0.0795 — 0.0796 in) | | |
| | | 0.05 mm (0.0020 in) US | | | 2.029 — 2.032 mm (0.0799 — 0.0800 in) | | |
| | | 0.25 mm (0.0098 in) US | | | 2.129 — 2.132 mm (0.0838 — 0.0839 in) | | |

GENERAL DESCRIPTION

MECHANICAL

B: COMPONENT

1. TIMING BELT



ME-00376

- | | |
|--|--|
| (1) Belt cover No. 2 (RH) | (9) Automatic belt tensioner ASSY |
| (2) Timing belt guide (MT vehicles only) | (10) Belt idler No. 2 |
| (3) Crankshaft sprocket | (11) Camshaft sprocket No. 2 |
| (4) Belt cover No. 2 (LH) | (12) Timing belt |
| (5) Camshaft sprocket No. 1 | (13) Front belt cover |
| (6) Belt idler (No. 1) | (14) Belt cover (LH) |
| (7) Tensioner bracket | (15) Crankshaft pulley (2000 cc model) |
| (8) Belt idler (No. 2) | (16) Crankshaft pulley (2500 cc model) |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 5 (0.5, 3.6)

T2: 10 (1.0, 7.2)


T3: 25 (2.5, 18.1)

T4: 39 (4.0, 28.9)

T5: 78 (8.0, 57.9)

T6: <Ref. to ME(SOHC)-43, INSTALLATION, Crankshaft Pulley.>

2. CYLINDER HEAD AND CAMSHAFT



- | | |
|-------------------------------|-------------------------|
| (1) Rocker cover (RH) | (11) Cylinder head (LH) |
| (2) Intake valve rocker ASSY | (12) Camshaft (LH) |
| (3) Exhaust valve rocker ASSY | (13) Camshaft cap (LH) |
| (4) Camshaft cap (RH) | (14) Oil filler cap |
| (5) Oil seal | (15) Gasket |
| (6) Camshaft (RH) | (16) Oil filler duct |
| (7) Plug | (17) O-ring |
| (8) Spark plug pipe gasket | (18) Rocker cover (LH) |
| (9) Cylinder head (RH) | (19) Stud bolt |
| (10) Cylinder head gasket | |

Tightening torque: N-m (kgf-m, ft-lb)

T1: <Ref. to ME(SOHC)-60, INSTALLATION, Cylinder Head Assembly.>

T2: 5 (0.5, 3.6)

T3: 10 (1.0, 7.2)

T4: 18 (1.8, 13.0)


T5: 25 (2.5, 18.1)

T6: 6.4 (0.65, 4.7)

GENERAL DESCRIPTION

MECHANICAL

3. VALVE ROCKER ASSEMBLY



ME-00187

- | | |
|-------------------------------|------------------------------|
| (1) Intake valve rocker arm | (5) Rocker shaft support |
| (2) Valve rocker nut | (6) Intake rocker shaft |
| (3) Valve rocker adjust screw | (7) Exhaust rocker shaft |
| (4) Spring | (8) Exhaust valve rocker arm |


Tightening torque: N-m (kgf-m, ft-lb)

T1: 5 (0.5, 3.6)

T2: 10 (1.0, 7.2)

T3: 25 (2.5, 18.1)

4. CYLINDER HEAD AND VALVE ASSEMBLY



ME-00188

- (1) Exhaust valve
- (2) Intake valve
- (3) Valve guide


- (4) Valve spring seat
- (5) Intake valve oil seal
- (6) Valve spring

- (7) Retainer
- (8) Retainer key
- (9) Exhaust valve oil seal

GENERAL DESCRIPTION

MECHANICAL

5. CYLINDER BLOCK



ME-00377

- | | |
|--------------------------|----------------------------|
| (1) Oil pressure switch | (14) Baffle plate |
| (2) Cylinder block (RH) | (15) Oil filter connector |
| (3) Service hole plug | (16) Oil strainer |
| (4) Gasket | (17) Gasket |
| (5) Oil separator cover | (18) Oil pan |
| (6) Water by-pass pipe | (19) Drain plug |
| (7) Oil pump | (20) Metal gasket |
| (8) Front oil seal | (21) Oil level gauge guide |
| (9) Rear oil seal | (22) Water pump sealing |
| (10) O-ring | (23) Oil filter |
| (11) Service hole cover | (24) Gasket |
| (12) Cylinder block (LH) | (25) Water pump hose |
| (13) Water pump | (26) Plug |

Tightening torque: N-m (kgf-m, ft-lb)

T1: 5 (0.5, 3.6)

T2: 6.4 (0.65, 4.7)

T3: 10 (1.0, 7.2)

T4: 25 (2.5, 18.1)

**T5: <Ref. to ME(SOHC)-72,
INSTALLATION, Cylinder
Block.>**

T6: 70 (7.1, 50.6)

**T7: First 12 (1.2, 8.7)
Second 12 (1.2, 8.7)**

T8: 45 (4.6, 33.3)

T9: 44 (4.5, 33)

T10: 25 (2.5, 18.1)

ME(SOHC)-10

GENERAL DESCRIPTION

MECHANICAL


- | | | |
|--------------------------------------|--------------------------------|--------------------------------|
| (1) Flywheel (MT vehicles only) | (9) Circlip | (17) Crankshaft bearing #2, #4 |
| (2) Reinforcement (AT vehicles only) | (10) Connecting rod bolt | (18) Crankshaft bearing #5 |
| (3) Drive plate (AT vehicles only) | (11) Connecting rod | |
| (4) Top ring | (12) Connecting rod bearing | |
| (5) Second ring | (13) Connecting rod cap | |
| (6) Oil ring | (14) Crankshaft | |
| (7) Piston | (15) Woodruff key | |
| (8) Piston pin | (16) Crankshaft bearing #1, #3 | |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 45 (4.6, 33.3)

T2: 72 (7.3, 52.8)

7. ENGINE MOUNTING



ME-00413

(1) Front cushion rubber

(2) Front engine mounting bracket

Tightening torque: N-m (kgf-m, ft-lb)

T1: 35 (3.6, 25.8)

T2: 42 (4.3, 31.0)

T3: 85 (8.7, 63)

GENERAL DESCRIPTION

MECHANICAL



C: CAUTION

- Wear working clothing, including a cap, protective goggles, and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust or dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly, and replacement.
- Be careful not to burn your hands, because each part in the vehicle is hot after running.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or safety stands at the specified points.
- Before disconnecting electrical connectors of sensors or units, be sure to disconnect the ground cable from battery.
- All parts should be thoroughly cleaned, paying special attention to the engine oil passages, pistons and bearings.

- Rotating parts and sliding parts such as piston, bearing and gear should be coated with oil prior to assembly.
- Be careful not to let oil, grease or coolant contact the timing belt, clutch disc and flywheel.
- All removed parts, if to be reused, should be re-installed in the original positions and directions.
- Bolts, nuts and washers should be replaced with new ones as required.
- Even if necessary inspections have been made in advance, proceed with assembly work while making rechecks.
- Remove or install engine in an area where chain hoists, lifting devices, etc. are available for ready use.
- Be sure not to damage coated surfaces of body panels with tools or stain seats and windows with coolant or oil. Place a cover over fenders, as required, for protection.
- Prior to starting work, prepare the following:
Service tools, clean cloth, containers to catch coolant and oil, wire ropes, chain hoist, transmission jacks, etc.
- Lift-up or lower the vehicle when necessary. Make sure to support the correct positions.





D: PREPARATION TOOL

1. SPECIAL TOOLS

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|------------------------------------|--------------------------|---|
|  <p>ST18231AA010</p> | 18231AA010 | CAMSHAFT SPROCKET WRENCH | <ul style="list-style-type: none"> • Used for removing and installing camshaft sprocket. (LH side) • Also the CAMSHAFT SPROCKET WRENCH (499207100) can be used. |
|  <p>ST24082AA210</p> | 24082AA210 (Newly adopted tool) | CARTRIDGE | Troubleshooting for electrical systems. |





GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|---|--------------------------------|---|
|  <p style="text-align: center;">ST22771AA030</p> | <p style="text-align: center;">22771AA030</p> | <p>SELECT MONI-TOR KIT</p> | <p>Troubleshooting for electrical systems.</p> <ul style="list-style-type: none"> • English: 22771AA030 (Without printer) • German: 22771AA070 (Without printer) • French: 22771AA080 (Without printer) • Spanish: 22771AA090 (Without printer) |
|  <p style="text-align: center;">ST-498267800</p> | <p style="text-align: center;">498267800</p> | <p>CYLINDER HEAD TABLE</p> | <ul style="list-style-type: none"> • Used for replacing valve guides. • Used for removing and installing valve springs. |
|  <p style="text-align: center;">ST-498277200</p> | <p style="text-align: center;">498277200</p> | <p>STOPPER SET</p> | <p>Used for installing automatic transmission assembly to engine.</p> |
|  <p style="text-align: center;">ST-498457000</p> | <p style="text-align: center;">498457000</p> | <p>ENGINE STAND ADAPTER RH</p> | <p>Used with ENGINE STAND (499817000).</p> |





GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|------------------------------|-------------------------|---|
|  <p style="text-align: center;">ST-498457100</p> | 498457100 | ENGINE STAND ADAPTER LH | Used with ENGINE STAND (499817000). |
|  <p style="text-align: center;">ST-498497100</p> | 498497100 | CRANKSHAFT STOPPER | Used for stopping rotation of flywheel when loosening and tightening crankshaft pulley bolt, etc. |
|  <p style="text-align: center;">ST-498547000</p> | 498547000 | OIL FILTER WRENCH | Used for removing and installing oil filter. |
|  <p style="text-align: center;">ST-398744300</p> | 398744300 (2000 cc model) | PISTON GUIDE | Used for installing piston in cylinder. |





GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|--|---|--|
|  <p style="text-align: center;">ST-498747300</p> | <p style="text-align: center;">498747300 (2500 cc model)</p> | <p style="text-align: center;">PISTON GUIDE</p> | <p>Used for installing piston in cylinder.</p> |
|  <p style="text-align: center;">ST-498857100</p> | <p style="text-align: center;">498857100</p> | <p style="text-align: center;">VALVE OIL SEAL GUIDE</p> | <p>Used for press-fitting of intake and exhaust valve guide oil seals.</p> |
|  <p style="text-align: center;">ST-499017100</p> | <p style="text-align: center;">499017100</p> | <p style="text-align: center;">PISTON PIN GUIDE</p> | <p>Used for installing piston pin, piston and connecting rod.</p> |
|  <p style="text-align: center;">ST-499037100</p> | <p style="text-align: center;">499037100</p> | <p style="text-align: center;">CONNECTING ROD BUSHING REMOVER & INSTALLER</p> | <p>Used for removing and installing connecting rod bushing.</p> |





GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|-------------|-------------------------------|--|
|  <p style="text-align: center;">ST-499057000</p> | 499057000 | TORX PLUS | Used for removing flywheel (Dual mass flywheel). |
|  <p style="text-align: center;">ST-499587200</p> | 499587200 | CRANKSHAFT OIL SEAL INSTALLER | <ul style="list-style-type: none"> • Used for installing crankshaft oil seal. • Used with CRANKSHAFT OIL SEAL GUIDE (499597100). |
|  <p style="text-align: center;">ST-499587500</p> | 499587500 | OIL SEAL INSTALLER | Used for installing camshaft oil seal. |
|  <p style="text-align: center;">ST-499587700</p> | 499587700 | CAMSHAFT OIL SEAL INSTALLER | Used for installing cylinder head plug. |





GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|-------------|--------------------------------|---|
|  <p style="text-align: center;">ST-499097700</p> | 499097700 | PISTON PIN REMOVER ASSY | Used for removing piston pin. |
|  <p style="text-align: center;">ST-499207400</p> | 499207400 | CAMSHAFT SPROCKET WRENCH | Used for removing and installing camshaft sprocket. (RH side) |
|  <p style="text-align: center;">ST-499497000</p> | 499497000 | TORX PLUS | Used for removing and installing camshaft cap. |
|  <p style="text-align: center;">ST-499587100</p> | 499587100 | OIL SEAL INSTALLER | Used for installing oil pump oil seal. |





GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|-------------|---------------------------|--|
|  <p style="text-align: center;">ST-499597000</p> | 499597000 | OIL SEAL GUIDE | <ul style="list-style-type: none"> • Used for installing camshaft oil seal. • Used with CAMSHAFT OIL SEAL INSTALLER (499587500). |
|  <p style="text-align: center;">ST-499597100</p> | 499597100 | CRANKSHAFT OIL SEAL GUIDE | <ul style="list-style-type: none"> • Used for installing crankshaft oil seal. • Used with CRANKSHAFT OIL SEAL INSTALLER (499587200). |
|  <p style="text-align: center;">ST-499718000</p> | 499718000 | VALVE SPRING REMOVER | Used for removing and installing valve spring. |
|  <p style="text-align: center;">ST-499767200</p> | 499767200 | VALVE GUIDE REMOVER | Used for removing valve guides. |



GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|---|-----------------------------|--|
|  <p style="text-align: center;">ST-499767400</p> | <p style="text-align: center;">499767400</p> | <p>VALVE GUIDE REAMER</p> | <p>Used for reaming valve guides.</p> |
|  <p style="text-align: center;">ST-499767700</p> | <p style="text-align: center;">499767700 (Intake side) 499767800 (Exhaust side)</p> | <p>VALVE GUIDE ADJUSTER</p> | <p>Used for installing valve guides.</p> |
|  <p style="text-align: center;">ST-499817100</p> | <p style="text-align: center;">499817100</p> | <p>ENGINE STAND</p> | <ul style="list-style-type: none"> • Stand used for engine disassembly and assembly. • Used with ENGINE STAND ADAPTER RH (498457000) & LH (498457100). |
|  <p style="text-align: center;">ST-499977100</p> | <p style="text-align: center;">499977100</p> | <p>CRANK PULLEY WRENCH</p> | <p>Used for stopping rotation of crankshaft pulley when loosening and tightening crankshaft pulley bolts. (2500 cc model)</p> |

GENERAL DESCRIPTION

MECHANICAL

| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|-------------|---------------------|--|
|  ST-499977400 | 499977400 | CRANK PULLEY WRENCH | Used for stopping rotation of crankshaft pulley when loosening and tightening crankshaft pulley bolts. (2000 cc model) |
|  ST-499987500 | 499987500 | CRANKSHAFT SOCKET | Used for rotating crankshaft. |

2. GENERAL PURPOSE TOOLS

| TOOL NAME | REMARKS |
|-------------------------------------|-------------------------------------|
| Compression Gauge | Used for measuring compression. |
| Tachometer (Secondary pick-up type) | Used for measuring idle speed. |
| Timing Light | Used for measuring ignition timing. |

E: PROCEDURE

It is possible to conduct the following service procedures with engine on the vehicle, however, the procedures described in this section are based on the condition that the engine is removed from the vehicle.

- V-belt
- Timing Belt
- Valve Rocker Assembly
- Camshaft
- Cylinder Head

2. Compression

A: INSPECTION

CAUTION:


After warming-up, engine becomes very hot. Be careful not to burn yourself during measurement.

- 1) After warming-up the engine, turn the ignition switch to OFF.
- 2) Make sure that the battery is fully charged.
- 3) Lower the fuel pressure. <Ref. to FU(SOHC)-49, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 4) Remove all the spark plugs. <Ref. to IG(SOHC)-5, REMOVAL, Spark Plug.>
- 5) Fully open the throttle valve.
- 6) Check the starter motor for satisfactory performance and operation.
- 7) Hold the compression gauge tight against spark plug hole.

NOTE:

When using a screw-in type compression gauge, the screw (put into cylinder head spark plug hole) should be less than 18 mm (0.71 in) long.

- 8) Crank the engine by means of starter motor, and then read the maximum value on the gauge when the pointer is steady.



- 9) Perform at least two measurements per cylinder, and make sure that the values are correct.

Compression (350 rpm and fully open throttle):

Standard;

1,275 kPa (13.0 kgf/cm², 185 psi)

Limit;

1,020 kPa (10.4 kgf/cm², 148 psi)

Difference between cylinders;


49 kPa (0.5 kgf/cm², 7 psi), or less

3. Idle Speed

A: INSPECTION

- 1) Before checking idle speed, check the following:
 - (1) Ensure the air cleaner element is free from clogging, ignition timing is correct, spark plugs are in good condition, and the hoses are connected properly.
 - (2) Ensure the malfunction indicator light (CHECK ENGINE light) does not illuminate.
- 2) Warm-up the engine.
- 3) Stop the engine, and then turn the ignition switch to OFF.
- 4) When using the SUBARU SELECT MONITOR, refer to the following. <Ref. to ME(SOHC)-14, SPECIAL TOOLS, PREPARATION TOOL, General Description.>


- (1) Insert the cartridge to SUBARU SELECT MONITOR.
- (2) Connect the SUBARU SELECT MONITOR to data link connector.



- (3) Turn the ignition switch to ON, and SUBARU SELECT MONITOR switch to ON.
- (4) Select the {2. Each System Check} in Main Menu.
- (5) Select the {Engine Control System} in Selection Menu.
- (6) Select the {1. Current Data Display & Save} in Engine Control System Diagnosis.
- (7) Select the {1.12 Data Display} in Data Display Menu.
- (8) Start the engine, and then read the engine idle speed.

- 5) When using the tachometer (Secondary pick-up type).

- (1) Attach the pick-up clip to No. 1 cylinder spark plug cord.
- (2) Start the engine, and then read the engine idle speed.



NOTE:

- When using the OBD-II general scan tool, carefully read its operation manual.
- This ignition system provides simultaneous ignition for #1 and #2 plugs. It must be noted that some tachometers may register twice that of actual engine speed.

- 6) Check the idle speed when unloaded. (With headlights, heater fan, rear defroster, radiator fan, air conditioning, etc. OFF)

Idle speed (No load and gears in neutral (MT vehicles), or N or P (AT vehicles) position):

- 650±100 rpm (MT vehicles)**
- 700±100 rpm (AT vehicles)**

- 7) Check the idle speed when loaded. (Turn the air conditioning switch to "ON" and operate the compressor for at least 1 minute before measurement.)

Idle speed [A/C "ON", no load and gears in neutral (MT vehicles) or N or P (AT vehicles) position]:

- 850±100 rpm**

NOTE:

Idle speed can not be adjusted manually, because the idle speed is automatically adjusted. If the specified idle speed can not be maintained, refer to General On-board Diagnosis Table under "Engine Control System". <Ref. to EN(SOHC)-2, Basic Diagnostic Procedure.>

4. Ignition Timing

A: INSPECTION

CAUTION:


After warming-up, engine becomes very hot. Be careful not to burn yourself during measurement.

- 1) Warm-up the engine.
- 2) To check the ignition timing, connect a timing light to #1 cylinder spark plug cord, and illuminate the timing mark with timing light.
- 3) Start the engine at idle speed and check the ignition timing.

Ignition timing [BTDC/rpm]:

$10^{\circ}\pm 8^{\circ}/650$ (MT vehicles)

$15^{\circ}\pm 8^{\circ}/700$ (AT vehicles)



If the timing is not correct, check the ignition control system.

Refer to Engine Control System. <Ref. to EN(SOHC)-2, Basic Diagnostic Procedure.>

INTAKE MANIFOLD VACUUM


MECHANICAL

5. Intake Manifold Vacuum

A: INSPECTION

- 1) Warm-up the engine.
- 2) Disconnect the brake vacuum hose, and then install the vacuum gauge to hose fitting on manifold.
- 3) Keep the engine at idle speed, and then read the vacuum gauge indication.

By observing the gauge needle movement, the internal condition of engine can be diagnosed as described below.




Vacuum pressure (at idling, A/C "OFF"):
Less than -60.0 kPa (-450 mmHg, -17.72 in-Hg)

| Diagnosis of engine condition by measurement of manifold vacuum | |
|---|---|
| Vacuum gauge indication | Possible engine condition |
| 1. Needle is steady but lower than normal position. This tendency becomes more evident as engine temperature rises. | Leakage around intake manifold gasket or disconnection or damaged vacuum hose |
| 2. When engine speed is reduced slowly from higher speed, needle stops temporarily when it is lowering or becomes steady above normal position. | Back pressure too high, or exhaust system clogged |
| 3. Needle intermittently drops to position lower than normal position. | Leakage around cylinder |
| 4. Needle drops suddenly and intermittently from normal position. | Sticky valves |
| 5. When engine speed is gradually increased, needle begins to vibrate rapidly at certain speed, and then vibration increases as engine speed increases. | Weak or broken valve springs |
| 6. Needle vibrates above and below normal position in narrow range. | Defective ignition system |

6. Engine Oil Pressure

A: INSPECTION

1) Disconnect the ground cable from battery.




2) Remove the generator from bracket. <Ref. to SC(SOHC)-15, REMOVAL, Generator.>

3) Disconnect the connector from oil pressure switch.


4) Remove the oil pressure switch from engine cylinder block. <Ref. to LU(SOHC)-21, REMOVAL, Oil Pressure Switch.>

5) Connect the oil pressure gauge hose to cylinder block.

6) Connect the battery ground cable to battery.



7) Start the engine, and then measure the oil pressure.



Oil pressure:

88 kPa (0.9 kg/cm², 13 psi) or more at 800 rpm
294 kPa (3.0 kg/cm², 43 psi) or more at 5,000 rpm

CAUTION:

- If the oil pressure is out of specification, check the oil pump, oil filter and lubrication line. <Ref. to LU(SOHC)-25, INSPECTION, Engine Lubrication System Trouble in General.>
- If the oil pressure warning light is turned ON and oil pressure is in specification, replace the oil pressure switch. <Ref. to LU(SOHC)-25, INSPECTION, Engine Lubrication System Trouble in General.>

NOTE:

The specified data is based on an engine oil temperature of 80°C (176°F).

8) After measuring the oil pressure, install the oil pressure switch. <Ref. to LU(SOHC)-21, INSTALLATION, Oil Pressure Switch.>

Tightening torque:

25 N·m (2.5 kgf-m, 18.1 ft-lb)

9) Install the generator and V-belt in the reverse order of removal, and then adjust the V-belt deflection. <Ref. to ME(SOHC)-41, INSTALLATION, V-belt.>

FUEL PRESSURE

MECHANICAL

7. Fuel Pressure

A: INSPECTION

WARNING:

Before removing the fuel pressure gauge, lower the fuel pressure.


NOTE:

If out of specification, check or replace the pressure regulator and pressure regulator vacuum hose.


1) Lower the fuel pressure. <Ref. to FU(SOHC)-49, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>

2) Open the fuel flap lid, and then remove the fuel filler cap.

3) Disconnect the fuel delivery hoses from fuel damper, and then connect the fuel pressure gauge.



4) Connect the connector of fuel pump relay.




5) Start the engine.

6) Measure the fuel pressure while disconnecting the pressure regulator vacuum hose from intake manifold.

Fuel pressure:


Standard; 284 — 314 kPa (2.9 — 3.2 kg/cm², 41 — 46 psi)



7) After connecting the pressure regulator vacuum hose, measure the fuel pressure.

Fuel pressure:

Standard; 206 — 235 kPa (2.1 — 2.4 kg/cm², 30 — 34 psi)



NOTE:

The fuel pressure gauge registers 10 to 20 kPa (0.1 to 0.2 kg/cm², 1 to 3 psi) higher than standard values during high-altitude operations.


8. Valve Clearance

A: INSPECTION


NOTE:

Inspection and adjustment of the valve clearance should be performed while engine is cold.

- 1) Set the vehicle on a lift.
- 2) Lift-up the vehicle.
- 3) Remove the under cover.
- 4) Lower the vehicle.
- 5) Disconnect the ground cable from battery.



- 6) Remove the belt cover (LH).




- 7) When inspecting the #1 and #3 cylinders;
 - (1) Disconnect the spark plug cords from spark plugs RH side. <Ref. to IG(SOHC)-5, RH SIDE, REMOVAL, Spark Plug.>
 - (2) Disconnect the PCV hose from rocker cover (RH).
 - (3) Remove the bolts, and then remove the rocker cover (RH).
- 8) When inspecting the #2 and #4 cylinders;
 - (1) Disconnect the spark plug cords from spark plugs (LH Side) <Ref. to IG(SOHC)-5, LH SIDE, REMOVAL, Spark Plug.>
 - (2) Disconnect the PCV hose from rocker cover (LH).
 - (3) Remove the bolts, and then remove the rocker cover (LH).

- 9) Set the #1 cylinder piston to top dead center of compression stroke by rotating crankshaft pulley clockwise using a socket wrench.

NOTE:

When arrow mark (A) on the camshaft sprocket (LH) comes exactly to the top, #1 cylinder piston is brought to the top dead center of compression stroke.



- 10) Measure the #1 cylinder valve clearance by using thickness gauge.

CAUTION:

- Insert the thickness gauge (A) in as horizontal a direction as possible with respect to the valve stem end face.
- Measure the exhaust valve clearances while lifting-up the vehicle.


Valve clearance:

Intake;

0.20±0.02 mm (0.0079±0.0008 in)

Exhaust;

0.25±0.02 mm (0.0098±0.0008 in)



- 11) If necessary, adjust the valve clearance. <Ref. to ME(SOHC)-30, ADJUSTMENT, Valve Clearance.>


VALVE CLEARANCE

MECHANICAL

12) Similar to measurement procedures used for #1 cylinder, measure the #2, #3 and #4 cylinder valve clearances.

NOTE:

- Be sure to set the cylinder pistons to their respective top dead centers on compression stroke before measuring valve clearances.
- To set the #3, #2 and #4 cylinder pistons to their top dead centers on compression stroke, turn the crankshaft pulley clockwise 90° at a time starting with arrow mark on camshaft sprocket (LH) facing up.




13) After inspection, install the related parts in the reverse order of removal.

Resonator chamber:

Air cleaner case;

33 N·m (3.4 kgf·m, 25 ft·lb)



B: ADJUSTMENT


NOTE:

Adjustment of the valve clearance should be performed while engine is cold.

1) Set the #1 cylinder piston to top dead center of compression stroke by rotating crankshaft pulley clockwise using socket wrench.

NOTE:

When arrow mark (A) on the camshaft sprocket (LH) comes exactly to the top, #1 cylinder piston is brought to the top dead center of compression stroke.



2) Adjust the #1 cylinder valve clearance.

- (1) Loosen the valve rocker nut and screw.
- (2) Place suitable thickness gauge.
- (3) While noting the valve clearance, tighten the valve rocker adjust screw.
- (4) When specified valve clearance is obtained, tighten the valve rocker nut.

Tightening torque:

10 N·m (1.0 kgf·m, 7.2 ft·lb)

CAUTION:

- Insert the thickness gauge in as horizontal a direction as possible with respect to the valve stem end face.
- Adjust the exhaust valve clearances while lifting up the vehicle.


Valve clearance:

Intake;

0.20 ± 0.02 mm (0.0079 ± 0.0008 in)

Exhaust;


0.25 ± 0.02 mm (0.0098 ± 0.0008 in)



- 3) Ensure the valve clearances are within specifications.
- 4) Turn the crankshaft two complete rotations until #1 cylinder piston is again set to the top dead center on compression stroke.
- 5) Ensure the valve clearances are within specifications. If necessary, readjust the valve clearances.
- 6) Similar to adjustment procedures used for #1 cylinder, adjust the #2, #3 and #4 cylinder valve clearances.

NOTE:

- Be sure to set the cylinder pistons to their respective top dead centers on compression stroke before adjusting valve clearances.
- To set the #3, #2 and #4 cylinder pistons to their top dead centers on compression stroke, turn the crankshaft pulley clockwise 90° at a time starting with arrow mark on camshaft sprocket (LH) facing up.




ENGINE ASSEMBLY

MECHANICAL

9. Engine Assembly


A: REMOVAL

- 1) Set the vehicle on lift arms.
- 2) Open the front hood fully, and then support with the hood stay.
- 3) Lower the fuel pressure. <Ref. to FU(SOHC)-49, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 4) Disconnect the A/C pressure hoses from A/C compressor.
- 5) Remove the fuel filler cap.
- 6) Disconnect the ground cable from battery.




- 7) Remove the air intake duct and air cleaner case. <Ref. to IN(SOHC)-7, REMOVAL, Air Intake Duct.> and <Ref. to IN(SOHC)-6, REMOVAL, Air Cleaner Case.>
- 8) Remove the under cover.
- 9) Remove the radiator from vehicle. <Ref. to CO(SOHC)-27, REMOVAL, Radiator.>
- 10) Remove the air cleaner case stay.

• MT VEHICLES




• AT VEHICLES




- 11) Disconnect the following connectors and cables.


(1) Front oxygen (A/F) sensor connector




(2) Rear oxygen sensor connector



(3) Engine ground cable




(4) Engine harness connectors



ME-00207


(5) Generator connector, terminal and A/C compressor connector



ME-00208


- (A) Generator connector and terminal
- (B) A/C compressor connector

(6) Accelerator cable (A) and cruise control cable (B)



ME-00328


(7) Pressure switch



FU-00017


12) Disconnect the following hoses.

(1) Brake booster vacuum hose



ME-00329

(2) Heater inlet outlet hose



ME-00330


13) Remove the power steering pump from bracket.

- (1) Remove the resonator chamber.
- (2) Loosen the lock bolt and slider bolt, and then remove the front side V-belt.<Ref. to ME(SOHC)-41, FRONT SIDE BELT, REMOVAL, V-belt.>


ENGINE ASSEMBLY

MECHANICAL


(3) Remove the pipe with bracket.




(4) Remove the bolts which install power steering pump bracket.




(5) Remove the power steering tank from bracket by pulling it upward.




(6) Place the power steering pump on right side wheel apron.



15) Remove the nuts which hold lower side of transmission to engine.




16) Remove the nuts which install front cushion rubber onto front crossmember.




17) Separate the torque converter clutch from drive plate. (AT vehicles)

- (1) Lower the vehicle.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold torque converter clutch to drive plate.
- (4) Remove other bolts while rotating the engine using socket wrench.



14) Remove the front and center exhaust pipe.
<Ref. to EX(SOHC)-7, REMOVAL, Front Exhaust Pipe.>


18) Remove the pitching stopper.




19) Disconnect the fuel delivery hose (A), return hose (B) and evaporation hose (C).

CAUTION:

- Disconnect the hose with its end wrapped with cloth to prevent fuel from splashing.
- Catch fuel from the hose into container.



20) Support the engine with a lifting device and wire ropes.




21) Support the transmission with a garage jack.

CAUTION:

Before moving the engine away from transmission, check to be sure no work has been overlooked. Doing this is very important in order to


facilitate re-installation and because the transmission lowers under its own weight.



- (A) Transmission
- (B) Garage jack


22) Separation of the engine and transmission.

- (1) Remove the starter. <Ref. to SC(SOHC)-6, REMOVAL, Starter.>
- (2) Remove the bolts which hold upper side of transmission to engine.



23) Install the ST to torque converter clutch case. (AT vehicles)

ST 498277200 STOPPER SET



24) Remove the engine from vehicle.

- (1) Slightly raise the engine.
- (2) Raise the transmission with garage jack.
- (3) Move the engine horizontally until main shaft is withdrawn from clutch cover.


ENGINE ASSEMBLY

MECHANICAL

- (4) Slowly move the engine away from engine compartment.

NOTE:

Be careful not to damage the adjacent parts or body panels with crank pulley, oil level gauge, etc.



- 25) Remove the front cushion rubbers.

B: INSTALLATION

- 1) Install the front cushion rubbers.


Tightening torque:

34 N·m (3.5 kgf-m, 25.3 ft-lb)

- 2) Install the engine onto transmission.
 - (1) Position the engine in engine compartment and align it with transmission.

NOTE:

Be careful not to damage the adjacent parts or body panels with crank pulley, oil level gauge, etc.




- (2) Apply a small amount of grease to the spline of main shaft. (MT vehicles)


- 3) Tighten the bolts which hold upper side of transmission to engine.

Tightening torque:

50 N·m (5.1 kgf-m, 36.9 ft-lb)



- 4) Remove the lifting device and wire ropes.




- 5) Remove the garage jack.
- 6) Install the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 37 ft-lb)

T2: 58 N·m (5.9 kgf-m, 43 ft-lb)



- 7) Remove the ST from torque converter clutch case. (AT vehicles)

NOTE:

Be careful not to drop the ST into torque converter clutch case when removing ST.

ST 498277200 STOPPER SET

- 8) Install the starter. <Ref. to SC(SOHC)-6, INSTALLATION, Starter.>

- 9) Install the torque converter clutch onto drive plate. (AT vehicles)


- (1) Tighten the bolts which hold torque converter clutch to drive plate.
- (2) Tighten other bolts while rotating the engine by using a socket wrench.

NOTE:


Be careful not to drop the bolts into torque converter clutch housing.

Tightening torque:


25 N·m (2.5 kgf-m, 18.1 ft-lb)




- (3) Tighten the bolts which install power steering pump bracket, and then install the spark plug cords.



- (3) Clog the plug onto service hole.
- 10) Install the power steering pump on bracket.
- (1) Install the power steering tank on bracket.



- (4) Connect the power steering switch connector.





- (5) Install the front side V-belt, and adjust it. <Ref. to ME(SOHC)-41, FRONT SIDE BELT, INSTALLATION, V-belt.>
- (6) Install the resonator chamber.

Tightening torque:

33 N·m (3.4 kgf-m, 24.6 ft-lb)

Tightening torque:

20.1 N·m (2.05 kgf-m, 14.8 ft-lb)




ENGINE ASSEMBLY

MECHANICAL

11) Tighten the nuts which hold lower side of transmission to engine.

Tightening torque:

50 N·m (5.1 kgf·m, 36.9 ft·lb)




12) Tighten the nuts which install front cushion rubber onto crossmember.

Tightening torque:

85 N·m (8.7 kgf·m, 63 ft·lb)

NOTE:

Make sure the front cushion rubber mounting bolts (A) and locator (B) are securely installed.



13) Install the front and center exhaust pipe. <Ref. to EX(SOHC)-8, INSTALLATION, Front Exhaust Pipe.>

14) Connect the following hoses.

- (1) Fuel delivery hose, return hose and evaporation hose
- (2) Heater inlet and outlet hoses
- (3) Brake booster vacuum hose

15) Connect the following connectors.

- (1) Engine ground cables

Tightening torque:

14 N·m (1.4 kgf·m, 10.1 ft·lb)

- (2) Engine harness connectors
 - (3) Generator connector and terminal
 - (4) A/C compressor connectors
 - (5) Power steering pressure switch
- 16) Connect the following cables.
- (1) Accelerator cable
 - (2) Cruise control cable (With cruise control)
- 17) Adjust each connected cable.

18) Install the air cleaner case stay.

Tightening torque:

16 N·m (1.6 kgf·m, 11.6 ft·lb)

19) Install the A/C pressure hoses. <Ref. to AC-43, INSTALLATION, Hose and Tube.>

20) Install the radiator to vehicle. <Ref. to CO(SOHC)-29, INSTALLATION, Radiator.>

21) Install the air intake duct and air cleaner case. <Ref. to IN(SOHC)-7, REMOVAL, Air Intake Duct.> and <Ref. to IN(SOHC)-6, INSTALLATION, Air Cleaner Case.>

22) Install the under cover.

23) Install battery in the vehicle, and then connect the cables.

24) Fill engine coolant. <Ref. to CO(SOHC)-18, FILLING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>

25) Check the ATF level and correct if necessary. (AT vehicles) <Ref. to AT-29, INSPECTION, Automatic Transmission Fluid.>

26) Charge the A/C system with refrigerant. <Ref. to AC-27, OPERATION, Refrigerant Charging Procedure.>

27) Remove the front hood stay, and then close the front hood.

28) Take off the vehicle from lift arms.

C: INSPECTION

1) Make sure the pipes and hoses are installed correctly.

2) Make sure the engine coolant and ATF are at specified levels.

10.Engine Mounting

A: REMOVAL

- 1) Remove the engine assembly. <Ref. to ME(SOHC)-32, REMOVAL, Engine Assembly.>
- 2) Remove the engine mounting from engine assembly.

B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

Engine mounting;

34 N·m (3.5 kgf-m, 25.3 ft-lb)

C: INSPECTION


Make sure there are no cracks or other damage.

11.Preparation for Overhaul

A: PROCEDURE

1) After removing the engine from body, secure it in the ST shown below.

- ST1 498457000 ENGINE STAND ADAPTER
RH
- ST2 498457100 ENGINE STAND ADAPTER
LH
- ST3 499817100 ENGINE STAND



2) In this section the procedures described under each index are all connected and stated in order. It will be the complete procedure for overhauling of the engine itself when you go through all steps in the process.

Therefore, in this section, to conduct the particular procedure within the flow of a section, you need to go back and conduct the procedure described previously in order to do that particular procedure.

12.V-belt


A: REMOVAL

1. FRONT SIDE BELT


NOTE:

Perform the following procedures 1) to 4) with the engine installed to body.

- 1) Remove the V-belt cover.




- 2) Loosen the lock bolt (A).
- 3) Loosen the slider bolt (B).
- 4) Remove the front side belt (C).




2. REAR SIDE BELT

- 1) Loosen the lock nut (A).
- 2) Loosen the slider bolt (B).



- 3) Remove the A/C belt.
- 4) Remove the A/C belt tensioner.



B: INSTALLATION

1. FRONT SIDE BELT

- 1) Wipe off any oil or water on the belt and pulley.
- 2) Install the belt (C), and tighten the slider bolt so as to obtain the specified belt tension <Ref. to ME(SOHC)-42, INSPECTION, V-belt.>
- 3) Tighten the lock bolt (A)
- 4) Tighten the slider bolt (B).


Tightening torque:

Lock bolt through bolt:

25 N·m (2.5 kgf-m, 18.1 ft-lb)

Slider bolt:

8 N·m (0.8 kgf-m, 5.5 ft-lb)




2. REAR SIDE BELT

- 1) Install the belt, and tighten the slider bolt (B) so as to obtain the specified belt tension. <Ref. to ME(SOHC)-42, INSPECTION, V-belt.>
- 2) Tighten the lock nut (A).

Tightening torque:

Lock nut (A);

22.6 N·m (2.3 kgf·m, 16.6 ft·lb)



C: INSPECTION

- 1) Replace the belts, if cracks, fraying or wear is found.
- 2) Check the drive belt tension and adjust it if necessary by changing the generator installing position and/or idler pulley installing position.

Belt tension

(A)


replaced: 7 — 9 mm (0.276 — 0.354 in)

reused: 9 — 11 mm (0.354 — 0.433 in)

(B)

replaced: 7.5 — 8.5 mm (0.295 — 0.335 in)

reused: 9.0 — 10.0 mm (0.354 — 0.394 in)



- C/P Crankshaft pulley
- GEN Generator
- P/S Power steering oil pump pulley
- A/C Air conditioning compressor pulley
- I/P Idler pulley

13. Crankshaft Pulley


A: REMOVAL

1) Remove the V-belt. <Ref. to ME(SOHC)-41, REMOVAL, V-belt.>

2) Remove the crankshaft pulley bolt. To lock the crankshaft, use ST.

ST 499977400 CRANK PULLEY WRENCH
(2000 cc model)

ST 499977100 CRANK PULLEY WRENCH
(2500 cc model)



3) Remove the crankshaft pulley.

B: INSTALLATION

1. 2000 CC MODEL

1) Install the crankshaft pulley.

2) Install the pulley bolt.

To lock the crankshaft, use ST.

ST 499977400 CRANK PULLEY WRENCH

(1) Clean the crankshaft pulley thread using an air gun.


(2) Apply engine oil to the crankshaft pulley bolt seat and thread.

(3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf·m, 33 ft·lb).

(4) Tighten the crankshaft pulley bolts.

Tightening torque:

127 N·m (13.0 kgf·m, 94.0 ft·lb)



3) Confirm that the tightening angle of crankshaft pulley bolt is 45 degrees or more. If the tightening angle of crankshaft pulley bolt is less than 45 degrees, conduct the following procedures.

(1) Replace the crankshaft pulley bolts and clean them.

Crankshaft pulley bolt:

12369AA011

(2) Clean the crankshaft thread using an air gun.

(3) Apply engine oil to the crankshaft pulley bolt seal and thread.


(4) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf·m, 33 ft·lb).

(5) Tighten the crankshaft pulley bolts keeping them in an angle between 45 degrees and 60 degrees.


NOTE:

Conduct the tightening procedures by confirming the turning angle of crankshaft pulley bolt referring to the gauge indicated on belt cover.

4) Install the A/C belt tensioner.



5) Install the A/C belt.



CRANKSHAFT PULLEY

MECHANICAL

2. 2500 CC MODEL

- 1) Install the crankshaft pulley.
- 2) Install the pulley bolt.


To lock the crankshaft, use ST.

ST 499977100 CRANK PULLEY WRENCH

- (1) Clean the crankshaft pulley thread using an air gun.
- (2) Apply engine oil to the crankshaft pulley bolt seat and thread.
- (3) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf·m, 33 ft·lb).
- (4) Tighten the crankshaft pulley bolts.

Tightening torque:

177 N·m (18.0 kgf·m, 130.2 ft·lb)



- 3) Confirm that the tightening angle of crankshaft pulley bolt is 65 degrees or more. If the tightening angle of crankshaft pulley bolt is less than 65 degrees, conduct the following procedures.

- (1) Replace the crankshaft pulley bolts and clean them.

Crankshaft pulley bolt:


12369AA011

- (2) Clean the crankshaft thread using an air gun.
- (3) Apply engine oil to the crankshaft pulley bolt seal and thread.
- (4) Tighten the bolts temporarily with tightening torque of 44 N·m (4.5 kgf·m, 33 ft·lb).
- (5) Tighten the crankshaft pulley bolts keeping them in an angle between 65 degrees and 75 degrees.


NOTE:

Conduct the tightening procedures by confirming the turning angle of crankshaft pulley bolt referring to the gauge indicated on belt cover.

- 4) Install the A/C belt tensioner.



- 5) Install the A/C belt.




C: INSPECTION

- 1) Make sure the V-belt is not worn or otherwise damaged.
- 2) Check the tension of the belt. <Ref. to ME(SOHC)-42, INSPECTION, V-belt.>

14. Belt Cover

A: REMOVAL

- 1) Remove the V-belt. <Ref. to ME(SOHC)-41, REMOVAL, V-belt.>
- 2) Remove the crankshaft pulley. <Ref. to ME(SOHC)-43, REMOVAL, Crankshaft Pulley.>
- 3) Remove the belt cover (LH).
- 4) Remove the front belt cover.



- (A) Belt cover (LH)
- (B) Front belt cover

B: INSTALLATION

- 1) Install the front belt cover.


Tightening torque:

5 N·m (0.5 kgf·m, 3.6 ft·lb)

- 2) Install the belt cover (LH).

Tightening torque:

5 N·m (0.5 kgf·m, 3.6 ft·lb)



- (A) Belt cover (LH)
- (B) Front belt cover

- 3) Install the crankshaft pulley. <Ref. to ME(SOHC)-43, INSTALLATION, Crankshaft Pulley.>
- 4) Install the V-belt. <Ref. to ME(SOHC)-41, INSTALLATION, V-belt.>

C: INSPECTION

Make sure the cover is not damaged.