


28.ATF Filter

A: REMOVAL

- 1) Lift-up the vehicle.
 - 2) Using the ST, remove the ATF filter.
- ST 498545400 OIL FILTER WRENCH



(A) ATF filter

B: INSTALLATION

- 1) Apply a thin coat of ATF to the oil seal part of new ATF filter.
- 2) Install the ATF filter. Turn it by hand, being careful not to damage oil seal.
- 3) Tighten the ATF filter using ST.

Calculate the ATF filter tightening torque using following formula.

$$T2 = L2 / (L1 + L2) \times T1$$

T1: 14 N·m (1.4 kgf·m, 10.1 ft·lb)

[Required torque setting]

T2: Tightening torque

L1: ST length 78 mm (3.07 in)

L2: Torque wrench length

Example:

Torque wrench length mm (in)	Tightening torque N·m (kgf·m, ft·lb)
100 (3.94)	7.7 (0.79, 5.7)
150 (5.91)	9.0 (0.92, 6.7)
200 (7.87)	9.8 (1.0, 7.2)

NOTE:

Align the ST with the torque wrench while tightening the ATF filter.

ST 498545400 OIL FILTER WRENCH

- 4) Fill ATF.
- 5) Inspect the level of ATF. <Ref. to 4AT-28, Automatic Transmission Fluid.>

C: INSPECTION

- 1) Check for rust, holes, ATF leaks or other damage.
- 2) Replace the part if any damage is found in the inspection.

ATF Filter

PERIODIC MAINTENANCE SERVICES
