


10. Transmission Mounting System

A: REMOVAL

1. PITCHING STOPPER

- 1) Disconnect the ground cable from battery.
- 2) Remove the air intake chamber. (Non-turbo model)
<Ref. to IN (H4SO)-6, REMOVAL, Air Intake Chamber.>
- 3) Remove the intercooler. (Turbo model)
<Ref. to IN(H4DOTC)-11, REMOVAL, Intercooler.>
- 4) Remove the pitching stopper.




2. TRANSMISSION REAR CROSSMEMBER AND REAR CUSHION RUBBER

- 1) Disconnect the ground cable from battery.
- 2) Jack-up the vehicle and support it with rigid racks.
- 3) Remove the front, center, rear exhaust pipes and muffler. (Non-turbo model)
<Ref. to EX (H4SO)-4, REMOVAL, Front Exhaust Pipe.> <Ref. to EX (H4SO)-8, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX (H4SO)-9, REMOVAL, Muffler.>
- 4) Remove the center and rear exhaust pipe and muffler. (Turbo model)
<Ref. to EX(H4DOTC)-8, REMOVAL, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-13, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, REMOVAL, Muffler.>
- 5) Set the transmission jack under transmission.

NOTE:

Make sure that the support plate of transmission jack does not touch the oil pan.

- 6) Remove the transmission rear crossmember.



- 7) Remove the rear cushion rubber.

B: INSTALLATION


1. PITCHING STOPPER

- 1) Attach the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 37 ft-lb)

T2: 58 N·m (5.9 kgf-m, 43 ft-lb)



- 2) Install the air intake chamber. (Non-turbo model)
<Ref. to IN (H4SO)-6, INSTALLATION, Air Intake Chamber.>
- 3) Install the intercooler. (Turbo model)
<Ref. to IN(H4DOTC)-11, INSTALLATION, Intercooler.>

Transmission Mounting System

AUTOMATIC TRANSMISSION

2. TRANSMISSION REAR CROSSMEMBER AND REAR CUSHION RUBBER

1) Install the rear cushion rubber.

Tightening torque:


39 N·m (4.0 kgf·m, 29 ft-lb)

2) Install the transmission rear crossmember.

Tightening torque:

T1: 35 N·m (3.6 kgf·m, 26 ft-lb)

T2: 70 N·m (7.1 kgf·m, 51 ft-lb)



3) Remove the transmission jack.

4) Install the front, center and rear exhaust pipes, and the muffler. (Non-turbo model)

<Ref. to EX (H4SO)-5, INSTALLATION, Front Exhaust Pipe.> <Ref. to EX (H4SO)-8, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX (H4SO)-9, INSTALLATION, Muffler.>

5) Install the center, rear exhaust pipes and the muffler. (Turbo model)

<Ref. to EX(H4DOTC)-9, INSTALLATION, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-14, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, INSTALLATION, Muffler.>

C: INSPECTION

Perform the following inspection procedures and repair or replace defective parts.

1. PITCHING STOPPER

Make sure that the pitching stopper is not bent or damaged. Check that there are no cracks, hardening or damage on rubber parts.

2. TRANSMISSION REAR CROSSMEMBER AND REAR CUSHION RUBBER

Make sure that the cross member is not bent or damaged. Check the cushion rubber for cracks, hardening or damage.