

8. Diagnostics for Engine Starting Failure

A: BASIC DIAGNOSTICS CHART


1. Inspection of starter motor circuit. <Ref. to 2-7 [T8B0].>	↓
2. Inspection of ECM power supply and ground line. <Ref. to 2-7 [T8C0].>	↓
3. Inspection of ignition control system. <Ref. to 2-7 [T8D0].>	↓
4. Inspection of fuel pump circuit. <Ref. to 2-7 [T8E0].>	↓
5. Inspection of fuel injector circuit. <Ref. to 2-7 [T8F0].>	↓
6. Inspection of crankshaft position sensor circuit. <Ref. to 2-7 [T8G0].> or <Ref. to 2-7 [T8H0].>	↓
7. Inspection of camshaft position sensor circuit. <Ref. to 2-7 [T8I0].>	↓
8. Inspection using Subaru Select Monitor or OBD-II general scan tool (California spec. vehicles: <Ref. to 2-7 [T10A0].>, and except 2200 cc California spec. vehicles: <Ref. to 2-7 [T11A0].> or inspection using "9. General Diagnostics Table". <Ref. to 2-7 [T900].>	

B: STARTER MOTOR CIRCUIT

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


● **WIRING DIAGRAM:**



H2M3085

8B1 : CHECK INPUT SIGNAL FOR STARTER MOTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from starter motor.




- 3) Turn ignition switch to ST.

4) Measure power supply voltage between starter motor connector terminal and engine ground.

Connector & terminal

(B14) No. 1 (+) — Engine ground (-):



NOTE:

- On AT vehicles, place the selector lever in the “P” or “N” position.
- On MT vehicles, depress the clutch pedal.

CHECK : **Is the voltage more than 10 V?**

YES : Go to step 8B2.

NO : Go to step 8B3.

8B2 : CHECK GROUND CIRCUIT OF STARTER MOTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect terminal from starter motor.



3) Measure resistance of ground cable between ground cable terminal and engine ground.

CHECK : **Is resistance less than 5 Ω?**

YES : Check starter motor. <Ref. to 6-1 [K100].>

NO : Repair open circuit of ground cable.

8B3 : CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Remove SBF No. 4 from main fuse box.
- 3) Measure resistance of fuse.

CHECK : **Is resistance less than 1 Ω?**

YES : Replace SBF No. 4. <Ref. to 6-3 [D5A0].>


NO : Go to step 8B4.

8B4 : CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.

- 1) Install SBF No. 4 to main fuse box.
- 2) Turn ignition switch to ON.
- 3) Measure power supply voltage between ignition switch connector and chassis ground.

Connector & terminal

(B72) No. 1 (+) — Chassis ground (-):



CHECK : **Is the voltage more than 10 V?**

YES : Go to step 8B5.

NO : Repair open circuit in harness between ignition switch and SBF No. 4 connector.

8B5 : CHECK TRANSMISSION TYPE.

CHECK : **Is transmission type AT?**


YES : Go to step 8B6.

NO : Go to step 8B10.

8B6 : CHECK INHIBITOR SWITCH CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Place the selector lever in the "P" or "N" position.
- 3) Measure resistance between transmission harness connector receptacle's terminals.

Connector & terminal
(T3) No. 11 — No. 12:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Repair open circuit in harness between starter motor and ignition switch connector.
- NO** : Go to step 8B7.

8B7 : CHECK TRANSMISSION HARNESS.

- 1) Disconnect connector from inhibitor switch.
- 2) Measure resistance of harness between transmission harness and inhibitor switch connector.

Connector & terminal
(T3) No. 11 — (T7) No. 1:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8B8.
- NO** : Repair open circuit in harness between transmission harness and inhibitor switch connector.

8B8 : CHECK TRANSMISSION HARNESS.

Measure resistance of harness between transmission harness and inhibitor switch connector.

Connector & terminal
(T3) No. 12 — (T7) No. 2:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8B9.
- NO** : Repair open circuit in harness between transmission harness and inhibitor switch connector.

8B9 : CHECK POOR CONTACT.


Check poor contact in inhibitor switch connector.
 <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in inhibitor switch connector?
- YES** : Repair poor contact in inhibitor switch connector.
- NO** : Replace inhibitor switch. <Ref. to 3-2 [W2C0].>

8B10 : CHECK STARTER INTERLOCK CIRCUIT.

- 1) Turn ignition switch to "ST".
- 2) Measure voltage between clutch switch connector and chassis ground.

Connector & terminal
(B106) No. 2 (+) — Chassis ground (-):




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Replace starter interlock relay. <Ref. to 6-3 [D6D0].>
- NO** : Go to step **8B11**.

8B11 : CHECK STARTER INTERLOCK CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between clutch switch connector terminals while depressing the clutch pedal.

Connector & terminal
(B106) No. 1 — No. 2:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair open circuit in harness between starter motor and ignition switch connector.
- NO** : Replace clutch switch. <Ref. to 4-5 [C1A0].>

C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0]> and INSPECTION MODE <Ref. to 2-7 [T3E0]>.

● **WIRING DIAGRAM:**



H2M3003


8C1 : CHECK MAIN RELAY.

- 1) Turn the ignition switch to OFF.
- 2) Remove main relay.
- 3) Connect battery to main relay terminals No. 1 and No. 2.

4) Measure resistance between main relay terminals.

Terminals

No. 3 — No. 5:



H2M2268

CHECK : Is the resistance less than 10 Ω?

YES : Go to step 8C2.


NO : Replace main relay. <Ref. to 2-7 [W16A0]>

8C2 : CHECK MAIN RELAY.

Measure resistance between main relay terminals.

Terminals

No. 4 — No. 6:




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **8C3**.
- NO** : Replace main relay. <Ref. to 2-7 [W16A0].>

8C3 : CHECK GROUND CIRCUIT OF ECM.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness connector between ECM and chassis ground.

Connector & terminal

(B134) No. 7 — Chassis ground:




- CHECK** : *Is the resistance less than 5 Ω?*
- YES** : Go to step **8C4**.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C4 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B134) No. 8 — Chassis ground:




- CHECK** : *Is the resistance less than 5 Ω?*
- YES** : Go to step **8C5**.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C5 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B134) No. 27 — Chassis ground:




- CHECK** : *Is the resistance less than 5 Ω?*
- YES** : Go to step **8C6**.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C6 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal
(B134) No. 34 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8C7.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C7 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal
(B134) No. 35 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8C8.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C8 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal
(B136) No. 21 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8C9.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C9 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal
(B136) No. 22 — Chassis ground:




- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8C10.
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.

8C10 : CHECK INPUT VOLTAGE OF ECM.

- 1) Disconnect connector from ECM.
- 2) Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B136) No. 9 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
YES : Go to step 8C11.
NO : Repair open or ground short circuit of power supply circuit.

8C11 : CHECK INPUT VOLTAGE OF ECM.

- 1) Ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B135) No. 7 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
YES : Go to step 8C12.
NO : Repair open or ground short circuit of power supply circuit.

8C12 : CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.

- 1) Ignition switch to OFF.
- 2) Measure resistance between ECM and chassis ground.

Connector & terminal
(B135) No. 19 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
YES : Go to step 8C13.
NO : Repair ground short circuit in harness between ECM connector and main relay connector, then replace ECM.

8C13 : CHECK OUTPUT VOLTAGE FROM ECM.

- 1) Connect connector to ECM.
- 2) Ignition switch to ON.
- 3) Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B135) No. 19 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
YES : Go to step 8C14.
NO : Replace ECM.

8C14 : CHECK INPUT VOLTAGE OF MAIN RELAY.

Check voltage between main relay connector and chassis ground.

Connector & terminal

(B47) No. 2 (+) — Chassis ground (-):



H2M3212A


- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C15.
- NO** : Repair open circuit in harness between ECM connector and main relay connector.

8C15 : CHECK GROUND CIRCUIT OF MAIN RELAY.

- 1) Ignition switch to OFF.
- 2) Measure resistance between main relay connector and chassis ground.

Connector & terminal

(B47) No. 1 — Chassis ground:



H2M3213A


- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8C16.
- NO** : Repair open circuit between main relay and chassis ground.

8C16 : CHECK INPUT VOLTAGE OF MAIN RELAY.

Measure voltage between main relay connector and chassis ground.

Connector & terminal

(B47) No. 5 (+) — Chassis ground (-):



H2M3214A


- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C17.
- NO** : Repair open or ground short circuit in harness of power supply circuit.

8C17 : CHECK INPUT VOLTAGE OF MAIN RELAY.

Measure voltage between main relay connector and chassis ground.

Connector & terminal

(B47) No. 6 (+) — Chassis ground (-):




H2M3215A

- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8C18.
- NO** : Repair open or ground short circuit in harness of power supply circuit.

8C18 : CHECK INPUT VOLTAGE OF ECM.

- 1) Connect main relay connector.
- 2) Ignition switch to ON.
- 3) Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B136) No. 1 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step **8C19**.
- NO** : Repair open or ground short circuit in harness between ECM connector and main relay connector.

8C19 : CHECK INPUT VOLTAGE OF ECM.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B136) No. 2 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step **8C20**.
- NO** : Repair open or ground short circuit in harness between ECM connector and main relay connector.

8C20 : CHECK INPUT VOLTAGE OF ECM.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B136) No. 3 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step **8C21**.
- NO** : Repair open or ground short circuit in harness between ECM connector and main relay connector.

8C21 : CHECK TRANSMISSION TYPE.


- CHECK** : *Is transmission type AT?*
- YES** : Check ignition control system. <Ref. to 2-7 [T8D0].>
- NO** : Go to step **8C22**.

8C22 : CHECK GROUND CIRCUIT OF ECM.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B135) No. 25 — Chassis ground:



- CHECK** : **Is the resistance less than 5 Ω?**
- YES** : Check ignition control system. <Ref. to 2-7 [T8D0].>
- NO** : Repair open circuit in harness between ECM connector and engine grounding terminal.


MEMO:

D: IGNITION CONTROL SYSTEM

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● WIRING DIAGRAM:



H2M3004


8D1 : CHECK IGNITION SYSTEM FOR SPARKS.

- 1) Remove plug cord cap from each spark plug.
- 2) Install new spark plug on plug cord cap.

CAUTION:

Do not remove spark plug from engine.

- 3) Contact spark plug's thread portion on engine.
- 4) While opening throttle valve fully, crank engine to check that spark occurs at each cylinder.




- CHECK** : **Does spark occur at each cylinder?**
- YES** : Check fuel pump system. <Ref. to 2-7 [T8E0].>
- NO** : Go to step **8D2**.

8D2 : CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL & IGNITOR ASSEMBLY.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ignition coil & ignitor assembly.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage between ignition coil & ignitor assembly connector and engine ground.

Connector & terminal

(E12) No. 2 (+) — Engine ground (-):



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **8D3**.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ignition coil & ignitor assembly, and ignition switch connector
- Poor contact in coupling connectors (B22) and (F44)

8D3 : CHECK HARNESS OF IGNITION COIL & IGNITOR ASSEMBLY GROUND CIRCUIT.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ignition coil & ignitor assembly connector and engine ground.

Connector & terminal
(E12) No. 3 — Engine ground:



- CHECK** : Is the resistance between less than 5 Ω?
- YES** : Go to step 8D4.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ignition coil & ignitor assembly connector and engine grounding terminal

8D4 : CHECK IGNITION COIL & IGNITOR ASSEMBLY.

- 1) Remove spark plug cords.
- 2) Measure resistance between spark plug cord contact portions to check secondary coil.

Terminals

No. 1 — No. 2:




- CHECK** : Is the resistance between 10 and 15 kΩ?
- YES** : Go to step 8D5.
- NO** : Replace ignition coil & ignitor assembly. <Ref. to 6-1 [W4A0].>

8D5 : CHECK IGNITION COIL & IGNITOR ASSEMBLY.

Measure resistance between spark plug cord contact portions to check secondary coil.

Terminals

No. 3 — No. 4:




- CHECK** : Is the resistance between 10 and 15 kΩ?
- YES** : Go to step 8D6.
- NO** : Replace ignition coil & ignitor assembly. <Ref. to 6-1 [W4A0].>

8D6 : CHECK INPUT SIGNAL FOR IGNITION COIL & IGNITOR ASSEMBLY.

- 1) Connect connector to ignition coil & ignitor assembly.
- 2) Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil & ignitor assembly connector and engine ground.

Connector & terminal

(E12) No. 1 (+) — Engine ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8D7.
- NO** : Replace ignition coil & ignitor assembly.
<Ref. to 6-1 [W4A0].>

8D7 : CHECK INPUT SIGNAL FOR IGNITION COIL & IGNITOR ASSEMBLY.

Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil & ignitor assembly connector and engine ground.

Connector & terminal

(E12) No. 4 (+) — Engine ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8D8.
- NO** : Replace ignition coil & ignitor assembly.
<Ref. to 6-1 [W4A0].>

8D8 : CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Disconnect connector from ignition coil & ignitor assembly.
- 4) Measure resistance of harness between ECM and ignition coil & ignitor assembly connector.

Connector & terminal

(B134) No. 25 — (E12) No. 1:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8D9.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and ignition coil & ignitor assembly connector
- Poor contact in coupling connector (B22)

8D9 : CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.

Measure resistance of harness between ECM and ignition coil & ignitor assembly connector.

Connector & terminal
(B134) No. 26 — (E12) No. 4:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8D10.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and ignition coil & ignitor assembly connector
- Poor contact in coupling connector (B22)

8D10 : CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.

Measure resistance of harness between ECM and engine ground.

Connector & terminal:
(B134) No. 25 — Engine ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 8D11.
- NO** : Repair ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.

8D11 : CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR.

Measure resistance of harness between ECM and engine ground.

Connector & terminal
(B134) No. 26 — Engine ground:



- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 8D12.
- NO** : Repair ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.

8D12 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>


- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Check fuel pump circuit. <Ref. to 2-7 [T8E0].>

E: FUEL PUMP CIRCUIT

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



H2M3005

8E1 : CHECK OPERATING SOUND OF FUEL PUMP.

Make sure that fuel pump is in operation for two seconds when turning ignition switch to ON.

NOTE:


Fuel pump operation check can also be executed using Subaru Select Monitor (Function mode: FD01).

For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : Does fuel pump produce operating sound?
- YES** : Check fuel injector circuit. <Ref. to 2-7 [T8F0].>
- NO** : Go to step **8E2**.

8E2 : CHECK GROUND CIRCUIT OF FUEL PUMP.

- 1) Turn ignition switch to OFF.
- 2) Remove fuel pump access hole lid located on the right rear of trunk compartment floor (Sedan) or luggage compartment floor (Wagon).




S2M0392

- 3) Disconnect connector from fuel pump.

4) Measure resistance of harness connector between fuel pump and chassis ground.

Connector & terminal

(R58) No. 4 — Chassis ground:



- CHECK** : Is the resistance less than 5 Ω?
- YES** : Go to step 8E3.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between fuel pump connector and chassis grounding terminal
- Poor contact in coupling connector (R67)

8E3 : CHECK POWER SUPPLY TO FUEL PUMP.

1) Turn ignition switch to ON.
2) Measure voltage of power supply circuit between fuel pump connector and chassis ground.

Connector & terminal

(R58) No. 1 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Replace fuel pump. <Ref. to 2-8 [W5A0].>
- NO** : Go to step 8E4.

8E4 : CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.

1) Turn ignition switch to OFF.
2) Measure resistance of harness connector between fuel pump and fuel pump relay.

Connector & terminal

(R58) No. 1 — (B46) No. 4:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8E5.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between fuel pump connector and chassis grounding terminal
- Poor contact in coupling connectors (R67) and (B97)

8E5 : CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.

Measure resistance of harness between fuel pump and fuel pump relay connector.

Connector & terminal
(R58) No. 1 — Chassis ground:




- CHECK** : **Is the resistance more than 1 MΩ?**
- YES** : Go to step **8E6**.
- NO** : Repair short circuit in harness between fuel pump and fuel pump relay connector.

8E6 : CHECK FUEL PUMP RELAY.

- 1) Disconnect connectors from fuel pump relay and main relay.
- 2) Remove fuel pump relay and main relay with bracket.
- 3) Connect battery to fuel pump relay connector terminals No. 1 and No. 3.
- 4) Measure resistance between connector terminals of fuel pump relay.

Terminals
No. 2 — No. 4:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **8E7**.
- NO** : Replace fuel pump relay. <Ref. to 2-7 [W17A0].>

8E7 : CHECK HARNESS BETWEEN ECM AND FUEL PUMP RELAY CONNECTOR.

- 1) Disconnect connectors from ECM.
- 2) Measure resistance of harness between ECM and fuel pump relay connector.

Connector & terminal

(B134) No. 16 — (B46) No. 3:



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **8E8**.
- NO** : Repair open circuit in harness between ECM and fuel pump relay connector.

8E8 : CHECK POOR CONTACT.

Check poor contact in ECM connector.
 <Ref. to FOREWORD [T3C1].>


- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Check fuel injector circuit. <Ref. to 2-7 [T8F0].>

F: FUEL INJECTOR CIRCUIT

CAUTION:

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

• WIRING DIAGRAM:




H2M3006

8F1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground on faulty cylinders.

Connector & terminal

- #1 (B134) No. 4 (+) — Chassis ground (-):
- #2 (B134) No. 13 (+) — Chassis ground (-):
- #3 (B134) No. 14 (+) — Chassis ground (-):
- #4 (B134) No. 15 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 8F6.
- NO** : Go to step 8F2.

8F2 : CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel injector on faulty cylinders.
- 3) Measure voltage between ECM connector and engine ground on faulty cylinders.

Connector & terminal

- #1 (E5) No. 1 — Engine ground:
- #2 (E16) No. 1 — Engine ground:
- #3 (E6) No. 1 — Engine ground:
- #4 (E17) No. 1 — Engine ground:




- CHECK** : Is the resistance less than 10 Ω?
- YES** : Repair ground short circuit in harness between fuel injector and ECM connector.
- NO** : Go to step 8F3.

8F3 : CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.

Measure resistance of harness connector between ECM connector and fuel injector on faulty cylinders.

Connector & terminal

- #1 (B134) No. 4 — (E5) No. 1:
- #2 (B134) No. 13 — (E16) No. 1:
- #3 (B134) No. 14 — (E6) No. 1:
- #4 (B134) No. 15 — (E17) No. 1:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 8F4.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and fuel injector connector
- Poor contact in coupling connector (B22)

8F4 : CHECK FUEL INJECTOR.

Measure resistance between fuel injector terminals on faulty cylinder.

Terminals

No. 1 — No. 2:




- CHECK** : Is the resistance between 5 and 20 Ω?
- YES** : Go to step 8F5.
- NO** : Replace faulty fuel injector. <Ref. to 2-7 [W14A0].>

8F5 : CHECK POWER SUPPLY LINE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between fuel injector and engine ground on faulty cylinders.

Connector & terminal

- #1 (E5) No. 2 (+) — Engine ground (-):
- #2 (E16) No. 2 (+) — Engine ground (-):
- #3 (E6) No. 2 (+) — Engine ground (-):
- #4 (E17) No. 2 (+) — Engine ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Repair poor contact in all connectors in fuel injector circuit.
- NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between main relay and fuel injector connector on faulty cylinders
- Poor contact in coupling connector (B22)
- Poor contact in main relay connector
- Poor contact in fuel injector connector on faulty cylinders

8F6 : CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel injector on faulty cylinder.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM connector and chassis ground on faulty cylinders.

Connector & terminal

- #1 (B134) No. 4 (+) — Chassis ground (-):
- #2 (B134) No. 13 (+) — Chassis ground (-):
- #3 (B134) No. 14 (+) — Chassis ground (-):
- #4 (B134) No. 15 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Repair battery short circuit in harness between ECM and fuel injector. After repair, replace ECM. <Ref. to 2-7 [W15A0].>
- NO** : Go to step 8F7.

2-7 [T8F7]

ON-BOARD DIAGNOSTICS II SYSTEM


8. Diagnostics for Engine Starting Failure

8F7 : CHECK FUEL INJECTOR.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between fuel injector terminals on faulty cylinder.

Terminals

No. 1 — No. 2:



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Replace faulty fuel injector <Ref. to 2-7 [W14A0].> and ECM <Ref. to 2-7 [W15A0].>.
- NO** : Go to step **8F8**.

8F8 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Check crankshaft position sensor circuit. <Ref. to 2-7 [T8G0].>

G: CRANKSHAFT POSITION SENSOR CIRCUIT (2200 cc CALIFORNIA SPEC. VEHICLES)


CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

NOTE:

Check crankshaft position sensor circuit. <Ref. to 2-7 [T10AD0].>

● **WIRING DIAGRAM:**



B2M2069

H: CRANKSHAFT POSITION SENSOR CIRCUIT (EXCEPT 2200 cc CALIFORNIA SPEC. VEHICLES)


CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

NOTE:

Check crankshaft position sensor circuit. <Ref. to 2-7 [T11AC0].>

● **WIRING DIAGRAM:**



B2M2438

I: CAMSHAFT POSITION SENSOR CIRCUIT

CAUTION:


After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

NOTE:

Check camshaft position sensor circuit.

- 2200 cc California spec. vehicles: <Ref. to 2-7 [T10AF0].>
- Except 2200 cc California spec. vehicles: <Ref. to 2-7 [T11AE0].>

● WIRING DIAGRAM:



H2M3017