

## 10. Performance Test

### A: INSPECTION

#### 1. VEHICLE SET UP

In order to obtain meaningful test results, the vehicle must be set up to meet the following conditions:

- Vehicle in shade
- No wind
- All vehicle doors closed
- Front windows open
- Hood open
- Engine speed set at 1,500 rpm.
- A/C ON
- Temperature control dial — Maximum cold
- Air source — Recirculation
- Blower speed — 4th position (High)
- Operate A/C for 10 minutes (Minimum) before taking measurement.

#### 2. MEASUREMENTS

After 10 minutes (Minimum) of A/C operation and using accurate test equipment, take the following measurements (in order):

- 1) Evaporator intake air temperature at recirculation door.
- 2) Evaporator discharge air temperature at center grill.
- 3) Condenser (Ambient) intake air temperature measured 0.9 m (3 ft) in front and in line with the center of the condenser
- 4) Suction (Low) side pressure
- 5) Discharge (High) side pressure

#### NOTE:

If only one thermometer is available; 1) take the ambient measurement first; then 2) the intake air; and 3) discharge air temperature.

## 11. Compressor


### A: INSPECTION

#### 1. COMPRESSOR CLUTCH

#### NOTE:

- Compressor is a 5-vane rotary type. When trouble occurs, replace compressor as a single unit.
- Compressor clutch trouble is often caused by clutch slippage and noise. Check and take corrective measures, as required.


- 1) Remove belt cover.



- 2) Check that clearance between drive plate and pulley over the entire perimeter is within specifications.

#### Clearance:

**$0.45 \pm 0.15$  mm ( $0.0177 \pm 0.0059$  in)**



- 3) Check that voltage applied to magnetic coil is at least 10.5 volts.
- 4) When noise is noted, check that it originates in either compressor or pulley bearing.

### B: REMOVAL

- 1) Disconnect ground cable from battery.

## 4-7 [W11B0]

### 11. Compressor


## SERVICE PROCEDURE

2) Discharge refrigerant using refrigerant recovery system. <Ref. to 4-7 [W600].>

- (1) Fully close low-pressure valve of manifold gauge.
- (2) Connect low-pressure charging hose of manifold gauge to low-pressure service valve.
- (3) Open low-pressure manifold gauge valve slightly, and slowly discharge refrigerant from system.

#### CAUTION:


Do not allow refrigerant to rush out. Otherwise, compressor oil will be discharged along with refrigerant.



3) Remove low-pressure hose (A) (Flexible hose Ps) and high-pressure hose (B) (Flexible hose Pd).


#### CAUTION:

- Be careful not to lose O-ring of low-pressure hose.
- Plug the opening to prevent foreign matter from entering.




4) Compressor belt cover and generator belt cover:

Remove bolts which secure belt covers.




5) Remove alternator V-belt:

- (1) Loosen lock bolt on generator bracket.
- (2) Turn adjusting bolt and remove V-belt.




6) Remove compressor V-belt:


- (1) Loosen lock bolt on idler pulley.
- (2) Turn adjusting bolt and remove V-belt.




7) Disconnect alternator harness.



- 8) Disconnect compressor harness:  
Disconnect compressor harness from body harness.
- 9) Remove lower bracket:  
Remove bolts which secure lower compressor bracket.




- 10) Remove compressor:
  - (1) Remove bolts which secure compressor.
  - (2) Remove compressor from bracket.




## C: INSTALLATION

- 1) Install compressor:  
Install compressor on bracket.




- 2) Connect compressor harness.
- 3) Connect alternator harness.
- 4) Install compressor V-belt (Rear):  
After adjusting belt tension, tighten tension pulley lock bolt securely.
- 5) Install alternator V-belt:  
After adjusting V-belt tension, tighten generator bracket lock bolt securely.




- 6) Check drive belt tension and adjust it if necessary by changing alternator position and/or idler pulley position.

### CAUTION:

- Ensure that the V-belt is aligned correctly. If it is not, check for loose bolts.
- The V-belt should not be too tight or too loose. A belt which is too tight may break bearing or cause gas to leak from the shaft seal. A belt which is too loose slips, thereby causing the belt cut.
- After completing the compressor installation and testing the system operation, check and adjust the tension of both V-belts again.




Pulley arrangement		Tension mm (in)/98N (10 kg, 22 lb)	
 <p>Figures in table refer to the number of grooves in pulleys. C/P: Crankshaft pulley ALT: Alternator pulley P/S: Power steering oil pump pulley A/C: Air conditioner compressor pulley I/P: Idler pulley</p>		(A)	(B)
		<p>*New belt: 7.0 – 9.0 (0.276 – 0.354) Existing belt: 9.0 – 11.0 (0.354 – 0.433)</p>	<p>*New belt: 7.5 – 8.5 (0.295 – 0.335) Existing belt: 9.0 – 10.0 (0.354 – 0.394)</p>
		<p>*When replacing belts with new ones, adjust tensions to specification and then readjust to the same specification after running engine for 5 minutes.</p>	

B4M1098A

7) Install high-pressure hose (B) (Flexible hose Pd) and low-pressure hose (A) (Flexible hose Ps): Connect high-pressure hose (B) and low-pressure hose (A) with compressor.

**CAUTION:**

Be sure to apply compressor oil to the periphery of O-ring.



8) Install belt cover.

**CAUTION:**

- After installing belt cover, make sure it is not misaligned or twisted.
- After installing belt cover, check the clearance between pulley and belt cover.

9) Connect ground cable to negative terminal of battery.

10) Charging refrigerant. <Ref. to 4-7 [W700].>