

**ENGINE 2 SECTION**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**FUEL INJECTION (FUEL SYSTEMS) FU(SOHCw/oOBD)**

**EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) EC(SOHCw/oOBD)**

**EXHAUST EX(SOHCw/oOBD)**

**IGNITION IG(SOHCw/oOBD)**

**ENGINE(DIAGNOSTICS) EN(SOHCw/oOBD)**

**FUEL INJECTION (FUEL SYSTEMS) FU(DOHC TURBO)**

**EMISSION CONTROL (AUX. EMISSION CONTROL DEVICES) EC(DOHC TURBO)**

**INTAKE (INDUCTION) IN(DOHC TURBO)**

**MECHANICAL ME(DOHC TURBO)**

**EXHAUST EX(DOHC TURBO)**

**IGNITION IG(DOHC TURBO)**

**ENGINE (DIAGNOSTICS) EN(DOHC TURBO)**

# ENGINE (DIAGNOSTICS)

# *EN(SOHCw/oOBD)*

---

	<b>Page</b>
1. Basic Diagnostic Procedure .....	2
2. Check List for Interview .....	4
3. General Description .....	6
4. Electrical Components Location.....	10
5. Engine Control Module (ECM) I/O Signal .....	20
6. Subaru Select Monitor.....	23
7. Read Diagnostic Trouble Code .....	26
8. Inspection Mode.....	28
9. Clear Memory Mode.....	30
10. Compulsory Valve Operation Check Mode .....	31
11. Engine Malfunction Indicator Lamp (MIL) .....	32
12. Diagnostics for Engine Starting Failure.....	44
13. List of Diagnostic Trouble Code (DTC) .....	66
14. Diagnostic Procedure with Diagnostic Trouble Code (DTC) .....	68
15. General Diagnostic Table.....	114

# BASIC DIAGNOSTIC PROCEDURE

ENGINE (DIAGNOSTICS)

## 1. Basic Diagnostic Procedure

### A: PROCEDURE

#### 1. WITH SUBARU SELECT MONITOR

Step	Check	Yes	No
<b>1 CHECK ENGINE START FAILURE.</b> 1)Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(SOHCw/oOBD)-4, CHECK, Check List for Interview.> 2)Start the engine.	Does the engine start?	Go to step 2.	Inspection using "Diagnostics for Engine Starting Failure". <Ref. to EN(SOHCw/oOBD)-44, Diagnostics for Engine Starting Failure.>
<b>2 CHECK ILLUMINATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> <Ref. to EN(SOHCw/oOBD)-32, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL), Engine Malfunction Indicator Lamp (MIL).>	Does MIL illuminate?	Go to step 3.	Inspection using "General Diagnostic Table". <Ref. to EN(SOHCw/oOBD)-114, INSPECTION, General Diagnostic Table.>
<b>3 CHECK INDICATION OF DTC ON DISPLAY.</b> 1)Turn ignition switch to OFF. 2)Connect the Subaru Select Monitor to data link connector. 3)Turn ignition switch to ON and the Subaru Select Monitor switch to ON. 4)Read DTC on the Subaru Select Monitor. <Ref. to EN(SOHCw/oOBD)-26, WITH SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code.>	Does the Subaru Select Monitor indicate DTC? <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>	Record diagnostic trouble code. Repair the trouble cause. <Ref. to EN(SOHCw/oOBD)-68, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Go to step 4.	Repair the related parts. <b>NOTE:</b> If DTC is not shown on display although the MIL illuminates, perform diagnostics of MIL (CHECK ENGINE malfunction indicator lamp) circuit or combination meter. <Ref. to EN(SOHCw/oOBD)-32, Engine Malfunction Indicator Lamp (MIL).>
<b>4 PERFORM THE DIAGNOSIS.</b> 1)Perform the clear memory mode. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> 2)Perform the inspection mode. <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>	Does the Subaru Select Monitor indicate DTC? <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>	Record diagnostic trouble code. Repair the trouble cause. <Ref. to EN(SOHCw/oOBD)-68, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Go to step 4.	Complete the diagnosis.

# BASIC DIAGNOSTIC PROCEDURE

ENGINE (DIAGNOSTICS)

## 2. WITHOUT SUBARU SELECT MONITOR

- Be sure to check again from the beginning in order to prevent secondary trouble caused by repair work.

**CAUTION:**

- Check the connector while it is connected unless specified otherwise.

Step	Check	Yes	No
<b>1 CHECK ENGINE START FAILURE.</b> 1)Ask the customer when and how the trouble occurred using the interview check list. <Ref. to EN(SOHCw/oOBD)-4, CHECK, Check List for Interview.> 2)Start the engine.	Does the engine start?	Go to step 2.	Inspection using "Diagnostics for Engine Starting Failure". <Ref. to EN(SOHCw/oOBD)-44, Diagnostics for Engine Starting Failure.>
<b>2 CHECK ILLUMINATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> <Ref. to EN(SOHCw/oOBD)-32, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL), Engine Malfunction Indicator Lamp (MIL).>	Does MIL illuminate?	Go to step 3.	Inspection using "9. General Diagnostic Table". <Ref. to EN(SOHCw/oOBD)-114, INSPECTION, General Diagnostic Table.>
<b>3 CHECK INDICATION OF DTC ON MIL.</b> 1)Perform the read diagnostic trouble code (read memory mode).<Ref. to EN(SOHCw/oOBD)-26, WITHOUT SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code.> 2)Read DTC on MIL.	Does the MIL indicate DTC? <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>	Repair the trouble cause. Go to step 4.	Repair the related parts.  NOTE: If DTC is not shown on MIL although the MIL illuminates, perform diagnostics of MIL (CHECK ENGINE malfunction indicator lamp) circuit or combination meter.<Ref. to EN(SOHCw/oOBD)-32, Engine Malfunction Indicator Lamp (MIL).>
<b>4 PERFORM THE DIAGNOSIS.</b> 1)Perform the clear memory mode. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> 2)Perform the inspection mode. <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>	Does the MIL indicate DTC? <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>	Repair the trouble cause. Go to step 4.	Complete the diagnosis.

# CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

## 2. Check List for Interview

### A: CHECK

#### 1. CHECK LIST NO. 1

Check the following items when problem has occurred.

NOTE:

Use copies of this page for interviewing customers.

Customer's name		Engine no.	
Date of sale		Fuel brand	
Date of repair		Odometer reading	km
Vin no.			miles
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others:		
Outdoor temperature	°F (°C)		
	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold		
Place	<input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner city <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others:		
Engine temperature	<input type="checkbox"/> Cold <input type="checkbox"/> Warming-up <input type="checkbox"/> After warming-up <input type="checkbox"/> Any temperature <input type="checkbox"/> Others:		
Engine speed	rpm		
Vehicle speed	MPH		
Driving conditions	<input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH)		
Headlight	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Rear defogger	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Blower	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Radio	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
A/C compressor	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CD/Cassette	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Cooling fan	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	Car phone	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Front wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF	CB	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF
Rear wiper	<input type="checkbox"/> ON/ <input type="checkbox"/> OFF		

# CHECK LIST FOR INTERVIEW

ENGINE (DIAGNOSTICS)

## 2. CHECK LIST NO. 2

Check the following items about the vehicle's state when MIL turns on.

NOTE:

Use copies of this page for interviewing customers.

a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<input type="checkbox"/> Low fuel warning light <input type="checkbox"/> Charge indicator light <input type="checkbox"/> AT diagnostics indicator light <input type="checkbox"/> ABS warning light <input type="checkbox"/> Engine oil pressure warning light
b) Fuel level
<ul style="list-style-type: none"><li>• Lack of gasoline: <input type="checkbox"/> Yes/<input type="checkbox"/> No</li><li>• Indicator position of fuel gauge:</li></ul>
c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li></ul>
e) Installing of parts other than genuine parts: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• What:</li><li>• Where:</li></ul>
f) Occurrence of noise: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
g) Occurrence of smell: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
<ul style="list-style-type: none"><li>• From where:</li><li>• What kind:</li></ul>
h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes/ <input type="checkbox"/> No
i) Troubles occurred
<input type="checkbox"/> Engine does not start. <input type="checkbox"/> Engine stalls during idling. <input type="checkbox"/> Engine stalls while driving. <input type="checkbox"/> Engine speed decreases. <input type="checkbox"/> Engine speed does not decrease. <input type="checkbox"/> Rough idling <input type="checkbox"/> Poor acceleration <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> No shift <input type="checkbox"/> Excessive shift shock

# GENERAL DESCRIPTION

## ENGINE (DIAGNOSTICS)

### 3. General Description

#### A: CAUTION

1) Airbag system wiring harness is routed near the engine control module (ECM), main relay and fuel pump relay.

#### CAUTION:

- All Airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.

- Be careful not to damage Airbag system wiring harness when servicing the engine control module (ECM), transmission control module (TCM), main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other part will be damaged in just a few minutes more.

3) Do not disconnect the battery terminals while the engine is running.

- A large counter electromotive force will be generated in the alternator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and the ECM, be sure to turn OFF the ignition switch.

5) Poor contact has been identified as a primary cause of this problem. To measure the voltage and/or resistance of individual sensors or all electrical control modules at the harness side connector, use a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Before removing ECM from the located position, disconnect two cables on battery.


- Otherwise, the ECM may be damaged.

#### CAUTION:


**When replacing ECM, be careful not to use the wrong spec. ECM to avoid any damage on fuel injection system.**

7) The connectors to each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.


8) Use ECM mounting stud bolts at the body head grounding point when measuring voltage and resistance inside the passenger compartment.



9) Use engine grounding terminal or engine proper as the grounding point to the body when measuring voltage and resistance in the engine compartment.



10) Use TCM mounting stud bolts at the body head grounding point when measuring voltage and resistance inside the passenger compartment.



11) Every MFI-related part is a precision part. Do not drop them.

12) Observe the following cautions when installing a radio in MFI equipped models.

#### CAUTION:

- The antenna must be kept as far apart as possible from the control unit.

(The ECM is located under the steering column, inside of the instrument panel lower trim panel.)

- The antenna feeder must be placed as far apart as possible from the ECM and MFI harness.

- Carefully adjust the antenna for correct matching.

- When mounting a large power type radio, pay special attention to the three items above mentioned.

- Incorrect installation of the radio may affect the operation of the ECM.

13) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than five seconds to release pressure in the fuel system. If engine starts during this operation, run it until it stops.

14) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes must be distinguished clearly when performing diagnostics.

15) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes.

16) In AT vehicles, do not continue the stall for more than five seconds at a time (from closed throttle, fully open throttle to stall engine speed).

17) On ABS vehicle, when performing driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between the front and rear wheels. After diagnosis of engine control system, perform the ABS memory clearance procedure of self-diagnosis system.

## B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems:

### 1. BATTERY

1) Measure battery voltage and specific gravity of electrolyte.


**Standard voltage: 12 V**

**Specific gravity: Above 1.260**

2) Check the condition of the main and other fuses, and harnesses and connectors. Also check for proper grounding.

## 2. ENGINE GROUNDING

Make sure the engine grounding terminal is properly connected to the engine.



## C: NOTE

### 1. ENGINE AND EMISSION CONTROL SYSTEM

- The Multipoint Fuel Injection (MFI) system is a system that supplies the optimum air-fuel mixture to the engine for all the various operating conditions through the use of the latest electronic technology.

With this system fuel, which is pressurized at a constant pressure, is injected into the intake air passage of the cylinder head. The injection quantity of fuel is controlled by an intermittent injection system where the electro-magnetic injection valve (fuel injector) opens only for a short period of time, depending on the quantity of air required for one cycle of operation. In actual operation, the injection quantity is determined by the duration of an electric pulse applied to the fuel injector and this permits simple, yet highly precise metering of the fuel.

- Further, all the operating conditions of the engine are converted into electric signals, and this results in additional features of the system, such as large improved adaptability, easier addition of compensating element, etc.

The MFI system also has the following features:



- Reduced emission of harmful exhaust gases.
- Reduced in fuel consumption.
- Increased engine output.
- Superior acceleration and deceleration.
- Superior startability and warm-up performance in cold weather since compensation is made for coolant and intake air temperature.



# GENERAL DESCRIPTION

ENGINE (DIAGNOSTICS)

## D: PREPARATION TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 B2M3876	24082AA150 (Newly adopted tool)	CARTRIDGE	Troubleshooting for electrical systems.
 B2M3877	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"><li>• English: 22771AA030 (Without printer)</li><li>• German: 22771AA070 (Without printer)</li><li>• French: 22771AA080 (Without printer)</li><li>• Spanish: 22771AA090 (Without printer)</li></ul>





# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

## 4. Electrical Components Location

### A: LOCATION


#### 1. MODULE




- |   |                           |
|---|---------------------------|
| (1) Engine control module (ECM)                   | (3) Read memory connector |
| (2) CHECK ENGINE malfunction indicator lamp (MIL) | (4) Test mode connector   |
|   | (5) Data link connector   |

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




S2M0256A



EN0718



EN1034




EN0717

# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

## 2. SENSOR




- (1) Engine coolant temperature sensor
- (2) Intake air temperature and pressure sensor

- (3) Throttle position sensor
- (4) Knock sensor
- (5) Crankshaft position sensor
- (6) Camshaft position sensor


- (7) Vehicle speed sensor

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




S2M1248A




H2M3255A




H2M3256A




S2M1406B



B2M0213M



B2M0212F




S2M0907C

**SUBARU.**


# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)



EN0929

- (8) Oxygen sensor (With catalyst model)



S2M0264B

**SUBARU.**






# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)

## 3. SOLENOID VALVE, EMISSION CONTROL SYSTEM PARTS AND IGNITION SYSTEM PARTS



EN0930


- (1) Purge control solenoid valve
- (2) Idle air control solenoid valve

- (3) Ignition coil and ignitor ASSY


- (4) CO resistor (Without catalyst model)

# ELECTRICAL COMPONENTS LOCATION


ENGINE (DIAGNOSTICS)




H2M3258A



H2M3259A





H2M3261A



S2M1764B

# ELECTRICAL COMPONENTS LOCATION

## ENGINE (DIAGNOSTICS)




(1) Fuel pump

(2) Main relay

(3) Fuel pump relay


# ELECTRICAL COMPONENTS LOCATION

ENGINE (DIAGNOSTICS)




S2M1184A

LHD model



EN0744

RHD model



EN0748


**SUBARU.**

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

## 5. Engine Control Module (ECM) I/O Signal

### A: ELECTRICAL SPECIFICATION



# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

ENGINE (DIAGNOSTICS)

Content		Connector No.	Terminal No.		Signal (V)		Note
					Ignition SW	Engine ON	
					ON (Engine OFF)	(Idling)	
Crankshaft position sensor	Signal (+)	B135	*2	1	0	±6	Sensor output waveform
	Signal (-)	B135	8		0	0	—
	Shield	B135	10		0	0	—
Camshaft position sensor	Signal (+)	B135	*1	2	0	±6	Sensor output waveform
	Signal (-)	B135	8		0	0	—
	Shield	B135	10		0	0	—
Intake air temperature sensor	Signal	B136	13		2.3 — 2.5	1.4 — 1.6	Ambient temperature: 25°C (77°F)
Throttle position sensor	Signal	B136	17		Fully closed: 0.5±0.3 Fully opened: 4.3±0.3		—
	Power supply	B136	15		5	5	—
	GND	B136	16		0	0	—
Oxygen sensor	Signal	B136	7		0	Rich mixture: 0.7 Lean mixture: 0	
	Shield	B136	23		0	0	—
Engine coolant temperature sensor	Signal	B136	14		0.6 — 1.0	0.6 — 1.0	After warm-up
	GND	B136	16		0	0	—
Vehicle speed sensor		B135	24		0 or 5	0 or 5	"5" and "0" are repeatedly displayed when vehicle is driven.
Starter switch		B135	28		0	0	Cranking: 10 to 14
A/C switch		B135	27		ON: 10 — 13 OFF: 0	ON: 13 — 14 OFF: 0	—
Ignition switch		B135	7		10 — 13	13 — 14	—
Neutral position switch (MT)		B135	26		ON: 5 OFF: 0		Switch is ON when gear is in neutral position.
Park/Neutral position switch (AT)		B135	26		ON: 0 OFF: 5		Switch is ON when shift lever is in "P" or "N" position.
Test mode connector		B135	14		5	5	When connected: 0
Read memory connector		B135	15		5	5	When connected: 0
Back-up power supply		B136	9		10 — 13	13 — 14	—
Control unit power supply		B136	1		10 — 13	13 — 14	—
			2				
Ignition control	# 1, # 2	B134	25		0	3.4, max.	—
	# 3, # 4	B134	26		0	3.4, max.	—
Fuel injector	# 1	B134	4		10 — 13	13 — 14	Waveform
	# 2	B134	13		10 — 13	13 — 14	Waveform
	# 3	B134	14		10 — 13	13 — 14	Waveform
	# 4	B134	15		10 — 13	13 — 14	Waveform

\*: With immobilizer

# ENGINE CONTROL MODULE (ECM) I/O SIGNAL

## ENGINE (DIAGNOSTICS)

Content		Connector No.	Terminal No.		Signal (V)		Note
					Ignition SW	Engine ON (Idling)	
					ON (Engine OFF)		
Idle air control solenoid valve	Signal 1	B134	5		—	1 — 13	Waveform
	Signal 2	B134	6		—	1 — 13	Waveform
	Signal 3	B134	19		—	1 — 13	Waveform
	Signal 4	B134	20		—	1 — 13	Waveform
Torque control signal 1		B135	16		5	5	—
Torque control signal 2		B135	17		5	5	—
Fuel pump relay control		B134	29*	16	ON: 0 OFF: 10 — 13	0	—
A/C relay control		B134	17		ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Radiator fan relay 1 control		B134	3		ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Radiator fan relay 2 control		B134	12		ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
Self-shutoff control		B135	19		10 — 13	13 — 14	—
Malfunction indicator lamp		B134	11		—	—	Light "ON": 1, max. Light "OFF": 10 — 14
Engine speed output		B134	30		—	0 — 13, min.	Waveform
Knock sensor	Signal	B136	4		2.8	2.8	—
	Shield	B136	25		0	0	—
Pressure sensor	Signal	B136	5		3.4 — 3.6	1.2 — 1.8	—
	Power supply		15		5	5	—
	GND		16		0	0	—
Purge control solenoid valve		B134	2		ON: 0 OFF: 10 — 13	ON: 0 OFF: 13 — 14	—
GND (sensors)		B136	16		0	0	—
GND (injectors)		B134	7		0	0	—
GND (ignition system)		B134	27		0	0	—
GND (power supply)		B134	8		0	0	—
GND (control systems)		B136	21		0	0	—
		B136	22		0	0	—
Select monitor signal		B135	11		—	—	—
			12		—	—	—
Power steering switch		B135	13		ON: 0 OFF: 10 — 13	ON: 0 OFF: 10 — 13	—
Torque control cut signal		B134	31		8	8	—
AT load signal		B136	11		0 — 0.3	0.8 — 1.2	—
MT/AT identification		B135	2.5		MT: 0 AT: 5	MT: 0 AT: 5	—


\*: With immobilizer

## 6. Subaru Select Monitor

### A: OPERATION


#### 1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare Subaru Select Monitor kit.




2) Connect diagnosis cable to Subaru Select Monitor.

3) Insert cartridge into Subaru Select Monitor.




4) Connect Subaru Select Monitor to data link connector.

(1) Data link connector located in the lower portion of the instrument panel (on the driver's side).



(2) Connect diagnosis cable to data link connector.

5) Turn ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



6) Using Subaru Select Monitor, call up diagnostic trouble code(s) and various data, then record them.

#### 2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE.

Refer to Read Diagnostic Trouble Code for information about how to indicate DTC. <Ref. to EN(SOHCw/oOBD)-26, Read Diagnostic Trouble Code.>

#### CAUTION:

Do not connect scan tools except for Subaru Select Monitor.



# SUBARU SELECT MONITOR

## ENGINE (DIAGNOSTICS)

### 3. READ CURRENT DATA SHOWN ON DISPLAY.

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
  - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
  - 3) Press the [YES] key after displayed the information of engine type.
  - 4) On the «Engine Diagnosis» display screen, select the {1. Current Data Display & Save} and press the [YES] key.
  - 5) On the «Data Display Menu» display screen, select the {1. 12 Data Display} and press the [YES] key.
  - 6) Using the scroll key, move the display screen up or down until the desired data is shown.
- A list of the support data is shown in the following table.

Contents	Unit of measure
Battery voltage	V
Vehicle speed signal	km/h or MPH
Engine speed signal	rpm
Engine coolant temperature signal	°C or °F
Ignition timing signal	deg
Pressure sensor signal	mmHg or kPa or inHg or psi
Intake air temperature signal	°C or °F
Throttle position signal	V
Injection pulse width	ms
ISC valve step	STEP
Oxygen sensor output signal*1	V
Knock correction	deg
CO resistor*2	g/h
A/F correction #1	%
A/F learning #1	%
Ignition switch signal	ON or OFF
Automatic transmission vehicle identification signal	ON or OFF
Test mode connector signal	ON or OFF
Neutral position switch signal	ON or OFF
Air conditioning switch signal	ON or OFF
Air conditioning compressor signal	ON or OFF
Radiator fan relay signal #1	ON or OFF
Fuel pump relay signal	ON or OFF
Knocking signal	ON or OFF
Radiator fan relay signal #2	ON or OFF
Torque control signal #1	ON or OFF
Torque control signal #2	ON or OFF
Torque permission signal	ON or OFF
TCS AET signal	ON or OFF
Canister purge control solenoid valve	ON or OFF
Oxygen sensor rich signal	ON or OFF
Read memory connector signal	ON or OFF
P/S switch	ON or OFF
Starter switch	ON or OFF
Crankshaft position sensor signal	ON or OFF
Camshaft position sensor signal	ON or OFF
Rear defogger switch	ON or OFF
Blower fan switch	ON or OFF
Light switch	ON or OFF
Idle switch signal	ON or OFF

\*1: With catalyst model only

\*2: Without catalyst model only

# SUBARU SELECT MONITOR

ENGINE (DIAGNOSTICS)

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

## 4. LED OPERATION MODE FOR ENGINE

Contents	Message	LED "ON" requirements
Ignition switch signal	ON or OFF	When ignition switch is turned ON.
Automatic transmission vehicle identification signal	ON or OFF	When AT identification signal is entered.
Test mode connector signal	ON or OFF	When test mode connector is connected.
Neutral position switch signal*1	ON or OFF	When neutral position switch signal is entered.
Air conditioning switch signal	ON or OFF	When air conditioning switch is turned ON.
Air conditioning compressor signal	ON or OFF	When air conditioning compressor is in function.
Radiator fan relay signal #1	ON or OFF	When radiator fan relay #1 is in function.
Fuel pump relay signal	ON or OFF	When fuel pump relay is in function.
Knocking signal	ON or OFF	When knocking signal is entered.
Radiator fan relay signal #2	ON or OFF	When radiator fan relay #2 is in function.
Engine torque control signal #1	ON or OFF	When torque control signal #1 is entered.
Torque control signal #2	ON or OFF	When torque control signal #2 is entered.
Torque permission signal	ON or OFF	When torque permission signal is entered.
TCS AET signal	ON or OFF	When TCS AET signal is entered.
Canister purge control solenoid valve	ON or OFF	When canister purge control solenoid valve is in function.
Oxygen sensor rich signal*2	ON or OFF	When oxygen sensor mixture ratio is rich.
Read memory connector signal	ON or OFF	When read memory connector is connected.
P/S switch	ON or OFF	When steering wheel is turned.
Starter switch	ON or OFF	When starter switch signal is entered.
Crankshaft position sensor signal	ON or OFF	When crankshaft position sensor signal is entered.
Camshaft position sensor signal	ON or OFF	When camshaft position sensor signal is entered.
Rear defogger switch	ON or OFF	When rear defogger switch signal is entered.
Blower fan switch	ON or OFF	When blower fan switch signal is entered.
Light switch	ON or OFF	When light switch signal is entered.
Idle switch signal	ON or OFF	When throttle sensor sends signal that throttle opening angle is in idle position.

\*1: On MT model, switch is turned ON when gear position is in neutral position.

On AT model, switch is turned ON when shift position is in "P" or "N" position.

\*2: With catalyst model only

**NOTE:**

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

# READ DIAGNOSTIC TROUBLE CODE

ENGINE (DIAGNOSTICS)

## 7. Read Diagnostic Trouble Code

### A: OPERATION

#### 1. WITH SUBARU SELECT MONITOR

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Diagnostic Code(s) Display} and press the [YES] key.
- 5) On the «Diagnostic Code(s) Display» display screen, select the {Current Diagnostic Code(s)} or {History Diagnostic Code(s)} and press the [YES] key.

#### NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>

#### 2. WITHOUT SUBARU SELECT MONITOR

Step	Check	Yes	No
<b>1</b> <b>CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1) Turn ignition switch to OFF. 2) Connect read memory connector. <Ref. to EN(SOHCw/oOBD)-10, LOCATION, Electrical Components Location.> 3) Turn ignition switch to ON.	Does the MIL come on?	Go to step 2.	Check the following and repair if necessary. <b>NOTE:</b> <ul style="list-style-type: none"><li>• Open or short circuit in engine control module power supply or ground line</li><li>• Open or short circuit in CHECK ENGINE malfunction indicator lamp</li></ul>
<b>2</b> <b>CHECK DIAGNOSTIC TROUBLE CODE (DTC).</b>	Does the MIL indicate diagnostic trouble code (DTC)?	Record diagnostic trouble code (DTC). Then turn ignition switch to OFF, disconnect read memory connector.	Complete read diagnostic trouble code. Turn ignition switch to OFF and disconnect read memory connector.


# READ DIAGNOSTIC TROUBLE CODE

ENGINE (DIAGNOSTICS)

The CHECK ENGINE malfunction indicator lamp (MIL) flashes the code corresponding to the faulty parts. The long segment (1.3 seconds ON) indicates a "ten", and the short segment (0.2 seconds ON) signifies "one". And middle segment (0.5 seconds ON) means OK code.

**NOTE:**

- For detailed concerning diagnostic trouble codes, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>



## 8. Inspection Mode


### A: OPERATION

#### 1. PREPARATIONS FOR THE INSPECTION MODE

Raise the vehicle using a garage jack and place on safety stands or drive the vehicle onto free rollers.

**WARNING:**


- Before raising the vehicle, ensure parking brakes are applied.
- Do not use a pantograph jack in place of a safety stand.
- Secure a rope or wire to the front and rear towing or tie-down hooks to prevent the lateral runout of front wheels.
- Do not abruptly depress/release clutch pedal or accelerator pedal during works even when engine is operating at low speeds since this may cause vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the safety stands and the vehicle.
- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.




#### 2. WITH SUBARU SELECT MONITOR

After performing diagnostics and clearing the memory, check for any remaining unresolved trouble data.

- 1) Connect test mode connector (green).



- 2) Connect Subaru select monitor to data link connector. <Ref. to EN(SOHCw/oOBD)-10, LOCATION, Electrical Components Location.>
- 3) Turn ignition switch to ON (engine OFF) and Subaru select monitor switch to ON.



- 4) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 5) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 6) Press the [YES] key after displayed the information of engine type.
- 7) On the «Engine Diagnosis» display screen, select the {6. Dealer Check Mode Procedure} and press the [YES] key.
- 8) When the "Perform Inspection (Dealer Check) Mode?" is shown on the display screen, press the [YES] key.
- 9) Perform subsequent procedures as instructed on the display screen.
  - If trouble still remains in the memory, the corresponding diagnostic trouble code (DTC) appears on the display screen.

**NOTE:**

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning diagnostic trouble codes, refer to the DIAGNOSTIC TROUBLE CODE (DTC) LIST. <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>
- On AWD vehicles, release the parking brake.

# INSPECTION MODE

ENGINE (DIAGNOSTICS)

• The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When engine con-

trol diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

### 3. WITHOUT SUBARU SELECT MONITOR

Step	Check	Yes	No
<b>1</b> <b>CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1)Start and warm-up the engine. 2)Turn ignition switch to OFF. 3)Set shift lever to neutral position (MT vehicles), or set selector lever to "P" position (AT vehicles). 4)Connect test mode connector (green). 5)Turn ignition switch to ON.	Does the MIL come on?	Go to step 2.	Check the following and repair if necessary. NOTE: • Open or short circuit in engine control module power supply or ground line • Open or short circuit in CHECK ENGINE malfunction indicator lamp
<b>2</b> <b>CHECK DIAGNOSTIC TROUBLE CODE (DTC).</b> 1)Set selector lever to "N" position, and then set selector lever to "P" position again (AT vehicles only). 2)Start the engine.	Does the MIL indicate diagnostic trouble code (DTC)?	Record diagnostic trouble code (DTC) and inspect using DTC. <Ref. to EN(SOHCw/oOBD)-68, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Go to step 3.
<b>3</b> <b>CHECK DIAGNOSTIC TROUBLE CODE (DTC).</b> 1)Drive vehicle at speed greater than 11 km/h (7 MPH) for at least one minute. 2)Warm-up engine above 2,000 rpm.	Does the MIL indicate diagnostic trouble code (DTC)?	Record diagnostic trouble code (DTC) and inspect using DTC. <Ref. to EN(SOHCw/oOBD)-68, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Turn ignition switch to OFF. Disconnect test mode connector. Complete inspection mode. NOTE: When on-board diagnosis system indicates no trouble, the trouble is in a different symptom.

# CLEAR MEMORY MODE

ENGINE (DIAGNOSTICS)

## 9. Clear Memory Mode

### A: OPERATION

#### 1. WITH SUBARU SELECT MONITOR

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after displayed the information of engine type.
- 4) On the «Engine Diagnosis» display screen, select the {Clear Memory} and press the [YES] key.
- 5) When the `Done' and `Turn Ignition Switch OFF' are shown on the display screen, turn the Subaru Select Monitor and ignition switch to OFF.

#### NOTE:

- After the memory has been cleared, the ISC must be initialized. To do this, turn the ignition switch to the ON position. Wait 3 seconds before starting the engine.
- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.


#### 2. WITHOUT SUBARU SELECT MONITOR

	Step	Check	Yes	No
1	<b>CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1) Turn ignition switch to OFF. 2) Set shift lever to neutral position (MT vehicles), or set selector lever to "P" position (AT vehicles). 3) Connect test mode connector and read memory connector. 4) Turn ignition switch to ON.	Does the MIL come on?	Go to step 2.	Check the following and repair if necessary. NOTE: • Open or short circuit in engine control module power supply or ground line • Open or short circuit in CHECK ENGINE malfunction indicator lamp
2	<b>CHECK DIAGNOSTIC TROUBLE CODE (DTC).</b> 1) Set selector lever to "N" position, and then set selector lever to "P" position again (AT vehicles only). 2) Start the engine. 3) Drive vehicle at speed greater than 11 km/h (7 MPH) for at least one minute. 4) Warm-up engine above 2,000 rpm.	Does the MIL indicate diagnostic trouble code (DTC)? <Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).>	Record diagnostic trouble code. Repair the trouble cause. <Ref. to EN(SOHCw/oOBD)-68, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Turn ignition switch to OFF. Disconnect read memory connector and test mode connector. Complete clear memory mode.

## 10. Compulsory Valve Operation Check Mode

### A: OPERATION

1) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.



2) Each valve functions when ignition switch is turned to ON (engine OFF).

- A list of the support portion is shown in the following table.

Contents
Compulsory fuel pump relay operation check
Compulsory purge control solenoid valve operation check
Compulsory radiator fan relay operation check
Compulsory air conditioning relay operation check



# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## 11.Engine Malfunction Indicator Lamp (MIL)

### A: PROCEDURE


1. Activation of check engine malfunction indicator lamp (MIL). <Ref. to EN(SOHCw/oOBD)-32, ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL), Engine Malfunction Indicator Lamp (MIL).>
↓
2. Check engine malfunction indicator lamp (MIL) does not come on. <Ref. to EN(SOHCw/oOBD)-34, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>
↓
3. Check engine malfunction indicator lamp (MIL) does not go off. <Ref. to EN(SOHCw/oOBD)-37, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF., Engine Malfunction Indicator Lamp (MIL).>
↓
4. Check engine malfunction indicator lamp (MIL) does not blink at a cycle of 3 Hz. <Ref. to EN(SOHCw/oOBD)-39, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT BLINK AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MIL).>
↓
5. Check engine malfunction indicator lamp (MIL) remains blinking at a cycle of 3 Hz. <Ref. to EN(SOHCw/oOBD)-42, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 HZ., Engine Malfunction Indicator Lamp (MIL).>

### B: ACTIVATION OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL)


1) When ignition switch is turned to ON (engine off), the CHECK ENGINE malfunction indicator lamp (MIL) in the combination meter illuminates.

#### NOTE:


If the MIL does not illuminate, perform diagnostics of the CHECK ENGINE light circuit or the combination meter circuit. <Ref. to IDI-19, Combination Meter Assembly.>



2) After starting the engine, the MIL goes out. If it does not, either the engine or the emission control system is malfunctioning. <Ref. to EN(SOHCw/oOBD)-2, PROCEDURE, Basic Diagnostic Procedure.>



3) When ignition switch is turned to ON (engine off) or to "START" with the test mode connector connected, the MIL blinks at a cycle of 3 Hz.



# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)



---

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## C: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON.

- **DIAGNOSIS:**
  - The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.
- **TROUBLE SYMPTOM:**
  - When ignition switch is turned ON (engine OFF), MIL does not come on.
- **WIRING DIAGRAM:**



EN0860

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OUTPUT SIGNAL FROM ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B134) No. 11 (+) — Chassis ground (-):</b>	Is the voltage less than 1 V?	Go to step 4.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b>	Does the MIL come on when shaking or pulling ECM connector and harness?	Repair poor contact in ECM connector.	Go to step 3.
<b>3 CHECK ECM CONNECTOR.</b>	Is ECM connector correctly connected?	Replace ECM.	Repair connection of ECM connector.
<b>4 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Remove combination meter. <Ref. to IDI-19, Combination Meter Assembly.> 3) Disconnect connector from ECM and combination meter. 4) Measure resistance of harness between ECM and combination meter connector. <b>Connector &amp; terminal</b> <b>(B134) No. 11 — (i12) No. 6:</b>	Is resistance less than 1 Ω?	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and combination meter connector</li> <li>• Poor contact in coupling connector</li> </ul>
<b>5 CHECK POOR CONTACT.</b> Check poor contact in combination meter connector. <Ref. to IDI-19, Combination Meter Assembly.>	Is there poor contact in combination meter connector?	Repair poor contact in combination meter connector.	Go to step 6.

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR.</b></p> <p>1) Turn ignition switch to ON. 2) Measure voltage between combination meter connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(i10) No. 7 (+) — Chassis ground (-):</b></p>	<p>Is voltage more than 10 V?</p>	<p>Go to step 7.</p>	<p>Check the following and repair if necessary.</p> <p><b>NOTE:</b></p> <ul style="list-style-type: none"> <li>• Broken down ignition relay.</li> <li>• Blown out fuse (No. 5).</li> <li>• If replaced fuse (No. 5) blows easily, check the harness for short circuit of harness between fuse (No. 5) and ignition relay connector.</li> <li>• Open or short circuit in harness between fuse (No. 5) and battery terminal</li> <li>• Open circuit in harness between fuse (No. 5) and ignition relay connector</li> <li>• Poor contact in ignition relay connector</li> <li>• Poor contact in ignition switch connector</li> </ul>
<p><b>7</b></p> <p><b>CHECK POOR CONTACT.</b></p> <p>Check poor contact in combination meter connector. &lt;Ref. to IDI-19, Combination Meter Assembly.&gt;</p>	<p>Is there poor contact in combination meter connector?</p>	<p>Repair poor contact in combination meter connector.</p>	<p>Replace bulb or combination meter.</p>

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## D: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT GO OFF.



### • DIAGNOSIS:

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is shorted.

### • TROUBLE SYMPTOM:

- Although MIL comes on when engine runs, trouble code is not shown on Subaru select monitor or OBD-II general scan tool display.

### • WIRING DIAGRAM:



EN0860

Step	Check	Yes	No
1	<b>CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Turn ignition switch to ON.	Does the MIL come on?	Repair short circuit in harness between combination meter and ECM connector. Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

---

## **E: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT BLINK AT A CYCLE OF 3 HZ.**

- **DIAGNOSIS:**

- The CHECK ENGINE malfunction indicator lamp (MIL) circuit is open or shorted.
- Test mode connector circuit is in open.

- **TROUBLE SYMPTOM:**


- When inspection mode, MIL does not blink at a cycle of 3 Hz.



# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## • WIRING DIAGRAM:



EN0861

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).</b> 1) Turn ignition switch to OFF. 2) Disconnect test mode connector. 3) Turn ignition switch to ON.	Does the MIL come on?	Go to step 2.	Repair the MIL circuit. <Ref. to EN(SOHCw/oOBD)-34, CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) DOES NOT COME ON., Engine Malfunction Indicator Lamp (MIL).>
<b>2 CHECK OUTPUT SIGNAL FROM ECM.</b> Measure voltage between test mode connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B75) No. 1 (+) — Chassis ground (-):</i>	Is voltage less than 1 V?	Go to step 3.	Go to step 5.
<b>3 CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM and test mode connector. <i>Connector &amp; terminal</i> <i>(B135) No. 14 — (B75) No. 1:</i>	Is resistance less than 1 Ω?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and test mode connector
<b>4 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>
<b>5 CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between test mode connector and chassis ground. <i>Connector &amp; terminal</i> <i>(B76) No. 1 — Chassis ground:</i>	Is resistance less than 1 Ω?	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between test mode connector and chassis ground
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

## F: CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL) REMAINS BLINKING AT A CYCLE OF 3 HZ.


- **DIAGNOSIS:**

- Test mode connector circuit is shorted.

- **TROUBLE SYMPTOM:**

- Even though test mode connector is disconnected, MIL blinks at a cycle of 3 Hz when ignition switch is turned to ON.

- **WIRING DIAGRAM:**



EN0861

# ENGINE MALFUNCTION INDICATOR LAMP (MIL)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM connector and engine ground. <b>Connector &amp; terminal</b> <b>(B135) No. 14 — Engine ground:</b>	Is resistance less than 5 $\Omega$ ?	Repair short circuit in harness between ECM and test mode connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

## 12. Diagnostics for Engine Starting Failure

### A: PROCEDURE

1. Inspection of starter motor circuit. <Ref. to EN(SOHCw/oOBD)-46, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
2. Inspection of ECM power supply and ground line. <Ref. to EN(SOHCw/oOBD)-50, CONTROL MODULE POWER SUPPLY AND GROUND LINE, Diagnostics for Engine Starting Failure.>
↓
3. Inspection of ignition control system. <Ref. to EN(SOHCw/oOBD)-54, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>
↓
4. Inspection of fuel pump circuit. <Ref. to EN(SOHCw/oOBD)-58, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>
↓
5. Inspection of fuel injector circuit. <Ref. to EN(SOHCw/oOBD)-62, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## B: STARTER MOTOR CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0862

Step	Check	Yes	No
1	CHECK OPERATION OF STARTER MOTOR. Does starter motor operate when the switch starts?	Go to step 2.	Go to step 3.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2</b></p> <p><b>CHECK DTC.</b> &lt;Ref. to EN(SOHCw/oOBD)-26, OPERATION, Read Diagnostic Trouble Code.&gt;</p>	<p>Is the trouble code stored in memory? &lt;Ref. to EN(SOHCw/oOBD)-66, LIST, List of Diagnostic Trouble Code (DTC).&gt;</p>	<p>Record DTC. Repair the trouble cause. &lt;Ref. to EN(SOHCw/oOBD)-68, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</p>	<p>Go to step 3.</p>
<p><b>3</b></p> <p><b>CHECK INPUT SIGNAL FOR STARTER MOTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from starter motor. 3) Turn ignition switch to ST. 4) Measure power supply voltage between starter motor connector terminal and engine ground. <b>Connector &amp; terminal</b> <b>(B14) No. 1 (+) — Engine ground (-):</b> NOTE: On AT vehicles, place the selector lever in the "P" or "N" position.</p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 4.</p>	<p>Go to step 5.</p>
<p><b>4</b></p> <p><b>CHECK GROUND CIRCUIT OF STARTER MOTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect terminal from starter motor. 3) Measure resistance of ground cable between ground cable terminal and engine ground.</p>	<p>Is resistance less than 5 Ω?</p>	<p>Check starter motor. &lt;Ref. to SC-8, INSPECTION, Starter.&gt;</p>	<p>Repair open circuit of ground cable.</p>
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND STARTER MOTOR CIRCUIT.</b> 1) Turn ignition switch to OFF. 2) Measure resistance between starter motor and ECM. <b>Connector &amp; terminal</b> <b>(B14) No. 1 — Engine ground:</b></p>	<p>Is resistance less than 1 Ω?</p>	<p>Repair ground short circuit.</p>	<p>Go to step 6.</p>
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND STARTER MOTOR CIRCUIT.</b> 1) Turn ignition switch to START. 2) Measure resistance of fuse. <b>Connector &amp; terminal</b> <b>(B14) No. 1 — Engine ground:</b></p>	<p>Is resistance less than 1 Ω?</p>	<p>Go to step 7.</p>	<p>Repair ground short circuit.</p>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b> 1) Ignition switch to OFF. 2) Disconnect connector from ignition switch. 3) Measure power supply voltage between ignition switch connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B72) No. 1 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 8.</p>	<p>Repair open circuit in harness between ignition switch and battery.</p>
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR.</b> 1) Connect connector to ignition switch. 2) Turn ignition switch to START. 3) Measure voltage between ignition switch and chassis ground. <b>Connector &amp; terminal</b> <b>(B72) No. 3 (+) — Chassis ground (-):</b></p>	<p>Is the voltage more than 10 V?</p>	<p>Go to step 9.</p>	<p>Replace ignition switch.</p>



# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>9</b> <b>CHECK TRANSMISSION TYPE.</b>	Is the vehicle AT?	Go to step <b>10</b> .	Repair open circuit between ignition switch and starter motor circuit.
<b>10</b> <b>CHECK INHIBITOR SWITCH CIRCUIT.</b> 1) Turn ignition switch to OFF. 2) Place the selector lever in the "P" or "N" position. 3) Separate transmission harness connector. 4) Measure resistance between transmission harness connector receptacle's terminals. <b>Connector &amp; terminal</b> <b>(T3) No. 11 — No. 12:</b>	Is the resistance less than 1 $\Omega$ ?	Repair open circuit in harness between starter motor and ignition switch connector.	Go to step <b>11</b> .
<b>11</b> <b>CHECK TRANSMISSION HARNESS.</b> 1) Disconnect connector from inhibitor switch. 2) Measure resistance of harness between transmission harness and inhibitor switch connector. <b>Connector &amp; terminal</b> <b>(T3) No. 11 — (T7) No. 7:</b> <b>(T3) No. 12 — (T7) No. 12:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step <b>12</b> .	Repair open circuit in harness between transmission harness and inhibitor switch connector.
<b>12</b> <b>CHECK POOR CONTACT.</b> Check poor contact in inhibitor switch connector.	Is there poor contact in inhibitor switch connector?	Repair poor contact in inhibitor switch connector.	Replace inhibitor switch.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



Step	Check	Yes	No	
1	<p><b>CHECK MAIN RELAY.</b></p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Remove main relay.</p> <p>3) Connect battery to main relay terminals No. 1 and No. 2.</p> <p>4) Measure resistance between main relay terminals.</p> <p><b>Terminals</b></p> <p><b>No. 3 — No. 5:</b></p> <p><b>No. 4 — No. 6:</b></p>	Is the resistance less than 10 Ω?	Go to step 2.	Replace main relay.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2 CHECK GROUND CIRCUIT OF ECM.</b>                      1) Disconnect connector from ECM.                      2) Measure resistance of harness between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B136) No. 21 — Chassis ground:</i>  <i>(B136) No. 22 — Chassis ground:</i>  <i>(B134) No. 27 — Chassis ground:</i>  <i>(B134) No. 8 — Chassis ground:</i>  <i>(B134) No. 7 — Chassis ground:</i></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 3.	Repair open circuit in harness between ECM connector and engine grounding terminal.
<p><b>3 CHECK INPUT VOLTAGE OF ECM.</b>                      Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B136) No. 9 (+) — Chassis ground (-):</i></p>	Is the voltage more than 10 V?	Go to step 4.	Repair open or ground short circuit of power supply circuit.
<p><b>4 CHECK INPUT VOLTAGE OF ECM.</b>                      1) Turn ignition switch to ON.                      2) Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B135) No. 7 (+) — Chassis ground (-):</i></p>	Is the voltage more than 10 V?	Go to step 5.	Repair open or ground short circuit of power supply circuit.
<p><b>5 CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance between ECM and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B135) No. 19 — Chassis ground:</i></p>	Is the resistance more than 1 M $\Omega$ ?	Go to step 6.	Repair ground short circuit in harness between ECM connector and main relay connector, then replace ECM.
<p><b>6 CHECK OUTPUT VOLTAGE FROM ECM.</b>                      1) Connect connector to ECM.                      2) Turn ignition switch to ON.                      3) Measure voltage between ECM connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B135) No. 19 (+) — Chassis ground (-):</i></p>	Is the voltage more than 10 V?	Go to step 7.	Replace ECM.
<p><b>7 CHECK INPUT VOLTAGE OF MAIN RELAY.</b>                      Check voltage between main relay connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B47) No. 2 (+) — Chassis ground (-):</i></p>	Is the voltage more than 10 V?	Go to step 8.	Repair open circuit in harness between ECM connector and main relay connector.
<p><b>8 CHECK GROUND CIRCUIT OF MAIN RELAY.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance between main relay connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B47) No. 1 — Chassis ground:</i></p>	Is the resistance less than 5 $\Omega$ ?	Go to step 9.	Repair open circuit between main relay and chassis ground.
<p><b>9 CHECK INPUT VOLTAGE OF MAIN RELAY.</b>                      Measure voltage between main relay connector and chassis ground.  <b>Connector &amp; terminal</b>  <i>(B47) No. 5 (+) — Chassis ground (-):</i>  <i>(B47) No. 6 (+) — Chassis ground (-):</i></p>	Is the voltage more than 10 V?	Go to step 10.	Repair open or ground short circuit in harness of power supply circuit.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
10	<b>CHECK INPUT VOLTAGE OF ECM.</b> 1)Connect main relay connector. 2)Turn ignition switch to ON. 3)Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 1 (+) — Chassis ground (-):</b> <b>(B136) No. 2 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Check ignition control system. <Ref. to EN(SOHCw/oOBD)-54, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Repair open or ground short circuit in harness between ECM connector and main relay connector.



# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## D: IGNITION CONTROL SYSTEM

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0864

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK IGNITION SYSTEM FOR SPARKS.</b>                      1)Remove plug cord cap from each spark plug.                      2)Install new spark plug on plug cord cap.</p> <p><b>CAUTION:</b>  <b>Do not remove spark plug from engine.</b></p> <p>3)Contact spark plug's thread portion on engine.                      4)While opening throttle valve fully, crank engine to check that spark occurs at each cylinder.</p>	Does spark occur at each cylinder?	Check fuel pump system. <Ref. to EN(SOHCw/oOBD)-58, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.>	Go to step 2.
<p><b>2</b></p> <p><b>CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL &amp; IGNITOR ASSEMBLY.</b>                      1)Turn ignition switch to OFF.                      2)Disconnect connector from ignition coil &amp; ignitor assembly.                      3)Turn ignition switch to ON.                      4)Measure power supply voltage between ignition coil &amp; ignitor assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b>                      •1.6 Ω                      (E12) No. 1 (+) — Engine ground (-):                      •2.0 Ω                      (E12) No. 2 (+) — Engine ground (-):</p>	Is the voltage more than 10 V?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit or ground short in harness between ignition coil & ignitor assembly, and ignition switch connector • Poor contact in coupling connector (B22)
<p><b>3</b></p> <p><b>CHECK HARNESS OF IGNITION COIL &amp; IGNITOR ASSEMBLY GROUND CIRCUIT.</b>                      1)Turn ignition switch to OFF.                      2)Measure resistance between ignition coil &amp; ignitor assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b>                      (E12) No. 3 — Engine ground:</p>	Is the resistance between less than 5 Ω?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ignition coil & ignitor assembly connector and engine grounding terminal
<p><b>4</b></p> <p><b>CHECK IGNITION COIL &amp; IGNITOR ASSEMBLY.</b>                      1)Remove spark plug cords.                      2)Measure resistance between spark plug cord contact portions to check secondary coil.</p> <p><b>Terminals</b>                      •1.6 Ω                      No. 4 — No. 1:                      •2.0 Ω                      No. 1 — No. 2:</p>	Is the resistance between 10 and 15 Ω?	Go to step 5.	Replace ignition coil & ignitor assembly.
<p><b>5</b></p> <p><b>CHECK IGNITION COIL &amp; IGNITOR ASSEMBLY.</b>                      Measure resistance between spark plug cord contact portions to check secondary coil.</p> <p><b>Terminals</b>                      •1.6 Ω                      No. 3 — No. 2:                      •2.0 Ω                      No. 3 — No. 4:</p>	Is the resistance between 10 and 15 Ω?	Go to step 6.	Replace ignition coil & ignitor assembly.



# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>6 CHECK INPUT SIGNAL FOR IGNITION COIL &amp; IGNITOR ASSEMBLY.</b> Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil &amp; ignitor assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b></p> <ul style="list-style-type: none"> <li>•1.6 Ω (E12) No. 4 (+) — Engine ground (-):</li> <li>•2.0 Ω (E12) No. 1 (+) — Engine ground (-):</li> </ul>	Is the voltage more than 10 V?	Go to step 7.	Replace ignition coil & ignitor assembly.
<p><b>7 CHECK INPUT SIGNAL FOR IGNITION COIL &amp; IGNITOR ASSEMBLY.</b> Check if voltage varies synchronously with engine speed when cranking, while monitoring voltage between ignition coil &amp; ignitor assembly connector and engine ground.</p> <p><b>Connector &amp; terminal</b></p> <ul style="list-style-type: none"> <li>•1.6 Ω (E12) No. 2 (+) — Engine ground (-):</li> <li>•2.0 Ω (E12) No. 4 (+) — Engine ground (-):</li> </ul>	Is the voltage more than 10 V?	Go to step 8.	Replace ignition coil & ignitor assembly.
<p><b>8 CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b> 1)Disconnect connector from ECM. 2)Measure resistance of harness between ECM and ignition coil &amp; ignitor assembly connector.</p> <p><b>Connector &amp; terminal</b></p> <ul style="list-style-type: none"> <li>•1.6 Ω (B134) No. 26 — (E12) No. 2:</li> <li>•2.0 Ω (B134) No. 26 — (E12) No. 4:</li> </ul>	Is the resistance less than 1 Ω?	Go to step 9.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and ignition coil & ignitor assembly connector • Poor contact in a coupling connector (B22)
<p><b>9 CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b> Measure resistance of harness between ECM and ignition coil &amp; ignitor assembly connector.</p> <p><b>Connector &amp; terminal</b></p> <ul style="list-style-type: none"> <li>•1.6 Ω (B134) No. 25 — (E12) No. 4:</li> <li>•2.0 Ω (B134) No. 25 — (E12) No. 1:</li> </ul>	Is the resistance less than 1 Ω?	Go to step 10.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and ignition coil & ignitor assembly connector • Poor contact in a coupling connector (B22)

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>10</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b>                      Measure resistance of harness between ECM and ignition coil &amp; ignitor assembly connector.  <i><b>Connector &amp; terminal:</b></i>  <i><b>(B134) No. 27 — (E12) No. 3:</b></i></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 11.</p>	<p>Repair harness and connector.                      NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and ignition coil &amp; ignitor assembly connector</li> <li>• Poor contact in a coupling connector (B22)</li> </ul>
<p><b>11</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b>                      Measure resistance of harness between ECM and chassis ground.  <i><b>Connector &amp; terminal:</b></i>  <i><b>(B134) No. 26 — Chassis ground:</b></i></p>	<p>Is the resistance more than 1 <math>M\Omega</math>?</p>	<p>Go to step 12.</p>	<p>Repair ground short circuit in harness between ECM and ignition coil &amp; ignitor assembly connector.</p>
<p><b>12</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND IGNITION COIL &amp; IGNITOR ASSEMBLY CONNECTOR.</b>                      Measure resistance of harness between ECM and chassis ground.  <i><b>Connector &amp; terminal:</b></i>  <i><b>(B134) No. 25 — Chassis ground:</b></i></p>	<p>Is the resistance more than 1 <math>M\Omega</math>?</p>	<p>Go to step 13.</p>	<p>Repair ground short circuit in harness between ECM and ignition coil &amp; ignitor assembly connector.</p>
<p><b>13</b></p> <p><b>CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector.</p>	<p>Is there poor contact in ECM connector?</p>	<p>Repair poor contact in ECM connector.</p>	<p>Check spark plug and spark plug cord. &lt;Ref. to IG(SOHCw/oOBD)-6, INSPECTION, Spark Plug.&gt; &lt;Ref. to IG(SOHCw/oOBD)-10, INSPECTION, Spark Plug Cord.&gt;</p>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE


ENGINE (DIAGNOSTICS)

## E: FUEL PUMP CIRCUIT

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0933

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK OPERATING SOUND OF FUEL PUMP.</b> Make sure that fuel pump is in operation for two seconds when turning ignition switch to ON.</p> <p>NOTE: Fuel pump operation check can also be executed using Subaru Select Monitor. For the procedure, refer to the "COMPULSORY VALVE OPERATION CHECK MODE".&lt;Ref. to EN(SOHCw/oOBD)-31, OPERATION, Compulsory Valve Operation Check Mode.&gt;</p>	Does fuel pump produce operating sound?	Check fuel injector circuit. <Ref. to EN(SOHCw/oOBD)-62, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>	Go to step 2.
<p><b>2 CHECK GROUND CIRCUIT OF FUEL PUMP.</b> 1) Turn ignition switch to OFF. 2) Raise rear seat, and turn floor mat up. 3) Remove service hole cover. 4) Disconnect connector from fuel pump. 5) Measure resistance of harness connector between fuel pump and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(R58) No. 1 — Chassis ground:</b></p>	Is the resistance less than 5 Ω?	Go to step 3.	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between fuel pump connector and chassis grounding terminal</li> <li>• Poor contact in coupling connector (R57) and (R1)</li> </ul>
<p><b>3 CHECK POWER SUPPLY TO FUEL PUMP.</b> 1) Turn ignition switch to ON. 2) Measure voltage of power supply circuit between fuel pump connector and chassis ground.</p> <p><b>Connector &amp; terminal</b> <b>(R58) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Replace fuel pump.	Go to step 4.
<p><b>4 CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Measure resistance of harness between fuel pump and fuel pump relay connector.</p> <p><b>Connector &amp; terminal</b> <b>(R58) No. 2 — (B46) No. 4:</b></p>	Is the resistance less than 1 Ω?	Go to step 5.	Repair harness and connector.  NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between fuel pump and fuel pump relay connector</li> <li>• Poor contact in coupling connectors (R57) and (R1)</li> </ul>
<p><b>5 CHECK HARNESS BETWEEN FUEL PUMP AND FUEL PUMP RELAY CONNECTOR.</b> Measure resistance of harness between fuel pump and fuel pump relay connector.</p> <p><b>Connector &amp; terminal</b> <b>(R58) No. 2 — Chassis ground:</b></p>	Is the resistance more than 1 MΩ?	Go to step 6.	Repair ground short circuit in harness between fuel pump and fuel pump relay connector.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>6 CHECK FUEL PUMP RELAY.</b> 1)Disconnect connector from fuel pump relay. 2)Remove fuel pump relay from bracket. 3)Connect battery to fuel pump relay connector terminals No. 1 and No. 3. 4)Measure resistance between connector terminals of fuel pump relay. <i>Terminals</i> <i>No. 2 — No. 4:</i>	Is the resistance less than 10 $\Omega$ ?	Go to step 7.	Replace fuel pump relay.
<b>7 CHECK HARNESS BETWEEN ECM AND FUEL PUMP RELAY CONNECTOR.</b> 1)Disconnect connectors from ECM. 2)Measure resistance of harness between ECM and fuel pump relay connector. <i>Connector &amp; terminal</i> • <i>With Immobilizer</i> (B134) No. 29 — (B46) No. 3: • <i>Without Immobilizer</i> (B134) No. 16 — (B46) No. 3:	Is the resistance less than 1 $\Omega$ ?	Go to step 8.	Repair open circuit in harness between ECM and fuel pump relay connector.
<b>8 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Check fuel injector circuit. <Ref. to EN(SOHCw/oOBD)-62, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

---


# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

## F: FUEL INJECTOR CIRCUIT

### CAUTION:

- Check or repair only faulty parts.
- After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>
- WIRING DIAGRAM:



EN0866

Step	Check	Yes	No	
1	<p><b>CHECK OPERATION OF EACH FUEL INJECTOR.</b></p> <p>While cranking the engine, check that each fuel injector emits "operating" sound. Use a sound scope or attach a screwdriver to injector for this check.</p>	<p>Is the fuel injector emits "operating" sound?</p>	<p>Check fuel pressure. &lt;Ref. to ME(SOHC)-28, INSPECTION, Fuel Pressure.&gt;</p>	<p>Go to step 2.</p>

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>2</b></p> <p><b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from #1 cylinder fuel injector.                      3) Turn ignition switch to ON.                      4) Measure power supply voltage between the fuel injector terminal and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>#1 (E5) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connector (B22)</li> <li>• Poor contact in fuel injector connector</li> </ul>
<p><b>3</b></p> <p><b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from #2 cylinder fuel injector.                      3) Turn ignition switch to ON.                      4) Measure power supply voltage between the fuel injector terminal and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>#2 (E16) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connector (B22)</li> <li>• Poor contact in fuel injector connector</li> </ul>
<p><b>4</b></p> <p><b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b></p> <p>1) Turn ignition switch to OFF.                      2) Disconnect connector from #3 cylinder fuel injector.                      3) Turn ignition switch to ON.                      4) Measure power supply voltage between the fuel injector terminal and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>#3 (E6) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connectors (B22)</li> <li>• Poor contact in fuel injector connector</li> </ul>



# DIAGNOSTICS FOR ENGINE STARTING FAILURE

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>5</b></p> <p><b>CHECK POWER SUPPLY TO EACH FUEL INJECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from #4 cylinder fuel injector.                      3) Turn ignition switch to ON.                      4) Measure power supply voltage between the fuel injector terminal and engine ground.  <b>Connector &amp; terminal</b>  <b>#4 (E17) No. 2 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and fuel injector connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connectors (B22)</li> <li>• Poor contact in fuel injector connector</li> </ul>
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b>                      1) Disconnect connector from ECM.                      2) Measure resistance of harness between ECM and fuel injector connector.  <b>Connector &amp; terminal</b>  <b>(B134) No. 4 — (B136) No. 2:</b></p>	Is the resistance between 11 and 12 Ω?	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel injector connector</li> <li>• Poor contact in coupling connector (B22)</li> </ul>
<p><b>7</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b>                      Measure resistance of harness between ECM and fuel injector connector.  <b>Connector &amp; terminal</b>  <b>(B134) No. 4 — Chassis ground:</b></p>	Is the resistance less than 1 Ω?	Repair ground short circuit in harness between ECM and fuel injector connector.	Go to step 8.
<p><b>8</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b>                      Measure resistance of harness between ECM and fuel injector connector.  <b>Connector &amp; terminal</b>  <b>(B134) No. 13 — (B136) No. 2:</b></p>	Is the resistance between 11 and 12 Ω?	Go to step 9.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel injector connector</li> <li>• Poor contact in coupling connector (B22)</li> </ul>
<p><b>9</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b>                      Measure resistance of harness between ECM and fuel injector connector.  <b>Connector &amp; terminal</b>  <b>(B134) No. 13 — Chassis ground:</b></p>	Is the resistance less than 1 Ω?	Repair ground short circuit in harness between ECM and fuel injector connector.	Go to step 10.

# DIAGNOSTICS FOR ENGINE STARTING FAILURE

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>10 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> Measure resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> <b>(B134) No. 14 — (B136) No. 2:</b>	Is the resistance between 11 and 12 $\Omega$ ?	Go to step 11.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel injector connector</li> <li>• Poor contact in coupling connector (B22)</li> </ul>
<b>11 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> Measure resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> <b>(B134) No. 14 — Chassis ground:</b>	Is the resistance less than 1 $\Omega$ ?	Repair ground short circuit in harness between ECM and fuel injector connector.	Go to step 12.
<b>12 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> Measure resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> <b>(B134) No. 15 — (B136) No. 2:</b>	Is the resistance between 11 and 12 $\Omega$ ?	Go to step 13.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and fuel injector connector</li> <li>• Poor contact in coupling connector (B22)</li> </ul>
<b>13 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR.</b> Measure resistance of harness between ECM and fuel injector connector. <b>Connector &amp; terminal</b> <b>(B134) No. 15 — Chassis ground:</b>	Is the resistance less than 1 $\Omega$ ?	Repair ground short circuit in harness between ECM and fuel injector connector.	Go to step 14.
<b>14 CHECK EACH FUEL INJECTOR.</b> 1) Turn ignition switch to OFF. 2) Measure resistance between each fuel injector terminals. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 11 and 12 $\Omega$ ?	Go to step 15.	Replace faulty fuel injector.
<b>15 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Inspection using "General Diagnostic Table". <Ref. to EN(SOHCw/oOBD)-114, INSPECTION, General Diagnostic Table.>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## 13. List of Diagnostic Trouble Code (DTC)

### A: LIST

Trouble code	Item	Contents of diagnosis	Index
11	Crankshaft position sensor	<ul style="list-style-type: none"> <li>No signal entered from crankshaft position sensor when starter switch is ON.</li> <li>The harness connector between ECM and crankshaft position sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-68, DTC 11 CRANKSHAFT POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
12	Starter switch	<ul style="list-style-type: none"> <li>The starter switch signal is abnormal.</li> <li>The harness connector between ECM and starter switch is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-70, DTC 12 STARTER SWITCH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
13	Camshaft position sensor	<ul style="list-style-type: none"> <li>No signal entered from camshaft position sensor, but signal entered from crankshaft position sensor.</li> <li>The harness connector between ECM and camshaft position sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-72, DTC 13 CAMSHAFT POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
21	Engine coolant temperature sensor	<ul style="list-style-type: none"> <li>The engine coolant temperature sensor signal is abnormal.</li> <li>The harness connector between ECM and engine coolant temperature sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-76, DTC 21 ENGINE COOLANT TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
22	Knock sensor	<ul style="list-style-type: none"> <li>The knock sensor signal is abnormal.</li> <li>The harness connector between ECM and knock sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-80, DTC 22 KNOCK SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
24	Idle air control solenoid valve	<ul style="list-style-type: none"> <li>The idle air control solenoid valve is not in function.</li> <li>The harness connector between ECM and idle air control solenoid valve is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-82, DTC 24 IDLE AIR CONTROL SOLENOID VALVE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
26	Intake temperature sensor	<ul style="list-style-type: none"> <li>The intake air temperature sensor signal is abnormal.</li> <li>The harness connector between ECM and intake air temperature sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-86, DTC 26 INTAKE AIR TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
31	Throttle position sensor	<ul style="list-style-type: none"> <li>The throttle position sensor signal is abnormal.</li> <li>The throttle position sensor is installed abnormally.</li> <li>The harness connector between ECM and throttle position sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-90, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
32	Oxygen sensor	<ul style="list-style-type: none"> <li>The oxygen sensor is not in function.</li> <li>The harness connector between ECM and oxygen sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-92, DTC 32 OXYGEN SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
33	Vehicle speed signal	<ul style="list-style-type: none"> <li>The vehicle speed signal is abnormal.</li> <li>The harness connector between ECM and vehicle speed sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-96, DTC 33 VEHICLE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Trouble code	Item	Contents of diagnosis	Index
35	Purge control solenoid valve	<ul style="list-style-type: none"> <li>• The purge control solenoid valve is not in function.</li> <li>• The harness connector between ECM and purge control solenoid valve is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-98, DTC 35 PURGE CONTROL SOLENOID VALVE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
38	Torque control signal (AT)	<ul style="list-style-type: none"> <li>• Abnormal signal is entered from TCM.</li> <li>• The harness connector between ECM and TCM is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-102, DTC 38 TORQUE CONTROL SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
45	Pressure sensor	<ul style="list-style-type: none"> <li>• The pressure sensor signal is abnormal.</li> <li>• The harness connector between ECM and pressure sensor is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-104, DTC 45 PRESSURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
46	CO resistor (General spec. vehicles)	<ul style="list-style-type: none"> <li>• The CO resistor signal is abnormal.</li> <li>• The harness connector between ECM and CO resistor is in short or open.</li> <li>• The CO valve is not adjusted to specification.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-106, DTC 46 CO RESISTOR (GENERAL SPEC. VEHICLES), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
51	Neutral position switch (MT)	<ul style="list-style-type: none"> <li>• The neutral position switch signal is abnormal.</li> <li>• The harness connector between ECM and neutral position switch is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-108, DTC 51 NEUTRAL POSITION SWITCH (MT VEHICLE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
	Park/Neutral position switch (AT)	<ul style="list-style-type: none"> <li>• The park/neutral position switch signal is abnormal.</li> <li>• The shift cable is connected abnormally.</li> <li>• The harness connector between ECM and inhibitor switch is in short or open.</li> </ul>	<Ref. to EN(SOHCw/oOBD)-110, DTC 51 PARK/NEUTRAL POSITION SWITCH (AT VEHICLE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
53*	Immobilizer system	Faulty immobilizer system.	<Ref. to IM-2, Basic Diagnostic Procedure.>
85	Charge system	Charge system is abnormal.	<Ref. to EN(SOHCw/oOBD)-112, DTC 85 CHARGE SYSTEM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

\*: Immobilizer system equipped model only

## 14. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

### A: DTC 11 CRANKSHAFT POSITION SENSOR

• **DIAGNOSIS:**

- No signal entered from crankshaft position sensor when ignition switch is ON.
- The harness connector between ECM and crankshaft position sensor is in short or open.


• **TROUBLE SYMPTOM:**

- Engine stalls.
- Restarting impossible

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

• **WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK CONDITION OF CRANKSHAFT POSITION SENSOR INSTALLATION.</b>	Go to step 2.	Tighten crankshaft position sensor installing bolts securely.
2	<b>CHECK CRANKSHAFT POSITION SENSOR.</b> 1)Remove crankshaft position sensor. 2)Measure resistance between connector terminals of crankshaft position sensor. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Go to step 3.	Replace crankshaft position sensor.
3	<b>CHECK HARNESS BETWEEN ECM AND CRANKSHAFT POSITION SENSOR CONNECTOR.</b> 1)Connect connector to crankshaft position sensor. 2)Disconnect connector from ECM. 3)Measure resistance of harness between crankshaft position sensor connector and ECM. <b>Connector &amp; terminal</b> • <b>With Immobilizer</b> <b>(B135) No. 8 — (B135) No. 2</b> • <b>Without Immobilizer</b> <b>(B135) No. 8 — (B135) No. 1</b>	Go to step 4.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between crankshaft position sensor and ECM connector • Poor contact in coupling connector (B21)
4	<b>CHECK HARNESS BETWEEN ECM AND CRANKSHAFT POSITION SENSOR CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 8 — Chassis ground:</b>	Repair ground short circuit in harness between crankshaft position sensor and ECM connector.	Go to step 5.
5	<b>CHECK INPUT SIGNAL FOR ECM.</b> 1)Turn ignition switch to OFF. 2)Set the positive (+) probe and ground lead of oscilloscope at ECM connector terminals. 3)Measure voltage indicated on oscilloscope while cranking the engine. <b>Connector &amp; terminal</b> • <b>With Immobilizer</b> <b>(B135) No. 2 (+) — (B135) No. 8 (-)</b> • <b>Without Immobilizer</b> <b>(B135) No. 1 (+) — (B135) No. 8 (-)</b>	Go to step 6.	Replace crankshaft position sensor.
6	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Repair poor contact in ECM connector.	Go to step 7.
7	<b>CHECK ECM.</b> 1)Connect all connectors. 2)Erase the memory. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> 3)Perform inspection mode. <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.> 4)Read out the trouble code. <Ref. to EN(SOHCw/oOBD)-26, OPERATION, Read Diagnostic Trouble Code.>	Replace generator.	Go to step 8.
8	<b>CHECK ANY OTHER TROUBLE CODES APPEARANCE.</b>	Proceed with the diagnosis corresponding to the trouble code.	A temporary poor contact.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## B: DTC 12 STARTER SWITCH

### • DIAGNOSIS:

- The starter switch signal is abnormal.
- The harness connector between ECM and starter switch is in short or open.


### • TROUBLE SYMPTOM:

- Failure of engine to start

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0862

Step	Check	Yes	No
1	CHECK OPERATION OF STARTER MOTOR. Does starter motor operate when ignition switch starts?	Go to step 2.	Check starter motor circuit.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>2</b> <b>CHECK HARNESS BETWEEN ECM AND IGNITION SWITCH CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Turn ignition switch to ST. 4) Measure power supply voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 28 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Repair poor contact in ECM connector.	Repair open or ground short circuit in harness between ECM and ignition switch connector.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## C: DTC 13 CAMSHAFT POSITION SENSOR

**DIAGNOSIS:**

- No signal entered from camshaft position sensor, but signal entered from crankshaft position sensor.
- The harness connector between ECM and camshaft position sensor is in short or open.


**TROUBLE SYMPTOM:**

- Engine stalls.
- Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

**WIRING DIAGRAM:**



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK CONDITION OF CAMSHAFT POSITION SENSOR INSTALLATION.</b>	Go to step 2.	Tighten camshaft position sensor installing bolts securely.
2	<b>CHECK CAMSHAFT POSITION SENSOR.</b> 1)Remove camshaft position sensor. 2)Measure resistance between connector terminals of camshaft position sensor. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Go to step 3.	Replace camshaft position sensor.
3	<b>CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b> 1)Connect connector to camshaft position sensor. 2)Disconnect connector from ECM. 3)Measure resistance of harness between camshaft position sensor connector and ECM. <b>Connector &amp; terminal</b> • <b>With Immobilizer</b> <b>(B135) No. 8 — (B135) No. 1</b> • <b>Without Immobilizer</b> <b>(B135) No. 8 — (B135) No. 2</b>	Go to step 4.	Repair harness and connector. <b>NOTE:</b> In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in coupling connector (B21)
4	<b>CHECK HARNESS BETWEEN ECM AND CAMSHAFT POSITION SENSOR CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 8 — Chassis ground:</b>	Repair ground short circuit in harness between camshaft position sensor and ECM connector.	Go to step 5.
5	<b>CHECK INPUT SIGNAL FOR ECM.</b> 1)Turn ignition switch to OFF. 2)Disconnect connector from ECM. 3)Set the positive (+) probe and ground lead of oscilloscope at ECM connector terminals. 4)Measure voltage indicated on oscilloscope while cranking the engine. <b>Connector &amp; terminal</b> • <b>With Immobilizer</b> <b>(B135) No. 1 (+) — (B135) No. 8 (-)</b> • <b>Without Immobilizer</b> <b>(B135) No. 2 (+) — (B135) No. 8 (-)</b>	Go to step 6.	Replace camshaft position sensor.
6	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Repair poor contact in ECM connector.	Go to step 7.
7	<b>CHECK ECM.</b> 1)Connect all connectors. 2)Erase the memory. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> 3)Perform inspection mode. <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.> 4)Read out the trouble code. <Ref. to EN(SOHCw/oOBD)-26, OPERATION, Read Diagnostic Trouble Code.>	Replace generator.	Go to step 8.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
8	CHECK ANY OTHER TROUBLE CODES APPEARANCE.	Are other trouble codes being output?	Proceed with the diagnosis corresponding to the trouble code.	A temporary poor contact.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## D: DTC 21 ENGINE COOLANT TEMPERATURE SENSOR

### • DIAGNOSIS:

- The engine coolant temperature sensor signal is abnormal.
- The harness connector between ECM and engine coolant temperature sensor is in short or open.


### • TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0936

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to OFF.                  2) Remove generator.                  3) Disconnect connector from engine coolant temperature sensor.                  4) Measure voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E8) No. 1 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.	Go to step 2.
<p><b>2</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>1) Turn ignition switch to ON.                  2) Measure voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E8) No. 1 (+) — Engine ground (-):</b></p>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.	Go to step 3.
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b></p> <p>Measure voltage between engine coolant temperature sensor connector and engine ground.</p> <p><b>Connector &amp; terminal</b>  <b>(E8) No. 1 (+) — Engine ground (-):</b></p>	Is the voltage more than 4 V?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li> <li>• Poor contact in engine coolant temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector (B21)</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>4</b>      <b>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance of harness between engine coolant temperature sensor connector and engine ground.  <b>Connector &amp; terminal</b>  <b>(E8) No. 2 — Engine ground:</b></p>	<p>Is the resistance less than 5 <math>\Omega</math>?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.                      NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and engine coolant temperature sensor connector</li> <li>• Poor contact in engine coolant temperature sensor connector</li> <li>• Poor contact in ECM connector</li> <li>• Poor contact in coupling connector (B21)</li> <li>• Poor contact in sensor ground joint connector (B83)</li> </ul>
<p><b>5</b>      <b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b>                      Measure resistance between engine coolant temperature sensor terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 2 and 3 k<math>\Omega</math> at 20°C (68°F)?</p>	<p>Go to step 6.</p>	<p>Replace engine coolant temperature sensor.</p>
<p><b>6</b>      <b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b>                      Measure resistance between engine coolant temperature sensor terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 0.35 and 0.4 k<math>\Omega</math> at 80°C (176°F)?</p>	<p>Go to step 7.</p>	<p>Replace engine coolant temperature sensor.</p>
<p><b>7</b>      <b>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</b>                      Measure resistance between engine coolant temperature sensor terminals.  <b>Terminals</b>  <b>No. 1 — No. 2:</b></p>	<p>Is the resistance between 0.2 and 0.3 k<math>\Omega</math> at 90°C (194°F)?</p>	<p>Replace ECM.</p>	<p>Replace engine coolant temperature sensor.</p>





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## E: DTC 22 KNOCK SENSOR

**DIAGNOSIS:**

- The knock sensor signal is abnormal.
- The harness connector between ECM and knock sensor is in short or open.


**TROUBLE SYMPTOM:**

- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

**WIRING DIAGRAM:**



EN0937

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 4 (+) — Chassis ground (-):</b>	Is the voltage more than 3 V?	Go to step 2.	Go to step 3.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>
<b>3 CHECK KNOCK SENSOR.</b> 1) Disconnect connector from knock sensor. 2) Measure resistance between knock sensor connector terminal and engine ground. <b>Terminal</b> <b>No. 2 — Engine ground:</b>	Is the resistance between 530 k $\Omega$ and 590 k $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between knock sensor and ECM connector</li> <li>• Poor contact in knock sensor connector</li> <li>• Poor contact in coupling connector (B21)</li> </ul>
<b>4 CHECK HARNESS CONNECTOR BETWEEN ECM AND KNOCK SENSOR.</b> Measure resistance of harness connector between ECM and knock sensor. <b>Connector &amp; terminal</b> <b>(E14) No. 2 — Chassis ground:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Replace knock sensor. <Ref. to FU(SOHCw/oOBD)-30, Knock Sensor.>
<b>5 CHECK HARNESS CONNECTOR BETWEEN ECM AND KNOCK SENSOR.</b> Measure resistance of harness of harness connector between ECM connector and knock sensor. <b>Connector &amp; terminal</b> <b>(B136) No. 4 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 6.	Repair ground short circuit between ECM and knock sensor.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### F: DTC 24 IDLE AIR CONTROL SOLENOID VALVE

**DIAGNOSIS:**

- The idle air control solenoid valve is not in function.
- The harness connector between ECM and idle air control solenoid valve is in short or open.


**TROUBLE SYMPTOM:**

- Erroneous idling
- Hard to start
- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

**WIRING DIAGRAM:**



EN0882

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from idle air control solenoid valve.                      3) Turn ignition switch to ON.                      4) Measure voltage between idle air control solenoid valve connector and engine ground.</p> <p><b>Connector &amp; terminal</b>                      (E7) No. 2 (+) — Engine ground (-):                      (E7) No. 5 (+) — Engine ground (-):</p>	Is the voltage more than 10 V?	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between idle air control solenoid valve and main relay connector</li> <li>• Poor contact in coupling connector (B22)</li> </ul>
<p><b>2 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b>                      1) Turn ignition switch to OFF.                      2) Measure resistance between ECM and idle air control solenoid valve connector.</p> <p><b>Connector &amp; terminal</b>                      #1; (B134) No. 20 — (E7) No. 3:                      #2; (B134) No. 6 — (E7) No. 1:                      #3; (B134) No. 19 — (E7) No. 6:                      #4; (B134) No. 5 — (E7) No. 4:</p>	Is the resistance less than 1 Ω?	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and idle air control solenoid valve connector</li> <li>• Poor contact in coupling connector (B21)</li> </ul>
<p><b>3 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</b>                      1) Disconnect connector from ECM.                      2) Measure resistance between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>                      #1; (B134) No. 20 — Chassis ground:                      #2; (B134) No. 6 — Chassis ground:                      #3; (B134) No. 19 — Chassis ground:                      #4; (B134) No. 5 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 4.	Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.
<p><b>4 CHECK POOR CONTACT.</b>                      Check poor contact in ECM connector and idle air control solenoid valve connector.</p>	Is there poor contact in ECM connector or idle air control solenoid valve connector?	Repair poor contact in ECM connector or idle air control solenoid valve connector.	Go to step 5.
<p><b>5 CHECK IDLE SPEED.</b></p>	Is idling speed higher than standard?	Go to step 6.	Go to step 8.
<p><b>6 CHECK AIR INTAKE SYSTEM.</b>                      1) Turn ignition switch to ON.                      2) Start engine, and idle it.                      3) Check the following items.</p> <ul style="list-style-type: none"> <li>• Loose installation of intake manifold, idle air control solenoid valve and throttle body</li> <li>• Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket</li> <li>• Disconnections of vacuum hoses</li> </ul>	Is there a fault in air intake system?	Repair air suction and leaks.	Go to step 7.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK AIR BY-PASS LINE.</b> 1) Turn ignition switch to OFF. 2) Remove idle air control solenoid valve from throttle body. <Ref. to FU(SOHCw/oOBD)-35, Idle Air Control Solenoid Valve.> 3) Confirm that there are no foreign particles in by-pass air line.	Are foreign particles in by-pass air line?	Remove foreign particles from by-pass air line.	Replace idle air control solenoid valve. <Ref. to FU(SOHCw/oOBD)-35, Idle Air Control Solenoid Valve.>
8	<b>CHECK AIR BY-PASS LINE.</b> 1) Turn ignition switch to OFF. 2) Remove idle air control solenoid valve from throttle body. <Ref. to FU(SOHCw/oOBD)-35, Idle Air Control Solenoid Valve.> 3) Remove throttle body from intake manifold. <Ref. to FU(SOHCw/oOBD)-14, Throttle Body.> 4) Confirm that there are no foreign particles in the throttle body. 5) Using an air gun, force air into idle air control solenoid valve installation area. Confirm that forced air subsequently escapes from throttle body interior.	Does air flow out?	Replace idle air control solenoid valve. <Ref. to FU(SOHCw/oOBD)-35, Idle Air Control Solenoid Valve.>	Replace throttle body. <Ref. to FU(SOHCw/oOBD)-14, Throttle Body.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## G: DTC 26 INTAKE AIR TEMPERATURE SENSOR

**DIAGNOSIS:**

- The intake air temperature sensor signal is abnormal.
- The harness connector between ECM and intake air temperature sensor is in short or open.


**TROUBLE SYMPTOM:**

- Hard to start
- Erroneous idling
- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

**WIRING DIAGRAM:**



EN0938

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK INTAKE AIR TEMPERATURE SENSOR.</b>                      1) Turn ignition switch to OFF.                      2) Disconnect connector from intake air temperature sensor.                      3) Measure resistance between intake air temperature sensor terminals.</p> <p><b>Terminals</b>  <b>No. 2 — No. 3:</b></p>	<p>Is the resistance between 2 and 3 k<math>\Omega</math> at 20°C (68°F)?</p>	<p>Go to step 2.</p>	<p>Replace intake air temperature sensor. &lt;Ref. to FU(SOHCw/oOBD)-34, Intake Air Temperature and Pressure Sensor.&gt;</p>
<p><b>2</b></p> <p><b>CHECK INTAKE AIR TEMPERATURE SENSOR.</b>                      Measure resistance between intake air temperature sensor terminals.</p> <p><b>Terminals</b>  <b>No. 2 — No. 3:</b></p>	<p>Is the resistance between 0.66 and 1 k<math>\Omega</math> at 50°C (122°F)?</p>	<p>Go to step 3.</p>	<p>Replace intake air temperature sensor. &lt;Ref. to FU(SOHCw/oOBD)-34, Intake Air Temperature and Pressure Sensor.&gt;</p>
<p><b>3</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b>                      1) Disconnect connector from ECM.                      2) Measure resistance of harness connector between ECM and intake air temperature sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 15 — (E20) No. 3:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 4.</p>	<p>Repair harness and connector.                      NOTE:                      In this case, repair the following:</p> <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and intake air temperature and pressure sensor connector</li> <li>• Poor contact in coupling connector (B21)</li> </ul>
<p><b>4</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b>                      Measure resistance of harness connector between ECM and intake air temperature sensor connector.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 — (E20) No. 2:</b></p>	<p>Is the resistance less than 1 <math>\Omega</math>?</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p>
<p><b>5</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b>                      Measure resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 15 — Chassis ground:</b></p>	<p>Is the resistance more than 1 M<math>\Omega</math>?</p>	<p>Go to step 6.</p>	<p>Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.</p>
<p><b>6</b></p> <p><b>CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE SENSOR CONNECTOR.</b>                      Measure resistance of harness between ECM connector and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 13 — Chassis ground:</b></p>	<p>Is the resistance more than 1 M<math>\Omega</math>?</p>	<p>Go to step 7.</p>	<p>Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.</p>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Contact with your Subaru distributor. NOTE: Inspection by your Subaru distributor is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## H: DTC 31 THROTTLE POSITION SENSOR

### • DIAGNOSIS:

- The throttle position sensor signal is abnormal.
- The throttle position sensor is installed abnormally.
- The harness connector between ECM and throttle position sensor is in short or open.


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0939

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR.</b> 1)Disconnect connector from ECM and throttle position sensor. 2)Measure resistance between ECM and throttle position sensor. <i>Connector &amp; terminal</i> (B136) No. 16 — (E13) No. 2: (B136) No. 17 — (E13) No. 3: (B136) No. 15 — (E13) No. 4:	Is the resistance less than 1 $\Omega$ ?	Go to step 2.	Repair open circuit between ECM and throttle position sensor.
<b>2 CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</b> 1)Disconnect connector from TCM. (AT vehicle) 2)Measure resistance between ECM and chassis ground. <i>Connector &amp; terminal</i> (B136) No. 16 — Chassis ground: (B136) No. 17 — Chassis ground: (B136) No. 15 — Chassis ground:	Is the resistance more than 1 M $\Omega$ ?	Go to step 3.	Repair ground short circuit between ECM and chassis ground.
<b>3 CHECK INPUT SIGNAL FOR ECM.</b> 1)Connect connector to ECM and throttle position sensor. 2)Ignition switch to ON. 3)Measure voltage between ECM terminals while throttle valve is fully closed. <i>Connector &amp; terminal</i> (B136) No. 17 — No. 15:	Is the voltage less than 0.1 V?	Go to step 5.	Go to step 4.
<b>4 CHECK INPUT SIGNAL FROM ECM.</b> Measure voltage between ECM terminals while throttle valve is fully opened. <i>Connector &amp; terminal</i> (B136) No. 17 — No. 15:	Is the voltage more than 4.5 V?	Go to step 5.	Go to step 6.
<b>5 CHECK POOR CONTACT.</b> Check poor contact in throttle position sensor connector.	Is there poor contact in throttle position sensor connector?	Repair poor contact in throttle position sensor connector.	Replace throttle position sensor.
<b>6 CHECK CONDITION OF THROTTLE POSITION SENSOR INSTALLATION.</b>	Are the throttle position sensor installing screw tightened securely?	Replace throttle position sensor.	Adjust throttle position sensor and tighten throttle position sensor installing screws securely.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### I: DTC 32 OXYGEN SENSOR

#### • DIAGNOSIS:

- The oxygen sensor is not in function.
- The harness connector between ECM and oxygen sensor is in short or open.


#### • TROUBLE SYMPTOM:

- Failure of engine to start
- Erroneous idling
- Poor driving performance
- Engine stalls.
- Idle mixture is out of specifications.

#### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

#### • WIRING DIAGRAM:



EN0940

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	<p><b>CHECK FOR OTHER CAUSES AFFECTING EXHAUST GAS.</b></p> <p>NOTE:</p> <ul style="list-style-type: none"> <li>•Check for use of improper fuel.</li> <li>•Check if engine oil or coolant level is extremely low.</li> </ul>	Is CO% more than 2% after engine warm up?	Check fuel system.	Go to step 2.
2	<p><b>CHECK EXHAUST SYSTEM.</b></p>	Is there a fault in exhaust system?	Repair exhaust system. NOTE: <ul style="list-style-type: none"> <li>• Loose installation of front portion of exhaust pipe onto cylinder heads</li> <li>• Loose connection between front exhaust pipe and front catalytic converter</li> <li>• Damage of exhaust pipe resulting in hole</li> </ul>	Go to step 3.
3	<p><b>CHECK INPUT VOLTAGE FOR OXYGEN SENSOR.</b></p> <p>1)Disconnect connector from oxygen sensor connector.                      2)Measure voltage between main relay and oxygen sensor.</p> <p><b>Connector &amp; terminal</b>  <b>(B18) No. 2 (+) — Chassis ground (-):</b></p>	Is the voltage more than 10 V?	Go to step 4.	Repair open circuit between main relay and oxygen sensor.
4	<p><b>CHECK HARNESS CONNECTOR BETWEEN OXYGEN SENSOR AND ENGINE GROUND TERMINAL.</b></p> <p>Measure resistance between oxygen sensor and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B18) No. 1 — Chassis ground:</b></p>	Is the resistance less than 1Ω?	Go to step 5.	Repair open circuit between oxygen sensor and chassis ground.
5	<p><b>CHECK OXYGEN SENSOR.</b></p> <p>Measure resistance between oxygen sensor terminals.</p> <p><b>Connector &amp; terminal</b>  <b>No. 1 — No. 2:</b></p>	Is the resistance less than 30 Ω?	Repair poor contact.	Go to step 6.
6	<p><b>CHECK HARNESS BETWEEN ECM AND OXYGEN SENSOR.</b></p> <p>1)Disconnect connector from ECM.                      2)Measure resistance between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 7 — Chassis ground:</b></p>	Is the resistance more than 1 MΩ?	Go to step 7.	Repair ground short circuit between ECM and chassis ground.
7	<p><b>CHECK HARNESS BETWEEN ECM AND OXYGEN SENSOR.</b></p> <p>1)Ignition switch to ON.                      2)Measure voltage between ECM and chassis ground.</p> <p><b>Connector &amp; terminal</b>  <b>(B136) No. 7 (+) — Chassis ground (-):</b></p>	Is the voltage more than 0.2 V?	Go to step 8.	Repair battery short circuit between ECM and oxygen sensor.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
8	<b>CHECK INPUT VOLTAGE FOR ECM.</b> 1)Connect connector to ECM and oxygen sensor. 2)Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 7 (+) — Chassis ground (-):</b>	Do 0.1 and 1 V waveform patterns alternately appear on the oscilloscope screen?	Go to step 9.	Replace oxygen sensor.
9	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Replace oxygen sensor connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>





# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## J: DTC 33 VEHICLE SPEED SIGNAL

### • DIAGNOSIS:

- The vehicle speed signal is abnormal.
- The harness connector between ECM and vehicle speed sensor is in short or open.


### • TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0941

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1	<b>CHECK SPEEDOMETER OPERATION IN COMBINATION METER.</b> Does speedometer operate normally?	Go to step 2.	Check speedometer and vehicle speed sensor.
2	<b>CHECK INPUT SIGNAL FOR ECM.</b> 1)Lift-up the vehicle. 2)Set the positive (+) terminal and earth lead of oscilloscope at ECM connector terminals. <b>Connector &amp; terminal</b> <b>(B135) No. 24 (+) — Chassis ground (-):</b> 1)Start the engine. 2)Shift on the gear position, and put the vehicle at constant speed. 3)Measure signal voltage indicated on oscilloscope.	Go to step 3.	Go to step 4.
3	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Repair poor contact in ECM.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>
4	<b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b> Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 24 (+) — Chassis ground (-):</b>	Repair harness and connector. NOTE: In this case, repair the following: Battery short circuit in harness between ECM and combination meter connector	Go to step 5.
5	<b>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.</b> 1)Turn ignition switch to OFF. 2)Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 24 — Chassis ground:</b>	Repair ground short circuit in harness between ECM and combination meter connector.	Go to step 6.
6	<b>CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Repair poor contact in ECM.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## K: DTC 35 PURGE CONTROL SOLENOID VALVE

### • DIAGNOSIS:

- The purge control solenoid valve is not in function.
- The harness connector between ECM and purge control solenoid valve is in short or open.


### • TROUBLE SYMPTOM:

- Erroneous idling

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0942

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK OPERATION SOUND OF PURGE CONTROL SOLENOID VALVE.</b> 1) Turn ignition switch to OFF. 2) Connect test mode connector. 3) Turn ignition switch to ON. 4) Make sure that the ON/OFF operating sound of purge control solenoid valve occurs at about 10 Hz.	Does purge control solenoid valve produce operating sound?	Go to step 2.	Go to step 3.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect test mode connector. 3) Disconnect connector from purge control solenoid valve. 4) Turn ignition switch to ON. 5) Measure voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B134) No. 2 (+) — Chassis ground (-):</i>	Is the voltage more than 10 V?	Repair battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace ECM.	Go to step 4.
<b>4 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM. 3) Measure resistance of harness between ECM and purge control solenoid valve of harness connector. <i>Connector &amp; terminal</i> <i>(B134) No. 2 — (E4) No. 2:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 5.	Repair open circuit in harness between ECM and purge control solenoid valve connector.
<b>5 CHECK PURGE CONTROL SOLENOID VALVE.</b> 1) Remove purge control solenoid valve. 2) Measure resistance between purge control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i>	Is the resistance between 23 and 27 $\Omega$ ?	Go to step 6.	Replace purge control solenoid valve. <Ref. to EC(SOHCw/oOBD)-8, Purge Control Solenoid Valve.>
<b>6 CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.</b> 1) Turn ignition switch to ON. 2) Measure voltage between purge control solenoid valve and engine ground. <i>Connector &amp; terminal</i> <i>(E4) No. 1 (+) — Engine ground (-):</i>	Is the voltage more than 10 V?	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between main relay and purge control solenoid valve connector</li> <li>• Poor contact in main relay connector</li> <li>• Poor contact in coupling connector (B22)</li> </ul>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
7	<b>CHECK POOR CONTACT.</b> Check poor contact in purge control solenoid valve connector.	Is there poor contact in purge control solenoid valve connector?	Repair poor contact in purge control solenoid valve connector.	Contact with your Subaru distributor. <b>NOTE:</b> Inspection by your Subaru distributor is required, because probable cause is deterioration of multiple parts.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## L: DTC 38 TORQUE CONTROL SIGNAL


### • DIAGNOSIS:

- Abnormal signal entered from TCM
- The harness connector between ECM and TCM is in short.

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN1033

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> 1)Disconnect connectors from ECM and TCM. 2)Measure resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 17 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and TCM connector.	Go to step 2.
2	<b>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.</b> Measure resistance of harness between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 16 — Chassis ground:</b>	Is there resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and TCM connector.	Replace TCM. <Ref. to AT-44, Transmission Control Module (TCM).>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## M: DTC 45 PRESSURE SENSOR

**DIAGNOSIS:**

- The pressure sensor signal is abnormal.
- The harness connector between ECM and pressure sensor is in short or open.


**TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

**WIRING DIAGRAM:**



EN0938

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1)Disconnect connector from pressure sensor. 2)Turn ignition switch to ON. 3)Measure voltage between pressure sensor connector and engine ground. <b>Connector &amp; terminal</b> <b>(E20) No. 3 (+) — Engine ground (-):</b>	Is the voltage between 4.5 and 5.5 V?	Go to step 2.	Repair open or ground short circuit in harness between ECM and pressure sensor.
<b>2 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> 1)Disconnect connector from ECM. 2)Measure resistance of harness between ECM and pressure sensor connector. <b>Connector &amp; terminal</b> <b>(B136) No. 16 — (E20) No. 1:</b> <b>(B136) No. 5 — (E20) No. 4:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 3.	Repair open circuit in harness between ECM and pressure sensor connector.
<b>3 CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 5 — Chassis ground:</b> <b>(B136) No. 16 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 4.	Repair ground short circuit in harness between ECM and pressure sensor connector.
<b>4 CHECK INPUT SIGNAL FOR ECM.</b> 1)Turn ignition switch to OFF. 2)Connect connector to ECM and pressure sensor. 3)Turn ignition switch to ON. 4)Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 5 (+) — Chassis ground (-):</b>	Is the voltage between 2.3 and 2.5 V?	Go to step 5.	Replace pressure sensor. <Ref. to FU(SOHCw/oOBD)-34, Intake Air Temperature and Pressure Sensor.>
<b>5 CHECK INPUT SIGNAL FOR ECM.</b> 1)Start engine, and idle it. 2)Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 5 (+) — Chassis ground (-):</b>	Is the voltage between 1.2 and 1.8 V?	Go to step 6.	Replace pressure sensor. <Ref. to FU(SOHCw/oOBD)-34, Intake Air Temperature and Pressure Sensor.>
<b>6 CHECK POOR CONTACT.</b> Check poor contact in pressure sensor connector.	Is there poor contact in pressure sensor connector?	Repair poor contact in pressure sensor connector.	Replace pressure sensor. <Ref. to FU(SOHCw/oOBD)-34, Intake Air Temperature and Pressure Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## N: DTC 46 CO RESISTOR (GENERAL SPEC. VEHICLES)

### • DIAGNOSIS:

- The CO resistor signal is abnormal.
- The harness connector between ECM and CO resistor is in short or open.
- The CO value is not adjusted to specifications.


### • TROUBLE SYMPTOM:

- Erroneous idling
- Mixture ratio is too rich or too lean.

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0943

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 12 (+) — Chassis ground (-):</b>	Is the voltage between 0.5 and 4.5 V?	Go to step 3.	Go to step 2.
<b>2 CHECK POOR CONTACT.</b>	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>
<b>3 CHECK HARNESS BETWEEN CO RESISTOR AND ECM CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from ECM and CO resistor. 3) Measure resistance of harness between ECM and CO resistor connector. <b>Connector &amp; terminal</b> <b>(B136) No. 15 — (B155) No. 3:</b> <b>(B136) No. 12 — (B155) No. 2:</b> <b>(B136) No. 16 — (B155) No. 1:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair open circuit in harness between ECM and CO resistor connector.
<b>4 CHECK HARNESS BETWEEN CO RESISTOR AND ECM CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B136) No. 15 — Chassis ground:</b> <b>(B136) No. 12 — Chassis ground:</b> <b>(B136) No. 16 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 5.	Repair short circuit in harness between ECM and CO resistor connector.
<b>5 CHECK CO RESISTOR.</b> Measure resistance between CO resistor terminals. <b>Terminals</b> <b>No. 1 — No. 3:</b>	Is the resistance between 4 and 6 k $\Omega$ ?	Go to step 6.	Replace CO resistor.
<b>6 CHECK CO RESISTOR.</b> Measure variable resistance between CO resistor terminals while rotating the screw of CO resistor. <b>Terminals</b> <b>No. 1 — No. 2:</b>	Is the resistance between 0 and 6 k $\Omega$ ?	Replace ECM.	Replace CO resistor. <b>NOTE:</b> Ensure resistance varies in response to screw rotation.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## O: DTC 51 NEUTRAL POSITION SWITCH (MT VEHICLE)

### • DIAGNOSIS:

- The neutral position switch signal is abnormal.
- The harness connector between ECM and neutral position switch is in short or open.


### • TROUBLE SYMPTOM:

- Erroneous idling

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0888

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 26 (+) — Chassis ground (-):</i>	Is the voltage between 4.5 and 5.5 V in neutral position?	Go to step 3.	Go to step 2.
<b>2 CHECK INPUT SIGNAL FOR ECM.</b> Measure voltage between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 26 (+) — Chassis ground (-):</i>	Is the voltage less than 1 V in other positions?	Go to step 3.	Go to step 4.
<b>3 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>
<b>4 CHECK NEUTRAL POSITION SWITCH.</b> 1) Turn ignition switch to OFF. 2) Disconnect connector from transmission harness. 3) Measure resistance between transmission harness and connector terminals. <i>Connector &amp; terminal</i> <i>(T2) No. 1 — No. 2:</i>	Is the resistance more than 1 M $\Omega$ in neutral position?	Go to step 5.	Repair short circuit in transmission harness or replace neutral position switch.
<b>5 CHECK NEUTRAL POSITION SWITCH.</b> Measure resistance between transmission harness connector terminals. <i>Connector &amp; terminal</i> <i>(T2) No. 1 — No. 2:</i>	Is the resistance less than 10 $\Omega$ in other positions?	Go to step 6.	Repair open circuit in transmission harness or replace neutral position switch.
<b>6 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR.</b> 1) Disconnect connector from ECM. 2) Measure resistance of harness between ECM and transmission harness connector. <i>Connector &amp; terminal</i> <i>(B135) No. 26 — (B25) No. 1:</i>	Is the resistance less than 1 $\Omega$ ?	Go to step 7.	Repair open circuit in harness between ECM and transmission harness connector.
<b>7 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR.</b> Measure resistance between ECM and chassis ground. <i>Connector &amp; terminal</i> <i>(B135) No. 26 — Chassis ground:</i>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and transmission harness connector.	Go to step 8.
<b>8 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## ENGINE (DIAGNOSTICS)

### P: DTC 51 PARK/NEUTRAL POSITION SWITCH (AT VEHICLE)

**DIAGNOSIS:**

- The park/neutral position switch signal is abnormal.
- The shift cable is connected abnormally.
- The harness connector between ECM/TCM and inhibitor switch is in short or open.


**TROUBLE SYMPTOM:**

- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

**WIRING DIAGRAM:**



B2M4207

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK INPUT SIGNAL FOR ECM.</b> 1) Turn ignition switch to ON. 2) Measure voltage between ECM and chassis ground in selector lever "N" and "P" positions. <b>Connector &amp; terminal</b> <b>(B135) No. 26 (+) — Chassis ground (-):</b>	Is the voltage less than 1 V?	Go to step 2.	Go to step 3.
<b>2 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Go to step 3.
<b>3 CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR.</b> 1) Turn ignition switch to OFF. 2) Disconnect connectors from ECM and inhibitor switch. 3) Measure resistance of harness between ECM and inhibitor switch connector. <b>Connector &amp; terminal</b> <b>(B135) No. 26 — (T7) No. 12:</b>	Is the resistance less than 1 $\Omega$ ?	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> <li>• Open circuit in harness between ECM and inhibitor switch connector</li> <li>• Poor contact in coupling connector (B12)</li> <li>• Poor contact in inhibitor switch connector</li> <li>• Poor contact in ECM connector</li> </ul>
<b>4 CHECK INHIBITOR SWITCH GROUND LINE.</b> Measure resistance of harness between inhibitor switch connector and engine ground. <b>Connector &amp; terminal</b> <b>(T7) No. 12 — Engine ground:</b>	Is the resistance less than 5 $\Omega$ ?	Go to step 5.	Repair open circuit in inhibitor switch ground line.
<b>5 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.</b> Measure resistance of harness between ECM connector and chassis ground. <b>Connector &amp; terminal</b> <b>(B135) No. 26 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Repair ground short circuit in harness between ECM and transmission harness connector.	Go to step 6.
<b>6 CHECK POOR CONTACT.</b> Check poor contact in ECM connector.	Is there poor contact in ECM connector?	Repair poor contact in ECM connector.	Replace ECM. <Ref. to FU(SOHCw/oOBD)-44, Engine Control Module.>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

## Q: DTC 85 CHARGE SYSTEM

### • DIAGNOSIS:

- Power source voltage of the ECM is low or high.


### • TROUBLE SYMPTOM:

- Charge warning light comes on.

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY and INSPECTION MODES. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> and <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.>

### • WIRING DIAGRAM:



EN0944

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK GENERATOR.</b> 1)Start engine. 2)Idling after warm-up. 3)Measure voltage between generator B terminal and chassis ground. <i>Terminal</i> <b>Generator B terminal (+) — Chassis ground (-):</b>	Is the voltage between 10.8 V and 16.2 V?	Go to step 2.	Repair generator. <Ref. to SC-12, Generator.>
<b>2 CHECK GENERATOR.</b> 1)Run engine at 5,000 rpm. 2)Measure voltage between generator B terminal and chassis gorund. <i>Terminal</i> <b>Generator B terminal (+) — Chassis ground (-):</b>	Is the voltage between 10.8 V and 16.2 V?	Go to step 3.	Repair generator. <Ref. to SC-12, Generator.>
<b>3 CHECK BATTERY TERMINAL.</b> Turn ignition switch to OFF.	Are the positive and negative battery terminals tightly clamped?	Go to step 4.	Tighten the clamp of terminal.
<b>4 CHECK INPUT VOLTAGE OF ECM.</b> 1)Run the engine at idle. 2)Measure voltage between ECM connector and chassis ground. <i>Connector &amp; terminal</i> <b>(B136) No. 1 (+) — Chassis ground (-):</b> <b>(B136) No. 2 (+) — Chassis ground (-):</b>	Is the voltage between 10.8 V and 16.2 V?	Go to step 5.	Repair harness connector between battery, main relay and ECM.
<b>5 CHECK POOR CONTACT IN CONNECTORS.</b>	Is there poor contact in connectors between generator, battery and ECM?	Repair connector.	Go to step 6.
<b>6 CHECK ECM.</b> 1)Connect all connectors. 2)Erase the memory. <Ref. to EN(SOHCw/oOBD)-30, OPERATION, Clear Memory Mode.> 3)Perform inspection mode. <Ref. to EN(SOHCw/oOBD)-28, OPERATION, Inspection Mode.> 4)Read out the trouble code. <Ref. to EN(SOHCw/oOBD)-26, OPERATION, Read Diagnostic Trouble Code.>	Is the same trouble code as in the current diagnosis still being output?	Replace generator.	Go to step 7.
<b>7 CHECK ANY OTHER TROUBLE CODES APPEARANCE.</b>	Are other trouble codes being output?	Proceed with the diagnosis corresponding to the trouble code.	A temporary poor contact.

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

## 15. General Diagnostic Table

### A: INSPECTION

NOTE:

- Malfunction of parts other than those listed is also possible.
- The right-hand priority column indicates the inspection priority of probable causes of the symptom. Carry out the check starting from A.

Symptom	Problem parts	Priority
1. Engine does not start. (internal combustion does not occur.)	1) ECM power supply	A
	2) Engine ground terminal	A
	3) Crankshaft position sensor	B
	4) Camshaft position sensor	B
	5) Fuel pump	B
	6) Pressure regulator	B
	7) Ignition coil & ignitor	C
	8) Spark plug	C
	9) Fuel injector	C
2. Engine does not start. (internal combustion occurs.)	1) ECM power supply	A
	2) Spark plug	A
	3) Engine coolant temperature sensor	B
	4) Pressure regulator	B
	5) Pressure sensor	C
	6) Fuel pump	C
	7) Fuel injector	C
	8) Camshaft position sensor	C
	9) Crankshaft position sensor	C
	10) Idle air control solenoid valve	C
3. Engine does not start. (engine stalls after internal combustion.)	1) ECM power supply	A
	2) Pressure sensor	A
	3) Engine coolant temperature sensor	B
	4) Spark plug	B
	5) Ignition coil	C
	6) Fuel pump	C
	7) Pressure regulator	C
	8) Fuel injector	C
	9) Idle air control solenoid valve	C
4. Engine stalls.	1) Idle air control solenoid valve	A
	2) Pressure sensor	B
	3) Spark plug	B
	4) Accelerator cable is out of adjustment	B
	5) ECM power supply	C
	6) Throttle position sensor	C
	7) Crankshaft position sensor	C
	8) Vehicle speed sensor	C
	9) Ignition coil	C
	10) Fuel pump	C

# GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

Symptom	Problem parts	Priority
5. Rough idling	1) Spark plug	A
	2) Pressure sensor	B
	3) Engine coolant temperature sensor	B
	4) Pressure regulator	B
	5) Idle air control solenoid valve	B
	6) Air leak in air intake system	B
	7) ECM power supply	C
	8) Throttle position sensor	C
	9) Camshaft position sensor	C
	10) Crankshaft position sensor	C
	11) Oxygen sensor	C
	12) Fuel pump	C
	13) Fuel injector	C
	14) Test mode or read memory connectors are connected.	C
	15) Intake air temperature sensor	C
6. Hard to drive at constant speed	1) Pressure regulator	A
	2) Fuel injector	B
	3) Pressure sensor	C
	4) Engine coolant temperature sensor	C
	5) Throttle position sensor	C
	6) Fuel pump	C
7. Poor acceleration/deceleration	1) Spark plug	A
	2) Throttle position sensor	B
	3) Ignition coil	B
	4) Fuel pump	B
	5) Pressure regulator	B
	6) Fuel injector	B
	7) Pressure sensor	C
	8) Engine coolant temperature sensor	C
	9) Idle air control solenoid valve	C
	10) Knock sensor	C
8. Poor return to idling	1) Accelerator cable is out of adjustment	A
	2) Throttle position sensor	B
	3) Idle air control solenoid valve	B
	4) Pressure sensor	C
	5) Engine coolant temperature sensor	C
9. Back fire	1) Spark plug	A
	2) Fuel injector	B
	3) Ignition coil and ignitor	C
	4) Fuel pump	C
	5) Pressure regulator	C
10. Knocking	1) Pressure sensor	A
	2) Fuel pump	B
	3) Knock sensor	B
	4) Pressure regulator	B
	5) Engine coolant temperature sensor	C
11. Excessive fuel consumption	1) Pressure sensor	A
	2) Pressure regulator	B
12. Shocks while driving	1) Pressure regulator	A
	2) ECM power supply	B
	3) Throttle position sensor	B

# GENERAL DIAGNOSTIC TABLE

## ENGINE (DIAGNOSTICS)

Symptom	Problem parts	Priority
13. Poor engine revving	1) Pressure regulator 2) Pressure sensor 3) Engine coolant temperature sensor 4) Throttle sensor 5) Fuel pump	A B B B B
14. Remarks	1) ECM power supply 2) Pressure sensor 3) Pressure regulator 4) Idle air control solenoid valve 5) Air leak in air intake system	A* B* B* B* B*

A\*: Including ECM ground circuit

B\*: Check hoses.