

BASIC DIAGNOSTIC PROCEDURE

ENGINE (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

1. ENGINE

Step	Check	Yes	No
1 CHECK ENGINE START FAILURE. 1)Ask the customer when and how trouble occurred using the interview check list. <Ref. to EN(STi)-3, CHECK, Check List for Interview.> 2)Start the engine.	Does the engine start?	Go to step 2.	Inspection using "Diagnostics for Engine Start Failure". <Ref. to EN(STi)-54, Diagnostics for Engine Starting Failure.>
2 CHECK ILLUMINATION OF MALFUNCTION INDICATOR LIGHT.	Does the malfunction indicator light illuminate?	Go to step 3.	Inspection using "General Diagnostics Table". <Ref. to EN(STi)-359, General Diagnostic Table.>
3 CHECK INDICATION OF DTC ON DISPLAY. 1)Turn the ignition switch to OFF. 2)Connect the Subaru Select Monitor or OBD-II general scan tool to data link connector. 3)Turn the ignition switch to ON and the Subaru Select Monitor or OBD-II general scan tool switch to ON. 4)Read the DTC on Subaru Select Monitor or OBD-II general scan tool.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC?	Record the DTC code. Repair the trouble cause. <Ref. to EN(STi)-66, List of Diagnostic Trouble Code (DTC).> Go to step 4.	Repair the related parts. NOTE: If a DTC is not shown on display although malfunction indicator light illuminates, perform diagnostics of malfunction indicator light circuit or combination meter. <Ref. to EN(STi)-45, Malfunction Indicator Light.>
4 PERFORM THE DIAGNOSIS. 1)Perform the clear memory mode. <Ref. to EN(STi)-42, Clear Memory Mode.> 2)Perform the inspection mode. <Ref. to EN(STi)-35, Inspection Mode.>	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC?	Inspect using "Diagnostics Procedure with Diagnostic Trouble Code (DTC)". <Ref. to EN(STi)-73, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Complete the diagnosis.