


4. Front Ball Joint

A: REMOVAL

- 1) Remove the wheel.
- 2) Pull out the cotter pin from ball stud, remove the castle nut, and extract the ball stud from transverse link.
- 3) Remove the bolt securing ball joint to housing.



- 4) Extract the ball joint from housing.

B: INSTALLATION

- 1) Install the ball joint onto housing.

Tightening torque (Bolt):

50 N·m (5.1 kgf·m, 37 ft·lb)

CAUTION:

Do not apply grease to tapered portion of ball stud.

- 2) Connect the ball joint to transverse link.

Tightening torque (Castle nut):

STi model:

30 N·m (3.1 kgf·m, 22 ft·lb)

Except STi model:

40 N·m (4.1 kgf·m, 30 ft·lb)


- 3) Retighten the castle nut further within 60° until a slot in castle nut is aligned with the hole in ball stud end, then insert a new cotter pin and bend it around castle nut.

- 4) Install the front wheel.


C: INSPECTION

- 1) Measure the play of ball joint by the following procedures. Replace with a new one when the play exceeds specified value.

- (1) With 686 N (70 kgf, 154 lb) loaded in direction shown in the figure, measure the dimension \varnothing_1 .



- (2) With 686 N (70 kgf, 154 lb) loaded in opposite direction shown in the figure, measure the dimension \varnothing_2 .



- (3) Calculate plays from the following formula.

$$S = \varnothing_2 - \varnothing_1$$

- (4) When plays are larger than the following value, replace with a new one.

FRONT BALL JOINT

Specified play for replacement: S

Less than 0.3 mm (0.012 in)

- 2) When the play is smaller than specified value, visually inspect the dust cover.

- 3) The ball joint and cover that have been removed must be checked for wear, damage or cracks, and any defective part must be replaced.

- 4) If the dust cover is damaged, replace with a new ball joint.