

Check the fluid level on the outside of the reservoir. If the level is below "MIN", add the recommended brake fluid to "MAX".

Use only brake fluid from a sealed container.

■ **Changing the fluid**

Replace the brake fluid according to the maintenance schedule in the warranty and maintenance booklet. If the vehicle is subject to rough driving, or used on hilly roads or under other demanding conditions, replace the fluid more frequently than recommended in the maintenance schedule.

■ **Recommended brake fluid**

FMVSS No. 116, fresh DOT 3 or 4 brake fluid

Brake booster

■ **Checking brake booster operation**

If the brake booster does not operate as described below, have it checked by your SUBARU dealer.

1. With the engine off, depress the brake pedal several times, applying the same pedal force each time. The distance the pedal travels should not vary.
2. With the brake pedal depressed, start the engine. The pedal should move slightly down to the floor.
3. With the brake pedal depressed, stop the engine and keep the pedal depressed for 30 seconds. The pedal height should not change.