

## 5. Remote Controlled Rearview Mirror


### A: DIAGNOSTICS PROCEDURE

**5A1 : CHECK FUSE AND POWER SUPPLY FOR REMOTE CONTROLLED REARVIEW MIRROR SWITCH.**

- 1) Check fuse No. 3.
- 2) Disconnect connector of rearview mirror switch.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between rearview mirror switch connector and chassis ground.

**Connector & terminal**

**(i6) No. 4 (+) — Chassis ground (-):**




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 5A2.
- NO** : Replace fuse or repair wiring harness.

**5A2 : CHECK GROUND CIRCUIT OF REARVIEW MIRROR SWITCH.**

- 1) Disconnect connector of rearview mirror switch.
- 2) Measure resistance of harness connector between rearview mirror switch and chassis ground.

**Connector & terminal**

**(i6) No.2 (+) — Chassis ground (-):**



- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step 5A3.
- NO** : Repair wiring harness.

**5A3 : CHECK REARVIEW MIRROR SWITCH.**

Perform inspection of rearview mirror switch. <Ref. to 6-2 [W19B1].>

- CHECK** : Is rearview mirror switch normal?
- YES** : Go to step 5A4.
- NO** : Replace rearview mirror switch.


## 6-2b [T5A4] BODY ELECTRICAL SYSTEM (ELECTRICAL PARTS)

### 5. Remote Controlled Rearview Mirror

#### 5A4 : CHECK HARNESS CONNECTOR BETWEEN REARVIEW MIRROR SWITCH AND REARVIEW MIRROR (RH AND LH).

- 1) Disconnect connectors of rearview mirror switch and rearview mirror.
- 2) Measure resistance of harness connector between rearview mirror switch and rearview mirror.

##### Connector & terminal (i6) No. 1 — (D15) No. 1:




- CHECK** : Is the resistance less than 10 Ω? (RH side)
- YES** : Go to step 5A5.
- NO** : Repair wiring harness. Go to step 5A5.

#### 5A5 : CHECK HARNESS CONNECTOR BETWEEN REARVIEW MIRROR SWITCH AND REARVIEW MIRROR (RH AND LH).

Measure resistance of harness connector between rearview mirror switch and rearview mirror.

##### Connector & terminal (i6) No. 8 — (D15) No. 2:




- CHECK** : Is the resistance less than 10 Ω? (RH side)
- YES** : Go to step 5A6.
- NO** : Repair wiring harness. Go to step 5A6.

#### 5A6 : CHECK HARNESS CONNECTOR BETWEEN REARVIEW MIRROR SWITCH AND REARVIEW MIRROR (RH AND LH).

Measure resistance of harness connector between rearview mirror switch and rearview mirror.

##### Connector & terminal (i6) No. 6 — (D15) No. 3:




- CHECK** : Is the resistance less than 10 Ω? (RH side)
- YES** : Go to step 5A7.
- NO** : Repair wiring harness. Go to step 5A7.

**5A7 : CHECK HARNESS CONNECTOR BETWEEN REARVIEW MIRROR SWITCH AND REARVIEW MIRROR (RH AND LH).**

Measure resistance of harness connector between rearview mirror switch and rearview mirror.

**Connector & terminal**  
(i6) No. 1 — (D5) No. 1:



**CHECK** : Is the resistance less than 10 Ω? (LH side)


**YES** : Go to step 5A8.

**NO** : Repair wiring harness. Go to step 5A8.

**5A8 : CHECK HARNESS CONNECTOR BETWEEN REARVIEW MIRROR SWITCH AND REARVIEW MIRROR (RH AND LH).**

Measure resistance of harness connector between rearview mirror switch and rearview mirror.

**Connector & terminal**  
(i6) No. 9 — (D5) No. 2:



**CHECK** : Is the resistance less than 10 Ω? (LH side)


**YES** : Go to step 5A9.

**NO** : Repair wiring harness. Go to step 5A9.

**5A9 : CHECK HARNESS CONNECTOR BETWEEN REARVIEW MIRROR SWITCH AND REARVIEW MIRROR (RH AND LH).**

Measure resistance of harness connector between rearview mirror switch and rearview mirror.

**Connector & terminal**  
(i6) No. 7 — (D5) No. 3:



**CHECK** : Is the resistance less than 10 Ω? (LH side)

**YES** : Go to step 5A10.

**NO** : Repair wiring harness.

**5A10 : CHECK REARVIEW MIRROR MOTOR.**

Perform inspection of rearview mirror motor. <Ref. to 6-2 [W19B2].>

**CHECK** : Is rearview mirror motor normal?

**YES** : System circuit is normal.

**NO** : Replace rearview mirror assembly.