

16. Diagnostics Chart with Trouble Code for 2500 cc Models

A: DIAGNOSTIC TROUBLE CODE (DTC) LIST

DTC No.	Item	Index
P0101	Mass air flow sensor circuit range/performance problem (low input)	<Ref. to 2-7 [T16B0].>
P0102	Mass air flow sensor circuit low input	<Ref. to 2-7 [T16C0].>
P0103	Mass air flow sensor circuit high input	<Ref. to 2-7 [T16D0].>
P0106	Pressure sensor circuit range/performance problem	<Ref. to 2-7 [T16E0].>
P0107	Pressure sensor circuit low input	<Ref. to 2-7 [T16F0].>
P0108	Pressure sensor circuit high input	<Ref. to 2-7 [T16G0].>
P0116	Engine coolant temperature sensor circuit low input	<Ref. to 2-7 [T16H0].>
P0117	Engine coolant temperature sensor circuit high input	<Ref. to 2-7 [T16I0].>
P0121	Throttle position sensor circuit range/performance problem (high input)	<Ref. to 2-7 [T16J0].>
P0122	Throttle position sensor circuit low input	<Ref. to 2-7 [T16K0].>
P0123	Throttle position sensor circuit high input	<Ref. to 2-7 [T16L0].>
P0125	Insufficient coolant temperature for closed loop fuel control	<Ref. to 2-7 [T16M0].>
P0130	Front oxygen sensor circuit malfunction	<Ref. to 2-7 [T16N0].>
P0133	Front oxygen sensor circuit slow response	<Ref. to 2-7 [T16O0].>
P0135	Front oxygen sensor heater circuit low input	<Ref. to 2-7 [T16P0].>
P0136	Rear oxygen sensor circuit malfunction	<Ref. to 2-7 [T16Q0].>
P0139	Rear oxygen sensor circuit slow response	<Ref. to 2-7 [T16R0].>
P0141	Rear oxygen sensor heater circuit low input	<Ref. to 2-7 [T16S0].>
P0170	Fuel trim malfunction	<Ref. to 2-7 [T16T0].>
P0181	Fuel temperature sensor A circuit range/performance problem	<Ref. to 2-7 [T16U0].>
P0182	Fuel temperature sensor A circuit low input	<Ref. to 2-7 [T16V0].>
P0183	Fuel temperature sensor A circuit high input	<Ref. to 2-7 [T16W0].>
P0261	Fuel injector circuit low input - #1	<Ref. to 2-7 [T16X0].>
P0262	Fuel injector circuit high input - #1	<Ref. to 2-7 [T16AB0].>
P0264	Fuel injector circuit low input - #2	<Ref. to 2-7 [T16Y0].>

ON-BOARD DIAGNOSTICS II SYSTEM

[T16A0] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

DTC No.	Item	Index
P0265	Fuel injector circuit high input - #2	<Ref. to 2-7 [T16AC0].>
P0267	Fuel injector circuit low input - #3	<Ref. to 2-7 [T16Z0].>
P0268	Fuel injector circuit high input - #3	<Ref. to 2-7 [T16AD0].>
P0270	Fuel injector circuit low input - #4	<Ref. to 2-7 [T16AA0].>
P0271	Fuel injector circuit high input - #4	<Ref. to 2-7 [T16AE0].>
P0301	Cylinder 1 misfire detected	<Ref. to 2-7 [T16AF0].>
P0302	Cylinder 2 misfire detected	<Ref. to 2-7 [T16AG0].>
P0303	Cylinder 3 misfire detected	<Ref. to 2-7 [T16AH0].>
P0304	Cylinder 4 misfire detected	<Ref. to 2-7 [T16AI0].>
P0325	Knock sensor circuit malfunction	<Ref. to 2-7 [T16AJ0].>
P0335	Crankshaft position sensor circuit malfunction	<Ref. to 2-7 [T16AK0].>
P0336	Crankshaft position sensor circuit range/performance problem	<Ref. to 2-7 [T16AL0].>
P0340	Camshaft position sensor circuit malfunction	<Ref. to 2-7 [T16AM0].>
P0341	Camshaft position sensor circuit range/performance problem	<Ref. to 2-7 [T16AN0].>
P0400	Exhaust gas recirculation flow malfunction	<Ref. to 2-7 [T16AO0].>
P0403	Exhaust gas recirculation circuit low input	<Ref. to 2-7 [T16AP0].>
P0420	Catalyst system efficiency below threshold	<Ref. to 2-7 [T16AQ0].>
P0440	Evaporative emission control system malfunction	<Ref. to 2-7 [T16AR0].>
P0441	Evaporative emission control system incorrect purge flow	<Ref. to 2-7 [T16AS0].>
P0443	Evaporative emission control system purge control valve circuit low input	<Ref. to 2-7 [T16AT0].>
P0446	Evaporative emission control system vent control low input	<Ref. to 2-7 [T16AU0].>
P0451	Evaporative emission control system pressure sensor range/performance problem	<Ref. to 2-7 [T16AV0].>
P0452	Evaporative emission control system pressure sensor low input	<Ref. to 2-7 [T16AW0].>
P0453	Evaporative emission control system pressure sensor high input	<Ref. to 2-7 [T16AX0].>
P0461	Fuel level sensor circuit range/performance problem	<Ref. to 2-7 [T16AY0].>
P0462	Fuel level sensor circuit low input	<Ref. to 2-7 [T16AZ0].>
P0463	Fuel level sensor circuit high input	<Ref. to 2-7 [T16BA0].>

2-7 [T16A0]

ON-BOARD DIAGNOSTICS II SYSTEM

16. Diagnostics Chart with Trouble Code for 2500 cc Models

DTC No.	Item	Index
P0480	Cooling fan relay 1 circuit low input	<Ref. to 2-7 [T16BB0].>
P0483	Cooling fan function problem	<Ref. to 2-7 [T16BC0].>
P0500	Vehicle speed sensor malfunction	<Ref. to 2-7 [T16BD0].>
P0505	Idle control system malfunction	<Ref. to 2-7 [T16BE0].>
P0506	Idle control system RPM lower than expected	<Ref. to 2-7 [T16BF0].>
P0507	Idle control system RPM higher than expected	<Ref. to 2-7 [T16BG0].>
P0600	Serial communication link malfunction	<Ref. to 2-7 [T16BH0].>
P0601	Internal control module memory check sum error	<Ref. to 2-7 [T16BI0].>
P0703	Brake switch input malfunction	<Ref. to 2-7 [T16BJ0].>
P0705	Transmission range sensor circuit malfunction	<Ref. to 2-7 [T16BK0].>
P0710	Transmission fluid temperature sensor circuit malfunction	<Ref. to 2-7 [T16BL0].>
P0715	Torque converter turbine speed sensor circuit malfunction	<Ref. to 2-7 [T16BM0].>
P0720	Output speed sensor (vehicle speed sensor 2) circuit malfunction	<Ref. to 2-7 [T16BN0].>
P0725	Engine speed input circuit malfunction	<Ref. to 2-7 [T16BO0].>
P0731	Gear 1 incorrect ratio	<Ref. to 2-7 [T16BP0].>
P0732	Gear 2 incorrect ratio	<Ref. to 2-7 [T16BQ0].>
P0733	Gear 3 incorrect ratio	<Ref. to 2-7 [T16BR0].>
P0734	Gear 4 incorrect ratio	<Ref. to 2-7 [T16BS0].>
P0740	Torque converter clutch system malfunction	<Ref. to 2-7 [T16BT0].>
P0743	Torque converter clutch system (Duty solenoid B) electrical	<Ref. to 2-7 [T16BU0].>
P0748	Pressure control solenoid (Duty solenoid A) electrical	<Ref. to 2-7 [T16BV0].>
P0753	Shift solenoid A (Shift solenoid 1) electrical	<Ref. to 2-7 [T16BW0].>
P0758	Shift solenoid B (Shift solenoid 2) electrical	<Ref. to 2-7 [T16BX0].>
P1100	Starter switch circuit low input	<Ref. to 2-7 [T16BY0].>
P1101	Neutral position switch circuit malfunction [MT vehicles]	<Ref. to 2-7 [T16BZ0].>
P1101	Neutral position switch circuit high input [AT vehicles]	<Ref. to 2-7 [T16CA].>
P1102	Pressure sources switching solenoid valve circuit low input	<Ref. to 2-7 [T16CB0].>

ON-BOARD DIAGNOSTICS II SYSTEM

[T16A0] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

DTC No.	Item	Index
P1103	Engine torque control signal circuit 1 malfunction	<Ref. to 2-7 [T16CC0].>
P1106	Engine torque control signal circuit 2 malfunction	<Ref. to 2-7 [T16CD0].>
P1115	Engine torque control cut signal circuit high input	<Ref. to 2-7 [T16CE0].>
P1116	Engine torque control cut signal circuit low input	<Ref. to 2-7 [T16CF0].>
P1120	Starter switch circuit high input	<Ref. to 2-7 [T16CG0].>
P1121	Neutral position switch circuit low input [AT vehicles]	<Ref. to 2-7 [T16CH0].>
P1122	Pressure sources switching solenoid valve circuit high input	<Ref. to 2-7 [T16CI0].>
P1141	Mass air flow sensor circuit range/performance problem (high input)	<Ref. to 2-7 [T16CJ0].>
P1142	Throttle position sensor circuit range/performance problem (low input)	<Ref. to 2-7 [T16CK0].>
P1143	Pressure sensor circuit range/performance problem (low input)	<Ref. to 2-7 [T16CL0].>
P1144	Pressure sensor circuit range/performance problem (high input)	<Ref. to 2-7 [T16CM0].>
P1150	Front oxygen sensor heater circuit high input	<Ref. to 2-7 [T16CN0].>
P1151	Rear oxygen sensor heater circuit high input	<Ref. to 2-7 [T16CO0].>
P1400	Fuel tank pressure control solenoid valve circuit low input	<Ref. to 2-7 [T16CP0].>
P1420	Fuel tank pressure control solenoid valve circuit high input	<Ref. to 2-7 [T16CQ0].>
P1421	Exhaust gas recirculation circuit high input	<Ref. to 2-7 [T16CR0].>
P1422	Evaporative emission control system purge control valve circuit high input	<Ref. to 2-7 [T16CS0].>
P1423	Evaporative emission control system vent control high input	<Ref. to 2-7 [T16CT0].>
P1440	Fuel tank pressure control system function problem (low input)	<Ref. to 2-7 [T16CU0].>
P1441	Fuel tank pressure control system function problem (high input)	<Ref. to 2-7 [T16CV0].>
P1442	Fuel level sensor circuit range/performance problem 2	<Ref. to 2-7 [T16CW0].>
P1443	Evaporative emission control system vent control function problem	<Ref. to 2-7 [T16CX0].>
P1507	Idle control system malfunction (fail-safe)	<Ref. to 2-7 [T16CY0].>
P1520	Cooling fan relay 1 circuit high input	<Ref. to 2-7 [T16CZ0].>
P1540	Vehicle speed sensor malfunction 2	<Ref. to 2-7 [T16DA0].>
P1700	Throttle position sensor circuit malfunction for automatic transmission	<Ref. to 2-7 [T16DB0].>
P1701	Cruise control set signal circuit malfunction for automatic transmission	<Ref. to 2-7 [T16DC0].>

2-7 [T16A0]**ON-BOARD DIAGNOSTICS II SYSTEM**16. Diagnostics Chart with Trouble Code for 2500 cc Models

DTC No.	Item	Index
P1702	Automatic transmission diagnosis input signal circuit low input	<Ref. to 2-7 [T16DD0].>
P1703	Low clutch timing control solenoid valve circuit malfunction	<Ref. to 2-7 [T16DE0].>
P1704	2-4 brake timing control solenoid valve circuit malfunction	<Ref. to 2-7 [T16DF0].>
P1705	2-4 brake pressure control solenoid valve (Duty solenoid D) circuit malfunction	<Ref. to 2-7 [T16DG0].>
P1722	Automatic transmission diagnosis input signal circuit high input	<Ref. to 2-7 [T16DH0].>
P1742	Automatic transmission diagnosis input signal circuit malfunction	<Ref. to 2-7 [T16DI0].>


B: DTC P0101 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

NOTE:

Check mass air flow sensor circuit.

<Ref. to 2-7 [T16B0].>

● **WIRING DIAGRAM:**



B2M1821


C: DTC P0102 — MASS AIR FLOW SENSOR CIRCUIT LOW INPUT —

NOTE:

Check mass air flow sensor circuit.

<Ref. to 2-7 [T16C0].>

● **WIRING DIAGRAM:**



B2M1821


D: DTC P0103 — MASS AIR FLOW SENSOR CIRCUIT HIGH INPUT —

NOTE:

Check mass air flow sensor circuit.

<Ref. to 2-7 [T16D0].>

● WIRING DIAGRAM:



B2M1821


E: DTC P0106 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M1822

16E1 : CHECK ANY OTHER DTC ON DISPLAY.


NOTE:

In this case, it is not necessary to inspect DTC P0106.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0107, P0108, P1102 or P1122?
- YES** : Inspect DTC P0107, P0108, P1102 or P1122 using "16. Diagnostics Chart with Trouble Code for 2500 cc Models". <Ref. to 2-7 [T16A0].>
- NO** : Go to step **16E2**.

16E2 : CHECK IDLE SWITCH SIGNAL.

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor to data link connector.



- 3) Turn ignition switch to ON and Subaru Select Monitor switch to ON.
- 4) Operate the LED operation mode for engine using Subaru Select Monitor.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". <Ref. to 2-7 [T3C8].>

CHECK : *Does the LED of {Idle Switch Signal} come on?*

YES : Go to step 16E3.


NO : Check throttle position sensor circuit. <Ref. to 2-7 [T16K0].>

NOTE:

In this case, it is not necessary to inspect DTC P0106.

16E3 : CHECK DATA FOR CONTROL.

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.



- 3) Turn ignition switch ON and Subaru Select Monitor or the OBD-II general scan tool switch ON.
- 4) Start engine.
- 5) Read data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

CHECK : *Is the value more than 85 kPa (638 mmHg, 25.12 inHg)?*

YES : Go to step 16E6.

NO : Go to step 16E4.

16E4 : CHECK DATA FOR CONTROL.

Read data of atmospheric absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

CHECK : *Is the value less than 32 kPa (240 mmHg, 9.45 inHg)?*

YES : Go to step 16E7.

NO : Go to step 16E5.

16E5 : CHECK DATA FOR CONTROL.


Read data of atmospheric absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

- CHECK** : *Is the value more than 133 kPa (998 mmHg, 39.29 inHg)?*
- YES** : Replace pressure sensor. <Ref. to 2-7 [W11A0].>
- NO** : Repair poor contact in pressure sensor connector, pressure sources switching solenoid valve connector, and ECM connector.

16E6 : CHECK VACUUM HOSES.

Check the following items.


- Disconnection of the vacuum hose from pressure sources switching solenoid valve to intake manifold
- Holes in the vacuum hose between pressure sources switching solenoid valve to intake manifold
- Clogging of the vacuum hose between pressure sources switching solenoid valve to intake manifold
- Disconnection of the vacuum hose from pressure sensor to pressure sources switching solenoid valve
- Holes in the vacuum hose between pressure sensor and pressure sources switching solenoid valve
- Clogging of the vacuum hose between pressure sensor and pressure sources switching solenoid valve
- Clogging of the filter



- CHECK** : *Is there a fault in vacuum hose?*
- YES** : Repair or replace hoses or filter.
- NO** : Go to step **16E7**.

16E7 : CHECK PRESSURE SOURCES SWITCHING SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.



- 3) Turn ignition switch to ON.

NOTE:

Pressure sources switching solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to the "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : *Does pressure sources switching solenoid valve produce operating sound? (ON ⇔ OFF each 1.5 sec.)*
- YES** : Replace pressure sensor. <Ref. to 2-7 [W11A0].>
- NO** : Replace pressure sources switching solenoid valve. <Ref. to 2-7 [W13A0].>


F: DTC P0107 — PRESSURE SENSOR CIRCUIT LOW INPUT —

NOTE:

Check pressure sensor circuit.

<Ref. to 2-7 [T16F0].>

● **WIRING DIAGRAM:**



B2M1822


G: DTC P0108 — PRESSURE SENSOR CIRCUIT HIGH INPUT —

NOTE:

Check pressure sensor circuit.

<Ref. to 2-7 [T16G0].>

● **WIRING DIAGRAM:**



B2M1822


H: DTC P0116 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —

NOTE:

Check engine coolant temperature sensor circuit.

<Ref. to 2-7 [T16H0].>

● WIRING DIAGRAM:




I: DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT HIGH INPUT —

NOTE:

Check engine coolant temperature sensor circuit.

<Ref. to 2-7 [T1610].>

● **WIRING DIAGRAM:**




J: DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

NOTE:

Check throttle position sensor circuit.

<Ref. to 2-7 [T16J0].>

● WIRING DIAGRAM:



B2M0540


K: DTC P0122 — THROTTLE POSITION SENSOR CIRCUIT LOW INPUT —

NOTE:

Check throttle position sensor circuit.

<Ref. to 2-7 [T16K0].>

● **WIRING DIAGRAM:**



B2M0540


L: DTC P0123 — THROTTLE POSITION SENSOR CIRCUIT HIGH INPUT —

NOTE:

Check throttle position sensor circuit.

<Ref. to 2-7 [T16L0].>

● **WIRING DIAGRAM:**




M: DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —

NOTE:

Check insufficient coolant temperature for closed loop fuel control.

<Ref. to 2-7 [T16M0].>

● **WIRING DIAGRAM:**



S2M0328


N: DTC P0130 — FRONT OXYGEN SENSOR CIRCUIT MALFUNCTION —

NOTE:

Check front oxygen sensor circuit.

<Ref. to 2-7 [T16N0].>

● **WIRING DIAGRAM:**



B2M1823


O: DTC P0133 — FRONT OXYGEN SENSOR CIRCUIT SLOW RESPONSE —

NOTE:

Check front oxygen sensor circuit.

<Ref. to 2-7 [T1600].>

● **WIRING DIAGRAM:**



B2M1823


P: DTC P0135 — FRONT OXYGEN SENSOR HEATER CIRCUIT LOW INPUT

NOTE:

Check front oxygen sensor heater circuit.

<Ref. to 2-7 [T16P0].>

● WIRING DIAGRAM:



B2M1824


Q: DTC P0136 — REAR OXYGEN SENSOR CIRCUIT MALFUNCTION —

NOTE:

Check rear oxygen sensor circuit.

<Ref. to 2-7 [T16Q0].>

● **WIRING DIAGRAM:**



B2M2207


R: DTC P0139 — REAR OXYGEN SENSOR CIRCUIT SLOW RESPONSE —

NOTE:

Check rear oxygen sensor circuit.

<Ref. to 2-7 [T16R0].>

● **WIRING DIAGRAM:**



B2M2207

T: DTC P0170 — FUEL TRIM MALFUNCTION —

NOTE:

Check fuel trim control system.

<Ref. to 2-7 [T16T0].>


U: DTC P0181 — FUEL TEMPERATURE SENSOR A CIRCUIT RANGE/PERFORMANCE PROBLEM —

NOTE:

Check fuel temperature sensor circuit.

<Ref. to 2-7 [T16U0].>

● **WIRING DIAGRAM:**



B2M0916


V: DTC P0182 — FUEL TEMPERATURE SENSOR A CIRCUIT LOW INPUT —

NOTE:

Check fuel temperature sensor circuit.

<Ref. to 2-7 [T16V0].>

● WIRING DIAGRAM:



B2M0916


W: DTC P0183 — FUEL TEMPERATURE SENSOR A CIRCUIT HIGH INPUT —

NOTE:

Check fuel temperature sensor circuit.

<Ref. to 2-7 [T16W0].>

● **WIRING DIAGRAM:**



B2M0916

X: DTC P0261 — FUEL INJECTOR CIRCUIT LOW INPUT - #1 —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16AA0].

<Ref. to 2-7 [T16AA0].>

Y: DTC P0264 — FUEL INJECTOR CIRCUIT LOW INPUT - #2 —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16AA0].

<Ref. to 2-7 [T16AA0].>

Z: DTC P0267 — FUEL INJECTOR CIRCUIT LOW INPUT - #3 —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16AA0].

<Ref. to 2-7 [T16AA0].>


AA: DTC P0270 — FUEL INJECTOR CIRCUIT LOW INPUT - #4 —

NOTE:

Check fuel injector circuit.

<Ref. to 2-7 [T16X0].>

● WIRING DIAGRAM:



B2M1827

AB: DTC P0262 — FUEL INJECTOR CIRCUIT HIGH INPUT - #1 —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16AE0].

<Ref. to 2-7 [T16AE0].>

AC: DTC P0265 — FUEL INJECTOR CIRCUIT HIGH INPUT - #2 —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16AE0].

<Ref. to 2-7 [T16AE0].>

AD: DTC P0268 — FUEL INJECTOR CIRCUIT HIGH INPUT - #3 —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16AE0].

<Ref. to 2-7 [T16AE0].>


AE: DTC P0271 — FUEL INJECTOR CIRCUIT HIGH INPUT - #4 —

NOTE:

Check fuel injector circuit.

<Ref. to 2-7 [T16AB0].>

● **WIRING DIAGRAM:**



B2M1827

AF: DTC P0301 — CYLINDER 1 MISFIRE DETECTED —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16A10].

<Ref. to 2-7 [T16A10].>

AG: DTC P0302 — CYLINDER 2 MISFIRE DETECTED —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16A10].

<Ref. to 2-7 [T16A10].>

AH: DTC P0303 — CYLINDER 3 MISFIRE DETECTED —

NOTE:

For the diagnostic procedure, refer to 2-7 [T16A10].

<Ref. to 2-7 [T16A10].>


AI: DTC P0304 — CYLINDER 4 MISFIRE DETECTED —

NOTE:

Check fuel injection control system.

<Ref. to 2-7 [T16AF0].>

● WIRING DIAGRAM:



B2M2208


AJ: DTC P0325 — KNOCK SENSOR CIRCUIT MALFUNCTION —

NOTE:

Check knock sensor circuit.

<Ref. to 2-7 [T16AJ0].>

● **WIRING DIAGRAM:**




AK: DTC P0335 — CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —

NOTE:

Check crankshaft position sensor circuit.

<Ref. to 2-7 [T16AK0].>

● WIRING DIAGRAM:



B2M1294


AL: DTC P0336 — CRANKSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —

NOTE:

Check crankshaft position sensor circuit.

<Ref. to 2-7 [T16AL0].>

● WIRING DIAGRAM:



B2M1294


AM: DTC P0340 — CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION

NOTE:

Check camshaft position sensor circuit.

<Ref. to 2-7 [T16AM0].>

● WIRING DIAGRAM:



B2M1055


AN: DTC P0341 — CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —

NOTE:

Check camshaft position sensor circuit.

<Ref. to 2-7 [T16AN0].>

● WIRING DIAGRAM:



B2M1055


AO: DTC P0400 — EXHAUST GAS RECIRCULATION FLOW MALFUNCTION

NOTE:

Check exhaust gas recirculation control system.

<Ref. to 2-7 [T16A00].>

● WIRING DIAGRAM:



B2M2545


AP: DTC P0403 — EXHAUST GAS RECIRCULATION CIRCUIT LOW INPUT —

NOTE:

Check exhaust gas recirculation control solenoid valve circuit.

<Ref. to 2-7 [T16AP0].>

● **WIRING DIAGRAM:**




B2M2545

AQ: DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD

NOTE:

Check catalyst system.
<Ref. to 2-7 [T16AQ0].>

● **WIRING DIAGRAM:**



B2M2210


AR: DTC P0440 — EVAPORATIVE EMISSION CONTROL SYSTEM MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Gasoline smell

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16AR1 : CHECK ANY OTHER DTC ON DISPLAY.

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using "16. Diagnostics Chart with Trouble Code for 2500 cc Models". <Ref. to 2-7 [T16A0].>
- NO** : Go to step **16AR2**.

16AR2 : CHECK FUEL FILLER CAP.


- 1) Turn ignition switch to OFF.
 - 2) Open the fuel flap.
- CHECK** : *Is the fuel filler cap tightened securely?*
 - YES** : Tighten fuel filler cap securely.
 - NO** : Go to step **16AR3**.

16AR3 : CHECK FUEL FILLER PIPE PACKING.

- CHECK** : *Is there any damage to the seal between fuel filler cap and fuel filler pipe?*
- YES** : Repair or replace fuel filler cap and fuel filler pipe. <Ref. to 2-8 [W3A0].>
- NO** : Go to step **16AR4**.

16AR4 : CHECK DRAIN VALVE.


1) Connect test mode connector.



2) Turn ignition switch to ON.

NOTE:

Drain valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : *Does drain valve produce operating sound?*
- YES** : Go to step **16AR5**.
- NO** : Replace drain valve. <Ref. to 2-1 [W17A0].>

16AR5 : CHECK PURGE CONTROL SOLENOID VALVE.

NOTE:

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : *Does purge control solenoid valve produce operating sound?*
- YES** : Go to step **16AR6**.
- NO** : Replace purge control solenoid valve. <Ref. to 2-1 [W4A0].>

16AR6 : CHECK PRESSURE CONTROL SOLENOID VALVE.

NOTE:

Pressure control solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>



- CHECK** : *Does pressure control solenoid valve produce operating sound?*
- YES** : Go to step **16AR7**.
- NO** : Replace pressure control solenoid valve. <Ref. to 2-1 [W10A0].>

2-7 [T16AR7]

ON-BOARD DIAGNOSTICS II SYSTEM

16. Diagnostics Chart with Trouble Code for 2500 cc Models

16AR7 : CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.

Turn ignition switch to OFF.

- CHECK** : *Does fuel leak in fuel line?*
YES : Repair or replace fuel line. <Ref. to 2-8 [W7A0].>
NO : Go to step **16AR8**.

16AR8 : CHECK CANISTER.

- CHECK** : *Is there any damage at canister?*
YES : Repair or replace canister. <Ref. to 2-1 [W3A0].>
NO : Go to step **16AR9**.

16AR9 : CHECK FUEL TANK.

- CHECK** : *Is there any damage at fuel tank?*
YES : Repair or replace fuel tank. <Ref. to 2-8 [W2A0].>
NO : Go to step **16AR10**.

16AR10 : CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM.

- CHECK** : *Are there holes, cracks, clogging or disconnections of hoses or pipes in evaporative emission control system?*
YES : Repair or replace hoses or pipes.
NO : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.


**AS: DTC P0441 — EVAPORATIVE EMISSION CONTROL SYSTEM
INCORRECT PURGE FLOW —**

NOTE:

Check canister purge control system.

<Ref. to 2-7 [T16AS0].>

● **WIRING DIAGRAM:**



B2M1832


AT: DTC P0443 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW INPUT —

NOTE:

Check purge control solenoid valve circuit.

<Ref. to 2-7 [T16AT0].>

● **WIRING DIAGRAM:**



B2M1832

ON-BOARD DIAGNOSTICS II SYSTEM

[T16AT0] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


AU: DTC P0446 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

- **WIRING DIAGRAM:**




B2M1833

16AU1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 35 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 10 V?
YES : Go to step 16AU2.
NO : Go to step 16AU3.

16AU2 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in ECM connector?
YES : Repair poor contact in ECM connector.
NO : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)

NOTE:


In this case, repair the following:

- Poor contact in drain valve connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B97, B98 and R57)

16AU3 : CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from drain valve and ECM.
- 3) Measure resistance of harness between drain valve connector and chassis ground.

Connector & terminal
(R69) No. 2 — Chassis ground:



- CHECK** : Is the resistance less than 10 Ω?
YES : Repair ground short circuit in harness between ECM and drain valve connector.
NO : Go to step 16AU4.

2-7 [T16AU4]

ON-BOARD DIAGNOSTICS II SYSTEM


16. Diagnostics Chart with Trouble Code for 2500 cc Models

16AU4 : CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.

Measure resistance of harness between ECM and drain valve connector.

Connector & terminal

(B84) No. 35 — (R69) No. 2:



CHECK : Is the voltage less than 1 Ω?

YES : Go to step 16AU5.

NO : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and drain valve connector
- Poor contact in coupling connectors (B98 and R57)

16AU5 : CHECK DRAIN VALVE.

Measure resistance between drain valve terminals.

Terminals

No. 1 — No. 2:



CHECK : Is the resistance between 10 and 100 Ω?

YES : Go to step 16AU6.


NO : Replace drain valve. <Ref. to 2-1 [W17A0].>

16AU6 : CHECK POWER SUPPLY TO DRAIN VALVE.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between drain valve and chassis ground.

Connector & terminal

(R69) No. 1 (+) — Chassis ground (-):



CHECK : Is the voltage more than 10 V?

YES : Go to step 16AU7.

NO : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between main relay and drain valve
- Poor contact in coupling connectors (B97 and R57)
- Poor contact in main relay connector

16AU7 : CHECK POOR CONTACT.

Check poor contact in drain valve connector. <Ref. to FOREWORD [T3C1].>

CHECK : Is there poor contact in drain valve connector?

YES : Repair poor contact in drain valve connector.

NO : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.


AV: DTC P0451 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE PROBLEM —

NOTE:

Check fuel tank pressure control system.

<Ref. to 2-7 [T16AW0].>

● WIRING DIAGRAM:



B2M2213


AW: DTC P0452 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


- **WIRING DIAGRAM:**



B2M2213

16AW1 : CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.

- 1) Turn ignition switch to OFF.
- 2) Remove fuel filler cap.
- 3) Install fuel filler cap.
- 4) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.



- 5) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 6) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

NOTE:


- Subaru Select Monitor
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value less than -2.8 kPa (-21.0 mmHg, -0.827 inHg)?*
- YES** : Go to step 16AW2.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

16AW2 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 21 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 16AW4.
- NO** : Go to step 16AW3.

16AW3 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 21 (+) — Chassis ground (-):



- CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair poor contact in ECM connector.
- NO** : Contact with SOA service.


NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

16AW4 : CHECK INPUT SIGNAL FOR ECM.

Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 4 (+) — Chassis ground (-):



- CHECK** : Is the voltage less than 0.2 V?
- YES** : Go to step 16AW6.
- NO** : Go to step 16AW5.

16AW5 : CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)

Read data of fuel tank pressure sensor signal using Subaru Select Monitor.

NOTE:


- Subaru Select Monitor
- For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- CHECK** : Does the value change more than -2.8 kPa (-21.0 mmHg, -0.827 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step 16AW6.

16AW6 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Remove rear seat cushion (Sedan) or move rear seat cushion (Wagon).
- 3) Separate rear wiring harness and fuel tank cord.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between rear wiring harness connector and chassis ground.

Connector & terminal
(R83) No. 1 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 4.5 V?
- YES** : Go to step 16AW7.
- NO** : Repair harness and connector.


NOTE:

- In this case, repair the following:
- Open circuit in harness between ECM and rear wiring harness connector (R83)
 - Poor contact in coupling connector (B97)

16AW7 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and rear wiring harness connector.

Connector & terminal
(B84) No. 20 — (R83) No. 2:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16AW8.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and rear wiring harness connector (R83)
- Poor contact in coupling connector (B98)

16AW8 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.

Measure resistance of harness between rear wiring harness connector and chassis ground.

Connector & terminal
(R83) No. 4 — Chassis ground:




- CHECK** : Is the resistance more than 500 kΩ?
- YES** : Go to step 16AW9.
- NO** : Repair ground short circuit in harness between ECM and rear wiring harness connector (R83).

16AW9 : CHECK FUEL TANK CORD.

- 1) Remove fuel tank. <Ref. to 2-8 [W2A0].>
- 2) Disconnect connector from fuel tank pressure sensor.
- 3) Measure resistance of fuel tank cord.

Connector & terminal
(R84) No. 1 — (R47) No. 3:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16AW10.
- NO** : Repair open circuit in fuel tank cord.

16AW10 : CHECK FUEL TANK CORD.

Measure resistance of fuel tank cord.

Connector & terminal

(R84) No. 2 — (R47) No. 1:




- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **16AW11**.
- NO** : Repair open circuit in fuel tank cord.

16AW11 : CHECK FUEL TANK CORD.

Measure resistance of harness between fuel tank pressure sensor connector and chassis ground.

Connector & terminal

(R47) No. 2 — Chassis ground:



- CHECK** : **Is the resistance more than 500 kΩ?**
- YES** : Go to step **16AW12**.
- NO** : Repair ground short circuit in fuel tank cord.

16AW12 : CHECK POOR CONTACT.

Check poor contact in fuel tank pressure sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in fuel tank pressure sensor connector?**
- YES** : Repair poor contact in fuel tank pressure sensor connector.
- NO** : Replace fuel tank pressure sensor. <Ref. to 2-1 [W9A0].>

ON-BOARD DIAGNOSTICS II SYSTEM

[T16AW12] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


AX: DTC P0453 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


- **WIRING DIAGRAM:**



B2M2213

16AX1 : CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.

- 1) Turn ignition switch to OFF.
- 2) Remove fuel filler cap.
- 3) Install fuel filler cap.
- 4) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.



- 5) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 6) Read data of fuel tank pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:


- Subaru Select Monitor
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?*
- YES** : Go to step 16AX12.
- NO** : Go to step 16AX2.

16AX2 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 21 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 16AX4.
- NO** : Go to step 16AX3.

16AX3 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 21 (+) — Chassis ground (-):




- CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W15A2].>

16AX4 : CHECK INPUT SIGNAL FOR ECM.

Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 4 (+) — Chassis ground (-):



- CHECK** : *Is the voltage less than 0.2 V?*
- YES** : Go to step 16AX6.
- NO** : Go to step 16AX5.

16AX5 : CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)

Read data of fuel tank pressure sensor signal using Subaru Select Monitor.

NOTE:


- Subaru Select Monitor
- For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- CHECK** : *Does the value change more than -2.8 kPa (-21.0 mmHg, -0.827 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?*
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step 16AX6.

16AX6 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Remove rear seat cushion (Sedan) or move rear seat cushion (Wagon).
- 3) Separate rear wiring harness and fuel tank cord.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between rear wiring harness connector and chassis ground.

Connector & terminal
(R83) No. 1 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 16AX7.
- NO** : Repair harness and connector.


NOTE:

- In this case, repair the following:
- Open circuit in harness between ECM and rear wiring harness connector (R83)
 - Poor contact in coupling connector (B97)

16AX7 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and rear wiring harness connector.

Connector & terminal
(B84) No. 4 — (R83) No. 4:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16AX8.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and rear wiring harness connector (R83)
- Poor contact in coupling connector (B98)

16AX8 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.

Measure resistance of harness between rear wiring harness connector and chassis ground.

Connector & terminal
(B84) No. 20 — (R83) No. 2:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16AX9.
- NO** : Repair ground short circuit in harness between ECM and rear wiring harness connector (R83).

16AX9 : CHECK FUEL TANK CORD.

- 1) Remove fuel tank. <Ref. to 2-8 [W2A0].>
- 2) Disconnect connector from fuel tank pressure sensor.
- 3) Measure resistance of fuel tank cord.

Connector & terminal
(R84) No. 4 — (R47) No. 2:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16AX10.
- NO** : Repair open circuit in fuel tank cord.

16AX10 : CHECK FUEL TANK CORD.

Measure resistance of fuel tank cord.

Connector & terminal

(R84) No. 2 — (R47) No. 1:



- CHECK** : **Is the resistance less than 1 Ω?**
YES : Go to step **16AX11**.
NO : Repair open circuit in fuel tank cord.

16AX11 : CHECK POOR CONTACT.

Check poor contact in fuel tank pressure sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in fuel tank pressure sensor connector?**
YES : Repair poor contact in fuel tank pressure sensor connector.
NO : Replace fuel tank pressure sensor. <Ref. to 2-1 [W9A0].>

16AX12 : CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.

- 1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.
- 2) Remove fuel tank. <Ref. to 2-8 [W2A0].>
- 3) Remove fuel tank cord from fuel tank.
- 4) Connect fuel tank cord to rear wiring harness.
- 5) Remove fuel filler cap.
- 6) Install fuel filler cap.
- 7) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 8) Read data of fuel tank pressure sensor signal using Subaru select monitor or the OBD-II general scan tool.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : **Is the value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?**
YES : Repair battery short circuit in harness between ECM and fuel tank pressure sensor connector.
NO : Replace fuel tank pressure sensor. <Ref. to 2-1 [W9A0].>


AY: DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/ PERFORMANCE PROBLEM —

NOTE:

Check fuel level sensor circuit.

<Ref. to 2-7 [T16AZ0].>

● WIRING DIAGRAM:



B2M1836


AZ: DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —

NOTE:

Check fuel level sensor circuit.

<Ref. to 2-7 [T16BA0].>

● **WIRING DIAGRAM:**



B2M1836


BA: DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —

NOTE:

Check fuel level sensor circuit.

<Ref. to 2-7 [T16BB0].>

● **WIRING DIAGRAM:**



B2M1836


BB: DTC P0480 — COOLING FAN RELAY 1 CIRCUIT LOW INPUT —

NOTE:

Check radiator fan relay 1 circuit.

<Ref. to 2-7 [T16BC0].>

● **WIRING DIAGRAM:**



B2M1837


BC: DTC P0483 — COOLING FAN FUNCTION PROBLEM —

NOTE:

Check radiator fan control system.

<Ref. to 2-7 [T16BD0].>

● **WIRING DIAGRAM:**



B2M2215


BD: DTC P0500 — VEHICLE SPEED SENSOR MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16BD1 : CHECK VEHICLE MODEL.

16BD2 : CHECK DTC P0720 ON DISPLAY.

- CHECK** : *Is the vehicle AT model?*
- YES** : Go to step 16BD2.
- NO** : Go to step 16BD3.

- CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?*
- YES** : Check vehicle speed sensor. <Ref. to 3-2 [T8G0].>
- NO** : Go to step 16BD3.


16BD3 : CHECK SPEEDOMETER OPERATION IN COMBINATION METER.

- CHECK** : Does speedometer operate normally?
- YES** : Go to step 16BD4.
- NO** : Check speedometer and vehicle speed sensor. <Ref. to 6-2b [T3A0].>

16BD4 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 83 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 2 V?
- YES** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and combination meter connector
- Poor contact in ECM connector
- Poor contact in combination meter connector
- Poor contact in coupling connector (B37)

- NO** : Go to step 16BD5.

16BD5 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

Connector & terminal
(B84) No. 83 — Chassis ground:



- CHECK** : Is the resistance less than 10 Ω?
- YES** : Repair ground short circuit in harness between ECM and combination meter connector.
- NO** : Repair poor contact in ECM connector.


BE: DTC P0505 — IDLE CONTROL SYSTEM MALFUNCTION —

NOTE:

Check idle air control solenoid valve circuit.

<Ref. to 2-7 [T16BF0].>

● **WIRING DIAGRAM:**




B2M1840

BF: DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED

NOTE:
Check idle air control system.
<Ref. to 2-7 [T16BG0].>

● **WIRING DIAGRAM:**



B2M1840


BG: DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED

NOTE:

Check idle air control system.

<Ref. to 2-7 [T16BH0].>

● WIRING DIAGRAM:



B2M1840


BH: DTC P0600 — SERIAL COMMUNICATION LINK MALFUNCTION —

NOTE:

Check serial communication circuit.

<Ref. to 2-7 [T16BI0].>

● **WIRING DIAGRAM:**



B2M1841


BI: DTC P0601 — INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR —

NOTE:

Check internal control module memory.

<Ref. to 2-7 [T16BJ0].>

● **WIRING DIAGRAM:**



ON-BOARD DIAGNOSTICS II SYSTEM

[T16B10] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:

BJ: DTC P0703 — BRAKE SWITCH INPUT MALFUNCTION —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M2217

16BJ1 : CHECK OPERATION OF BRAKE LIGHT.

- CHECK** : Does brake light come on when depressing the brake pedal?
- YES** : Go to step 16BJ2.
- NO** : Repair or replace brake light circuit.


16BJ2 : CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.

- 1) Disconnect connectors from TCM and brake light switch.
- 2) Measure resistance of harness between TCM and brake light switch connector.

Connector & terminal

(B55) No. 24 — (B64) No. 2:

(B55) No. 24 — (B65) No. 3 (With cruise control):



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16BJ3.
- NO** : Repair or replace harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between TCM and brake light switch connector
- Poor contact in TCM connector
- Poor contact in brake light switch connector

16BJ3 : CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal

(B55) No. 24 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BJ4.
- NO** : Repair ground short circuit in harness between TCM and brake light switch connector.

16BJ4 : CHECK INPUT SIGNAL FOR TCM.

- 1) Connect connectors to TCM and brake light switch.
- 2) Measure voltage between TCM and chassis ground.

Connector & terminal

(B55) No. 24 (+) — Chassis ground (-):



- CHECK** : Is the voltage less than 1 V when releasing the brake pedal?
- YES** : Go to step 16BJ5.
- NO** : Adjust or replace brake light switch. <Ref. to 4-5 [W1A1].>

2-7 [T16BJ5]

ON-BOARD DIAGNOSTICS II SYSTEM


16. Diagnostics Chart with Trouble Code for 2500 cc Models

16BJ5 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM and chassis ground.

Connector & terminal

(B55) No. 24 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V when depressing the brake pedal?*
- YES** : Go to step **16BJ6**.
- NO** : Adjust or replace brake light switch.
<Ref. to 4-5 [W1A1].>

16BJ6 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W22A0].>

ON-BOARD DIAGNOSTICS II SYSTEM

[T16BJ6] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models


MEMO:

16BK1 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and transmission.
- 3) Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal

(B55) No. 23 — (T7) No. 8:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16BK2.
- NO** : Repair harness and connector.

NOTE:


- In this case, repair the following:
- Open circuit in harness between ECM and inhibitor switch connector
 - Poor contact in coupling connector (B12)

16BK2 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal

(B55) No. 17 — (T7) No. 9:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16BK3.
- NO** : Repair harness and connector.

NOTE:

- In this case, repair the following:
- Open circuit in harness between ECM and inhibitor switch connector
 - Poor contact in coupling connector (B12)

2-7 [T16BK3]

ON-BOARD DIAGNOSTICS II SYSTEM


16. Diagnostics Chart with Trouble Code for 2500 cc Models

16BK3 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal

(B55) No. 22 — (T7) No. 5:



CHECK : Is the resistance less than 1 Ω?

YES : Go to step 16BK4.

NO : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and inhibitor switch connector.
- Poor contact in coupling connector (B12)

16BK4 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal

(B55) No. 8 — (T7) No. 6:



CHECK : Is the resistance less than 1 Ω?

YES : Go to step 16BK5.

NO : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector.
- Poor contact in coupling connector (B12)

16BK5 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal
(B55) No. 18 — (T7) No. 4:



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK6**.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector.
- Poor contact in coupling connector (B12)

16BK6 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal
(B54) No. 10 — (T7) No. 11:



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK7**.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector.
- Poor contact in coupling connector (B12)

16BK7 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and transmission harness connector.

Connector & terminal
(B54) No. 1 — (T7) No. 3:



- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16BK8.
- NO** : Repair harness and connector.

NOTE:


In this case, repair the following:

- Open circuit in harness between ECM and inhibitor switch connector.
- Poor contact in coupling connector (B12)

16BK8 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B55) No. 23 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK9.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK9 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B55) No. 17 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK10.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK10 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B55) No. 22 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK11.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK12 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B55) No. 18 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK13.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK11 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B55) No. 8 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK12.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK13 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B54) No. 10 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK14.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK14 : CHECK HARNESS BETWEEN TCM AND INHIBITOR SWITCH CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal
(B54) No. 1 — Chassis ground:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK15.
- NO** : Repair ground short circuit in harness between TCM and transmission harness connector.

16BK15 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever "P" position.

Terminals
No. 8 — No. 10:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16BK16.
- NO** : Go to step 16BK29.

16BK16 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "P" position.

Terminals
No. 8 — No. 10:




- CHECK** : Is the resistance more than 1 MΩ?
- YES** : Go to step 16BK17.
- NO** : Go to step 16BK29.

16BK17 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever for "R" position.

Terminals
No. 9 — No. 10:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16BK18.
- NO** : Go to step 16BK29.

16BK18 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "R" position.

Terminals

No. 9 — No. 10:




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **16BK19**.
- NO** : Go to step **16BK29**.

16BK19 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever for "N" position.

Terminals

No. 5 — No. 10:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK20**.
- NO** : Go to step **16BK29**.

16BK20 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "N" position.

Terminals

No. 5 — No. 10:




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **16BK21**.
- NO** : Go to step **16BK29**.

16BK21 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "D" position.

Terminals

No. 6 — No. 10:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK22**.
- NO** : Go to step **16BK29**.

16BK22 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "D" position.

Terminals

No. 6 — No. 10:




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **16BK23**.
- NO** : Go to step **16BK29**.

16BK24 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "3" position.

Terminals

No. 4 — No. 10:




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **16BK25**.
- NO** : Go to step **16BK29**.

16BK23 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever for "3" position.

Terminals

No. 4 — No. 10:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK24**.
- NO** : Go to step **16BK29**.

16BK25 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "2" position.

Terminals

No. 11 — No. 10:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK26**.
- NO** : Go to step **16BK29**.

16BK26 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "R" position.

Terminals

No. 11 — No. 10:



H2M1678


- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **16BK27**.
- NO** : Go to step **16BK29**.

16BK27 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "1" position.

Terminals

No. 3 — No. 10:



H2M1679


- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16BK28**.
- NO** : Go to step **16BK29**.

16BK28 : CHECK INHIBITOR SWITCH.

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "1" position.

Terminals

No. 3 — No. 10:



H2M1679

- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **16BK30**.
- NO** : Go to step **16BK29**.

16BK29 : CHECK SELECTOR CABLE.


- CHECK** : *Is there faulty connection in the selector cable?*
- YES** : Repair connection of selector cable.
- NO** : Replace inhibitor switch. <Ref. to 3-2 [W2C0].>

16BK30 : CHECK INPUT SIGNAL FOR TCM.

- 1) Turn ignition switch to OFF.
- 2) Connect connector to TCM and transmission.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between TCM and chassis ground.

Connector & terminal

(B55) No. 23 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 16BK31.
- NO** : Go to step 16BK44.

16BK31 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever except for "P" and "N" positions.

Connector & terminal

(B55) No. 23 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 8 V?
- YES** : Go to step 16BK32.
- NO** : Go to step 16BK44.

16BK32 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever "R" position.

Connector & terminal

(B55) No. 17 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 16BK33.
- NO** : Go to step 16BK44.

16BK33 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever except for "R" position.

Connector & terminal

(B55) No. 17 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 6 V?
- YES** : Go to step 16BK34.
- NO** : Go to step 16BK44.

16BK34 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever "P" and "N" positions.

Connector & terminal
(B55) No. 22 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 16BK35.
- NO** : Go to step 16BK44.

16BK35 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever except for "N" and "P" positions.

Connector & terminal
(B55) No. 22 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 8 V?
- YES** : Go to step 16BK36.
- NO** : Go to step 16BK44.

16BK36 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM and chassis ground in selector lever "D" position.

Connector & terminal
(B55) No. 8 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 16BK37.
- NO** : Go to step 16BK44.

16BK37 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever except for "N" and "P" positions.

Connector & terminal
(B55) No. 8 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 6 V?
- YES** : Go to step 16BK38.
- NO** : Go to step 16BK44.

16BK38 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever "3" position.

Connector & terminal
(B55) No. 18 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 16BK39.
- NO** : Go to step 16BK44.

16BK39 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM and chassis ground in selector lever except for "3" position.

Connector & terminal
(B55) No. 18 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 6 V?
- YES** : Go to step 16BK40.
- NO** : Go to step 16BK44.

16BK40 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever "2" position.

Connector & terminal
(B54) No. 10 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 16BK41.
- NO** : Go to step 16BK44.

16BK41 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM and chassis ground in selector lever except for "2" position.

Connector & terminal
(B54) No. 10 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 6 V?
- YES** : Go to step 16BK42.
- NO** : Go to step 16BK44.

16BK42 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever "1" position.

Connector & terminal
(B54) No. 1 (+) — Chassis ground (-):




- CHECK** : *Is the voltage less than 1 V?*
- YES** : Go to step **16BK43**.
- NO** : Go to step **16BK44**.

16BK43 : CHECK INPUT SIGNAL FOR TCM.

Measure voltage between TCM chassis ground in selector lever except for "1" position.

Connector & terminal
(B54) No. 1 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 6 V?*
- YES** : Repair poor contact in TCM connector.
- NO** : Go to step **16BK44**.

16BK44 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W22A0].>

BL: DTC P0710 — TRANSMISSION FLUID TEMPERATURE SENSOR CIRCUIT MALFUNCTION —

● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


● **TROUBLE SYMPTOM:**

- No shift up to 4th speed (after engine warm-up)
- No lock-up (after engine warm-up)
- Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2219

16BL1 : CHECK DTC P0710 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0710?
- YES** : Check ATF temperature sensor circuit. <Ref. to 3-2 [T8E0].>
- NO** : It is not necessary to inspect DTC P0710.

BM: DTC P0715 — TORQUE CONVERTER TURBIN SPEED SENSOR CIRCUIT MALFUNCTION —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2406

16BM1 : CHECK DTC P0715 ON DISPLAY.

CHECK : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0715?

YES : Check torque converter turbin speed sensor circuit. <Ref. to 3-2 [T8H0].>

NO : It is not necessary to inspect DTC P0715.


BN: DTC P0720 — OUTPUT SPEED SENSOR (VEHICLE SPEED SENSOR 2) CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - No shift or excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2220

16BN1 : CHECK DTC P0720 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?
- YES** : Check vehicle speed sensor 1 circuit. <Ref. to 3-2 [T8G0].>
- NO** : It is not necessary to inspect DTC P0720.

BO: DTC P0725 — ENGINE SPEED INPUT CIRCUIT MALFUNCTION —

● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


● **TROUBLE SYMPTOM:**

- No lock-up (after engine warm-up)
- AT diagnostic indicator light (AT OIL TEMP indicator light) remains on when vehicle speed is "0".

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M2221

16B01 : CHECK DTC P0725 ON DISPLAY.

CHECK : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0725?

YES : Check engine speed input circuit. <Ref. to 3-2 [T8C0].>

NO : It is not necessary to inspect DTC P0725.

BP: DTC P0731 — GEAR 1 INCORRECT RATIO —**NOTE:**

For the diagnostic procedure, refer to 2-7 [T16BS0]. <Ref. to 2-7 [T16BS0].>

BQ: DTC P0732 — GEAR 2 INCORRECT RATIO —**NOTE:**

For the diagnostic procedure, refer to 2-7 [T16BS0]. <Ref. to 2-7 [T16BS0].>

BR: DTC P0733 — GEAR 3 INCORRECT RATIO —**NOTE:**

For the diagnostic procedure, refer to 2-7 [T16BS0]. <Ref. to 2-7 [T16BS0].>

BS: DTC P0734 — GEAR 4 INCORRECT RATIO —**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


● TROUBLE SYMPTOM:

- Shift point too high or too low; engine brake not effected in “3” range; excessive shift shock; excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● WIRING DIAGRAM:



B2M2546

16BS1 : CHECK ANY OTHER DTC ON DISPLAY.

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect relevant DTC using "16. Diagnostics Chart with Trouble Code for 2500 cc Models". <Ref. to 2-7 [T16A0].>
- NO** : Go to step **16BS2**.

16BS2 : CHECK THROTTLE POSITION SENSOR CIRCUIT.

- Check throttle position sensor circuit. <Ref. to 3-2 [T8F0].>
- CHECK** : *Is there any trouble in throttle position sensor circuit?*
- YES** : Repair or replace throttle position sensor circuit.
- NO** : Go to step **16BS3**.

16BS3 : CHECK VEHICLE SPEED SENSOR 2 CIRCUIT.

Check vehicle speed sensor 2 circuit. <Ref. to 3-2 [T8G0].>

- CHECK** : *Is there any trouble in vehicle speed sensor 2 circuit?*
- YES** : Repair or replace vehicle speed sensor 2 circuit.
- NO** : Go to step **16BS4**.

16BS4 : CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT.

Check torque converter turbine speed sensor circuit. <Ref. to 3-2 [T8H0].>

- CHECK** : *Is there any trouble in torque converter turbine speed sensor circuit?*
- YES** : Repair or replace torque converter turbine speed sensor circuit.
- NO** : Go to step **16BS5**.

16BS5 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Go to step **16BS6**.

16BS6 : CHECK MECHANICAL TROUBLE.

Check mechanical trouble in automatic transmission.

- CHECK** : *Is there any mechanical trouble in automatic transmission?*
- YES** : Repair or replace automatic transmission. <Ref. to 2-11 [W300].>
- NO** : Replace TCM. <Ref. to 3-2 [W22A0].>

ON-BOARD DIAGNOSTICS II SYSTEM

[T16BS6] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:

BT: DTC P0740 — TORQUE CONVERTER CLUTCH SYSTEM MALFUNCTION

• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


• TROUBLE SYMPTOM:

- No lock-up (after engine warm-up)
- No shift or excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

• WIRING DIAGRAM:



B2M2223

16BT1 : CHECK ANY OTHER DTC ON DISPLAY.

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using "16. Diagnostics Chart with Trouble Code for 2500 cc Models". <Ref. to 2-7 [T16A0].>
- NO** : Go to step **16BT2**.

16BT2 : CHECK DUTY SOLENOID B CIRCUIT.

Check duty solenoid B circuit. <Ref. to 3-2 [T8Q0].>

- CHECK** : *Is there any trouble in duty solenoid B circuit?*
- YES** : Repair or replace duty solenoid B circuit.
- NO** : Go to step **16BT3**.

16BT3 : CHECK THROTTLE POSITION SENSOR CIRCUIT.

Check throttle position sensor circuit. <Ref. to 3-2 [T8F0].>

- CHECK** : *Is there any trouble in throttle position sensor circuit?*
- YES** : Repair or replace throttle position sensor circuit.
- NO** : Go to step **16BT4**.

16BT4 : CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT.

Check torque converter turbine speed sensor circuit. <Ref. to 3-2 [T8H0].>

- CHECK** : *Is there any trouble in torque converter turbine speed sensor circuit?*
- YES** : Repair or replace torque converter turbine speed sensor circuit.
- NO** : Go to step **16BT5**.

16BT5 : CHECK ENGINE SPEED INPUT CIRCUIT.

Check engine speed input circuit. <Ref. to 3-2 [T8C0].>

- CHECK** : *Is there any trouble in engine speed input circuit?*
- YES** : Repair or replace engine speed input circuit.
- NO** : Go to step **16BT6**.

16BT6 : CHECK INHIBITOR SWITCH CIRCUIT.

Check inhibitor switch circuit. <Ref. to 2-7 [T16BK0].>

- CHECK** : *Is there any trouble in inhibitor switch circuit?*
- YES** : Repair or replace inhibitor switch circuit.
- NO** : Go to step **16BT7**.

16BT7 : CHECK BRAKE LIGHT SWITCH CIRCUIT.

Check brake light switch circuit. <Ref. to 2-7 [T16BJ0].>

- CHECK** : *Is there any trouble in brake light switch circuit?*
- YES** : Repair or replace brake light switch circuit.
- NO** : Go to step **16BT8**.

16BT8 : CHECK ATF TEMPERATURE SENSOR CIRCUIT.

Check ATF temperature sensor circuit. <Ref. to 3-2 [T8E0].>

- CHECK** : *Is there any trouble in ATF temperature sensor circuit?*
- YES** : Repair or replace ATF temperature sensor circuit.
- NO** : Go to step **16BT9**.

2-7 [T16BT9]

ON-BOARD DIAGNOSTICS II SYSTEM

16. Diagnostics Chart with Trouble Code for 2500 cc Models

16BT9 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

CHECK : *Is there poor contact in TCM connector?*

YES : Repair poor contact in TCM connector.

NO : Go to step **16BT10**.

16BT10 : CHECK MECHANICAL TROUBLE.

Check mechanical trouble in automatic transmission.

CHECK : *Is there any mechanical trouble in automatic transmission?*

YES : Repair or replace automatic transmission. <Ref. to 2-11 [W300].>

NO : Replace TCM. <Ref. to 3-2 [W22A0].>


BU: DTC P0743 — TORQUE CONVERTER CLUTCH SYSTEM (DUTY SOLENOID B) ELECTRICAL —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - No lock-up (after engine warm-up)

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2224

16BU1 : CHECK DTC P0743 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0743?
- YES** : Check duty solenoid B circuit. <Ref. to 3-2 [T8Q0].>
- NO** : It is not necessary to inspect DTC P0743.


BV: DTC P0748 — PRESSURE CONTROL SOLENOID (DUTY SOLENOID A) ELECTRICAL —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16BV1 : CHECK DTC P0748 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0748?
- YES** : Check duty solenoid A circuit. <Ref. to 3-2 [T800].>
- NO** : It is not necessary to inspect DTC P0748.


BW: DTC P0753 — SHIFT SOLENOID A (SHIFT SOLENOID 1) ELECTRICAL

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - No shift

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2226

16BW1 : CHECK DTC P0753 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0753?
- YES** : Check shift solenoid 1 circuit. <Ref. to 3-2 [T8K0].>
- NO** : It is not necessary to inspect DTC P0753.


BX: DTC P0758 — SHIFT SOLENOID B (SHIFT SOLENOID 2) ELECTRICAL —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - No shift

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2098

16BX1 : CHECK DTC P0758 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0758?
- YES** : Check shift solenoid 2 circuit. <Ref. to 3-2 [T8L0].>
- NO** : It is not necessary to inspect DTC P0758.


BY: DTC P1100 — STARTER SWITCH CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16BY1 : CHECK OPERATION OF STARTER MOTOR.

NOTE:

- On AT vehicles, place the inhibitor switch in the "P" or "N" position.
- On MT vehicles, depress the clutch pedal.

CHECK : *Does starter motor operate when ignition switch to "ST"?*

YES : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open or ground short circuit in harness between ECM and starter motor connector.
- Poor contact in ECM connector.

NO : Check starter motor circuit. <Ref. to 2-7 [T10B0].>


BZ: DTC P1101 — NEUTRAL POSITION SWITCH CIRCUIT MALFUNCTION [MT VEHICLES] —

NOTE:

Check neutral position switch circuit.

<Ref. to 2-7 [T16CB0].>

● **WIRING DIAGRAM:**



B2M0588


CA: DTC P1101 — NEUTRAL POSITION SWITCH CIRCUIT HIGH INPUT [AT VEHICLES] —

NOTE:

Check neutral position switch circuit.

<Ref. to 2-7 [T16CC0].>

● WIRING DIAGRAM:



B2M1700


CB: DTC P1102 — PRESSURE SOURCES SWITCHING SOLENOID VALVE CIRCUIT LOW INPUT —

NOTE:

Check pressure sources switching solenoid valve circuit.

<Ref. to 2-7 [T16CD0].>

● **WIRING DIAGRAM:**



B2M1822

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CB0] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


CC: DTC P1103 — ENGINE TORQUE CONTROL SIGNAL CIRCUIT 1 MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M2230

16CC1 : CHECK INPUT SIGNAL FOR ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal

(B84) No. 79 (+) — Chassis ground (-):



B2M0599A

- CHECK** : Is the voltage more than 4.5 V?
- YES** : Go to step 16CC2.
- NO** : Go to step 16CC3.

16CC2 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>


- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W15A2].>

16CC3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and TCM connector.

Connector & terminal

(B84) No. 79 — (B54) No. 13:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16CC4**.
- NO** : Repair open circuit in harness between ECM and TCM connector.

16CC4 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 79 — Chassis ground:



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step **16CC5**.

16CC5 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W22A0].>


CD: DTC P1106 — ENGINE TORQUE CONTROL SIGNAL CIRCUIT 2 MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M2502

16CD1 : CHECK INPUT SIGNAL FOR ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal

(B84) No. 78 (+) — Chassis ground (-):



B2M2573A

- CHECK** : Is the voltage more than 4.5 V?
- YES** : Go to step 16CD2.
- NO** : Go to step 16CD3.

16CD2 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>


- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W15A2].>

16CD3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and TCM connector.

Connector & terminal

(B84) No. 78 — (B54) No. 21:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **16CD4**.
- NO** : Repair open circuit in harness between ECM and TCM connector.

16CD4 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 78 — Chassis ground:



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step **16CD5**.

16CD5 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W22A0].>


CE: DTC P1115 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

- **WIRING DIAGRAM:**




B2M2645

16CE1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 61 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 8 V?
- YES** : Go to step 16CE2.
- NO** : Go to step 16CE4.

16CE2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 61 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Repair battery short circuit in harness between ECM and TCM connector.
- NO** : Go to step 16CE3.

16CE3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 61 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Repair battery short circuit in harness between ECM and TCM connector.
- NO** : Go to step 16CE4.

16CE4 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM and TCM connector.
- 3) Measure resistance of harness between ECM and TCM connector.

Connector & terminal

(B84) No. 61 — (B54) No. 2:



CHECK : **Is the resistance less than 1 Ω?**

YES : Go to step **16CE5**.

NO : Repair harness and connector.

NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and TCM connector.
- Poor contact ECM connector.
- Poor contact TCM connector.

16CE5 : CHECK POOR CONTACT.

Check poor contact in ECM or TCM connector.
<Ref. to FOREWORD [T3C1].>

CHECK : **Is there poor contact in ECM or TCM connector?**

YES : Repair poor contact in ECM or TCM connector.

NO : Contact with SOA service.

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CE5] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:

CF: DTC P1116 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT LOW INPUT —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M2645

16CF1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal

(B84) No. 61 (+) — Chassis ground (-):




- CHECK** : **Is the voltage more than 8 V?**
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step **16CF2**.

16CF2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and chassis ground.

Connector & terminal

(B84) No. 61 — Chassis ground:



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Contact with SOA service.


CG: DTC P1120 — STARTER SWITCH CIRCUIT HIGH INPUT —

NOTE:

Check starter switch circuit.

<Ref. to 2-7 [T16CG0].>

● **WIRING DIAGRAM:**



B2M2201


CH: DTC P1121 — NEUTRAL POSITION SWITCH CIRCUIT LOW INPUT [AT VEHICLES] —

NOTE:

Check neutral position switch circuit.

<Ref. to 2-7 [T16CH0].>

● WIRING DIAGRAM:



B2M1700


CI: DTC P1122 — PRESSURE SOURCES SWITCHING SOLENOID VALVE CIRCUIT HIGH INPUT —

NOTE:

Check pressure sources switching solenoid valve circuit.

<Ref. to 2-7 [T16CI0].>

● **WIRING DIAGRAM:**



B2M1822


CJ: DTC P1141 — MASS AIR FLOW SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

NOTE:

Check mass air flow sensor circuit.

<Ref. to 2-7 [T16CK0].>

● **WIRING DIAGRAM:**



B2M1821


CK: DTC P1142 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

NOTE:

Check throttle position sensor circuit.

<Ref. to 2-7 [T16CL0].>

● **WIRING DIAGRAM:**



ON-BOARD DIAGNOSTICS II SYSTEM

[T16CK0] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


CL: DTC P1143 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>


● **WIRING DIAGRAM:**



B2M1822

16CL1 : CHECK DATA FOR CONTROL.

- 1) Turn ignition switch to OFF.
- 2) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.



- 3) Turn ignition switch ON and Subaru Select Monitor or the OBD-II general scan tool switch ON.
- 4) Start engine.
- 5) Read data of atmospheric absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value less than 32 kPa (240 mmHg, 9.45 inHg)?*
- YES** : Go to step 16CL3.
- NO** : Go to step 16CL2.

16CL2 : CHECK PRESSURE SENSOR.

- 1) Measure actual atmospheric pressure.
- 2) Read data of atmospheric absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>


- CHECK** : *Is the difference between absolute value of Subaru Selector Monitor indication and actual atmospheric pressure greater than 10 kPa (75 mmHg, 2.95 inHg)?*
- YES** : Replace pressure sensor. <Ref. to 2-7 [W11A0].>
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

16CL3 : CHECK VACUUM HOSES.


Check the following item. Incorrect hose connections in line between the pressure sources switching solenoid valve and pressure sensor, intake manifold and/or CPC solenoid valve.



- CHECK** : *Is there a fault in vacuum hose?*
- YES** : Repair or replace hoses or filter.
- NO** : Go to step 16CL4.

16CL4 : CHECK PRESSURE SOURCES SWITCHING SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.



- 3) Turn ignition switch to ON.

NOTE:

Pressure sources switching solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to the "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : **Does pressure sources switching solenoid valve produce operating sound? (ON ↔ OFF each 1.5 sec.)**
- YES** : Replace pressure sensor. <Ref. to 2-7 [W11A0].>
- NO** : Replace pressure sources switching solenoid valve. <Ref. to 2-7 [W13A0].>


CM: DTC P1144 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —

NOTE:

Check pressure sensor circuit.

<Ref. to 2-7 [T16CN0].>

● **WIRING DIAGRAM:**



B2M1822

CN: DTC P1150 — FRONT OXYGEN SENSOR HEATER CIRCUIT HIGH INPUT


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M1824

16CN1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage ECM connector and chassis ground.


Connector & terminal
(B84) No. 38 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 8 V?*
- YES** : Go to step 16CN2.
- NO** : Go to step 16CN3.

16CN2 : CHECK FRONT OXYGEN SENSOR HEATER CURRENT.

- 1) Turn ignition switch to OFF.
- 2) Repair battery short circuit in harness between ECM and front oxygen sensor connector.
- 3) Connect Subaru Select Monitor or OBD-II general scan tool to data link connector.



- 4) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 5) Read data of front oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.

NOTE:

- Subaru Select Monitor
 For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool
 For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


- CHECK** : *Is the value more than 7 A?*
- YES** : Replace ECM. <Ref. to 2-7 [W15A2].>
- NO** : END

16CN3 : CHECK OUTPUT SIGNAL FROM ECM.
--

Measure voltage of ECM connector and chassis ground.

Connector & terminal

(B84) No. 38 (+) — Chassis ground (-):



- CHECK** : **Does the voltage change more than 8 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**
- YES** : Repair battery short circuit in harness between ECM and front oxygen sensor connector.
- NO** : END

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CN3] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


CO: DTC P1151 — REAR OXYGEN SENSOR HEATER CIRCUIT HIGH INPUT

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M2650

16C01 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage ECM connector and chassis ground.


Connector & terminal
(B84) No. 37 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 8 V?
- YES** : Go to step 16C02.
- NO** : Go to step 16C03.

16C02 : CHECK FRONT OXYGEN SENSOR HEATER CURRENT.

- 1) Turn ignition switch to OFF.
- 2) Repair battery short circuit in harness between ECM and front oxygen sensor connector.
- 3) Connect Subaru Select Monitor or OBD-II general scan tool to data link connector.



- 4) Turn ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON.
- 5) Read data of front oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.

NOTE:

- Subaru Select Monitor
 For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool
 For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


- CHECK** : Is the value more than 7 A?
- YES** : Replace ECM. <Ref. to 2-7 [W15A2].>
- NO** : END

16CO3 : CHECK OUTPUT SIGNAL FROM ECM.
--

Measure voltage of ECM connector and chassis ground.

Connector & terminal

(B84) No. 37 (+) — Chassis ground (-):



- CHECK** : **Does the voltage change more than 8 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**
- YES** : Repair battery short circuit in harness between ECM and front oxygen sensor connector.
- NO** : END


CP: DTC P1400 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —

NOTE:

Check fuel tank pressure control solenoid valve circuit.

<Ref. to 2-7 [T16CO0].>

● WIRING DIAGRAM:



B2M1854


CQ: DTC P1420 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —

NOTE:

Check fuel tank pressure control solenoid valve circuit.

<Ref. to 2-7 [T16CP0].>

● **WIRING DIAGRAM:**



B2M1854


CR: DTC P1421 — EXHAUST GAS RECIRCULATION CIRCUIT HIGH INPUT —

NOTE:

Check exhaust gas recirculation circuit.

<Ref. to 2-7 [T16CQ0].>

● **WIRING DIAGRAM:**



B2M2545


CS: DTC P1422 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH INPUT —

NOTE:

Check canister purge control system.

<Ref. to 2-7 [T16CR0].>

● **WIRING DIAGRAM:**



B2M1832

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CS0] 2-7


16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:

16CT1 : CHECK OUTPUT SIGNAL FROM ECM.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 35 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step **16CT3**.
- NO** : Go to step **16CT2**.

16CT2 : CHECK POOR CONTACT.


Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W15A2].>

16CT3 : CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from drain valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 35 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Repair battery short circuit in harness between ECM and drain valve connector. After repair, replace ECM. <Ref. to 2-7 [W15A2].>
- NO** : Go to step **16CT4**.

2-7 [T16CT4]

ON-BOARD DIAGNOSTICS II SYSTEM


16. Diagnostics Chart with Trouble Code for 2500 cc Models

16CT4 : CHECK DRAIN VALVE.

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between drain valve terminals.

Terminals

No. 1 — No. 2:



CHECK : *Is the resistance less than 1 Ω?*

YES : Replace drain valve <Ref. to 2-1 [W17A0].> and ECM <Ref. to 2-7 [W15A2].>.

NO : Go to step **16CT5**.

16CT5 : CHECK POOR CONTACT.

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

CHECK : *Is there poor contact in ECM connector?*

YES : Repair poor contact in ECM connector.

NO : Replace ECM. <Ref. to 2-7 [W15A2].>

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CT5] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


CU: DTC P1440 — FUEL TANK PRESSURE CONTROL SYSTEM FUNCTION PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>


● **WIRING DIAGRAM:**



B2M1854

16CU1 : CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.



- 3) Turn ignition switch to ON.

NOTE:

Fuel tank pressure control solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : *Does fuel tank pressure control solenoid valve produce operating sound?*
- YES** : Go to step **16CU2**.
- NO** : Replace fuel tank pressure control solenoid valve. <Ref. to 2-1 [W10A0].>

16CU2 : CHECK FUEL FILLER CAP.

- 1) Turn ignition switch to OFF.
- 2) Open the fuel flap.

- CHECK** : *Is the fuel filler cap tightened securely?*
- YES** : Tighten fuel filler cap securely.
- NO** : Go to step **16CU3**.

16CU3 : CHECK FUEL FILLER PIPE SEAL.


- CHECK** : *Is there any damage to the seal between fuel filler cap and fuel filler pipe?*
- YES** : Repair or replace fuel filler cap and fuel filler pipe. <Ref. to 2-8 [W3A0].>
- NO** : Go to step **16CU4**.

16CU4 : CHECK DRAIN VALVE.

Turn ignition switch to ON.

NOTE:

Drain valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : *Does drain valve produce operating sound?*
- YES** : Go to step **16CU5**.
- NO** : Replace drain valve. <Ref. to 2-1 [W17A0].>

16CU5 : CHECK PURGE CONTROL SOLENOID VALVE.

NOTE:

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>



- CHECK** : *Does purge control solenoid valve produce operating sound?*
- YES** : Go to step **16CU6**.
- NO** : Replace purge control solenoid valve. <Ref. to 2-1 [W4A0].>

2-7 [T16CU6]

ON-BOARD DIAGNOSTICS II SYSTEM

16. Diagnostics Chart with Trouble Code for 2500 cc Models

16CU6 : CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.

Turn ignition switch to OFF.

- CHECK** : **Does fuel leak in fuel line?**
YES : Repair or replace fuel line. <Ref. to 2-8 [W7A0].>
NO : Go to step **16CU7**.

16CU7 : CHECK CANISTER.

- CHECK** : **Is there any damage at canister?**
YES : Repair or replace canister. <Ref. to 2-1 [W3A0].>
NO : Go to step **16CU8**.

16CU8 : CHECK FUEL TANK.

- CHECK** : **Is there any damage at fuel tank?**
YES : Repair or replace fuel tank. <Ref. to 2-8 [W2A0].>
NO : Go to step **16CU9**.

16CU9 : CHECK OTHER MECHANICAL TROUBLE.

- CHECK** : **Are there holes, cracks or disconnections of hoses or pipes in evaporative emission control system?**
YES : Repair or replace hoses or pipes.
NO : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CU9] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


CV: DTC P1441 — FUEL TANK PRESSURE CONTROL SYSTEM FUNCTION PROBLEM (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>


● **WIRING DIAGRAM:**



B2M1854

16CV1 : CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector.



- 3) Turn ignition switch to ON.

NOTE:

Fuel tank pressure control solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : **Does fuel tank pressure control solenoid valve produce operating sound?**
- YES** : Go to step **16CV2**.
- NO** : Replace fuel tank pressure control solenoid valve. <Ref. to 2-1 [W10A0].>

16CV2 : CHECK FUEL FILLER CAP.

- 1) Turn ignition switch to OFF.
- 2) Open the fuel flap.


- CHECK** : **Is there any damage at fuel filler cap and fuel filler pipe?**
- YES** : Repair or replace fuel filler cap and fuel filler pipe. <Ref. to 2-8 [W3A0].>
- NO** : Go to step **16CV3**.

16CV3 : CHECK DRAIN VALVE.

Turn ignition switch to ON.

NOTE:

Drain valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : **Does drain valve produce operating sound?**
- YES** : Go to step **16CV4**.
- NO** : Replace drain valve. <Ref. to 2-1 [W17A0].>

16CV4 : CHECK PURGE CONTROL SOLENOID VALVE.

NOTE:

Purge control solenoid valve operation check can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>



- CHECK** : **Does purge control solenoid valve produce operating sound?**
- YES** : Go to step **16CV5**.
- NO** : Replace purge control solenoid valve. <Ref. to 2-1 [W4A0].>

2-7 [T16CV5]

ON-BOARD DIAGNOSTICS II SYSTEM

16. Diagnostics Chart with Trouble Code for 2500 cc Models

16CV5 : CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.

Turn ignition switch to OFF.

CHECK : *Is there any damage at canister?*

YES : Repair or replace canister. <Ref. to 2-1 [W3A0].>

NO : Go to step **16CV6**.

16CV6 : CHECK FUEL TANK.

CHECK : *Is there any damage at fuel tank?*

YES : Repair or replace fuel tank. <Ref. to 2-8 [W2A0].>

NO : Go to step **16CV7**.

16CV7 : CHECK OTHER MECHANICAL TROUBLE.

CHECK : *Is there clogging of hoses or pipes in evaporative emission control system?*

YES : Repair or replace hoses or pipes.

NO : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.


CW: DTC P1442 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM 2 —

NOTE:

Check fuel level sensor circuit.

<Ref. to 2-7 [T16CW0].>

● **WIRING DIAGRAM:**



B2M1836


CX: DTC P1443 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL FUNCTION PROBLEM —

NOTE:

Check evaporative emission control system.

<Ref. to 2-7 [T16CX0].>

● **WIRING DIAGRAM:**



B2M1833


CY: DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —

NOTE:

Check idle air control system.

<Ref. to 2-7 [T16CY0].>

● **WIRING DIAGRAM:**




CZ: DTC P1520 — COOLING FAN RELAY 1 CIRCUIT HIGH INPUT —

NOTE:

Check radiator fan relay 1 circuit.

<Ref. to 2-7 [T16CZ0].>

● **WIRING DIAGRAM:**



B2M1837

ON-BOARD DIAGNOSTICS II SYSTEM

[T16CZ0] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:


DA: DTC P1540 — VEHICLE SPEED SENSOR MALFUNCTION 2 —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16DA1 : CHECK VEHICLE MODEL.

16DA2 : CHECK DTC P0720 ON DISPLAY.

- CHECK** : Is the vehicle AT model?
- YES** : Go to step 16DA2.
- NO** : Go to step 16DA3.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?
- YES** : Check vehicle speed sensor circuit. <Ref. to 3-2 [T8G0].>
- NO** : Go to step 16DA3.


16DA3 : CHECK SPEEDOMETER OPERATION IN COMBINATION METER.

- CHECK** : Does speedometer operate normally?
- YES** : Go to step 16DA4.
- NO** : Check speedometer and vehicle speed sensor <Ref. to 6-2b [T3A0].>.

16DA4 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from TCM.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 83 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 2 V?
- YES** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and combination meter connector
- Poor contact in ECM connector
- Poor contact in combination meter connector
- Poor contact in coupling connector (B37)

- NO** : Go to step 16DA5.

16DA5 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

Connector & terminal
(B84) No. 83 — Chassis ground:



- CHECK** : Is the resistance less than 10 Ω?
- YES** : Repair ground short circuit in harness between ECM and combination meter connector.
- NO** : Repair poor contact in ECM connector.

DB: DTC P1700 — THROTTLE POSITION SENSOR CIRCUIT MALFUNCTION FOR AUTOMATIC TRANSMISSION —

● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


● **TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effected in “3” range; excessive shift shock; excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16DB1 : CHECK DTC P1700 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1700?
- YES** : Check throttle position sensor circuit. <Ref. to 3-2 [T8F0].>
- NO** : It is not necessary to inspect DTC P1700.

ON-BOARD DIAGNOSTICS II SYSTEM

[T16DB1] 2-7

16. Diagnostics Chart with Trouble Code for 2500 cc Models

MEMO:

DC: DTC P1701 — CRUISE CONTROL SET SIGNAL CIRCUIT MALFUNCTION FOR AUTOMATIC TRANSMISSION —


● DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● WIRING DIAGRAM:




16DC1 : CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and CCM.
- 3) Measure resistance of harness between TCM and CCM connector.

Connector & terminal

(B54) No. 11 — (B94) No. 3:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 16DC2.
- NO** : Repair open circuit in harness between TCM and CCM connector.

16DC2 : CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.

Measure resistance of harness between TCM and chassis ground.

Connector & terminal

(B54) No. 11 — Chassis ground:



- CHECK** : Is the resistance less than 10 Ω?
- YES** : Repair short circuit in harness between TCM and CCM connector.
- NO** : Go to step 16DC3.

16DC3 : CHECK INPUT SIGNAL FOR TCM.

- 1) Connect connector to TCM and CCM.
- 2) Lift-up the vehicle or set the vehicle on free rollers.


CAUTION:

Raise all wheels off ground.

- 3) Start the engine.
- 4) Cruise control main switch to ON.
- 5) Move selector lever to "D" and slowly increase vehicle speed to 50 km/h (31 MPH).
- 6) Cruise control set switch to ON.
- 7) Measure voltage between TCM and chassis ground.

Connector & terminal

(B54) No. 11 (+) — Chassis ground (-):



CHECK : **Is the resistance less than 1 V?**

YES : Go to step **16DC4**.

NO : Check cruise control set circuit. <Ref. to 6-2a [T7A0].>

16DC4 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

CHECK : **Is there poor contact in TCM connector?**

YES : Repair poor contact in TCM connector.

NO : Replace TCM. <Ref. to 3-2 [W22A0].>


DD: DTC P1702 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2752


16DD1 : CHECK TRANSMISSION TYPE.

- CHECK** : *Is transmission type AT?*
- YES** : Go to step 16DD2.
- NO** : Check AT/MT identification circuit. <Ref. to 2-7 [T16DJ0].>

16DD2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 80 (+) — Chassis ground (-):



- CHECK** : *Is the voltage less than 1 V?*
- YES** : Go to step 16DD3.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.


NOTE:

- In this case, repair the following:
- Poor contact in ECM connector
 - Poor contact in TCM connector

16DD3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM and TCM.
- 3) Measure resistance of harness between ECM and chassis ground.

Connector & terminal
(B84) No. 80 — Chassis ground:




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step 16DD4.

16DD4 : CHECK OUTPUT SIGNAL FOR ECM.

- 1) Connect connector to ECM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 80 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 5 V?*
- YES** : Replace TCM. <Ref. to 3-2 [W22A0].>
- NO** : Contact SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

DE: DTC P1703 — LOW CLUTCH TIMING CONTROL SOLENOID VALVE CIRCUIT MALFUNCTION —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2401

16DE1 : CHECK DTC P1703 ON DISPLAY.

CHECK : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1703?

YES : Check low clutch timing control solenoid valve circuit. <Ref. to 3-2 [T8M0].>

NO : It is not necessary to inspect DTC P1703.

DF: DTC P1704 — 2-4 BRAKE TIMING CONTROL SOLENOID VALVE CIRCUIT MALFUNCTION —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2403

16DF1 : CHECK DTC P1704 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1705?
- YES** : Check 2-4 brake timing control solenoid valve circuit. <Ref. to 3-2 [T8N0].>
- NO** : It is not necessary to inspect DTC P1704.


DG: DTC P1705 — 2-4 BRAKE PRESSURE CONTROL SOLENOID VALVE (DUTY SOLENOID D) MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



16DG1 : CHECK DTC P1705 ON DISPLAY.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1705?
- YES** : Check 2-4 brake pressure control solenoid valve circuit. <Ref. to 3-2 [T8P0].>
- NO** : It is not necessary to inspect DTC P1705.


DH: DTC P1722 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M2752


16DH1 : CHECK TRANSMISSION TYPE.

- CHECK** : *Is transmission type AT?*
- YES** : Go to step 16DH2.
- NO** : Check AT/MT identification circuit. <Ref. to 2-7 [T16DJ0].>

16DH2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 80 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
YES : Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM. <Ref. to 2-7 [W15A2].>
NO : Go to step 16DH3.

16DH3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 80 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 4 V?
YES : Go to step 16DH6.
NO : Go to step 16DH4.

16DH4 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

Measure voltage between ECM connector and chassis ground.

Connector & terminal
(B84) No. 80 (+) — Chassis ground (-):




- CHECK** : Is the voltage less than 1 V?
YES : Repair poor contact in ECM connector.
NO : Go to step 16DH5.

16DH5 : CHECK OUTPUT SIGNAL FROM ECM.

Measure voltage between ECM and chassis ground.

Connector & terminal
(B84) No. 80 (+) — Chassis ground (-):



CHECK : Does the voltage change from 1 V to 4 V while monitoring the value with voltage meter?

YES : Even if MIL lights up, the circuit has returned to a normal condition at this time.

NOTE:

In this case, repair the following:

- Poor contact in ECM connector
- Poor contact in TCM connector

NO : Contact with SOA service.


NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

16DH6 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.

Measure voltage between TCM and chassis ground.

Connector & terminal
(B54) No. 4 (+) — Chassis ground (-):



CHECK : Is the voltage more than 4 V?

YES : Go to step 16DH7.

NO : Repair open circuit in harness between ECM and TCM connector.

16DH7 : CHECK POOR CONTACT.

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

CHECK : Is there poor contact in TCM connector?

YES : Repair poor contact in TCM connector.

NO : Check TCM power supply line and grounding line.


DI: DTC P1742 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT MALFUNCTION —

NOTE:

Check automatic transmission diagnosis input signal circuit.

<Ref. to 2-7 [T16DF0].>

● **WIRING DIAGRAM:**




DJ: — AT/MT IDENTIFICATION CIRCUIT MALFUNCTION [MT VEHICLES] —

NOTE:

Check AT/MT identification circuit.

<Ref. to 2-7 [T16DG0].>

● WIRING DIAGRAM:



B2M0617

MEMO: