

## 11. Diagnostics Chart with Trouble Code for AT Vehicles

### A: DIAGNOSTIC TROUBLE CODE (DTC) LIST

DTC No.	Item	Index
P0106	Pressure sensor circuit range/performance problem	<Ref. to 2-7 [T11B0].>
P0107	Pressure sensor circuit low input	<Ref. to 2-7 [T11C0].>
P0108	Pressure sensor circuit high input	<Ref. to 2-7 [T11D0].>
P0111	Intake air temperature sensor circuit range/performance problem	<Ref. to 2-7 [T11E0].>
P0112	Intake air temperature sensor circuit low input	<Ref. to 2-7 [T11F0].>
P0113	Intake air temperature sensor circuit high input	<Ref. to 2-7 [T11G0].>
P0116	Engine coolant temperature sensor circuit low input	<Ref. to 2-7 [T11H0].>
P0117	Engine coolant temperature sensor circuit high input	<Ref. to 2-7 [T11I0].>
P0121	Throttle position sensor circuit range/performance problem (high input)	<Ref. to 2-7 [T11J0].>
P0122	Throttle position sensor circuit low input	<Ref. to 2-7 [T11K0].>
P0123	Throttle position sensor circuit high input	<Ref. to 2-7 [T11L0].>
P0125	Insufficient coolant temperature for closed loop fuel control	<Ref. to 2-7 [T11M0].>
P0130	Front oxygen (A/F) sensor circuit range/performance problem	<Ref. to 2-7 [T11N0].>
P0133	Front oxygen (A/F) sensor circuit slow response	<Ref. to 2-7 [T11O0].>
P0136	Rear oxygen sensor circuit malfunction	<Ref. to 2-7 [T11P0].>
P0139	Rear oxygen sensor circuit slow response	<Ref. to 2-7 [T11Q0].>
P0141	Rear oxygen sensor heater circuit malfunction	<Ref. to 2-7 [T11R0].>
P0170	Fuel trim malfunction	<Ref. to 2-7 [T11S0].>
P0181	Fuel temperature sensor A circuit range/performance problem	<Ref. to 2-7 [T11T0].>
P0182	Fuel temperature sensor A circuit low input	<Ref. to 2-7 [T11U0].>
P0183	Fuel temperature sensor A circuit high input	<Ref. to 2-7 [T11V0].>
P0301	Cylinder 1 misfire detected	<Ref. to 2-7 [T11W0].>
P0302	Cylinder 2 misfire detected	<Ref. to 2-7 [T11X0].>
P0303	Cylinder 3 misfire detected	<Ref. to 2-7 [T11Y0].>
P0304	Cylinder 4 misfire detected	<Ref. to 2-7 [T11Z0].>

DTC No.	Item	Index
P0325	Knock sensor circuit high input	<Ref. to 2-7 [T11AA0].>
P0335	Crankshaft position sensor circuit malfunction	<Ref. to 2-7 [T11AB0].>
P0336	Crankshaft position sensor circuit range/performance problem	<Ref. to 2-7 [T11AC0].>
P0340	Camshaft position sensor circuit malfunction	<Ref. to 2-7 [T11AD0].>
P0341	Camshaft position sensor circuit range/performance problem	<Ref. to 2-7 [T11AE0].>
P0420	Catalyst system efficiency below threshold	<Ref. to 2-7 [T11AF0].>
P0440	Evaporative emission control system malfunction	<Ref. to 2-7 [T11AG0].>
P0442	Evaporative emission control system malfunction	<Ref. to 2-7 [T11AH0].>
P0443	Evaporative emission control system purge control valve circuit low input	<Ref. to 2-7 [T11AI0].>
P0446	Evaporative emission control system vent control low input	<Ref. to 2-7 [T11AJ0].>
P0451	Evaporative emission control system pressure sensor range/performance problem	<Ref. to 2-7 [T11AK0].>
P0452	Evaporative emission control system pressure sensor low input	<Ref. to 2-7 [T11AL0].>
P0453	Evaporative emission control system pressure sensor high input	<Ref. to 2-7 [T11AM0].>
P0461	Fuel level sensor circuit range/performance problem	<Ref. to 2-7 [T11AN0].>
P0462	Fuel level sensor circuit low input	<Ref. to 2-7 [T11AO0].>
P0463	Fuel level sensor circuit high input	<Ref. to 2-7 [T11AP0].>
P0480	Cooling fan relay 1 circuit low input	<Ref. to 2-7 [T11AQ0].>
P0483	Cooling fan function problem	<Ref. to 2-7 [T11AR0].>
P0500	Vehicle speed sensor malfunction	<Ref. to 2-7 [T11AS0].>
P0506	Idle control system RPM lower than expected	<Ref. to 2-7 [T11AT0].>
P0507	Idle control system RPM higher than expected	<Ref. to 2-7 [T11AU0].>
P0601	Internal control module memory check sum error	<Ref. to 2-7 [T11AV0].>
P0703	Brake switch input malfunction	<Ref. to 2-7 [T11AW0].>
P0705	Transmission range sensor circuit malfunction	<Ref. to 2-7 [T11AX0].>
P0710	Transmission fluid temperature sensor circuit malfunction	<Ref. to 2-7 [T11AY0].>
P0715	Torque converter turbine speed sensor circuit malfunction	<Ref. to 2-7 [T11AZ0].>
P0720	Output speed sensor (vehicle speed sensor 2) circuit malfunction	<Ref. to 2-7 [T11BA0].>

## 11. Diagnostics Chart with Trouble Code for AT Vehicles

DTC No.	Item	Index
P0725	Engine speed input circuit malfunction	<Ref. to 2-7 [T11BB0].>
P0731	Gear 1 incorrect ratio	<Ref. to 2-7 [T11BC0].>
P0732	Gear 2 incorrect ratio	<Ref. to 2-7 [T11BD0].>
P0733	Gear 3 incorrect ratio	<Ref. to 2-7 [T11BE0].>
P0734	Gear 4 incorrect ratio	<Ref. to 2-7 [T11BF0].>
P0740	Torque converter clutch system malfunction	<Ref. to 2-7 [T11BG0].>
P0743	Torque converter clutch system (Lock-up duty solenoid) electrical	<Ref. to 2-7 [T11BH0].>
P0748	Pressure control solenoid (Line pressure duty solenoid) electrical	<Ref. to 2-7 [T11BI0].>
P0753	Shift solenoid A (Shift solenoid 1) electrical	<Ref. to 2-7 [T11BJ0].>
P0758	Shift solenoid B (Shift solenoid 2) electrical	<Ref. to 2-7 [T11BK0].>
P1100	Starter switch circuit low input	<Ref. to 2-7 [T11BL0].>
P1101	Neutral position switch circuit high input	<Ref. to 2-7 [T11BM0].>
P1103	Engine torque control signal 1 circuit malfunction	<Ref. to 2-7 [T11BN0].>
P1106	Engine torque control signal 2 circuit malfunction	<Ref. to 2-7 [T11BO0].>
P1110	Atmospheric pressure sensor low input	<Ref. to 2-7 [T11BP0].>
P1111	Atmospheric pressure sensor high input	<Ref. to 2-7 [T11BQ0].>
P1112	Atmospheric pressure sensor range/performance problem	<Ref. to 2-7 [T11BR0].>
P1115	Engine torque control cut signal circuit high input	<Ref. to 2-7 [T11BS0].>
P1116	Engine torque control cut signal circuit low input	<Ref. to 2-7 [T11BT0].>
P1120	Starter switch circuit high input	<Ref. to 2-7 [T11BU0].>
P1121	Neutral position switch circuit low input	<Ref. to 2-7 [T11BV0].>
P1130	Front oxygen (A/F) sensor circuit malfunction (open circuit)	<Ref. to 2-7 [T11BW0].>
P1131	Front oxygen (A/F) sensor circuit malfunction (short circuit)	<Ref. to 2-7 [T11BX0].>
P1132	Front oxygen (A/F) sensor heater circuit low input	<Ref. to 2-7 [T11BY0].>
P1133	Front oxygen (A/F) sensor heater circuit high input	<Ref. to 2-7 [T11BZ0].>
P1142	Throttle position sensor circuit range/performance problem (low input)	<Ref. to 2-7 [T11CA0].>
P1151	Rear oxygen sensor heater circuit high input	<Ref. to 2-7 [T11CB0].>

DTC No.	Item	Index
P1207	Air assist injector solenoid valve circuit low input	<Ref. to 2-7 [T11CC0].>
P1208	Air assist injector solenoid valve circuit high input	<Ref. to 2-7 [T11CD0].>
P1325	Knock sensor circuit low input	<Ref. to 2-7 [T11CE0].>
P1400	Fuel tank pressure control solenoid valve circuit low input	<Ref. to 2-7 [T11CF0].>
P1420	Fuel tank pressure control solenoid valve circuit high input	<Ref. to 2-7 [T11CG0].>
P1422	Evaporative emission control system purge control valve circuit high input	<Ref. to 2-7 [T11CH0].>
P1423	Evaporative emission control system vent control high input	<Ref. to 2-7 [T11CI0].>
P1442	Fuel level sensor circuit range/performance problem 2	<Ref. to 2-7 [T11CJ0].>
P1443	Evaporative emission control system vent control function problem	<Ref. to 2-7 [T11CK0].>
P1445	Air assist injector solenoid valve malfunction	<Ref. to 2-7 [T11CL0].>
P1490	Thermostat malfunction	<Ref. to 2-7 [T11CM0].>
P1507	Idle control system malfunction (fail-safe)	<Ref. to 2-7 [T11CN0].>
P1510	Idle air control solenoid valve signal 1 circuit low input	<Ref. to 2-7 [T11CO0].>
P1511	Idle air control solenoid valve signal 1 circuit high input	<Ref. to 2-7 [T11CP0].>
P1512	Idle air control solenoid valve signal 2 circuit low input	<Ref. to 2-7 [T11CQ0].>
P1513	Idle air control solenoid valve signal 2 circuit high input	<Ref. to 2-7 [T11CR0].>
P1514	Idle air control solenoid valve signal 3 circuit low input	<Ref. to 2-7 [T11CS0].>
P1515	Idle air control solenoid valve signal 3 circuit high input	<Ref. to 2-7 [T11CT0].>
P1516	Idle air control solenoid valve signal 4 circuit low input	<Ref. to 2-7 [T11CU0].>
P1517	Idle air control solenoid valve signal 4 circuit high input	<Ref. to 2-7 [T11CV0].>
P1520	Cooling fan relay 1 circuit high input	<Ref. to 2-7 [T11CW0].>
P1540	Vehicle speed sensor malfunction 2	<Ref. to 2-7 [T11CX0].>
P1560	Back-up voltage circuit malfunction	<Ref. to 2-7 [T11CY0].>
P1700	Throttle position sensor circuit malfunction for automatic transmission	<Ref. to 2-7 [T11CZ0].>
P1701	Cruise control set signal circuit malfunction for automatic transmission	<Ref. to 2-7 [T11DA0].>
P1702	Automatic transmission diagnosis input signal circuit low input	<Ref. to 2-7 [T11DB0].>
P1703	Low clutch timing control solenoid valve circuit malfunction	<Ref. to 2-7 [T11DC0].>

DTC No.	Item	Index
P1704	2-4 brake timing control solenoid valve circuit malfunction	<Ref. to 2-7 [T11DD0].>
P1705	2-4 brake pressure control solenoid valve circuit malfunction	<Ref. to 2-7 [T11DE0].>
P1722	Automatic transmission diagnosis input signal circuit high input	<Ref. to 2-7 [T11DF0].>
P1742	Automatic transmission diagnosis input signal circuit malfunction	<Ref. to 2-7 [T11DG0].>

**MEMO:**


**B: DTC P0106 — PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3766

**11B1 : CHECK ANY OTHER DTC ON DISPLAY.**

**NOTE:**

In this case, it is not necessary to inspect DTC P0106.

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0107, P0108 or P1112?
- YES** : Inspect DTC P0107, P0108 or P1112 using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11B2**.

**11B2 : CHECK AIR INTAKE SYSTEM.**

- CHECK** : Are there holes, loose bolts or disconnection of hose on air intake system?
- YES** : Repair air intake system.
- NO** : Go to step **11B3**.

**11B3 : CHECK PRESSURE SENSOR.**

- 1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).
- 2) Place the shift lever in the selector lever in "N" or "P" position.
- 3) Turn A/C switch to OFF.
- 4) Turn all accessory switches to OFF.
- 5) Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.

## Specification:

- Intake manifold absolute pressure

Engine speed	Specified value
Ignition ON	73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)
Idling	20.0 — 46.7 kPa (150 — 350 mmHg, 5.91 — 13.78 inHg)

**CHECK** : *Is the value within the specifications?*

**YES** : Go to step **11B4**.

**NO** : Replace intake air temperature sensor and pressure sensor. <Ref. to 2-7 [W13A0].>

**11B4 : CHECK THROTTLE POSITION.**

Read data of throttle position signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is throttle positioning ratio equal to or less than 5% when throttle is fully closed?*

**YES** : Go to step **11B5**.

**NO** : Adjust or replace throttle position sensor. <Ref. to 2-7 [W10A0].>

**11B5 : CHECK THROTTLE POSITION.**

**CHECK** : *Is throttle positioning ratio equal to or more than 85% when throttle is fully open?*

**YES** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>

**NO** : Replace throttle position sensor. <Ref. to 2-7 [W10A0].>




**C: DTC P0107 — PRESSURE SENSOR CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3766

**11C1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value less than 13.3 kPa (100 mmHg, 3.94 inHg)?*

**YES** : Go to step 11C3.

**NO** : Go to step 11C2.

**11C2 : CHECK POOR CONTACT.**

Check poor contact in ECM and pressure sensor connector. <Ref. to 2-7 [T3C8].>

**CHECK** : *Is there poor contact in ECM or pressure sensor connector?*


**YES** : Repair poor contact in ECM or pressure sensor connector.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**11C3 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
*(B136) No. 15 (+) — Chassis ground (-):*



**CHECK** : *Is the voltage more than 4.5 V?*


**YES** : Go to step 11C5.

**NO** : Go to step 11C4.

**11C4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
*(B136) No. 15 (+) — Chassis ground (-):*



**CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.


NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11C5 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
*(B136) No. 5 (+) — Chassis ground (-):*



**CHECK** : *Is the voltage less than 0.2 V?*

**YES** : Go to step 11C7.

**NO** : Go to step 11C6.

**11C6 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Read data of atmospheric absolute pressure signal using Subaru Select Monitor.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

**CHECK** : *Does the value change more than 13.3 kPa (100 mmHg, 3.94 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?*


- YES** : Repair poor contact in ECM connector.  
**NO** : Go to step 11C7.

**11C7 : CHECK HARNESS BETWEEN ECM  
AND INTAKE AIR TEMPERATURE  
AND PRESSURE SENSOR CON-  
NECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from intake air temperature and pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between intake air temperature sensor and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 3 (+) — Engine ground (-):**




- CHECK** : *Is the voltage more than 4.5 V?*  
**YES** : Go to step 11C8.  
**NO** : Repair open circuit in harness between ECM and intake air temperature and pressure sensor connector.

**11C8 : CHECK HARNESS BETWEEN ECM  
AND INTAKE AIR TEMPERATURE  
AND PRESSURE SENSOR CON-  
NECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and intake air temperature and pressure sensor connector.

**Connector & terminal**

**(B136) No. 16 — (E21) No. 1:**




- CHECK** : *Is the resistance less than 1 Ω?*  
**YES** : Go to step 11C9.  
**NO** : Repair open circuit in harness between ECM and intake air temperature and pressure sensor connector.

**11C9 : CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE AND PRESSURE SENSOR CONNECTOR.**

Measure resistance of harness between intake air temperature and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 4 — Engine ground:**



- CHECK** : **Is the resistance more than 500 kΩ?**
- YES** : Go to step **11C10**.
- NO** : Repair ground short circuit in harness between ECM and intake air temperature and pressure sensor connector.

**11C10 : CHECK POOR CONTACT.**

Check poor contact in intake manifold pressure sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in intake manifold pressure sensor connector?**
- YES** : Repair poor contact in intake air temperature and pressure sensor connector.
- NO** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>


**D: DTC P0108 — PRESSURE SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M3766

**11D1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value more than 119.5 kPa (896.5 mmHg, 35.29 inHg)?*


**YES** : Go to step 11D10.

**NO** : Go to step 11D2.

**11D2 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
*(B136) No. 15 (+) — Chassis ground (-):*



**CHECK** : *Is the voltage more than 4.5 V?*


**YES** : Go to step 11D4.

**NO** : Go to step 11D3.

**11D3 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
*(B136) No. 15 (+) — Chassis ground (-):*



**CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.


NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11D4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
*(B136) No. 5 (+) — Chassis ground (-):*



**CHECK** : *Is the voltage less than 0.2 V?*

**YES** : Go to step 11D6.

**NO** : Go to step 11D5.

**11D5 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Read data of atmospheric absolute pressure signal using Subaru Select Monitor.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

**CHECK** : Does the value change more than 13.3 kPa (100 mmHg, 3.94 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?


- YES** : Repair poor contact in ECM connector.  
**NO** : Go to step 11D6.

**11D6 : CHECK HARNESS BETWEEN ECM  
AND INTAKE AIR TEMPERATURE  
AND PRESSURE SENSOR CON-  
NECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from intake air temperature and pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between intake air temperature and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 3 (+) — Engine ground (-):**




- CHECK** : Is the voltage more than 4.5 V?  
**YES** : Go to step 11D7.  
**NO** : Repair open circuit in harness between ECM and intake air temperature and pressure sensor connector.

**11D7 : CHECK HARNESS BETWEEN ECM  
AND INTAKE AIR TEMPERATURE  
AND PRESSURE SENSOR CON-  
NECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and intake air temperature and pressure sensor connector.

**Connector & terminal**

**(B136) No. 5 — (E21) No. 4:**




- CHECK** : Is the resistance less than 1 Ω?  
**YES** : Go to step 11D8.  
**NO** : Repair open circuit in harness between ECM and intake air temperature and pressure sensor connector.

**11D8 : CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE AND PRESSURE SENSOR CONNECTOR.**

Measure resistance of harness between ECM and intake air temperature and pressure sensor connector.

**Connector & terminal**

**(B136) No. 16 — (E21) No. 1:**



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **11D9**.
- NO** : Repair open circuit in harness between ECM and intake air temperature and pressure sensor connector.

**11D9 : CHECK POOR CONTACT.**

Check poor contact in intake air temperature and pressure sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in intake manifold pressure sensor connector?**
- YES** : Repair poor contact in intake air temperature and pressure sensor connector.
- NO** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>

**11D10 : CHECK HARNESS BETWEEN ECM AND INTAKE AIR TEMPERATURE AND PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF.
- 2) Disconnect connector from intake air temperature and pressure sensor.
- 3) Turn ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON.
- 4) Read data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : **Is the value more than 119.5 kPa (896.5 mmHg, 35.29 inHg)?**
- YES** : Repair battery short circuit in harness between ECM and intake air temperature and pressure sensor connector.
- NO** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>




**E: DTC P0111 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT RANGE/ PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3766

**11E1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0112, P0113, P0116, P0117 or P0125?*

**YES** : Inspect DTC P0112, P0113, P0116, P0117 or P0125 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0111.

**NO** : Go to step **11E2**.

**11E2 : CHECK ENGINE COOLANT TEMPERATURE.**

- 1) Start the engine and warm it up completely.
- 2) Measure engine coolant temperature using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the engine coolant temperature between 75°C (167°F) and 95°C (203°F)?*

**YES** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>

**NO** : Inspect DTC P0125 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>


**F: DTC P0112 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT LOW INPUT**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3766

**11F1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value greater than 120°C (248°F)?*

**YES** : Go to step 11F2.

**NO** : Repair poor contact.

## NOTE:

In this case, repair the following:

- Poor contact in intake air temperature and pressure sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**11F2 : CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from intake air temperature and pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Read data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value less than -40°C (-40°F)?*

**YES** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>

**NO** : Repair ground short circuit in harness between intake air temperature sensor and ECM connector.


**G: DTC P0113 — INTAKE AIR TEMPERATURE SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3766

**11G1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value less than  $-40^{\circ}\text{C}$  ( $-40^{\circ}\text{F}$ )?*

**YES** : Go to step **11G2**.

**NO** : Repair poor contact.

**NOTE:**

In this case, repair the following:


- Poor contact in intake air temperature and pressure sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**11G2 : CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from intake air temperature and pressure sensor.
- 3) Measure voltage between intake air temperature and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 2 (+) — Engine ground (-):**



**CHECK** : *Is the voltage more than 10 V?*

**YES** : Repair battery short circuit in harness between intake air temperature and pressure sensor and ECM connector.


**NO** : Go to step **11G3**.

**11G3 : CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between intake air temperature and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 2 (+) — Engine ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between intake air temperature and pressure sensor and ECM connector.
- NO** : Go to step **11G4**.

**11G4 : CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.**

Measure voltage between intake air temperature and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 2 (+) — Engine ground (-):**



- CHECK** : **Is the voltage more than 3 V?**
- YES** : Go to step **11G5**.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between intake air temperature and pressure sensor and ECM connector
- Poor contact in intake air temperature and pressure sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**11G5 : CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE AND PRESSURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between intake air temperature and pressure sensor connector and engine ground.

**Connector & terminal**

**(E21) No. 1 — Engine ground:**



**CHECK** : **Is the resistance less than 5 Ω?**

**YES** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between intake air temperature and pressure sensor and ECM connector
- Poor contact in intake air temperature and pressure sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)




## H: DTC P0116 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3564

**11H1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : ***Is the value greater than 150°C (302°F)?***

**YES** : Go to step 11H2.

**NO** : Repair poor contact.

## NOTE:

In this case, repair the following:

- Poor contact in engine coolant temperature sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**11H2 : CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from engine coolant temperature sensor.
- 3) Turn ignition switch to ON.
- 4) Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : ***Is the value less than -40°C (-40°F)?***

**YES** : Replace engine coolant temperature sensor. <Ref. to 2-7 [W4A0].>

**NO** : Repair ground short circuit in harness between engine coolant temperature sensor and ECM connector.


**I: DTC P0117 — ENGINE COOLANT TEMPERATURE SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Hard to start
  - Erroneous idling
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3564

**1111 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : **Is the value less than  $-40^{\circ}\text{C}$  ( $-40^{\circ}\text{F}$ )?**

**YES** : Go to step **1112**.

**NO** : Repair poor contact.

## NOTE:

In this case, repair the following:


- Poor contact in engine coolant temperature sensor
- Poor contact in ECM
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**1112 : CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from engine coolant temperature sensor.
- 3) Measure voltage between engine coolant temperature sensor connector and engine ground.

**Connector & terminal**

**(E8) No. 1 (+) — Engine ground (-):**



**CHECK** : **Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.


**NO** : Go to step **1113**.

**1113 : CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between engine coolant temperature sensor connector and engine ground.

**Connector & terminal**

**(E8) No. 1 (+) — Engine ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.
- NO** : Go to step **1114**.

**1114 : CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

Measure voltage between engine coolant temperature sensor connector and engine ground.

**Connector & terminal**

**(E8) No. 1 (+) — Engine ground (-):**



- CHECK** : **Is the voltage more than 4 V?**
- YES** : Go to step **1115**.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and engine coolant temperature sensor connector
- Poor contact in engine coolant temperature sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**1115 : CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between engine coolant temperature sensor connector and engine ground.

**Connector & terminal**

**(E8) No. 2 — Engine ground:**



**CHECK** : **Is the resistance less than 5 Ω?**

**YES** : Replace engine coolant temperature sensor. <Ref. to 2-7 [W4A0].>

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and engine coolant temperature sensor connector
- Poor contact in engine coolant temperature sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)


**J: DTC P0121 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (HIGH INPUT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3774

**11J1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0122 or P0123?
- YES** : Inspect DTC P0122 or P0123 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0121.

- NO** : Replace throttle position sensor. <Ref. to 2-7 [W10A2].>

**MEMO:**




**K: DTC P0122 — THROTTLE POSITION SENSOR CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3774

**11K1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value less than 0.1 V?*
- YES** : Go to step 11K2.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.


NOTE:

- In this case, repair the following:
- Poor contact in throttle position sensor connector
  - Poor contact in ECM connector
  - Poor contact in coupling connector (B21)

**11K2 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground while throttle valve is fully closed.

**Connector & terminal**  
**(B136) No. 15 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 11K4.
- NO** : Go to step 11K3.

**11K3 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
**(B136) No. 15 (+) — Chassis ground (-):**



- CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair poor contact in ECM connector.
- NO** : Contact with SOA service.


NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11K4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
**(B136) No. 17 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage less than 0.1 V?*
- YES** : Go to step 11K6.
- NO** : Go to step 11K5.

**11K5 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Measure voltage between ECM connector and chassis ground.

**CHECK** : *Does the voltage change more than 0.1 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?*

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 11K6.

**11K6 : CHECK HARNESS BETWEEN ECM  
AND THROTTLE POSITION SENSOR  
CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from throttle position sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between throttle position sensor connector and engine ground.

**Connector & terminal**

**(E13) No. 4 (+) — Engine ground (-):**



**CHECK** : *Is the voltage more than 4.5 V?*

**YES** : Go to step 11K7.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between throttle position sensor and ECM connector
- Poor contact in throttle position sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**11K7 : CHECK HARNESS BETWEEN ECM  
AND THROTTLE POSITION SENSOR  
CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between ECM connector and throttle position sensor connector.

**Connector & terminal**

**(B136) No. 17 — (E13) No. 3:**



**CHECK** : *Is the resistance less than 1 Ω?*

**YES** : Go to step 11K8.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between throttle position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in throttle position sensor connector
- Poor contact in coupling connector (B21)

**11K8 : CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.**

Measure resistance of harness between throttle position sensor connector and engine ground.

**Connector & terminal**

**(E13) No. 3 — Engine ground:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between throttle position sensor and ECM connector.
- NO** : Go to step **11K9**.

**11K9 : CHECK POOR CONTACT.**

Check poor contact in throttle position sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in throttle position sensor connector?**
- YES** : Repair poor contact in throttle position sensor connector.
- NO** : Replace throttle position sensor. <Ref. to 2-7 [W10A2].>


**L: DTC P0123 — THROTTLE POSITION SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3774

**11L1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value more than 4.9 V?*

**YES** : Go to step 11L2.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.

**NOTE:**

In this case, repair the following:


- Poor contact in throttle position sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

**11L2 : CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from throttle position sensor.
- 3) Measure resistance of harness between throttle position sensor connector and engine ground.

**Connector & terminal**

**(E13) No. 2 — Engine ground:**



**CHECK** : *Is the resistance less than 5 Ω?*

**YES** : Go to step 11L3.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between throttle position sensor and ECM connector
- Poor contact in coupling connector (B21)
- Poor contact in joint connector (B83)

**11L3 : CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between throttle position sensor connector and engine ground.

**Connector & terminal**

**(E13) No. 3 (+) — Engine ground (-):**



- CHECK** : **Is the voltage more than 4.9 V?**
- YES** : Repair battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Replace throttle position sensor. <Ref. to 2-7 [W10A2].>


**M: DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine would not return to idling.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



**11M1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0116 or P0117?
- YES** : Inspect DTC P0116 or P0117 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0125.

- NO** : Go to step **11M2**.

**11M2 : CHECK THERMOSTAT.**

- CHECK** : Does thermostat remain opened?
- YES** : Replace thermostat. <Ref. to 2-5 [W2A0].>
- NO** : Replace engine coolant temperature sensor. <Ref. to 2-7 [W4A0].>




**N: DTC P0130 — FRONT OXYGEN (A/F) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3775

**11N1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1130, P1131, P1132 or P1133?
- YES** : Inspect DTC P1130, P1131, P1132 or P1133 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>
- NO** : Go to step 11N2.

**11N2 : CHECK FRONT OXYGEN (A/F) SENSOR DATA.**

- 1) Start engine.
- 2) While observing the Subaru Select Monitor or OBD-II general scan tool screen, warm-up the engine until coolant temperature is above 70°C (160°F).  
If the engine is already warmed-up, operate at idle speed for at least 1 minute.
- 3) Read data of front oxygen (A/F) sensor signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value equal to or more than 0.85 and equal to less than 1.15 in idling?*

**YES** : Go to step 11N3.

**NO** : Go to step 11N4.

**11N3 : CHECK FRONT OXYGEN (A/F) SENSOR DATA.**

Race engine at speeds from idling to 5,000 rpm for a total of 5 cycles.

NOTE:

To increase engine speed to 5,000 rpm, slowly depress accelerator pedal, taking approximately 5 seconds, and quickly release accelerator pedal to decrease engine speed.

**CHECK** : *Is the value more than 1.1 for a moment?*

**YES** : Go to step 11N6.

**NO** : Go to step 11N4.

**11N4 : CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM and front oxygen (A/F) sensor connector.
- 3) Measure resistance between ECM and front oxygen (A/F) sensor.


**Connector & terminals**

**(B136) No. 6 — (B18) No. 1:**

**(B136) No. 7 — (B18) No. 6:**

**(B136) No. 19 — (B18) No. 3:**

**(B136) No. 20 — (B18) No. 4:**



**CHECK** : *Is the resistance less than 5 Ω?*

**YES** : Go to step 11N5.

**NO** : Repair open circuit between ECM and front oxygen (A/F) sensor.

**11N5 : CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR.**

Measure resistance between ECM and chassis ground.


**Connector & terminals**

**(B136) No. 6 — Chassis ground:**

**(B136) No. 7 — Chassis ground:**

**(B136) No. 19 — Chassis ground:**

**(B136) No. 20 — Chassis ground:**



**CHECK** : **Is the resistance more than 1 MΩ?**

**YES** : Go to step **11N6**.

**NO** : Repair ground short circuit between ECM and front oxygen (A/F) sensor.

**11N6 : CHECK EXHAUST SYSTEM.**

Check exhaust system parts.

**NOTE:**

Check the following items.

- Loose installation of portions
- Damage (crack, hole etc.) of parts
- Looseness of front oxygen (A/F) sensor
- Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor

**CHECK** : **Is there a fault in exhaust system?**

**YES** : Repair or replace faulty parts.

**NO** : Replace front oxygen (A/F) sensor.  
<Ref. to 2-7 [W8A0].>

**O: DTC P0133 — FRONT OXYGEN (A/F) SENSOR CIRCUIT SLOW RESPONSE —**


**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**



B2M3775

**1101 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1130, P1131, P1132 or P1133?

**YES** : Inspect DTC P1130, P1131, P1132 or P1133 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**  
In this case, it is not necessary to inspect DTC P0133.

**NO** : Go to step 1102.

**1102 : CHECK EXHAUST SYSTEM.**

**NOTE:**

Check the following items.

- Loose installation of front portion of exhaust pipe onto cylinder heads
- Loose connection between front exhaust pipe and front catalytic converter
- Damage of exhaust pipe resulting in a hole

**CHECK** : Is there a fault in exhaust system?

**YES** : Repair exhaust system.

**NO** : Replace front oxygen (A/F) sensor. <Ref. to 2-7 [W8A0].>

**P: DTC P0136 — REAR OXYGEN SENSOR CIRCUIT MALFUNCTION —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**● WIRING DIAGRAM:**



B2M3778

**11P1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1130 or P1131?
- YES** : Go to step 11P2.
- NO** : Go to step 11P3.

**11P2 : CHECK FAILURE CAUSE OF P0130.**

Inspect DTC P1130 or P1131 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

- CHECK** : Is the failure cause of P1130 or P1131 in the fuel system?
- YES** : Check fuel system.

**NOTE:**

In this case, it is not necessary to inspect DTC P0136.

- NO** : Go to step 11P3.

**11P3 : CHECK REAR OXYGEN SENSOR DATA.**

1) Warm-up the engine until engine coolant temperature is above 70°C (160°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for two minutes.

2) Read data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Does the value fluctuate?*
- YES** : Go to step **11P7**.
- NO** : Go to step **11P4**.

**11P4 : CHECK REAR OXYGEN SENSOR DATA.**

Read data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II General Scan Tool.


- CHECK** : *Is the value fixed between 0.2 and 0.4 V?*
- YES** : Go to step **11P5**.
- NO** : Replace rear oxygen sensor. <Ref. to 2-7 [W9A0].>

**11P5 : CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and rear oxygen sensor.
- 3) Measure resistance of harness between ECM and rear oxygen sensor connector.

**Connector & terminal**

**(B136) No. 16 — (T6) No. 3:**




- CHECK** : *Is the resistance more than 3 Ω?*
- YES** : Repair open circuit in harness between ECM and rear oxygen sensor connector.
- NO** : Go to step **11P6**.

**11P6 : CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from rear oxygen sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between rear oxygen sensor harness connector and engine ground or chassis ground.

**Connector & terminal**

**(T6) No. 4 (+) — Engine ground (-):**



**CHECK** : **Is the voltage more than 0.2 V?**

**YES** : Replace rear oxygen sensor. <Ref. to 2-7 [W9A0].>

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between rear oxygen sensor and ECM connector
- Poor contact in rear oxygen sensor connector
- Poor contact in ECM connector

**11P7 : CHECK EXHAUST SYSTEM.**

Check exhaust system parts.

**NOTE:**

Check the following items.

- Loose installation of portions
- Damage (crack, hole etc.) of parts
- Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor

**CHECK** : **Is there a fault in exhaust system?**

**YES** : Repair or replace faulty parts.

**NO** : Replace rear oxygen sensor. <Ref. to 2-7 [W9A0].>

**Q: DTC P0139 — REAR OXYGEN SENSOR CIRCUIT SLOW RESPONSE —**


**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**• WIRING DIAGRAM:**



B2M3778

**11Q1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0136?

**YES** : Inspect DTC P0136 using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>

**NOTE:**  
In this case, it is not necessary to inspect DTC P0139.

**NO** : Replace rear oxygen sensor. <Ref. to 2-7 [W9A0].>



**R: DTC P0141 — REAR OXYGEN SENSOR HEATER CIRCUIT MALFUNCTION**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**




B2M3778

**11R1 : CHECK GROUND CIRCUIT OF ECM.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 35 — Chassis ground:**



- CHECK** : *Is the resistance less than 5 Ω?*
- YES** : Go to step 11R3.
- NO** : Go to step 11R2.

**11R2 : CHECK GROUND CIRCUIT OF ECM.**

- 1) Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between ECM and engine ground terminal
- Poor contact in ECM connector
- Poor contact in coupling connector (B22)

- 2) Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 34 — Chassis ground:**



- CHECK** : *Is the resistance less than 5 Ω?*
- YES** : Go to step 11R3.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and engine ground terminal
- Poor contact in ECM connector
- Poor contact in coupling connector (B22)

**11R3 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of rear oxygen sensor heater current using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value more than 0.2 A?*

**YES** : Repair connector.

NOTE:

In this case, repair the following:

- Poor contact in rear oxygen sensor connector
- Poor contact in rear oxygen sensor connecting harness connector
- Poor contact in ECM connector


**NO** : Go to step 11R4.

**11R4 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Start and idle the engine.
- 2) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 21 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage less than 1.0 V?*

**YES** : Go to step 11R7.


**NO** : Go to step 11R5.

**11R5 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 21 (+) — Chassis ground (-):**



**CHECK** : *Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 11R6.

**11R6 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Disconnect connector from rear oxygen sensor.
- 2) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 21 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage less than 1.0 V?*

**YES** : Replace ECM. <Ref. to 2-7 [W19A0].>


**NO** : Repair battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>

**11R7 : CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from rear oxygen sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between rear oxygen sensor connector and engine ground or chassis ground.

**Connector & terminal**

**(T6) No. 2 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step 11R8.
- NO** : Repair power supply line.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between main relay and rear oxygen sensor connector
- Poor contact in rear oxygen sensor connector
- Poor contact in coupling connector (T5)

**11R8 : CHECK REAR OXYGEN SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between rear oxygen sensor connector terminals.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : *Is the resistance less than 30 Ω?*
- YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between rear oxygen sensor and ECM connector
- Poor contact in rear oxygen sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (T5)

- NO** : Replace rear oxygen sensor. <Ref. to 2-7 [W9A0].>

**S: DTC P0170 — FUEL TRIM MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- Erroneous idling
- Engine stalls.
- Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

**11S1 : CHECK EXHAUST SYSTEM.**

**CHECK** : *Are there holes or loose bolts on exhaust system?*

**YES** : Repair exhaust system.

**NO** : Go to step 11S2.

**11S2 : CHECK AIR INTAKE SYSTEM.**

**CHECK** : *Are there holes, loose bolts or disconnection of hose on air intake system?*

**YES** : Repair air intake system.


**NO** : Go to step 11S3.

**11S3 : CHECK FUEL PRESSURE.****WARNING:**


- Place “NO FIRE” signs near the working area.
- Be careful not to spill fuel on the floor.

1) Release fuel pressure.

(1) Disconnect connector from fuel pump relay.




- (2) Start the engine and run it until it stalls.
  - (3) After the engine stalls, crank it for five more seconds.
  - (4) Turn ignition switch to OFF.
- 2) Connect connector to fuel pump relay.
  - 3) Disconnect fuel delivery hose from fuel filter, and connect fuel pressure gauge.



- 4) Install fuel filler cap.
- 5) Start the engine and idle while gear position is neutral.
- 6) Measure fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold.

**WARNING:**  
**Before removing fuel pressure gauge, release fuel pressure.**

**NOTE:**  
 If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.



**CHECK** : **Is fuel pressure between 284 and 314 kPa (2.9 — 3.2 kg/cm<sup>2</sup>, 41 — 46 psi)?**

- YES** : Go to step 11S4.
- NO** : Repair the following items.

Fuel pressure too high	<ul style="list-style-type: none"> <li>● Clogged fuel return line or bent hose</li> </ul>
Fuel pressure too low	<ul style="list-style-type: none"> <li>● Improper fuel pump discharge</li> <li>● Clogged fuel supply line</li> </ul>


**11S4 : CHECK FUEL PRESSURE.**

After connecting pressure regulator vacuum hose, measure fuel pressure.

**WARNING:**  
**Before removing fuel pressure gauge, release fuel pressure.**

**NOTE:**

- If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.
- If out of specification as measured at this step, check or replace pressure regulator and pressure regulator vacuum hose.



**CHECK** : **Is fuel pressure between 206 and 235 kPa (2.1 — 2.4 kg/cm<sup>2</sup>, 30 — 34 psi)?**

- YES** : Go to step 11S5.
- NO** : Repair the following items.

Fuel pressure too high	<ul style="list-style-type: none"> <li>● Faulty pressure regulator</li> <li>● Clogged fuel return line or bent hose</li> </ul>
Fuel pressure too low	<ul style="list-style-type: none"> <li>● Faulty pressure regulator</li> <li>● Improper fuel pump discharge</li> <li>● Clogged fuel supply line</li> </ul>

**11S5 : CHECK ENGINE COOLANT TEMPERATURE SENSOR.**

- 1) Start the engine and warm-up completely.
- 2) Read data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : ***Is temperature between 70°C (158°F) and 100°C (212°F)?***

**YES** : Go to step **11S6**.

**NO** : Replace engine coolant temperature sensor. <Ref. to 2-7 [W4A0].>

**11S6 : CHECK INTAKE MANIFOLD PRESSURE SENSOR SIGNAL.**

- 1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).
- 2) Place the selector lever in "N" or "P" position.
- 3) Turn A/C switch to OFF.
- 4) Turn all accessory switches to OFF.
- 5) Read data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**Specification:**

Engine speed	Specified value
Idling	24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 41.3 inHg)
Ignition ON	73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)

**CHECK** : ***Is the voltage within the specifications?***

**YES** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**NO** : Replace intake air temperature and pressure sensor. <Ref. to 2-7 [W13A0].>

**T: DTC P0181 — FUEL TEMPERATURE SENSOR A CIRCUIT RANGE/PERFORMANCE PROBLEM —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**



B2M3780

**11T1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0182 or P0183?

**YES** : Inspect DTC P0182 or P0183 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**  
In this case, it is not necessary to inspect DTC P0181.

**NO** : Replace fuel temperature sensor. <Ref. to 2-1 [W6A0].>



**U: DTC P0182 — FUEL TEMPERATURE SENSOR A CIRCUIT LOW INPUT —**


**● DTC DETECTING CONDITION:**

- Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**



B2M3780

**11U1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


**CHECK** : **Is the value greater than 150°C (302°F)?**

**YES** : Go to step 11U2.

**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**11U2 : CHECK CURRENT DATA.**

- 1) Turn ignition switch to OFF.
- 2) Remove access hole lid.



- 3) Disconnect connector from fuel pump.
- 4) Turn ignition switch to ON.
- 5) Read data of fuel temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : **Is the value less than -40°C (-40°F)?**

**YES** : Replace fuel temperature sensor. <Ref. to 2-1 [W6A0].>

**NO** : Repair ground short circuit in harness between fuel pump and ECM connector.


**V: DTC P0183 — FUEL TEMPERATURE SENSOR A CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3780

**11V1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.


- CHECK** : *Is the value less than -40°C (-40°F)?*  
**YES** : Go to step 11V2.  
**NO** : Repair poor contact.

NOTE:

- In this case, repair the following:
- Poor contact in fuel pump connector
  - Poor contact in ECM connector
  - Poor contact in coupling connectors (B22, B99 and R57)
  - Poor contact in joint connector (B83)


**11V2 : CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Remove access hole lid.



- 3) Disconnect connector from fuel pump.
- 4) Measure voltage between fuel pump connector and chassis ground.

**Connector & terminal**  
**(R58) No. 6 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 10 V?*  
**YES** : Repair battery short circuit in harness between ECM and fuel pump connector.  
**NO** : Go to step 11V3.

**11V3 : CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between fuel pump connector and chassis ground.

**Connector & terminal**

**(R58) No. 6 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and fuel pump connector.
- NO** : Go to step **11V4**.

**11V4 : CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.**

Measure voltage between fuel pump connector and chassis ground.

**Connector & terminal**

**(R58) No. 6 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 4 V?**
- YES** : Go to step **11V5**.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and fuel pump connector
- Poor contact in fuel pump connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B99 and R57)

**11V5 : CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance of harness between fuel pump connector and chassis ground.

**Connector & terminal**

**(R58) No. 5 — Chassis ground:**



**CHECK** : **Is the resistance less than 5  $\Omega$ ?**

**YES** : Replace fuel temperature sensor. <Ref. to 2-1 [W6A0].>

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and fuel pump connector
- Poor contact in fuel pump connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B99 and R57)
- Poor contact in joint connector (B83)

**W: DTC P0301 — CYLINDER 1 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to 2-7 [T11Z0].>

**X: DTC P0302 — CYLINDER 2 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to 2-7 [T11Z0].>

**Y: DTC P0303 — CYLINDER 3 MISFIRE DETECTED —**

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to 2-7 [T11Z0].>

**Z: DTC P0304 — CYLINDER 4 MISFIRE DETECTED —**

**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)


**• TROUBLE SYMPTOM:**

- Engine stalls.
- Erroneous idling
- Rough driving

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**



B2M3781

**11Z1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P0116, P0117 or P0125?

**YES** : Inspect DTC P0106, P0107, P0108, P0116, P0117 or P0125 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

NOTE:

In this case, it is not necessary to inspect DTC P0301, P0302, P0303 and P0304.


**NO** : Go to step 11Z2.

**11Z2 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground on faulty cylinders.

**Connector & terminal**

- #1 (B134) No. 4 (+) — Chassis ground (-):
- #2 (B134) No. 13 (+) — Chassis ground (-):
- #3 (B134) No. 14 (+) — Chassis ground (-):
- #4 (B134) No. 15 (+) — Chassis ground (-):



**CHECK** : Is the voltage more than 10 V?

**YES** : Go to step 11Z7.


**NO** : Go to step 11Z3.

**11Z3 : CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel injector on faulty cylinders.
- 3) Measure voltage between ECM connector and engine ground on faulty cylinders.

**Connector & terminal**

- #1 (E5) No. 1 — Engine ground:
- #2 (E16) No. 1 — Engine ground:
- #3 (E6) No. 1 — Engine ground:
- #4 (E17) No. 1 — Engine ground:



**CHECK** : Is the resistance less than 10 Ω?

**YES** : Repair ground short circuit in harness between fuel injector and ECM connector.

**NO** : Go to step 11Z4.




**11Z4 : CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.**

Measure resistance of harness connector between ECM connector and fuel injector on faulty cylinders.

**Connector & terminal**

- #1 (B134) No. 4 — (E5) No. 1:
- #2 (B134) No. 13 — (E16) No. 1:
- #3 (B134) No. 14 — (E6) No. 1:
- #4 (B134) No. 15 — (E17) No. 1:



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 11Z5.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and fuel injector connector
- Poor contact in coupling connector (B21)

**11Z5 : CHECK FUEL INJECTOR.**

Measure resistance between fuel injector terminals on faulty cylinder.

**Terminals**

**No. 1 — No. 2:**




- CHECK** : *Is the resistance between 5 and 20 Ω?*
- YES** : Go to step 11Z6.
- NO** : Replace faulty fuel injector. <Ref. to 2-7 [W18A0].>

**11Z6 : CHECK POWER SUPPLY LINE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between fuel injector and engine ground on faulty cylinders.

**Connector & terminal**

- #1 (E5) No. 2 (+) — Engine ground (-):
- #2 (E16) No. 2 (+) — Engine ground (-):
- #3 (E6) No. 2 (+) — Engine ground (-):
- #4 (E17) No. 2 (+) — Engine ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Repair poor contact in all connectors in fuel injector circuit.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between main relay and fuel injector connector on faulty cylinders
- Poor contact in coupling connector
- Poor contact in main relay connector
- Poor contact in fuel injector connector on faulty cylinders

**11Z7 : CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel injector on faulty cylinder.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM connector and chassis ground on faulty cylinders.

**Connector & terminal**


- #1 (B134) No. 4 (+) — Chassis ground (-):
- #2 (B134) No. 13 (+) — Chassis ground (-):
- #3 (B134) No. 14 (+) — Chassis ground (-):
- #4 (B134) No. 15 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Repair battery short circuit in harness between ECM and fuel injector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step 11Z8.

**11Z8 : CHECK FUEL INJECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between fuel injector terminals on faulty cylinder.

**Terminals****No. 1 — No. 2:**

- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Replace faulty fuel injector <Ref. to 2-7 [W18A0].> and ECM <Ref. to 2-7 [W19A0].>.
- NO** : Go to step **11Z9**.

**11Z9 : CHECK INSTALLATION OF CAM-SHAFT POSITION SENSOR/ CRANKSHAFT POSITION SENSOR.**

- CHECK** : **Is camshaft position sensor or crankshaft position sensor loosely installed?**
- YES** : Tighten camshaft position sensor or crankshaft position sensor.
- NO** : Go to step **11Z10**.

**11Z10 : CHECK CRANKSHAFT SPROCKET.**


Remove timing belt cover.

- CHECK** : **Is crankshaft sprocket rusted or does it have broken teeth?**
- YES** : Replace crankshaft sprocket. <Ref. to 2-3 [W3A4].>
- NO** : Go to step **11Z11**.

**11Z11 : CHECK INSTALLATION CONDITION OF TIMING BELT.**


Turn crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block.

ST 499987500 CRANKSHAFT SOCKET



- CHECK** : **Is timing belt dislocated from its proper position?**
- YES** : Repair installation condition of timing belt. <Ref. to 2-3 [W3A0].>
- NO** : Go to step **11Z12**.


**11Z12 : CHECK FUEL LEVEL.**



- CHECK** : *Is the fuel meter indication higher than the "Lower" level?*
- YES** : Go to step 11Z13.
- NO** : Replenish fuel so fuel meter indication is higher than the "Lower" level. After replenishing fuel, Go to step 11Z13.

**11Z13 : CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL).**

- 1) Clear memory using Subaru Select Monitor.  
<Ref. to 2-7 [T3D0].>
- 2) Start engine, and drive the vehicle more than 10 minutes.



- CHECK** : *Is the MIL coming on or blinking?*
- YES** : Go to step 11Z15.
- NO** : Go to step 11Z14.

**11Z14 : CHECK CAUSE OF MISFIRE DIAGNOSED.**

- CHECK** : *Was the cause of misfire diagnosed when the engine is running?*
- YES** : Finish diagnostics operation, if the engine has no abnormality.

NOTE:  
Ex. Remove spark plug cord, etc.

- NO** : Repair poor contact.

NOTE:  
In this case, repair the following:

- Poor contact in ignitor connector
- Poor contact in ignition coil connector
- Poor contact in fuel injector connector on faulty cylinders
- Poor contact in ECM connector
- Poor contact in coupling connector

**11Z15 : CHECK AIR INTAKE SYSTEM.**

- CHECK** : *Is there a fault in air intake system?*
- YES** : Repair air intake system.

NOTE:  
Check the following items:

- Are there air leaks or air suction caused by loose or dislocated nuts and bolts?
- Are there cracks or any disconnection of hoses?

- NO** : Go to step 11Z16.

**11Z16 : CHECK MISFIRE SYMPTOM.**

- 1) Turn ignition switch to ON.
  - 2) Read diagnostic trouble code (DTC).
    - Subaru Select Monitor  
<Ref. to 2-7 [T3C2].>
    - OBD-II general scan tool
- For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.

NOTE:  
Perform diagnosis according to the items listed below.

- CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate only one DTC?*
- YES** : Go to step 11Z21.
- NO** : Go to step 11Z17.

**11Z17 : CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.**

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0301 and P0302?*

**YES** : Go to step 11Z22.

**NO** : Go to step 11Z18.

**11Z18 : CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.**

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0303 and P0304?*

**YES** : Go to step 11Z23.

**NO** : Go to step 11Z19.

**11Z19 : CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.**

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0301 and P0303?*

**YES** : Go to step 11Z24.

**NO** : Go to step 11Z20.

**11Z20 : CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.**

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0302 and P0304?*

**YES** : Go to step 11Z25.

**NO** : Go to step 11Z26.

**11Z21 : ONLY ONE CYLINDER**

**CHECK** : *Is there a fault in that cylinder?*

**YES** : Repair or replace faulty parts.

**NOTE:**

Check the following items.

- Spark plug
- Spark plug cord
- Fuel injector
- Compression ratio

**NO** : Go to DTC P0170. <Ref. to 2-7 [T11S0].>

**11Z22 : GROUP OF #1 AND #2 CYLINDERS**

**CHECK** : *Are there faults in #1 and #2 cylinders?*

**YES** : Repair or replace faulty parts.

**NOTE:**

- Check the following items.
  - Spark plugs
  - Fuel injectors
  - Ignition coil
  - Compression ratio
- If no abnormal is discovered, check for "8. D: IGNITION CONTROL SYSTEM" of #1 and #2 cylinders side. <Ref. to 2-7 [T8D0].>

**NO** : Go to DTC P0170. <Ref. to 2-7 [T11S0].>

**11Z23 : GROUP OF #3 AND #4 CYLINDERS**

**CHECK** : *Are there faults in #3 and #4 cylinders?*

**YES** : Repair or replace faulty parts.

**NOTE:**

- Check the following items.
  - Spark plugs
  - Fuel injectors
  - Ignition coil
- If no abnormal is discovered, check for "9. D: IGNITION CONTROL SYSTEM" of #3 and #4 cylinders side. <Ref. to 2-7 [T8D0].>

**NO** : Go to DTC P0170. <Ref. to 2-7 [T11S0].>

**11Z24 : GROUP OF #1 AND #3 CYLINDERS**

**CHECK** : *Are there faults in #1 and #3 cylinders?*

**YES** : Repair or replace faulty parts.

**NOTE:**

Check the following items.

- Spark plugs
- Fuel injectors
- Skipping timing belt teeth

**NO** : Go to DTC P0170. <Ref. to 2-7 [T11S0].>

**11Z25 : GROUP OF #2 AND #4 CYLINDERS**

**CHECK** : *Are there faults in #2 and #4 cylinders?*

**YES** : Repair or replace faulty parts.

NOTE:

Check the following items.

- Spark plugs
- Fuel injectors
- Compression ratio
- Skipping timing belt teeth

**NO** : Go to DTC P0170. <Ref. to 2-7 [T11S0].>

**11Z26 : CYLINDER AT RANDOM**

**CHECK** : *Is the engine idle rough?*

**YES** : Go to DTC P0170. <Ref. to 2-7 [T11S0].>

**NO** : Repair or replace faulty parts.

NOTE:

Check the following items.

- Spark plugs
- Fuel injectors
- Compression ratio


**AA: DTC P0325 — KNOCK SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Poor driving performance
  - Knocking occurs.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3571

**11AA1 : CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance between ECM harness connector and chassis ground.

**Connector & terminal**  
**(B136) No. 4 — Chassis ground:**




- CHECK** : *Is the resistance more than 700 kΩ?*
- YES** : Go to step 11AA3.
- NO** : Go to step 11AA2.

**11AA2 : CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**  
**(B136) No. 4 — Chassis ground:**




- CHECK** : *Is the resistance less than 400 kΩ?*
- YES** : Go to step 11AA5.
- NO** : Go to step 11AA6.

**11AA3 : CHECK KNOCK SENSOR.**

- 1) Disconnect connector from knock sensor.
- 2) Measure resistance between knock sensor connector terminal and engine ground.

**Terminal**  
**No. 2 — Engine ground:**



- CHECK** : *Is the resistance more than 700 kΩ?*
- YES** : Go to step 11AA4.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between knock sensor and ECM connector
- Poor contact in knock sensor connector
- Poor contact in coupling connector (B21)

**11AA4 : CHECK CONDITION OF KNOCK SENSOR INSTALLATION.**

- CHECK** : *Is the knock sensor installation bolt tightened securely?*
- YES** : Replace knock sensor. <Ref. to 2-7 [W7A0].>
- NO** : Tighten knock sensor installation bolt securely.




**11AA5 : CHECK KNOCK SENSOR.**

- 1) Disconnect connector from knock sensor.
- 2) Measure resistance between knock sensor connector terminal and engine ground.

**Terminal**

**No. 2 — Engine ground:**



- CHECK** : **Is the resistance less than 400 kΩ?**
- YES** : Replace knock sensor. <Ref. to 2-7 [W7A0].>
- NO** : Repair ground short circuit in harness between knock sensor connector and ECM connector.

**NOTE:**


The harness between both connectors is shielded. Repair short circuit of harness together with shield.

**11AA6 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Connect connectors to ECM and knock sensor.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B136) No. 4 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 2 V?**
- YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)

**NOTE:**

In this case, repair the following:

- Poor contact in knock sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- NO** : Repair poor contact in ECM connector.

**MEMO:**


**AB: DTC P0335 — CRANKSHAFT POSITION SENSOR CIRCUIT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**




B2M3822

**11AB1 : CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from crankshaft position sensor.
- 3) Measure resistance of harness between crankshaft position sensor connector and engine ground.

**Connector & terminal**

**(E10) No. 1 — Engine ground:**



**CHECK** : **Is the resistance more than 100 kΩ?**

**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between crankshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)


**NO** : Go to step **11AB2**.

**11AB2 : CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between crankshaft position sensor connector and engine ground.

**Connector & terminal**

**(E10) No. 1 — Engine ground:**



**CHECK** : **Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between crankshaft position sensor and ECM connector.

**NOTE:**

The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.


**NO** : Go to step **11AB3**.

**11AB3 : CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between crankshaft position sensor connector and engine ground.

**Connector & terminal**

**(E10) No. 2 — Engine ground:**



**CHECK** : **Is the resistance less than 5 Ω?**

**YES** : Go to step **11AB4**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between crankshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

**11AB4 : CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.**

**CHECK** : **Is the crankshaft position sensor installation bolt tightened securely?**

**YES** : Go to step **11AB5**.


**NO** : Tighten crankshaft position sensor installation bolt securely.

**11AB5 : CHECK CRANKSHAFT POSITION SENSOR.**

- 1) Remove crankshaft position sensor.
- 2) Measure resistance between connector terminals of crankshaft position sensor.

**Terminals**

**No. 1 — No. 2:**



**CHECK** : **Is the resistance between 1 and 4 kΩ?**

**YES** : Repair poor contact in crankshaft position sensor connector.

**NO** : Replace crankshaft position sensor. <Ref. to 2-7 [W5A0].>

**MEMO:**


**AC: DTC P0336 — CRANKSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M3822

**11AC1 : CHECK ANY OTHER DTC ON DISPLAY.**

**11AC2 : CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0335?
- YES** : Inspect DTC P0335 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T10A0].>
- NO** : Go to step **11AC2**.

- Turn ignition switch to OFF.
- CHECK** : Is the crankshaft position sensor installation bolt tightened securely?
- YES** : Go to step **11AC3**.
- NO** : Tighten crankshaft position sensor installation bolt securely.

**11AC3 : CHECK CRANKSHAFT SPROCKET.**

Remove front belt cover.

**CHECK** : **Are crankshaft sprocket teeth cracked or damaged?**


**YES** : Replace crankshaft sprocket. <Ref. to 2-3 [W3A0].>

**NO** : Go to step **11AC4**.

**11AC4 : CHECK INSTALLATION CONDITION OF TIMING BELT.**

Turn crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block.

ST 499987500 CRANKSHAFT SOCKET



**CHECK** : **Is timing belt dislocated from its proper position?**

**YES** : Repair installation condition of timing belt. <Ref. to 2-3 [W3A0].>

**NO** : Replace crankshaft position sensor. <Ref. to 2-7 [W5A0].>




**AD: DTC P0340 — CAMSHAFT POSITION SENSOR CIRCUIT MALFUNCTION**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3562

**11AD1 : CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from camshaft position sensor.
- 3) Measure resistance of harness between camshaft position sensor connector and engine ground.

**Connector & terminal**

**(E15) No. 1 — Engine ground:**



**CHECK** : **Is the resistance more than 100 kΩ?**

**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between camshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)


**NO** : Go to step **11AD2**.

**11AD2 : CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between camshaft position sensor connector and engine ground.

**Connector & terminal**

**(E15) No. 1 — Engine ground:**



**CHECK** : **Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between camshaft position sensor and ECM connector.

**NOTE:**

The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.


**NO** : Go to step **11AD3**.

**11AD3 : CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between camshaft position sensor connector and engine ground.

**Connector & terminal**

**(E15) No. 2 — Engine ground:**



**CHECK** : **Is the resistance less than 5 Ω?**

**YES** : Go to step **11AD4**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between camshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

**11AD4 : CHECK CONDITION OF CAMSHAFT POSITION SENSOR.**

**CHECK** : **Is the camshaft position sensor installation bolt tightened securely?**

**YES** : Go to step **11AD5**.


**NO** : Tighten camshaft position sensor installation bolt securely.

**11AD5 : CHECK CAMSHAFT POSITION SENSOR.**

- 1) Remove camshaft position sensor.
- 2) Measure resistance between connector terminals of camshaft position sensor.

**Terminals**

**No. 1 — No. 2:**



**CHECK** : **Is the resistance between 1 and 4 kΩ?**

**YES** : Repair poor contact in camshaft position sensor connector.

**NO** : Replace camshaft position sensor. <Ref. to 2-7 [W6A0].>

**MEMO:**


**AE: DTC P0341 — CAMSHAFT POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3562

**11AE1 : CHECK ANY OTHER DTC ON DISPLAY.**


- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0340?
- YES** : Inspect DTC P0340 using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11AE2**.

**11AE2 : CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from camshaft position sensor.
- 3) Measure resistance of harness between camshaft position sensor connector and engine ground.

**Connector & terminal**

**(E15) No. 1 — Engine ground:**



**CHECK** : **Is the resistance more than 100 kΩ?**

**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between camshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)


**NO** : Go to step **11AE3**.

**11AE3 : CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between camshaft position sensor connector and engine ground.

**Connector & terminal**

**(E15) No. 1 — Engine ground:**



**CHECK** : **Is the resistance less than 10 Ω?**

**YES** : Repair ground short circuit in harness between camshaft position sensor and ECM connector.

**NOTE:**

The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.


**NO** : Go to step **11AE4**.

**11AE4 : CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between camshaft position sensor connector and engine ground.

**Connector & terminal**

**(E15) No. 2 — Engine ground:**



**CHECK** : *Is the resistance less than 5 Ω?*

**YES** : Go to step 11AE5.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between camshaft position sensor and ECM connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)

**11AE5 : CHECK CONDITION OF CAMSHAFT POSITION SENSOR.**

**CHECK** : *Is the camshaft position sensor installation bolt tightened securely?*

**YES** : Go to step 11AE6.


**NO** : Tighten camshaft position sensor installation bolt securely.

**11AE6 : CHECK CAMSHAFT POSITION SENSOR.**

- 1) Remove camshaft position sensor.
- 2) Measure resistance between connector terminals of camshaft position sensor.

**Terminals**

**No. 1 — No. 2:**



**CHECK** : *Is the resistance between 1 and 4 kΩ?*

**YES** : Go to step 11AE7.

**NO** : Replace camshaft position sensor. <Ref. to 2-7 [W6A0].>

**11AE7 : CHECK CONDITION OF CAMSHAFT POSITION SENSOR.**

Turn ignition switch to OFF.

**CHECK** : *Is the camshaft position sensor installation bolt tightened securely?*

**YES** : Go to step 11AE8.

**NO** : Tighten camshaft position sensor installation bolt securely.

**11AE8 : CHECK CAMSHAFT SPROCKET.**

Remove front belt cover. <Ref. to 2-3 [W3A0].>

**CHECK** : *Are camshaft sprocket teeth cracked or damaged?*


**YES** : Replace camshaft sprocket. <Ref. to 2-3 [W3A0].>

**NO** : Go to step 11AE9.

**11AE9 : CHECK INSTALLATION CONDITION OF TIMING BELT.**

Turn camshaft using ST, and align alignment mark on camshaft sprocket with alignment mark on timing belt cover LH.

ST 499207100 CAMSHAFT SPROCKET WRENCH



- CHECK** : ***Is timing belt dislocated from its proper position?***
- YES** : Repair installation condition of timing belt. <Ref. to 2-3 [W3A0].>
- NO** : Replace camshaft position sensor. <Ref. to 2-7 [W6A0].>




**AF: DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine stalls.
  - Idle mixture is out of specifications.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3782

**11AF1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0130, P0133, P0136, P0139, P0141, P0301, P0302, P0303, P0304, P1130, P1131, P1132, P1133 and P1151?

**YES** : Inspect the relevant DTC using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**  
In this case, it is not necessary to inspect DTC P0420.

**NO** : Go to step 11AF2.

**11AF2 : CHECK EXHAUST SYSTEM.**

Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes.

**NOTE:**  
Check the following positions.

- Between cylinder head and front exhaust pipe
- Between front exhaust pipe and front catalytic converter
- Between front catalytic converter and rear catalytic converter


**CHECK** : Is there a fault in exhaust system?

**YES** : Repair or replace exhaust system. <Ref. to 2-9 [W1A0].>

**NO** : Go to step 11AF3.

**11AF3 : CHECK REAR CATALYTIC CONVERTER.**

Separate rear catalytic converter from rear exhaust pipe.




**CHECK** : Is there damage at rear face of rear catalyst?

**YES** : Replace front catalytic converter <Ref. to 2-1 [W1A0].> and rear catalytic converter <Ref. to 2-1 [W2A0].>

**NO** : Go to step 11AF4.

**11AF4 : CHECK FRONT CATALYTIC CONVERTER.**

Remove front catalytic converter.



**CHECK** : Is there damage at rear face or front face of front catalyst?

**YES** : Replace front catalytic converter. <Ref. to 2-1 [W1A0].>

**NO** : Contact with SOA service.

**NOTE:**  
Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**AG: DTC P0440 — EVAPORATIVE EMISSION CONTROL SYSTEM MALFUNCTION —**

**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**• TROUBLE SYMPTOM:**

- Gasoline smell
- There is a hole of more than 1.0 mm (0.04 in) dia. in evaporation system or fuel tank.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**



B2M3582

**11AG1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11AG2**.

**11AG2 : CHECK FUEL FILLER CAP.**


- 1) Turn ignition switch to OFF.
  - 2) Check the fuel filler cap.
- NOTE:**  
The DTC code is stored in memory if fuel filler cap is or was loose or if the cap chain was caught while tightening.
- CHECK** : *Is the fuel filler cap tightened securely?*
  - YES** : Go to step **11AG3**.
  - NO** : Tighten fuel filler cap securely.

**11AG3 : CHECK FUEL FILLER PIPE PACKING.**

- CHECK** : *Is there any damage to the seal between fuel filler cap and fuel filler pipe?*
- YES** : Repair or replace fuel filler cap and fuel filler pipe. <Ref. to 2-8 [W2A0].>
- NO** : Go to step **11AG4**.


**11AG4 : CHECK DRAIN VALVE.**

1) Connect test mode connector.



- 2) Turn ignition switch to ON.
- 3) Operate drain valve.

**NOTE:**  
Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : *Does drain valve produce operating sound?*
- YES** : Go to step **11AG5**.
- NO** : Replace drain valve. <Ref. to 2-1 [W13A0].>

**11AG5 : CHECK PURGE CONTROL SOLENOID VALVE.**

Operate purge control solenoid valve.

**NOTE:**  
Purge control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : *Does purge control solenoid valve produce operating sound?*
- YES** : Go to step **11AG6**.
- NO** : Replace purge control solenoid valve. <Ref. to 2-1 [W4A0].>

**11AG6 : CHECK PRESSURE CONTROL SOLENOID VALVE.**

Operate pressure control solenoid valve.

**NOTE:**

Pressure control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>



- CHECK** : **Does pressure control solenoid valve produce operating sound?**
- YES** : Go to step **11AG7**.
- NO** : Replace pressure control solenoid valve. <Ref. to 2-1 [W9A0].>

**11AG7 : CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.**

Turn ignition switch to OFF.

- CHECK** : **Is there a hole of more than 1.0 mm (0.04 in) dia. on fuel line?**
- YES** : Repair or replace fuel line. <Ref. to 2-8 [W8A0].>
- NO** : Go to step **11AG8**.

**11AG8 : CHECK CANISTER.**

- CHECK** : **Is canister damaged or is there a hole of more than 1.0 mm (0.04 in) dia. in it?**
- YES** : Repair or replace canister. <Ref. to 2-1 [W3A0].>
- NO** : Go to step **11AG9**.

**11AG9 : CHECK FUEL TANK.**

Remove fuel tank. <Ref. to 2-8 [W1C0].>

- CHECK** : **Is fuel tank damaged or is there a hole of more than 1.0 mm (0.04 in) dia. in it?**
- YES** : Repair or replace fuel tank. <Ref. to 2-8 [W1C0].>
- NO** : Go to step **11AG10**.

**11AG10 : CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM.**

- CHECK** : **Are there holes of more than 1.0 mm (0.04 in) dia., cracks, clogging or disconnections of hoses or pipes in evaporative emission control system?**
- YES** : Repair or replace hoses or pipes.
- NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**MEMO:**

**AH: DTC P0442 — EVAPORATIVE EMISSION CONTROL SYSTEM MALFUNCTION —**

**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**• TROUBLE SYMPTOM:**

- Gasoline smell
- There is a hole of more than 0.5 mm (0.020 in) dia. in evaporation system or fuel tank.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**



B2M3582

**11AH1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11AH2**.

**11AH2 : CHECK FUEL FILLER CAP.**

- 1) Turn ignition switch to OFF.
- 2) Check the fuel filler cap.

**NOTE:**

The DTC code is stored in memory if fuel filler cap is or was loose or if the cap chain was caught while tightening.


- CHECK** : *Is the fuel filler cap tightened securely?*
- YES** : Go to step **11AH3**.
- NO** : Tighten fuel filler cap securely.

**11AH3 : CHECK FUEL FILLER PIPE PACKING.**

- CHECK** : *Is there any damage to the seal between fuel filler cap and fuel filler pipe?*
- YES** : Repair or replace fuel filler cap and fuel filler pipe. <Ref. to 2-8 [W2A0].>
- NO** : Go to step 11AH4.


**11AH4 : CHECK DRAIN VALVE.**

1) Connect test mode connector.



- 2) Turn ignition switch to ON.
- 3) Operate drain valve.

**NOTE:**  
Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>




- CHECK** : *Does drain valve produce operating sound?*
- YES** : Go to step 11AH5.
- NO** : Replace drain valve. <Ref. to 2-1 [W13A0].>

**11AH5 : CHECK PURGE CONTROL SOLENOID VALVE.**

Operate purge control solenoid valve.

**NOTE:**  
Purge control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>



- CHECK** : *Does purge control solenoid valve produce operating sound?*
- YES** : Go to step 11AH6.
- NO** : Replace purge control solenoid valve. <Ref. to 2-1 [W4A0].>




**11AH6 : CHECK PRESSURE CONTROL SOLENOID VALVE.**

Operate pressure control solenoid valve.

**NOTE:**

Pressure control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>



- CHECK** : **Does pressure control solenoid valve produce operating sound?**
- YES** : Go to step **11AH7**.
- NO** : Replace pressure control solenoid valve. <Ref. to 2-1 [W9A0].>

**11AH7 : CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE.**

Turn ignition switch to OFF.

- CHECK** : **Is there a hole of more than 0.5 mm (0.020 in) dia. on fuel line?**
- YES** : Repair or replace fuel line. <Ref. to 2-8 [W8A0].>
- NO** : Go to step **11AH8**.

**11AH8 : CHECK CANISTER.**

- CHECK** : **Is canister damaged or is there a hole of more than 0.5 mm (0.020 in) dia. in it?**
- YES** : Repair or replace canister. <Ref. to 2-1 [W3A0].>
- NO** : Go to step **11AH9**.

**11AH9 : CHECK FUEL TANK.**

Remove fuel tank. <Ref. to 2-8 [W1C0].>

- CHECK** : **Is fuel tank damaged or is there a hole of more than 0.5 mm (0.020 in) dia. in it?**
- YES** : Repair or replace fuel tank. <Ref. to 2-8 [W1C0].>
- NO** : Go to step **11AH10**.

**11AH10 : CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM.**

- CHECK** : **Are there holes of more than 0.5 mm (0.020 in) dia., cracks, clogging or disconnections of hoses or pipes in evaporative emission control system?**
- YES** : Repair or replace hoses or pipes.
- NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**MEMO:**


**AI: DTC P0443 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3583

**11A11 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 2 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.


- NO** : Go to step **11A12**.

**11A12 : CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from purge control solenoid valve and ECM.
- 3) Measure resistance of harness between purge control solenoid valve connector and engine ground.

**Connector & terminal**

**(E4) No. 2 — Engine ground:**




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and purge control solenoid valve connector.
- NO** : Go to step **11A13**.

**11A13 : CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

Measure resistance of harness between ECM and purge control solenoid valve of harness connector.

**Connector & terminal**

**(B134) No. 2 — (E4) No. 2:**



- CHECK** : **Is the resistance less than 1  $\Omega$ ?**  
**YES** : Go to step **11A14**.  
**NO** : Repair open circuit in harness between ECM and purge control solenoid valve connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and purge control solenoid valve connector
- Poor contact in coupling connector (B22)

**11A14 : CHECK PURGE CONTROL SOLENOID VALVE.**

- 1) Remove purge control solenoid valve.
- 2) Measure resistance between purge control solenoid valve terminals.

**Terminals**

**No. 1 — No. 2:**




- CHECK** : **Is the resistance between 10 and 100  $\Omega$ ?**  
**YES** : Go to step **11A15**.  
**NO** : Replace purge control solenoid valve. <Ref. to 2-1 [W4A0].>

**11A15 : CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between purge control solenoid valve and engine ground.

**Connector & terminal**

**(E4) No. 1 (+) — Engine ground (-):**



- CHECK** : **Is the voltage more than 10 V?**  
**YES** : Go to step **11A16**.  
**NO** : Repair open circuit in harness between main relay and purge control solenoid valve connector.

**11A16 : CHECK POOR CONTACT.**

Check poor contact in purge control solenoid valve connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : ***Is there poor contact in purge control solenoid valve connector?***

**YES** : Repair poor contact in purge control solenoid valve connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

### AJ: DTC P0446 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL LOW INPUT —


● DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● WIRING DIAGRAM:




B2M3588

**11AJ1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 10 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step 11AJ2.
- NO** : Go to step 11AJ3.

**11AJ2 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)

**NOTE:**

In this case, repair the following:


- Poor contact in drain valve connector
- Poor contact in ECM connector
- Poor contact in coupling connectors (B97 and B99)

**11AJ3 : CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from drain valve and ECM.
- 3) Measure resistance of harness between drain valve connector and chassis ground.

**Connector & terminal**

**(R69) No. 2 — Chassis ground:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and drain valve connector.
- NO** : Go to step 11AJ4.




**11AJ4 : CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.**

Measure resistance of harness between ECM and drain valve connector.

**Connector & terminal**

**(B134) No. 10 — (R69) No. 2:**



**CHECK** : *Is the voltage less than 1 Ω?*

**YES** : Go to step 11AJ5.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and drain valve connector
- Poor contact in coupling connectors (B99)

**11AJ5 : CHECK DRAIN VALVE.**

Measure resistance between drain valve terminals.

**Terminals**

**No. 1 — No. 2:**



**CHECK** : *Is the resistance between 10 and 100 Ω?*

**YES** : Go to step 11AJ6.


**NO** : Replace drain valve. <Ref. to 2-1 [W13A0].>

**11AJ6 : CHECK POWER SUPPLY TO DRAIN VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between drain valve and chassis ground.

**Connector & terminal**

**(R69) No. 1 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage more than 10 V?*

**YES** : Go to step 11AJ7.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between main relay and drain valve
- Poor contact in coupling connectors (B97)
- Poor contact in main relay connector

**11AJ7 : CHECK POOR CONTACT.**

Check poor contact in drain valve connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : *Is there poor contact in drain valve connector?*

**YES** : Repair poor contact in drain valve connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

## AK: DTC P0451 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE PROBLEM —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M3592

**11AK1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any DTC on display?*  
**YES** : Inspect the relevant DTC using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>  
**NO** : Go to step **11AK2**.

**11AK2 : CHECK FUEL FILLER CAP.**

- 1) Turn ignition switch to OFF.  
 2) Open the fuel flap.  
**CHECK** : *Is the fuel filler cap tightened securely?*  
**YES** : Go to step **11AK3**.  
**NO** : Tighten fuel filler cap securely.

**11AK3 : CHECK PRESSURE/VACUUM LINE.**

- NOTE:**  
 Check the following items.  
 ● Disconnection, leakage and clogging of the vacuum hoses and pipes between fuel tank pressure sensor and fuel tank  
 ● Disconnection, leakage and clogging of air ventilation hoses and pipes between fuel filler pipe and fuel tank
- CHECK** : *Is there a fault in pressure/vacuum line?*  
**YES** : Repair or replace hoses and pipes.  
**NO** : Replace fuel tank pressure sensor. <Ref. to 2-1 [W8A0].>


**AL: DTC P0452 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

- **WIRING DIAGRAM:**



B2M3592

**11AL1 : CHECK CURRENT DATA.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuel filler cap.
- 3) Install fuel filler cap.
- 4) Turn ignition switch to ON.
- 5) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

**NOTE:**


- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value less than -2.8 kPa (-21.0 mmHg, -0.827 inHg)?*
- YES** : Go to step 11AL2.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**11AL2 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
(B136) No. 15 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 11AL4.
- NO** : Go to step 11AL3.

**11AL3 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
(B136) No. 15 (+) — Chassis ground (-):



- CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair poor contact in ECM connector.
- NO** : Contact with SOA service.


**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11AL4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
(B136) No. 12 (+) — Chassis ground (-):



- CHECK** : *Is the voltage less than 0.2 V?*
- YES** : Go to step 11AL6.
- NO** : Go to step 11AL5.

**11AL5 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Read data of fuel tank pressure sensor signal using Subaru Select Monitor.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

**CHECK** : Does the value change more than  $-2.8 \text{ kPa}$  ( $-21.0 \text{ mmHg}$ ,  $-0.827 \text{ inHg}$ ) by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?


- YES** : Repair poor contact in ECM connector.  
**NO** : Go to step 11AL6.

**11AL6 : CHECK HARNESS BETWEEN ECM  
AND COUPLING CONNECTOR IN  
REAR WIRING HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Remove rear seat cushion (Sedan) or move rear seat cushion (Wagon).
- 3) Separate rear wiring harness and fuel tank cord.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between rear wiring harness connector and chassis ground.

**Connector & terminal**

**(R134) No. 5 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than  $4.5 \text{ V}$ ?  
**YES** : Go to step 11AL7.  
**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and rear wiring harness connector (R134)
- Poor contact in coupling connector (B99)

**11AL7 : CHECK HARNESS BETWEEN ECM  
AND COUPLING CONNECTOR IN  
REAR WIRING HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and rear wiring harness connector.

**Connector & terminal**

**(B136) No. 16 — (R134) No. 3:**



- CHECK** : Is the resistance less than  $1 \Omega$ ?  
**YES** : Go to step 11AL8.  
**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and rear wiring harness connector (R134)
- Poor contact in coupling connector (B99)
- Poor contact in joint connector (B83)

**11AL8 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.**

Measure resistance of harness between rear wiring harness connector and chassis ground.

**Connector & terminal**

**(R134) No. 3 — Chassis ground:**




- CHECK** : **Is the resistance more than 500 kΩ?**
- YES** : Go to step **11AL9**.
- NO** : Repair ground short circuit in harness between ECM and rear wiring harness connector (R134).

**11AL9 : CHECK FUEL TANK CORD.**

- 1) Disconnect connector from fuel tank pressure sensor.
- 2) Measure resistance of fuel tank cord.

**Connector & terminal**

**(R135) No. 5 — (R47) No. 3:**




- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **11AL10**.
- NO** : Repair open circuit in fuel tank cord.

**11AL10 : CHECK FUEL TANK CORD.**

Measure resistance of fuel tank cord.

**Connector & terminal**

**(R135) No. 3 — (R47) No. 1:**




- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step **11AL11**.
- NO** : Repair open circuit in fuel tank cord.

**11AL11 : CHECK FUEL TANK CORD.**

Measure resistance of harness between fuel tank pressure sensor connector and chassis ground.

**Connector & terminal**

**(R47) No. 2 — Chassis ground:**



- CHECK** : **Is the resistance more than 500 kΩ?**
- YES** : Go to step **11AL12**.
- NO** : Repair ground short circuit in fuel tank cord.

**11AL12 : CHECK POOR CONTACT.**

Check poor contact in fuel tank pressure sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in fuel tank pressure sensor connector?*
- YES** : Repair poor contact in fuel tank pressure sensor connector.
- NO** : Replace fuel tank pressure sensor. <Ref. to 2-1 [W8A0].>

**MEMO:**




**AM: DTC P0453 — EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

- **WIRING DIAGRAM:**



B2M3592

**11AM1 : CHECK CURRENT DATA.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuel filler cap.
- 3) Install fuel filler cap.
- 4) Turn ignition switch to ON.
- 5) Read data of fuel tank pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool.

**NOTE:**


- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?*
- YES** : Go to step 11AM12.
- NO** : Go to step 11AM2.

**11AM2 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
(B136) No. 15 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 11AM4.
- NO** : Go to step 11AM3.

**11AM3 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
(B136) No. 15 (+) — Chassis ground (-):




- CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**11AM4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
(B136) No. 12 (+) — Chassis ground (-):



- CHECK** : *Is the voltage less than 0.2 V?*
- YES** : Go to step 11AM6.
- NO** : Go to step 11AM5.

**11AM5 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Read data of fuel tank pressure sensor signal using Subaru Select Monitor.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

**CHECK** : *Does the value change more than  $-2.8$  kPa ( $-21.0$  mmHg,  $-0.827$  inHg) by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?*

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 11AM6.

**11AM6 : CHECK HARNESS BETWEEN ECM  
AND COUPLING CONNECTOR IN  
REAR WIRING HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Remove rear seat cushion (Sedan) or move rear seat cushion (Wagon).
- 3) Separate rear wiring harness and fuel tank cord.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between rear wiring harness connector and chassis ground.

**Connector & terminal**

**(R134) No. 5 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage more than 4.5 V?*

**YES** : Go to step 11AM7.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and rear wiring harness connector (R134)
- Poor contact in coupling connector (B99)

**11AM7 : CHECK HARNESS BETWEEN ECM  
AND COUPLING CONNECTOR IN  
REAR WIRING HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and rear wiring harness connector.

**Connector & terminal**

**(B136) No. 12 — (R134) No. 6:**



**CHECK** : *Is the resistance less than 1  $\Omega$ ?*

**YES** : Go to step 11AM8.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and rear wiring harness connector (R134)
- Poor contact in coupling connector (B99)

**11AM8 : CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.**

Measure resistance of harness between rear wiring harness connector and chassis ground.

**Connector & terminal**

**(B136) No. 16 — (R134) No. 3:**




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **11AM9**.
- NO** : Repair ground short circuit in harness between ECM and rear wiring harness connector (R134).

**11AM9 : CHECK FUEL TANK CORD.**

- 1) Disconnect connector from fuel tank pressure sensor.
- 2) Measure resistance of fuel tank cord.

**Connector & terminal**

**(R135) No. 6 — (R47) No. 2:**




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **11AM10**.
- NO** : Repair open circuit in fuel tank cord.

**11AM10 : CHECK FUEL TANK CORD.**

Measure resistance of fuel tank cord.

**Connector & terminal**

**(R135) No. 3 — (R47) No. 1:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **11AM11**.
- NO** : Repair open circuit in fuel tank cord.

**11AM11 : CHECK POOR CONTACT.**

Check poor contact in fuel tank pressure sensor connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in fuel tank pressure sensor connector?*
- YES** : Repair poor contact in fuel tank pressure sensor connector.
- NO** : Replace fuel tank pressure sensor. <Ref. to 2-1 [W8A0].>

**11AM12 : CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel tank pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Read data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : ***Is the value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?***

**YES** : Repair battery short circuit in harness between ECM and fuel tank pressure sensor connector.

**NO** : Replace fuel tank pressure sensor. <Ref. to 2-1 [W8A0].>

# AN: DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —


## DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

## CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

## WIRING DIAGRAM:



B2M3563

**11AN1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK :** Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0462 or P0463?

**YES :** Inspect DTC P0462 or P0463 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**

In this case, it is not necessary to inspect this trouble.

**NO :** Replace fuel sending unit <Ref. to 2-1 [W5A0].> and fuel sub level sensor <Ref. to 2-1 [W7A0].>

**AO: DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**



B2M3563

**11A01 : CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.**


- CHECK** : Does speedometer and tachometer operate normally?
- YES** : Go to step 11A02.
- NO** : Repair or replace combination meter.

**11A02 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON. (Engine OFF)
- 2) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 27 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage less than 0.12 V?*  
**YES** : Go to step 11A06.  
**NO** : Go to step 11A03.

**11A03 : CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)**

Read data of fuel level sensor signal using Subaru Select Monitor.

**NOTE:**

- Subaru Select Monitor
- For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- CHECK** : *Does the value change less than 0.12 V by shaking harness and connector of ECM while monitoring the value with Subaru Select Monitor?*
- YES** : Repair poor contact in ECM connector.  
**NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.

**NOTE:**


- In this case, repair the following:
- Poor contact in combination meter connector
  - Poor contact in ECM connector
  - Poor contact in coupling connectors (B99)

**11A04 : CHECK INPUT VOLTAGE OF ECM.**

- 1) Turn ignition switch to OFF.
- 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15).
- 3) Turn ignition switch to ON.
- 4) Measure voltage of harness between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 27 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 0.12 V?*  
**YES** : Go to step 11A04.  
**NO** : Go to step 11A07.

**11A05 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from connector (i10) and ECM connector.
- 3) Measure resistance between ECM and chassis ground.

**Connector & terminal**

**(B136) No. 27 — Chassis ground:**



- CHECK** : *Is the resistance more than 1 MΩ?*  
**YES** : Go to step 11A06.  
**NO** : Repair ground short circuit in harness between ECM and combination meter connector.




**11A06 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER.**

Measure resistance between ECM and combination meter connector.

**Connector & terminal**

**(B136) No. 27 — (i10) No. 3:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair or replace combination meter. <Ref. to 6-2 [W8A0].>
- NO** : Repair open circuit between ECM and combination meter connector.

**NOTE:**


In this case, repair the following:  
Poor contact in coupling connector (R98)

**11A07 : CHECK FUEL TANK CORD.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel sub level sensor.
- 3) Measure resistance between fuel sub level sensor and chassis ground.

**Connector & terminal**

**(R59) No. 1 — Chassis ground:**




- CHECK** : **Is the resistance more than 1 MΩ?**
- YES** : Go to step 11A08.
- NO** : Repair ground short circuit in fuel tank cord.

**11A08 : CHECK FUEL TANK CORD.**

- 1) Disconnect connector from fuel pump assembly.
- 2) Measure resistance between fuel pump assembly and chassis ground.

**Connector & terminal**

**(R59) No. 2 — Chassis ground:**



- CHECK** : **Is the resistance more than 1 MΩ?**
- YES** : Go to step 11A09.
- NO** : Repair ground short circuit in fuel tank cord.

**11A09 : CHECK FUEL LEVEL SENSOR.**


**WARNING:**

During work procedures, if fuel tank is more than 3/4 full, be careful because fuel may spill.

- 1) Remove fuel pump assembly. <Ref. to 2-8 [W3A0].>
- 2) Measure resistance between fuel level sensor and terminals with its float set to the full position.

**Terminals**

**No. 3 — No. 6:**



- CHECK** : **Is the resistance between 0.5 and 2.5 Ω?**
- YES** : Go to step 11A010.
- NO** : Replace fuel level sensor.


**11A010 : CHECK FUEL SUB LEVEL SENSOR.****WARNING:**

During work procedures, if fuel tank is more than 3/4 full, be careful because fuel may spill.

- 1) Remove fuel sub level sensor. <Ref. to 2-8 [W6A0].>
- 2) Measure resistance between fuel sub level sensor and terminals with its float set to the full position.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : **Is the resistance between 0.5 and 2.5 Ω?**
- YES** : Repair poor contact in harness between ECM and combination meter connector.
- NO** : Replace fuel sub level sensor.

**AP: DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**



B2M3563

**11AP1 : CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.**


- CHECK** : Does speedometer and tachometer operate normally?
- YES** : Go to step 11AP2.
- NO** : Repair or replace combination meter. <Ref. to 6-2 [W8A0].>

**11AP2 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON. (Engine OFF)
- 2) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 27 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 4.75 V?**
- YES** : Go to step **11AP3**.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.

**NOTE:**

In this case, repair the following:


- Poor contact in fuel pump connector
- Poor contact in coupling connector (B22, R98 and R57)

**11AP3 : CHECK INPUT VOLTAGE OF ECM.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect combination meter connector (i10) and ECM connector.
- 3) Turn ignition switch to ON.
- 4) Measure voltage of harness between ECM and chassis ground.

**Connector & terminal**

**(B136) No. 27 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 4.75 V?**
- YES** : Go to step **11AP4**.
- NO** : Repair battery short circuit between ECM and combination meter connector.

**11AP4 : CHECK HARNESS BETWEEN ECM AND FUEL TANK CORD.**

- 1) Turn ignition switch to OFF.
- 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15).
- 3) Measure resistance between ECM and fuel tank cord.

**Connector & terminal**

**(B136) No. 27 — (R15) No. 6:**




- CHECK** : **Is the resistance less than 5 Ω?**
- YES** : Go to step **11AP5**.
- NO** : Repair open circuit between ECM and fuel tank cord.

**11AP5 : CHECK HARNESS BETWEEN FUEL TANK CORD AND CHASSIS GROUND.**

Measure resistance between fuel tank cord and chassis ground.

**Connector & terminal**  
**(R15) No. 5 — Chassis ground:**



- CHECK** : **Is the resistance less than 5 Ω?**
- YES** : Go to step **11AP6**.
- NO** : Repair open circuit between fuel tank cord and chassis ground.


**NOTE:**

In this case, repair the following:  
Poor contact in coupling connectors (B22 and B99)

**11AP6 : CHECK FUEL TANK CORD.**

- 1) Disconnect connector from fuel level sensor.
- 2) Measure resistance between fuel level sensor and coupling connector.

**Connector & terminal**  
**(R57) No. 5 — (R58) No. 3:**




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **11AP7**.
- NO** : Repair open circuit between coupling connector and fuel level sensor.

**11AP7 : CHECK FUEL TANK CORD.**

- 1) Disconnect connector from fuel sub level sensor.
- 2) Measure resistance between fuel level sensor and fuel sub level sensor.

**Connector & terminal**  
**(R58) No. 6 — (R59) No. 2:**




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **11AP8**.
- NO** : Repair open circuit between fuel level sensor and fuel sub level sensor.

**11AP8 : CHECK FUEL TANK CORD.**

Measure resistance between fuel sub level sensor and coupling connector.

**Connector & terminal**  
**(R57) No. 6 — (R59) No. 1:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **11AP9**.
- NO** : Repair open circuit between coupling connector and fuel sub level sensor.


**11AP9 : CHECK FUEL LEVEL SENSOR.****WARNING:**

During work procedures, if fuel tank is more than 3/4 full, be careful because fuel may spill.

- 1) Remove fuel pump assembly. <Ref. to 2-8 [W3A0].>
- 2) While moving fuel level sensor float up and down, measure resistance between fuel level sensor terminals.

**Terminals**

**No. 3 — No. 6:**



- CHECK** : **Is the resistance more than 54.5  $\Omega$ ?**
- YES** : Replace fuel level sensor. <Ref. to 2-8 [W3A0].>
- NO** : Go to step **11AP10**.


**11AP10 : CHECK FUEL SUB LEVEL SENSOR.****WARNING:**

During work procedures, if fuel tank is more than 3/4 full, be careful because fuel may spill.

- 1) Remove fuel sub level sensor. <Ref. to 2-8 [W6A0].>
- 2) While moving fuel sub level sensor float up and down, measure resistance between fuel sub level sensor terminals.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : **Is the resistance more than 41.5  $\Omega$ ?**
- YES** : Replace fuel sub level sensor. <Ref. to 2-8 [W6A0].>
- NO** : Replace combination meter. <Ref. to 6-2 [W13A1].>


**AQ: DTC P0480 — COOLING FAN RELAY 1 CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Radiator fan does not operate properly.
  - Overheating

**CAUTION:**


After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



**11AQ1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.




- 3) Turn ignition switch to ON.
- 4) While operating radiator fan relay, measure voltage between ECM terminal and ground.

**NOTE:**

Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**Connector & terminal**

**(B134) No. 3 (+) — Chassis ground (-):**



**CHECK** : Does voltage change between 0 and 10 V?

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 11AQ2.

**11AQ2 : CHECK GROUND SHORT CIRCUIT IN RADIATOR FAN RELAY 1 CONTROL CIRCUIT.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 3 — Chassis ground:**



**CHECK** : Is the resistance less than 10 Ω?

**YES** : Repair ground short circuit in radiator fan relay 1 control circuit.


**NO** : Go to step 11AQ3.

**11AQ3 : CHECK POWER SUPPLY FOR RELAY.**

- 1) Remove main fan relay from A/C relay holder.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between fuse and relay box (F/B) connector and chassis ground.

**Connector & terminal**

**(F66) No. 5 (+) — Chassis ground (-):**



**CHECK** : Is the voltage more than 10 V?

**YES** : Go to step 11AQ4.

**NO** : Repair open circuit in harness between ignition switch and fuse and relay box (F/B) connector.




**11AQ4 : CHECK MAIN FAN RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between main fan relay terminals.

**Terminal**

**No. 5 — No. 6:**




- CHECK** : *Is the resistance between 87 and 107 Ω?*
- YES** : Go to step 11AQ5.
- NO** : Replace main fan relay.

**11AQ5 : CHECK OPEN CIRCUIT IN MAIN FAN RELAY CONTROL CIRCUIT.**

Measure resistance of harness between ECM and main fan relay connector.

**Connector & terminal**

**(B134) No. 3 — (F66) No. 6:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 11AQ6.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and main fan relay connector
- Poor contact in coupling connector (F45)

**11AQ6 : CHECK POOR CONTACT.**

Check poor contact in ECM or main fan relay connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ECM or main fan relay connector?*
- YES** : Repair poor contact in ECM or main fan relay connector.
- NO** : Contact with SOA service.

**AR: DTC P0483 — COOLING FAN FUNCTION PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Occurrence of noise
  - Overheating


**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**NOTE:**

If the vehicle, with the engine idling, is placed very close to a wall or another vehicle, preventing normal cooling function, the OBD system may detect malfunction.

● **WIRING DIAGRAM:**



**11AR1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>
- NO** : Check engine cooling system. <Ref. to 2-5 [T100].>

**AS: DTC P0500 — VEHICLE SPEED SENSOR MALFUNCTION —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**



B2M3787

**11AS1 : CHECK DTC P0720 ON DISPLAY.**

- CHECK :** Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?
- YES :** Check vehicle speed sensor 2 signal circuit. <Ref. to 3-2 [T8F0].>
- NO :** Go to step 11AS2.

**11AS2 : CHECK SPEEDOMETER OPERATION IN COMBINATION METER.**


- CHECK :** Does speedometer operate normally?
- YES :** Go to step 11AS3.
- NO :** Check speedometer and vehicle speed sensor. <Ref. to 6-2 [K3A0].>

**11AS3 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from combination meter.
- 3) Measure resistance between ECM and combination meter.

**Connector & terminal**

**(B135) No. 24 — (i10) No. 13:**



- CHECK** : **Is the resistance less than 10 Ω ?**
- YES** : Repair poor contact in ECM connector.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and combination meter connector
- Poor contact in ECM connector
- Poor contact in combination meter connector
- Poor contact in coupling connector (B36)


**AT: DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine is difficult to start.
  - Engine does not start.
  - Erroneous idling
  - Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3788

**11AT1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1510, P1511, P1512, P1513, P1514, P1515, P1516 or P1517?*

**YES** : Inspect DTC P1510, P1511, P1512, P1513, P1514, P1515, P1516 or P1517 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0506.

**NO** : Go to step **11AT2**.

**11AT2 : CHECK AIR BY-PASS LINE.**

- 1) Turn ignition switch to OFF.
- 2) Remove idle air control solenoid valve from throttle body. <Ref. to 2-7 [W15A2].>
- 3) Remove throttle body from intake manifold. <Ref. to 2-7 [W2A2].>
- 4) Using an air gun, force air into idle air control solenoid valve installation area. Confirm that forced air subsequently escapes from throttle body interior.

**CHECK** : *Does air flow out?*

**YES** : Replace idle air control solenoid valve. <Ref. to 2-7 [W15A2].>

**NO** : Replace throttle body. <Ref. to 2-7 [W2A2].>

**AU: DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED**

**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**



B2M3788

**11AU1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1510, P1511, P1512, P1513, P1514, P1515, P1516 or P1517?

**YES** : Inspect DTC P1510, P1511, P1512, P1513, P1514, P1515, P1516 or P1517 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P0507.

**NO** : Go to step 11AU2.

**11AU2 : CHECK AIR INTAKE SYSTEM.**

- 1) Turn ignition switch to ON.
- 2) Start engine, and idle it.
- 3) Check the following items.
  - Loose installation of intake manifold, idle air control solenoid valve and throttle body
  - Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket
  - Disconnections of vacuum hoses

**CHECK** : Is there a fault in air intake system?

**YES** : Repair air suction and leaks.

**NO** : Go to step 11AU3.

**11AU3 : CHECK THROTTLE CABLE.**

**CHECK** : *Does throttle cable have play for adjustment?*

**YES** : Go to step 11AU4.

**NO** : Adjust throttle cable. <Ref. to 4-5 [W1A3].>

**11AU4 : CHECK AIR BY-PASS LINE.**

- 1) Turn ignition switch to OFF.
- 2) Remove idle air control solenoid valve from throttle body. <Ref. to 2-7 [W15A2].>
- 3) Confirm that there are no foreign particles in by-pass air line.

**CHECK** : *Are foreign particles in by-pass air line?*

**YES** : Remove foreign particles from by-pass air line.

**NO** : Replace idle air control solenoid valve. <Ref. to 2-7 [W15A2].>




**AV: DTC P0601 — INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Engine does not start.
  - Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



**11AV1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0601?
- YES** : Replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : It is not necessary to inspect DTC P0601.

**MEMO:**

**AW: DTC P0703 — BRAKE SWITCH INPUT MALFUNCTION —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**



B2M3790

**11AW1 : CHECK OPERATION OF BRAKE LIGHT.**

- CHECK** : Does brake light come on when depressing the brake pedal?
- YES** : Go to step 11AW2.
- NO** : Repair or replace brake light circuit.


**11AW2 : CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.**

- 1) Disconnect connectors from TCM and brake light switch.
- 2) Measure resistance of harness between TCM and brake light switch connector.

**Connector & terminal**

**(B55) No. 24 — (B64) No. 2:**

**(B55) No. 24 — (B65) No. 3 (With cruise control):**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 11AW3.
- NO** : Repair or replace harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between TCM and brake light switch connector
- Poor contact in TCM connector
- Poor contact in brake light switch connector

**11AW3 : CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR.**

Measure resistance of harness between TCM and chassis ground.

**Connector & terminal**

**(B55) No. 24 — Chassis ground:**




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step 11AW4.
- NO** : Repair ground short circuit in harness between TCM and brake light switch connector.

**11AW4 : CHECK INPUT SIGNAL FOR TCM.**

- 1) Connect connectors to TCM and brake light switch.
- 2) Measure voltage between TCM and chassis ground.

**Connector & terminal**

**(B55) No. 24 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage less than 1 V when releasing the brake pedal?*
- YES** : Go to step 11AW5.
- NO** : Adjust or replace brake light switch. <Ref. to 4-5 [W1A1].>

**11AW5 : CHECK INPUT SIGNAL FOR TCM.**

Measure voltage between TCM and chassis ground.

**Connector & terminal**

**(B55) No. 24 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage more than 10 V when depressing the brake pedal?*
- YES** : Go to step **11AW6**.
- NO** : Adjust or replace brake light switch. <Ref. to 4-5 [W1A1].>

**11AW6 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W23A0].>

**AX: DTC P0705 — TRANSMISSION RANGE SENSOR CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- Starter does not rotate when selector lever is in “P” or “N” range.
- Starter rotates when selector lever is in “R”, “D”, “3”, “2” or “1” range.
- Engine brake is not effected when selector lever is in “3” range.
- Shift characteristics are erroneous.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check inhibitor switch circuit. <Ref. to 3-2 [T9T0].>

**AY: DTC P0710 — TRANSMISSION FLUID TEMPERATURE SENSOR CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- No shift up to 4th speed (after engine warm-up)
- No lock-up (after engine warm-up)
- Excessive shift shock

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check ATF temperature sensor circuit. <Ref. to 3-2 [T8D0].>

**AZ: DTC P0715 — TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check torque converter turbine speed sensor circuit. <Ref. to 3-2 [T8G0].>

**BA: DTC P0720 — OUTPUT SPEED SENSOR (VEHICLE SPEED SENSOR 2) CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- No shift or excessive tight corner “braking”

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check vehicle speed sensor 2 circuit. <Ref. to 3-2 [T8F0].>

**BB: DTC P0725 — ENGINE SPEED INPUT CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- No lock-up (after engine warm-up)
- AT diagnostic indicator light (AT OIL TEMP indicator light) remains on when vehicle speed is “0”.

**CAUTION:**

**After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.**

**NOTE:**

Check engine speed input signal circuit. <Ref. to 3-2 [T8C0].>

**BC: DTC P0731 — GEAR 1 INCORRECT RATIO —****NOTE:**

For the diagnostic procedure, refer to DTC P0734. <Ref. to 2-7 [T11BF0].>

**BD: DTC P0732 — GEAR 2 INCORRECT RATIO —****NOTE:**

For the diagnostic procedure, refer to DTC P0734. <Ref. to 2-7 [T11BF0].>

**BE: DTC P0733 — GEAR 3 INCORRECT RATIO —****NOTE:**

For the diagnostic procedure, refer to DTC P0734. <Ref. to 2-7 [T11BF0].>

**BF: DTC P0734 — GEAR 4 INCORRECT RATIO —**● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

● **TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effected in “3” range; excessive shift shock; excessive tight corner “braking”

**CAUTION:**

After repair or replacement of faulty parts, conduct **CLEAR MEMORY MODE** <Ref. to 2-7 [T3D0].> and **INSPECTION MODE** <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**

**11BF1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*  
**YES** : Inspect relevant DTC using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>  
**NO** : Go to step **11BF2**.

**11BF2 : CHECK THROTTLE POSITION SENSOR CIRCUIT.**

Check throttle position sensor circuit. <Ref. to 3-2 [T8E0].>

- CHECK** : *Is there any trouble in throttle position sensor circuit?*  
**YES** : Repair or replace throttle position sensor circuit.  
**NO** : Go to step **11BF3**.

**11BF3 : CHECK VEHICLE SPEED SENSOR 2 CIRCUIT.**

Check vehicle speed sensor 2 circuit. <Ref. to 3-2 [T8F0].>

- CHECK** : *Is there any trouble in vehicle speed sensor 2 circuit?*  
**YES** : Repair or replace vehicle speed sensor 2 circuit.  
**NO** : Go to step **11BF4**.

**11BF4 : CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT.**

Check torque converter turbine speed sensor circuit. <Ref. to 3-2 [T8G0].>

- CHECK** : *Is there any trouble in torque converter turbine speed sensor circuit?*  
**YES** : Repair or replace torque converter turbine speed sensor circuit.  
**NO** : Go to step **11BF5**.

**11BF5 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*  
**YES** : Repair poor contact in TCM connector.  
**NO** : Go to step **11BF6**.

**11BF6 : CHECK MECHANICAL TROUBLE.**

Check mechanical trouble in automatic transmission.

- CHECK** : *Is there any mechanical trouble in automatic transmission?*  
**YES** : Repair or replace automatic transmission. <Ref. to 3-2 [W100].>  
**NO** : Replace TCM. <Ref. to 3-2 [W23A0].>



**BG: DTC P0740 — TORQUE CONVERTER CLUTCH SYSTEM MALFUNCTION****• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**• TROUBLE SYMPTOM:**

- No lock-up (after engine warm-up)
- No shift or excessive tight corner “braking”

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**11BG1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*  
**YES** : Inspect the relevant DTC using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>  
**NO** : Go to step **11BG2**.

**11BG2 : CHECK DUTY SOLENOID B CIRCUIT.**

Check duty solenoid B circuit. <Ref. to 3-2 [T8P0].>

- CHECK** : *Is there any trouble in duty solenoid B circuit?*  
**YES** : Repair or replace duty solenoid B circuit.  
**NO** : Go to step **11BG3**.

**11BG3 : CHECK THROTTLE POSITION SENSOR CIRCUIT.**

Check throttle position sensor circuit. <Ref. to 3-2 [T8E0].>

- CHECK** : *Is there any trouble in throttle position sensor circuit?*  
**YES** : Repair or replace throttle position sensor circuit.  
**NO** : Go to step **11BG4**.

**11BG4 : CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT.**

Check torque converter turbine speed sensor circuit. <Ref. to 3-2 [T8G0].>

- CHECK** : *Is there any trouble in torque converter turbine speed sensor circuit?*  
**YES** : Repair or replace torque converter turbine speed sensor circuit.  
**NO** : Go to step **11BG5**.

**11BG5 : CHECK ENGINE SPEED INPUT CIRCUIT.**

Check engine speed input circuit. <Ref. to 3-2 [T8C0].>

- CHECK** : *Is there any trouble in engine speed input circuit?*  
**YES** : Repair or replace engine speed input circuit.  
**NO** : Go to step **11BG6**.

**11BG6 : CHECK INHIBITOR SWITCH CIRCUIT.**

Check inhibitor switch circuit. <Ref. to 3-2 [T9T0].>

- CHECK** : *Is there any trouble in inhibitor switch circuit?*  
**YES** : Repair or replace inhibitor switch circuit.  
**NO** : Go to step **11BG7**.

**11BG7 : CHECK BRAKE LIGHT SWITCH CIRCUIT.**

Check brake light switch circuit. <Ref. to 2-7 [T11AW0].>

**CHECK** : *Is there any trouble in brake light switch circuit?*

**YES** : Repair or replace brake light switch circuit.

**NO** : Go to step **11BG8**.

**11BG8 : CHECK ATF TEMPERATURE SENSOR CIRCUIT.**

Check ATF temperature sensor circuit. <Ref. to 3-2 [T8D0].>

**CHECK** : *Is there any trouble in ATF temperature sensor circuit?*

**YES** : Repair or replace ATF temperature sensor circuit.

**NO** : Go to step **11BG9**.

**11BG9 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : *Is there poor contact in TCM connector?*

**YES** : Repair poor contact in TCM connector.

**NO** : Go to step **11BG10**.

**11BG10 : CHECK MECHANICAL TROUBLE.**

Check mechanical trouble in automatic transmission.

**CHECK** : *Is there any mechanical trouble in automatic transmission?*

**YES** : Repair or replace automatic transmission. <Ref. to 3-2 [W100].>

**NO** : Replace TCM. <Ref. to 3-2 [W23A0].>

**BH: DTC P0743 — TORQUE CONVERTER CLUTCH SYSTEM (LOCK-UP DUTY SOLENOID) ELECTRICAL —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - No lock-up (after engine warm-up)

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check lock-up duty solenoid circuit. <Ref. to 3-2 [T8R0].>

**BI: DTC P0748 — PRESSURE CONTROL SOLENOID (LINE PRESSURE DUTY SOLENOID) ELECTRICAL —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Excessive shift shock

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check line pressure duty solenoid circuit. <Ref. to 3-2 [T8N0].>

**BJ: DTC P0753 — SHIFT SOLENOID A (SHIFT SOLENOID 1) ELECTRICAL —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - No shift

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check shift solenoid 1 circuit. <Ref. to 3-2 [T8J0].>

**BK: DTC P0758 — SHIFT SOLENOID B (SHIFT SOLENOID 2) ELECTRICAL —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - No shift

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check shift solenoid 2 circuit. <Ref. to 3-2 [T8K0].>


**BL: DTC P1100 — STARTER SWITCH CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



**11BL1 : CHECK OPERATION OF STARTER MOTOR.**

**NOTE:**

Place the inhibitor switch in the “P” or “N” position.

**CHECK** : *Does starter motor operate when ignition switch to “ST”?*

**YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open or ground short circuit in harness between ECM and starter motor connector.
- Poor contact in ECM connector.

**NO** : Check starter motor circuit. <Ref. to 2-7 [T8B0].>


**BM: DTC P1101 — NEUTRAL POSITION SWITCH CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M3813

**11BM1 : CHECK DTC P0705 ON DISPLAY.**


- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0705?
- YES** : Inspect DTC P0705 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>
- NO** : Go to step 11BM2.

**11BM2 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground in selector lever "N" and "P" positions.

**Connector & terminal**

**(B135) No. 26 (+) — Chassis ground (-):**




- CHECK** : Is the voltage less than 1 V?
- YES** : Go to step 11BM3.
- NO** : Go to step 11BM5.

**11BM3 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground in selector lever except for "N" and "P" positions.

**Connector & terminal**

**(B135) No. 26 (+) — Chassis ground (-):**



- CHECK** : Is the voltage between 4.5 and 5.5 V?
- YES** : Go to step 11BM4.
- NO** : Go to step 11BM5.

**11BM4 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Contact with SOA service.

**NOTE:**


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11BM5 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B135) No. 26 (+) — Chassis ground (-):**




- CHECK** : Is the voltage more than 10 V?
- YES** : Repair battery short circuit in harness between ECM and inhibitor switch connector.
- NO** : Go to step 11BM6.

**11BM6 : CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and inhibitor switch.
- 3) Measure resistance of harness between ECM and inhibitor switch connector.

**Connector & terminal**

**(B135) No. 26 — (T7) No. 12:**



**CHECK** : *Is the resistance less than 1 Ω?*

**YES** : Go to step 11BM7.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and inhibitor switch connector
- Poor contact in coupling connector (B12)
- Poor contact in inhibitor switch connector
- Poor contact in ECM connector

**11BM7 : CHECK INHIBITOR SWITCH GROUND LINE.**

Measure resistance of harness between inhibitor switch connector and engine ground.

**Connector & terminal**

**(T7) No. 7 — Engine ground:**



**CHECK** : *Is the resistance less than 5 Ω?*

**YES** : Go to step 11BM8.

**NO** : Repair open circuit in harness between inhibitor switch connector and starter motor ground line.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between inhibitor switch connector and starter motor ground line
- Poor contact in starter motor connector
- Poor contact in starter motor ground
- Starter motor

**11BM8 : CHECK INHIBITOR SWITCH.**

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever "N" and "P" positions.

**Terminals**

**No. 7 — No. 12:**



- CHECK** : ***Is the resistance less than 1 Ω?***
- YES** : Go to step **11BM9**.
- NO** : Replace inhibitor switch. <Ref. to 3-2 [W2C0].>

**11BM9 : CHECK SELECTOR CABLE CONNECTION.**

- CHECK** : ***Is there any fault in selector cable connection to inhibitor switch?***
- YES** : Repair selector cable connection. <Ref. to 3-2 [W2A0].>
- NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.




**BN: DTC P1103 — ENGINE TORQUE CONTROL SIGNAL 1 CIRCUIT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Excessive shift shock

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M2107

**11BN1 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**  
(B135) No. 16 (+) — Chassis ground (-):




B2M2094A

- CHECK** : Is the voltage more than 4.5 V?
- YES** : Go to step 11BN2.
- NO** : Go to step 11BN4.

**11BN2 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
(B135) No. 16 (+) — Chassis ground (-):



B2M2094A

- CHECK** : Is the voltage more than 10 V?
- YES** : Repair battery short circuit in harness between ECM and TCM connector.
- NO** : Go to step 11BN3.

**11BN3 : CHECK POOR CONTACT.**


Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**11BN4 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and TCM connector.

**Connector & terminal**  
(B135) No. 16 — (B54) No. 13:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 11BN5.
- NO** : Repair open circuit in harness between ECM and TCM connector.

**11BN5 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**  
(B135) No. 16 — Chassis ground:



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step 11BN6.

**11BN6 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W23A0].>


**BO: DTC P1106 — ENGINE TORQUE CONTROL SIGNAL 2 CIRCUIT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Excessive shift shock

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.


● **WIRING DIAGRAM:**



**11B01 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**  
**(B135) No. 17 (+) — Chassis ground (-):**




- CHECK** : Is the voltage more than 4.5 V?
- YES** : Go to step 11B02.
- NO** : Go to step 11B04.

**11B02 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
**(B135) No. 17 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 10 V?
- YES** : Repair battery short circuit in harness between ECM and TCM connector.
- NO** : Go to step 11B03.

**11B03 : CHECK POOR CONTACT.**


Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ECM connector?*
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**11B04 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and TCM connector.

**Connector & terminal**  
(B135) No. 17 — (B54) No. 21:




- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 11B05.
- NO** : Repair open circuit in harness between ECM and TCM connector.

**11B05 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**  
(B135) No. 17 — Chassis ground:



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step 11B06.

**11B06 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in TCM connector?*
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W23A0].>


**BP: DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



**11BP1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

- CHECK** : *Is the value less than 0 kPa (0 mmHg, 0 inHg)?*
- YES** : Go to step 11BP3.
- NO** : Go to step 11BP2.

**11BP2 : CHECK POOR CONTACT.**


Check poor contact in ECM and pressure sensor connector. <Ref. to 2-7 [T3C8].>

- CHECK** : *Is there poor contact in ECM or pressure sensor connector?*
- YES** : Repair poor contact in ECM or atmospheric pressure sensor connector.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**11BP3 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
**(B136) No. 15 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 4.5 V?*
- YES** : Go to step 11BP5.
- NO** : Go to step 11BP4.

**11BP4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**  
**(B136) No. 15 (+) — Chassis ground (-):**



- CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair poor contact in ECM connector.
- NO** : Contact with SOA service.


NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11BP5 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
**(B136) No. 29 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage less than 0.2 V?*
- YES** : Go to step 11BP7.
- NO** : Go to step 11BP6.

**11BP6 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Read data of atmospheric absolute pressure signal using Subaru Select Monitor.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

**CHECK** : *Does the value change more than 0 kPa (0 mmHg, 0 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?*


- YES** : Repair poor contact in ECM connector.  
**NO** : Go to step 11BP7.

**11BP7 : CHECK HARNESS BETWEEN ECM  
AND ATMOSPHERIC PRESSURE  
SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from atmospheric pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between atmospheric pressure sensor connector and engine ground.

**Connector & terminal**

**(B2) No. 3 (+) — Engine ground (-):**



- CHECK** : *Is the voltage more than 4.5 V?*  
**YES** : Go to step 11BP8.  
**NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and atmospheric pressure sensor connector
- Poor contact in joint connector (B83)

**11BP8 : CHECK HARNESS BETWEEN ECM  
AND ATMOSPHERIC PRESSURE  
SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and pressure sensor connector.

**Connector & terminal**

**(B136) No. 16 — (B2) No. 1:**



- CHECK** : *Is the resistance less than 1 Ω?*  
**YES** : Go to step 11BP9.  
**NO** : Repair harness and connector.

NOTE:

In this case, repair the following:


- Open circuit in harness between ECM and pressure sensor connector

**11BP9 : CHECK HARNESS BETWEEN ECM AND ATMOSPHERIC PRESSURE SENSOR CONNECTOR.**

Measure resistance of harness between pressure sensor connector and engine ground.

**Connector & terminal**

**(B2) No. 2 — Engine ground:**



- CHECK** : **Is the resistance more than 500 kΩ?**
- YES** : Go to step **11BP10**.
- NO** : Repair ground short circuit in harness between ECM and pressure sensor connector.

**11BP10 : CHECK POOR CONTACT.**

Check poor contact in pressure sensor connector.  
<Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in pressure sensor connector?**
- YES** : Repair poor contact in atmospheric pressure sensor connector.
- NO** : Replace atmospheric pressure sensor.  
<Ref. to 2-7 [W14A0].>




**BQ: DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**



B2M3796

**11BQ1 : CHECK CURRENT DATA.**

- 1) Start engine.
- 2) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value more than 140 kPa (1,050 mmHg, 41.34 inHg)?*

**YES** : Go to step 11BQ10.


**NO** : Go to step 11BQ2.

**11BQ2 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 15 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage more than 4.5 V?*

**YES** : Go to step 11BQ4.


**NO** : Go to step 11BQ3.

**11BQ3 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 15 (+) — Chassis ground (-):**



**CHECK** : *Does the voltage change more than 4.5 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*

**YES** : Repair poor contact in ECM connector.

**NO** : Contact with SOA service.

NOTE:


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11BQ4 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B136) No. 29 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage less than 0.2 V?*

**YES** : Go to step 11BQ6.

**NO** : Go to step 11BQ5.

**11BQ5 : CHECK INPUT SIGNAL FOR ECM.  
(USING SUBARU SELECT MONI-  
TOR.)**

Read data of atmospheric absolute pressure signal using Subaru Select Monitor.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

**CHECK** : *Does the value change more than 0 kPa (0 mmHg, 0 inHg) by shaking harness and connector of ECM while monitoring the value with Subaru select monitor?*


- YES** : Repair poor contact in ECM connector.  
**NO** : Go to step 11BQ6.

**11BQ6 : CHECK HARNESS BETWEEN ECM  
AND PRESSURE SENSOR CON-  
NECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from atmospheric pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between atmospheric pressure sensor connector and engine ground.

**Connector & terminal**

**(B2) No. 3 (+) — Engine ground (-):**



- CHECK** : *Is the voltage more than 4.5 V?*  
**YES** : Go to step 11BQ7.  
**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and pressure sensor connector
- Poor contact in joint connector (B83)

**11BQ7 : CHECK HARNESS BETWEEN ECM  
AND PRESSURE SENSOR CON-  
NECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and pressure sensor connector.

**Connector & terminal**

**(B136) No. 29 — (B2) No. 2:**



- CHECK** : *Is the resistance less than 1 Ω?*  
**YES** : Go to step 11BQ8.  
**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and pressure sensor connector
- Poor contact in joint connector (B83)

**11BQ8 : CHECK HARNESS BETWEEN ECM AND PRESSURE SENSOR CONNECTOR.**

Measure resistance of harness between ECM and pressure sensor connector.

**Connector & terminal**

**(B136) No. 16 — (B2) No. 1:**



**CHECK** : **Is the resistance less than 1 Ω?**

**YES** : Go to step **11BQ9**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and pressure sensor connector
- Poor contact in joint connector (B83)

**11BQ9 : CHECK POOR CONTACT.**

Check poor contact in pressure sensor connector.  
<Ref. to FOREWORD [T3C1].>

**CHECK** : **Is there poor contact in pressure sensor connector?**

**YES** : Repair poor contact in atmospheric pressure sensor connector.

**NO** : Replace atmospheric pressure sensor.  
<Ref. to 2-7 [W14A0].>

**11BQ10 : CHECK CURRENT DATA.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from atmospheric pressure sensor.
- 3) Turn ignition switch to ON.
- 4) Read data of intake manifold absolute pressure signal using Subaru select monitor or OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : **Is the value more than 140 kPa (1,050 mmHg, 41.34 inHg)?**

**YES** : Repair battery short circuit in harness between ECM and atmospheric pressure sensor connector.

**NO** : Replace atmospheric pressure sensor.  
<Ref. to 2-7 [W14A0].>

## BR: DTC P1112 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM —


### ● DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

### CAUTION:

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

### ● WIRING DIAGRAM:



**11BR1 : CHECK ANY OTHER DTC ON DISPLAY.**

**11BR2 : CHECK ATMOSPHERIC PRESSURE SENSOR FILTER.**

### NOTE:

In this case, it is not necessary to inspect DTC P0106.

**CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0106, P0107, P0108, P1110 or P1111?*

**YES** : Inspect DTC P0106, P0107, P0108, P1110 or P1111 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NO** : Go to step **11BR2**.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from atmospheric pressure sensor.
- 3) Remove atmospheric pressure sensor.
- 4) Check atmospheric pressure sensor filter.

**CHECK** : *Is atmospheric pressure sensor filter non-functional? (Check for contamination, damage, water leakage, etc.)*

**YES** : Replace atmospheric pressure sensor filter.

**NO** : Go to step **11BR3**.

**11BR3 : CHECK CURRENT DATA.**

- 1) Turn ignition switch to ON.
- 2) Read data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool.

## NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value between 73.3 kPa (550 mmHg, 21.65 inHg) and 106.6 kPa (800 mmHg, 31.50 inHg)?*

**YES** : Replace atmospheric pressure sensor. <Ref. to 2-7 [W14A0].>

**NO** : Replace intake air temperature and pressure. <Ref. to 2-7 [W13A0].>

### BS: DTC P1115 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT HIGH INPUT —


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**




B2M2667

**11BS1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Start engine, and warm-up the engine.
- 2) Turn ignition switch to OFF.
- 3) Disconnect connector from TCM.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 31 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage less than 3 V?**
- YES** : Go to step **11BS2**.
- NO** : Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>

**11BS2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 31 (+) — Chassis ground (-):**



- CHECK** : **Does the voltage change more than 10 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**
- YES** : Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.



**BT: DTC P1116 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT LOW INPUT —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**




B2M2667

**11BT1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Start engine, and warm-up the engine.
- 2) Turn ignition switch to OFF.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 31 (+) — Chassis ground (-):**



B2M2668A


- CHECK** : Is the voltage more than 3 V?
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step 11BT2.

**11BT2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and TCM.
- 3) Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 31 — Chassis ground:**



B2M2670A


- CHECK** : Is the resistance less than 10 Ω?
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step 11BT3.

**11BT3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure resistance of harness between ECM and TCM connector.

**Connector & terminal**

**(B134) No. 31 — (B54) No. 2:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Repair poor contact in ECM or TCM connector.
- NO** : Repair open circuit in harness between ECM and TCM connector.

**BU: DTC P1120 — STARTER SWITCH CIRCUIT HIGH INPUT —****● DTC DETECTING CONDITION:**


- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- Failure of engine to start

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**

B2M3792

**11BU1 : CHECK OPERATION OF STARTER MOTOR.****NOTE:**

Place the inhibitor switch in each position.

- CHECK** : **Does starter motor operate when ignition switch to "ON"?**
- YES** : Repair battery short circuit in starter motor circuit. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Check starter motor circuit. <Ref. to 2-7 [T8B0].>

**MEMO:**

**BV: DTC P1121 — NEUTRAL POSITION SWITCH CIRCUIT LOW INPUT —****● DTC DETECTING CONDITION:**


- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:****11BV1 : CHECK DTC P0705 ON DISPLAY.**


- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0705?
- YES** : Inspect DTC P0705 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11BV2**.

**11BV2 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B135) No. 26 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage between 4.5 and 5.5 V at except "N" and "P" positions?**
- YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time.
- NO** : Go to step **11BV3**.

**11BV3 : CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and transmission harness connector (T3).
- 3) Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**


**(B135) No. 26 — Chassis ground:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and transmission harness connector.
- NO** : Go to step **11BV4**.

**11BV4 : CHECK TRANSMISSION HARNESS CONNECTOR.**


- 1) Disconnect connector from inhibitor switch.
- 2) Measure resistance of harness between transmission harness connector and engine ground.

**Connector & terminal****(T3) No. 12 — Engine ground:**

- CHECK** : **Is the resistance less than 10  $\Omega$ ?**
- YES** : Repair ground short circuit in harness between transmission harness and inhibitor switch connector.
- NO** : Go to step **11BV5**.

**11BV5 : CHECK INHIBITOR SWITCH.**

Measure resistance between inhibitor switch connector receptacle's terminals in selector lever except for "N" position.

**Terminals****No. 7 — No. 12:**

- CHECK** : **Is the resistance more than 1  $M\Omega$  at except "N" and "P" positions?**
- YES** : Go to step **11BV6**.
- NO** : Replace inhibitor switch. <Ref. to 3-2 [W2C0].>

**11BV6 : CHECK SELECTOR CABLE CONNECTION.**

- CHECK** : **Is there any fault in selector cable connection to inhibitor switch?**
- YES** : Repair selector cable connection. <Ref. to 3-2 [W2A0].>
- NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**MEMO:**




**BW: DTC P1130 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (OPEN CIRCUIT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3775

**11BW1 : CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from ECM and front oxygen (A/F) sensor connector.
- 3) Measure resistance of harness between ECM and front oxygen (A/F) sensor connector.


**Connector & terminal**

**(B136) No. 6 — (E18) No. 1:**

**(B136) No. 7 — (B18) No. 6:**

**(B136) No. 19 — (B18) No. 3:**

**(B136) No. 20 — (B18) No. 4:**



**CHECK** : **Is the resistance less than 1 Ω?**

**YES** : Go to step **11BW2**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and front oxygen (A/F) sensor connector
- Poor contact in front oxygen (A/F) sensor connector
- Poor contact in ECM connector

**11BW2 : CHECK POOR CONTACT.**

Check poor contact in front oxygen (A/F) sensor connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : **Is there poor contact in front oxygen (A/F) sensor connector?**

**YES** : Repair poor contact in front oxygen (A/F) sensor connector.

**NO** : Replace front oxygen (A/F) sensor. <Ref. to 2-7 [W8A0].>


**BX: DTC P1131 — FRONT OXYGEN (A/F) SENSOR CIRCUIT MALFUNCTION (SHORT CIRCUIT) —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3775

**11BX1 : CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM connector and chassis ground.


**Connector & terminal**

**(B136) No. 6 — Chassis ground:**

**(B136) No. 7 — Chassis ground:**

**(B136) No. 19 — Chassis ground:**

**(B136) No. 20 — Chassis ground:**



- CHECK** : **Is the resistance more than 10 Ω?**
- YES** : Replace front oxygen (A/F) sensor.  
<Ref. to 2-7 [W8A0].>
- NO** : Repair ground short circuit in harness between ECM and front oxygen (A/F) sensor connector.

**BY: DTC P1132 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT LOW INPUT —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**● WIRING DIAGRAM:**



B2M3775

**11BY1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1132 and P0141 at the same time?

**YES** : Go to step 11BY2.


**NO** : Go to step 11BY5.

**11BY2 : CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from front oxygen (A/F) sensor.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between front oxygen (A/F) sensor connector and engine ground.

**Connector & terminal**

**(B18) No. 2 (+) — Engine ground (-):**



**CHECK** : *Is the voltage more than 10 V?*

**YES** : Go to step 11BY3.

**NO** : Repair power supply line.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between main relay and front oxygen (A/F) sensor connector
- Poor contact in front oxygen (A/F) sensor connector
- Poor contact in main relay connector

**11BY3 : CHECK GROUND CIRCUIT OF ECM.**

Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 35 — Chassis ground:**



**CHECK** : *Is the resistance less than 5 Ω?*

**YES** : Go to step 11BY4.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and engine ground terminal
- Poor contact in ECM connector
- Poor contact in coupling connector (B22)

### 11BY4 : CHECK GROUND CIRCUIT OF ECM.

1) Measure resistance of harness between ECM connector and chassis ground.

#### Connector & terminal

(B134) No. 34 — Chassis ground:



**CHECK** : *Is there resistance less than 5 Ω?*

**YES** : Go to step 11BY5.

**NO** : Repair harness and connector.

#### NOTE:

In this case, repair the following:

- Open circuit in harness between ECM and engine ground terminal
- Poor contact in ECM connector
- Poor contact in coupling connector (B22)

### 11BY5 : CHECK CURRENT DATA.

1) Start engine  
2) Read data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or OBD-II general scan tool.

#### NOTE:

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II scan tool

For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : *Is the value more than 0.2 A?*

**YES** : Repair poor contact in connector.

#### NOTE:

In this case, repair the following:

- Poor contact in front oxygen (A/F) sensor connector
- Poor contact in ECM connector


**NO** : Go to step 11BY6.

### 11BY6 : CHECK OUTPUT SIGNAL FROM ECM.

1) Start and idle the engine.  
2) Measure voltage between ECM connector and chassis ground.

#### Connector & terminal

(B134) No. 22 (+) — Chassis ground (-):



**CHECK** : *Is the voltage less than 1.0 V?*

**YES** : Go to step 11BY8.


**NO** : Go to step 11BY7.

### 11BY7 : CHECK OUTPUT SIGNAL FROM ECM.

Measure voltage between ECM connector and chassis ground.

#### Connector & terminal

(B134) No. 22 (+) — Chassis ground (-):



**CHECK** : *Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*

**YES** : Repair poor contact in ECM connector.


**NO** : Go to step 11BY8.

**11BY8 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 23 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage less than 1.0 V?**
- YES** : Go to step 11BY10.
- NO** : Go to step 11BY9.

**11BY9 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 23 (+) — Chassis ground (-):**




- CHECK** : **Does the voltage change less than 1.0 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step 11BY10.

**11BY10 : CHECK FRONT OXYGEN (A/F) SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between front oxygen (A/F) sensor connector terminals.

**Terminals**

**No. 2 — No. 5:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open or ground short circuit in harness between front oxygen (A/F) sensor and ECM connector
- Poor contact in front oxygen (A/F) sensor connector
- Poor contact in ECM connector
- NO** : Replace front oxygen (A/F) sensor. <Ref. to 2-7 [W8A0].>




**BZ: DTC P1133 — FRONT OXYGEN (A/F) SENSOR HEATER CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3775

**11BZ1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 23 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 8 V?*
- YES** : Go to step 11BZ3.
- NO** : Go to step 11BZ2.

**11BZ2 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 22 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage more than 8 V?*
- YES** : Go to step 11BZ3.
- NO** : Go to step 11BZ4.

**11BZ3 : CHECK FRONT OXYGEN (A/F) SENSOR HEATER CURRENT.**

- 1) Turn ignition switch to OFF.
- 2) Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.
- 3) Turn ignition switch to ON.
- 4) Read data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor  
For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>
- OBD-II general scan tool  
For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.


- CHECK** : *Is the value more than 2.3 A?*
- YES** : Replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : END

**11BZ4 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 23 (+) — Chassis ground (-):**




- CHECK** : *Does the voltage change more than 8 V by shaking harness and connector of ECM while monitoring the value with voltage meter?*
- YES** : Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.
- NO** : Go to step 11BZ5.

**11BZ5 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 22 (+) — Chassis ground (-):**



- CHECK** : **Does the voltage change more than 8 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**
- YES** : Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.
- NO** : END


### CA: DTC P1142 — THROTTLE POSITION SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM (LOW INPUT) —

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Poor driving performance

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3774

**11CA1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0122 or P0123?
- YES** : Inspect DTC P0122 or P0123 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**

In this case, it is not necessary to inspect DTC P1142.

- NO** : Replace throttle position sensor. <Ref. to 2-7 [W10A2].>

**CB: DTC P1151 — REAR OXYGEN SENSOR HEATER CIRCUIT HIGH INPUT**


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**




B2M3778

**11CB1 : CHECK INPUT SIGNAL FOR ECM.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 21 (+) — Chassis ground (-):**



**CHECK** : **Is the voltage more than 8 V?**

**YES** : Go to step **11CB2**.

**NO** : Go to step **11CB3**.

**11CB2 : CHECK CURRENT DATA.**

- 1) Turn ignition switch to OFF.
- 2) Repair battery short circuit in harness between ECM and rear oxygen sensor connector.
- 3) Turn ignition switch to ON.
- 4) Read data of rear oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool.

**NOTE:**

- Subaru Select Monitor

For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to 2-7 [T3C4].>

- OBD-II general scan tool

For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.

**CHECK** : **Is the value more than 7 A?**

**YES** : Replace ECM. <Ref. to 2-7 [W19A0].>

**NO** : END

**11CB3 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : **Is there poor contact in ECM connector?**

**YES** : Repair poor contact in ECM connector.

**NO** : END


**CC: DTC P1207 — AIR ASSIST INJECTOR SOLENOID VALVE CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3804

**11CC1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 24 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage more than 10 V?*
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step **11CC2**.

**11CC2 : CHECK POWER SUPPLY TO AIR ASSIST INJECTOR SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from air assist injector solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between air assist injector solenoid valve and engine ground.

**Connector & terminal**

**(E42) No. 2 (+) — Engine ground (-):**



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step **11CC3**.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between air assist injector solenoid valve and main relay connector
- Poor contact in coupling connector (B22)




**11CC3 : CHECK HARNESS BETWEEN ECM AND AIR ASSIST INJECTOR SOLENOID VALVE CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance of harness between ECM and air assist injector solenoid valve connector.

**Connector & terminal**

**(B134) No. 24 — (E42) No. 1:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step **11CC4**.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and air assist injector solenoid valve connector
- Poor contact in coupling connector (B22)

**11CC4 : CHECK HARNESS BETWEEN ECM AND AIR ASSIST INJECTOR SOLENOID VALVE CONNECTOR.**

Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 24 — Chassis ground:**



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and air assist injector solenoid valve connector.
- NO** : Go to step **11CC5**.

**11CC5 : CHECK POOR CONTACT.**

Check poor contact in ECM and air assist injector solenoid valve connectors. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ECM and air assist injector solenoid valve connectors?*
- YES** : Repair poor contact in ECM and air assist injector solenoid valve connectors.
- NO** : Replace air assist injector solenoid valve. <Ref. to 2-7 [W16A0].>

**MEMO:**


**CD: DTC P1208 — AIR ASSIST INJECTOR SOLENOID VALVE CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3804

**11CD1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 24 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **11CD2**.
- NO** : Go to step **11CD3**.

**11CD2 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from air assist injector solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 24 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and air assist injector solenoid valve connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Replace air assist injector solenoid valve <Ref. to 2-7 [W16A0].> and ECM <Ref. to 2-7 [W19A0].>.

**11CD3 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 24 (+) — Chassis ground (-):**



- CHECK** : **Does the voltage change more than 10 V by shaking harness and connector of ECM while monitoring the value with voltage meter?**
- YES** : Repair battery short circuit in harness between ECM and air assist injector solenoid valve connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Contact with SOA service.

**NOTE:**

Inseption by DTM is required, because probable cause is deterioration of multiple parts.

**MEMO:**


**CE: DTC P1325 — KNOCK SENSOR CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Poor driving performance
  - Knocking occurs.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3571

**11CE1 : CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM.
- 3) Measure resistance between ECM harness connector and chassis ground.

**Connector & terminal**  
**(B136) No. 4 — Chassis ground:**




- CHECK** : *Is the resistance more than 700 kΩ?*
- YES** : Go to step 11CE3.
- NO** : Go to step 11CE2.

**11CE2 : CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.**

Measure resistance of harness between ECM connector and chassis ground.

**Connector & terminal**  
**(B136) No. 4 — Chassis ground:**




- CHECK** : *Is the resistance less than 400 kΩ?*
- YES** : Go to step 11CE5.
- NO** : Go to step 11CE6.

**11CE3 : CHECK KNOCK SENSOR.**

- 1) Disconnect connector from knock sensor.
- 2) Measure resistance between knock sensor connector terminal and engine ground.

**Terminal**  
**No. 2 — Engine ground:**



- CHECK** : *Is the resistance more than 700 kΩ?*
- YES** : Go to step 11CE4.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between knock sensor and ECM connector
- Poor contact in knock sensor connector
- Poor contact in coupling connector (B21)

**11CE4 : CHECK CONDITION OF KNOCK SENSOR INSTALLATION.**

- CHECK** : *Is the knock sensor installation bolt tightened securely?*
- YES** : Replace knock sensor. <Ref. to 2-7 [W7A1].>
- NO** : Tighten knock sensor installation bolt securely.




**11CE5 : CHECK KNOCK SENSOR.**

- 1) Disconnect connector from knock sensor.
- 2) Measure resistance between knock sensor connector terminal and engine ground.

**Terminal**

**No. 2 — Engine ground:**



- CHECK** : **Is the resistance less than 400 kΩ?**
- YES** : Replace knock sensor. <Ref. to 2-7 [W7A0].>
- NO** : Repair ground short circuit in harness between knock sensor connector and ECM connector.

**NOTE:**


The harness between both connectors is shielded. Repair short circuit of harness together with shield.

**11CE6 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Connect connectors to ECM and knock sensor.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B136) No. 4 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 2 V?**
- YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.)

**NOTE:**

In this case, repair the following:

- Poor contact in knock sensor connector
- Poor contact in ECM connector
- Poor contact in coupling connector (B21)
- NO** : Repair poor contact in ECM connector.

**MEMO:**

**CF: DTC P1400 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW INPUT —**


**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**




B2M3601

**11CF1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 1 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **11CF2**.
- NO** : Go to step **11CF3**.

**11CF2 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Contact with SOA service.

**NOTE:**


Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11CF3 : CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from fuel tank pressure control solenoid valve and ECM.
- 3) Measure resistance of harness between fuel tank pressure control solenoid valve connector and chassis ground.

**Connector & terminal**

**(R68) No. 2 — Chassis ground:**




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM and fuel tank pressure control solenoid valve connector.
- NO** : Go to step **11CF4**.

**11CF4 : CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

Measure resistance of harness between ECM and fuel tank pressure control solenoid valve connector.

**Connector & terminal**  
**(B134) No. 1 — (R68) No. 2:**



- CHECK** : *Is the voltage less than 1 Ω?*
- YES** : Go to step **11CF5**.
- NO** : Repair harness and connector.

**NOTE:**


In this case, repair the following:

- Open circuit in harness between ECM and fuel tank pressure control solenoid valve connector
- Poor contact in coupling connectors (R134 and B99)

**11CF5 : CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.**

Measure resistance between fuel tank pressure control solenoid valve terminals.

**Terminals**  
**No. 1 — No. 2:**




- CHECK** : *Is the resistance between 10 and 100 Ω?*
- YES** : Go to step **11CF6**.
- NO** : Replace fuel tank pressure control solenoid valve. <Ref. to 2-1 [W9A0].>

**11CF6 : CHECK POWER SUPPLY TO FUEL TANK PRESSURE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between fuel tank pressure control solenoid valve and chassis ground.

**Connector & terminal**

**(R68) No. 1 (+) — Chassis ground (-):**



**CHECK** : **Is the voltage more than 10 V?**

**YES** : Go to step **11CF7**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between main relay and fuel tank pressure control solenoid valve connector
- Poor contact in coupling connectors (R134 and B97)
- Poor contact in main relay connector

**11CF7 : CHECK POOR CONTACT.**

Check poor contact in fuel tank pressure control solenoid valve connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : **Is there poor contact in fuel tank pressure control solenoid valve connector?**

**YES** : Repair poor contact in fuel tank pressure control solenoid valve connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**CG: DTC P1420 — FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT HIGH INPUT —**


**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


**• WIRING DIAGRAM:**



B2M3601

**11CG1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.




- 3) Turn ignition switch to ON.
- 4) While operating fuel tank pressure control solenoid valve, measure voltage between ECM and chassis ground.

**NOTE:**

Fuel tank pressure control solenoid valve operation can be executed using Subaru Select Monitor. For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**Connector & terminal**

**(B134) No. 1 (+) — Chassis ground (-):**




- CHECK** : Does voltage change between 0 and 10 V?
- YES** : Go to step 11CG2.
- NO** : Even if MIL light up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.

**11CG2 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 1 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 11CG4.
- NO** : Go to step 11CG3.

**11CG3 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>




**11CG4 : CHECK HARNESS BETWEEN FUEL TANK PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from fuel tank pressure control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 1 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and fuel tank pressure control solenoid valve connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CG5**.

**11CG5 : CHECK FUEL TANK PRESSURE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between fuel tank pressure control solenoid valve terminals.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Replace fuel tank pressure control solenoid valve <Ref. to 2-1 [W9A0].> and ECM <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CG6**.

**11CG6 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**MEMO:**


**CH: DTC P1422 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Erroneous idling

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


● **WIRING DIAGRAM:**



B2M3583

**11CH1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.




- 3) Turn ignition switch to ON.
- 4) While operating purge control solenoid valve, measure voltage between ECM and chassis ground.

**NOTE:**

Purge control solenoid valve operation can be executed using Subaru Select Monitor. For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**Connector & terminal**

**(B134) No. 2 (+) — Chassis ground (-):**




- CHECK** : Does voltage change between 0 and 10 V?
- YES** : Go to step 11CH2.
- NO** : Even if MIL light up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.

**11CH2 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 2 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 11CH4.
- NO** : Go to step 11CH3.

**11CH3 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>


- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**11CH4 : CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from purge control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 2 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CH5**.

**11CH5 : CHECK PURGE CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between purge control solenoid valve terminals.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Replace purge control solenoid valve <Ref. to 2-1 [W17A0].> and ECM <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CH6**.

**11CH6 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**MEMO:**

**CI: DTC P1423 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL HIGH INPUT —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


**● WIRING DIAGRAM:**



B2M3588

**11C11 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.




- 3) Turn ignition switch to ON.
- 4) While operating drain valve, measure voltage between ECM and chassis ground.

**NOTE:**

Drain valve operation can be executed using Subaru Select Monitor. For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**Connector & terminal**

**(B134) No. 10 (+) — Chassis ground (-):**




- CHECK** : Does voltage change between 0 and 10 V?
- YES** : Go to step 11C12.
- NO** : Even if MIL light up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.

**11C12 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 10 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 11C14.
- NO** : Go to step 11C13.

**11C13 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in ECM connector?
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>




**11CI4 : CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from drain valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B134) No. 10 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and drain valve connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CI5**.

**11CI5 : CHECK DRAIN VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between drain valve terminals.

**Terminals**

**No. 1 — No. 2:**



- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Replace drain valve <Ref. to 2-1 [W13A0].> and ECM <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CI6**.

**11CI6 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

## CJ: DTC P1442 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM 2 —


**DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**



B2M3563

**11CJ1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK :** Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0461, P0462 or P0463?

**YES :** Inspect DTC P0461, P0462 or P0463 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:** In this case, it is not necessary to inspect this trouble.

**NO :** Replace fuel level sensor <Ref. to 2-8 [W5A0].> and fuel sub level sensor. <Ref. to 2-8 [W6A0].>


**CK: DTC P1443 — EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL FUNCTION PROBLEM —**

- **DTC DETECTING CONDITION:**
  - Immediately after fault occurrence
- **TROUBLE SYMPTOM:**
  - Improper fuel supply

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3588


**11CK1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using “11. Diagnostics Chart with Trouble Code for AT Vehicles”. <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11CK2**.

**11CK2 : CHECK VENT LINE HOSES.**

Check the following items.


- Clogging of vent hoses between canister and drain valve
- Clogging of vent hose between drain valve and air filter
- Clogging of drain filter



- CHECK** : **Is there a fault in vent line?**
- YES** : Repair or replace the faulty part.
- NO** : Go to step **11CK3**.

**11CK3 : CHECK DRAIN VALVE OPERATION.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.



- 3) Turn ignition switch to ON.
- 4) Operate drain valve.

NOTE:

Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to the "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

- CHECK** : **Does drain valve produce operating sound?**

- YES** : Contact with SOA service.

NOTE:

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

- NO** : Replace drain valve. <Ref. to 2-1 [W13A0].>


**CL: DTC P1445 — AIR ASSIST INJECTOR SOLENOID VALVE MALFUNCTION**

- **DTC DETECTING CONDITION:**
  - Immediately after fault occurrence
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3804

**11CL1 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Is there any other DTC on display?*
- YES** : Inspect the relevant DTC using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>
- NO** : Go to step **11CL2**.

### 11CL2 : CHECK AIR ASSIST INJECTOR SOLENOID VALVE OPERATION.

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.



- 3) Turn ignition switch to ON.
- 4) Operate air assist injector solenoid valve.

#### NOTE:

Air assist injector solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to the "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**CHECK** : ***Does air assist injector solenoid valve operating sound?***

**YES** : Go to step **11CL3**.

**NO** : Replace air assist injector solenoid valve. <Ref. to 2-1 [W16A0].>

### 11CL3 : CHECK AIR BY-PASS HOSES.

Use your mouth to blow through air by-pass hose to make sure that there is a smooth air flow (no clogging).

**CHECK** : ***Is air by-pass hose damaged?***

**YES** : Repair or replace air by-pass hoses.

**NO** : Go to step **11CL4**.

### 11CL4 : CHECK FUEL INJECTOR.

- 1) Turn ignition switch to OFF.
- 2) Remove fuel injector. <Ref. to 2-7 [W18A0].>
- 3) Check for clogged fuel injectors.

**CHECK** : ***Is fuel injector clogged?***

**YES** : Replace fuel injector. <Ref. to 2-7 [W18A0].>

**NO** : Replace air assist injector solenoid valve. <Ref. to 2-7 [W16A0].>

**CM: DTC P1490 — THERMOSTAT MALFUNCTION —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Thermostat remains open.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**11CM1 : CHECK VEHICLE CONDITION.**

- CHECK** : *Has engine operated at idle or has vehicle been driven with part of engine submerged under water?*
- YES** : In this case, it is not necessary to inspect DTC P1490.
- NO** : Go to step 11CM2.

**11CM2 : CHECK ANY OTHER DTC ON DISPLAY.**

- CHECK** : *Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0125, P0301, P0302, P0303 and P0304 at same time?*
- YES** : Go to step 11CM3.
- NO** : Inspect DTC P0125, P0301, P0302, P0303 and P0304 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**11CM3 : CHECK ENGINE COOLANT.**

- CHECK** : *Are coolant level and mixture ratio of cooling water to anti-freeze solution correct?*
- YES** : Go to step 11CM4.
- NO** : Replace engine coolant. <Ref. to 2-5 [W9A0].>

**11CM4 : CHECK RADIATOR FAN.**

- 1) Start the engine.
  - 2) Check radiator fan operation.
- CHECK** : *Does radiator fan continuously rotate for more than 3 minutes during idling?*
- YES** : Repair radiator fan circuit. <Ref. to 2-5 [T100].>
- NO** : Replace thermostat. <Ref. to 2-5 [W2A0].>

**MEMO:**



**CN: DTC P1507 — IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE) —**

**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault


**• TROUBLE SYMPTOM:**

- Engine keeps running at higher revolution than specified idling revolution.

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**



B2M3788

**11CN1 : CHECK ANY OTHER DTC ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1510, P1511, P1512, P1513, P1514, P1515, P1516 or P1517?

**YES** : Inspect DTC P1510, P1511, P1512, P1513, P1514, P1515, P1516 or P1517 using "11. Diagnostics Chart with Trouble Code for AT Vehicles". <Ref. to 2-7 [T11A0].>

**NOTE:**  
In this case, it is not necessary to inspect DTC P0507.

**NO** : Go to step 11CN2.

**11CN2 : CHECK AIR INTAKE SYSTEM.**

- 1) Turn ignition switch to ON.
- 2) Start engine, and idle it.
- 3) Check the following items.
  - Loose installation of intake manifold, idle air control solenoid valve and throttle body
  - Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket
  - Disconnections of vacuum hoses

**CHECK** : Is there a fault in air intake system?  
**YES** : Repair air suction and leaks.  
**NO** : Go to step 11CN3.

**11CN3 : CHECK THROTTLE CABLE.**

- CHECK** : *Does throttle cable have play for adjustment?*
- YES** : Go to step **11CN4**.
- NO** : Adjust throttle cable. <Ref. to 4-5 [W1A3].>

**11CN4 : CHECK AIR BY-PASS LINE.**

- 1) Turn ignition switch to OFF.
- 2) Remove idle air control solenoid valve from throttle body. <Ref. to 2-7 [W15A2].>
- 3) Confirm that there are no foreign particles in by-pass air line.

- CHECK** : *Are foreign particles in by-pass air line?*
- YES** : Remove foreign particles from by-pass air line.
- NO** : Replace idle air control solenoid valve. <Ref. to 2-7 [W15A2].>

**MEMO:**

**CO: DTC P1510 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 1  
CIRCUIT LOW INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1516. <Ref. to 2-7 [T11CU0].>

**CP: DTC P1511 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 1  
CIRCUIT HIGH INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1517. <Ref. to 2-7 [T11CV0].>

**CQ: DTC P1512 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 2  
CIRCUIT LOW INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1516. <Ref. to 2-7 [T11CU0].>

**CR: DTC P1513 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 2  
CIRCUIT HIGH INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1517. <Ref. to 2-7 [T11CV0].>

**CS: DTC P1514 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 3  
CIRCUIT LOW INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1516. <Ref. to 2-7 [T11CU0].>

**CT: DTC P1515 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 3  
CIRCUIT HIGH INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1517. <Ref. to 2-7 [T11CV0].>


**CU: DTC P1516 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4  
CIRCUIT LOW INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Engine breathing

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**




B2M3788

**11CU1 : CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from idle air control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between idle air control solenoid valve connector and engine ground.

**Connector & terminal**

**(E7) No. 2 (+) — Engine ground (-):**



**CHECK** : *Is the voltage more than 10 V?*

**YES** : Go to step 11CU2.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between idle air control solenoid valve and main relay connector
- Poor contact in coupling connector (B22)

**11CU2 : CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.**

Measure voltage between idle air control solenoid valve connector and engine ground.

**Connector & terminal**

**(E7) No. 5 (+) — Engine ground (-):**



**CHECK** : *Is the voltage more than 10 V?*

**YES** : Go to step 11CU3.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between idle air control solenoid valve and main relay connector
- Poor contact in coupling connector (B22)

**11CU3 : CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ECM and idle air control solenoid valve connector.

**Connector & terminal**

**DTC P1510; (B134) No. 5 — (E7) No. 3:**  
**DTC P1512; (B134) No. 6 — (E7) No. 1:**  
**DTC P1514; (B134) No. 19 — (E7) No. 6:**  
**DTC P1516; (B134) No. 20 — (E7) No. 4:**



- CHECK** : **Is the resistance less than 1 Ω?**  
**YES** : Go to step **11CU4**.  
**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:


- Open circuit in harness between ECM and idle air control solenoid valve connector
- Poor contact in coupling connector (B21)

**11CU4 : CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.**

- 1) Disconnect connector from ECM.
- 2) Measure resistance between ECM connector and chassis ground.

**Connector & terminal**

**DTC P1510; (B134) No. 5 — Chassis ground:**  
**DTC P1512; (B134) No. 6 — Chassis ground:**  
**DTC P1514; (B134) No. 19 — Chassis ground:**  
**DTC P1516; (B134) No. 20 — Chassis ground:**



- CHECK** : **Is the resistance less than 10 Ω?**  
**YES** : Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.  
**NO** : Go to step **11CU5**.

**11CU5 : CHECK POOR CONTACT.**

Check poor contact in ECM connector and idle air control solenoid valve connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : *Is there poor contact in ECM connector or idle air control solenoid valve connector?*

**YES** : Repair poor contact in ECM connector or idle air control solenoid valve connector.

**NO** : Replace idle air control solenoid valve. <Ref. to 2-7 [W15A2].>




**CV: DTC P1517 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4  
CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
  - Erroneous idling
  - Engine stalls.
  - Engine breathing

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



B2M3788

**11CV1 : CHECK ANY OTHER DTC ON DISPLAY.**


- CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1511, P1513, P1515 and P1517 at same time?
- YES** : Go to step 11CV2.
- NO** : Go to step 11CV3.

**11CV2 : CHECK GROUND CIRCUIT FOR ECM.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between ECM connector and chassis ground.

**Connector & terminal**

**(B134) No. 7 — Chassis ground:**



**CHECK** : **Is the resistance less than 5 Ω?**

**YES** : Go to step **11CV3**.

**NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM connector and engine ground terminal
- Poor contact in ECM connector
- Poor contact in coupling connector (B22)

**11CV3 : CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from idle air control solenoid valve.
- 3) Turn ignition switch to ON.
- 4) Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**DTC P1511; (B134) No. 5 (+) — Chassis**

**ground (-):**

**DTC P1513; (B134) No. 6 (+) — Chassis**


**ground (-):**

**DTC P1515; (B134) No. 19 (+) — Chassis**

**ground (-):**

**DTC P1517; (B134) No. 20 (+) — Chassis**

**ground (-):**



**CHECK** : **Is the voltage more than 10 V?**

**YES** : Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>

**NO** : Replace ECM. <Ref. to 2-7 [W19A0].>


**CW: DTC P1520 — COOLING FAN RELAY 1 CIRCUIT HIGH INPUT —**

- **DTC DETECTING CONDITION:**
  - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
  - Radiator fan does not operate properly.
  - Overheating

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>


● **WIRING DIAGRAM:**



B2M3576

**11CW1 : CHECK OUTPUT SIGNAL FROM ECM.**

- 1) Turn ignition switch to OFF.
- 2) Connect test mode connector at the lower portion of instrument panel (on the driver's side), to the side of the center console box.




- 3) Turn ignition switch to ON.
- 4) While operating radiator fan relay, measure voltage between ECM and chassis ground.

**NOTE:**

Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "COMPULSORY VALVE OPERATION CHECK MODE". <Ref. to 2-7 [T3F0].>

**Connector & terminal**

**(B134) No. 3 (+) — Chassis ground (-):**




- CHECK** : Does voltage change between 0 and 10 V?
- YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.
- NO** : Go to step 11CW2.

**11CW2 : CHECK SHORT CIRCUIT IN RADIATOR FAN RELAY CONTROL CIRCUIT.**

- 1) Turn ignition switch to OFF.
- 2) Remove main fan relay and sub fan relay. (with A/C models)
- 3) Disconnect test mode connector.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between ECM and chassis ground.

**Connector & terminal**


**(B134) No. 3 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 10 V?
- YES** : Repair battery short circuit in radiator fan relay control circuit. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step 11CW3.

**11CW3 : CHECK MAIN FAN RELAY.**


- 1) Turn ignition switch to OFF.
- 2) Remove main fan relay.
- 3) Measure resistance between main fan relay terminals.

**Terminal****No. 1 — No. 3:**

- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Replace main fan relay and ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CW4**.

**11CW4 : CHECK SUB FAN RELAY.**

- 1) Remove sub fan relay.
- 2) Measure resistance between sub fan relay terminals.

**Terminal****No. 1 — No. 3**

- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Replace sub fan relay and ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11CW5**.

**11CW5 : CHECK POOR CONTACT.**

Check poor contact in ECM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in ECM connector?**
- YES** : Repair poor contact in ECM connector.
- NO** : Replace ECM. <Ref. to 2-7 [W19A0].>

**MEMO:**

**CX: DTC P1540 — VEHICLE SPEED SENSOR MALFUNCTION 2 —**


**DTC DETECTING CONDITION:**

- Immediately at fault recognition

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**WIRING DIAGRAM:**



B2M3787

**11CX1 : CHECK DTC P0720 ON DISPLAY.**

**CHECK** : Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?

**YES** : Check vehicle speed sensor 2 signal circuit. <Ref. to 3-2 [T8F0].>

**NO** : Go to step 11CX2.

**11CX2 : CHECK SPEEDOMETER OPERATION IN COMBINATION METER.**

**CHECK** : Does speedometer operate normally?

**YES** : Go to step 11CX3.


**NO** : Check speedometer and vehicle speed sensor. <Ref. to 6-2 [K3A0].>

**11CX3 : CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from combination meter.
- 3) Measure resistance between ECM and combination meter.

**Connector & terminal**

**(B135) No. 24 — (i10) No. 13:**



- CHECK** : **Is the resistance less than 10 Ω ?**
- YES** : Repair poor contact in ECM connector.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and combination meter connector
- Poor contact in ECM connector
- Poor contact in combination meter connector
- Poor contact in coupling connector (i2)



**CY: DTC P1560 — BACK-UP VOLTAGE CIRCUIT MALFUNCTION —**


**● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**● WIRING DIAGRAM:**




B2M3826

**11CY1 : CHECK INPUT SIGNAL FOR ECM.**

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B136) No. 9 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step **11CY2**.

**11CY2 : CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR.**

- 1) Disconnect connector from ECM.
- 2) Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**

**(B136) No. 9 — Chassis ground:**



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair ground short circuit in harness between ECM connector and battery terminal.
- NO** : Go to step **11CY3**.

**11CY3 : CHECK FUSE SBF-5.**

- CHECK** : **Is fuse blown?**
- YES** : Replace fuse. <Ref. to 6-3 [D6A0].>
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ECM and battery
- Poor contact in ECM connector
- Poor contact in battery terminal

**CZ: DTC P1700 — THROTTLE POSITION SENSOR CIRCUIT MALFUNCTION FOR AUTOMATIC TRANSMISSION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**● TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effected in “3” range; excessive shift shock; excessive tight corner “braking”

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check throttle position sensor circuit. <Ref. to 3-2 [T8F0].>

**MEMO:**

**DA: DTC P1701 — CRUISE CONTROL SET SIGNAL CIRCUIT MALFUNCTION FOR AUTOMATIC TRANSMISSION —**


**• DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

**• WIRING DIAGRAM:**



B2M2110

**11DA1 : CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.**


**11DA2 : CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and CCM.
- 3) Measure resistance of harness between TCM and CCM connector.


Measure resistance of harness between TCM and chassis ground.

**Connector & terminal**  
**(B54) No. 11 — Chassis ground:**

**Connector & terminal**  
**(B54) No. 11 — (B94) No. 3:**



B2M2681A



B2M2682A

- CHECK** : **Is the resistance less than 1 Ω?**
- YES** : Go to step 11DA2.
- NO** : Repair open circuit in harness between TCM and CCM connector.

- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Repair short circuit in harness between TCM and CCM connector.
- NO** : Go to step 11DA3.

**11DA3 : CHECK INPUT SIGNAL FOR TCM.**

- 1) Connect connector to TCM and CCM.
- 2) Lift-up the vehicle or set the vehicle on free rollers.


**CAUTION:**

**On AWD models, raise all wheels off ground.**

- 3) Start the engine.
- 4) Cruise control main switch to ON.
- 5) Move selector lever to "D" and slowly increase vehicle speed to 50 km/h (31 MPH).
- 6) Cruise control set switch to ON.
- 7) Measure voltage between TCM and chassis ground.

**Connector & terminal**

**(B54) No. 11 (+) — Chassis ground (-):**



- CHECK** : **Is the resistance less than 1 V?**
- YES** : Go to step **11DA4**.
- NO** : Check cruise control set circuit. <Ref. to 6-2 [T7A0].>

**11DA4 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in TCM connector?**
- YES** : Repair poor contact in TCM connector.
- NO** : Replace TCM. <Ref. to 3-2 [W23A0].>

**DB: DTC P1702 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT LOW INPUT —**


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● **WIRING DIAGRAM:**




B2M2111

**11DB1 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B135) No. 4 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage less than 1 V?*
- YES** : Go to step 11DB2.
- NO** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**NOTE:**


- In this case, repair the following:
- Poor contact in ECM connector
  - Poor contact in TCM connector

**11DB2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from ECM and TCM.
- 3) Measure resistance of harness between ECM and chassis ground.

**Connector & terminal**

**(B135) No. 4 — Chassis ground:**




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Repair ground short circuit in harness between ECM and TCM connector.
- NO** : Go to step 11DB3.

**11DB3 : CHECK OUTPUT SIGNAL FOR ECM.**

- 1) Connect connector to ECM.
- 2) Turn ignition switch to ON.
- 3) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B135) No. 4 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage more than 5 V?*
- YES** : Go to step 11DB4.
- NO** : Repair poor contact in ECM connector.



**11DB4 : CHECK TROUBLE CODE FOR  
AUTOMATIC TRANSMISSION.**

Read trouble code for automatic transmission.  
<Ref. to 3-2 [T8A0].>

- CHECK** : *Does trouble code appear for automatic transmission?*
- YES** : Inspect trouble code for automatic transmission. <Ref. to 3-2 [T8A0].>
- NO** : Replace TCM. <Ref. to 3-2 [W23A0].>

**DC: DTC P1703 — LOW CLUTCH TIMING CONTROL SOLENOID VALVE  
CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check low clutch timing control solenoid valve circuit. <Ref. to 3-2 [T8L0].>

**DD: DTC P1704 — 2-4 BRAKE TIMING CONTROL SOLENOID VALVE  
CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check 2-4 brake timing control solenoid valve circuit. <Ref. to 3-2 [T8M0].>

**DE: DTC P1705 — 2-4 BRAKE PRESSURE CONTROL SOLENOID VALVE  
CIRCUIT MALFUNCTION —****● DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

**NOTE:**

Check 2-4 brake pressure control solenoid valve circuit. <Ref. to 3-2 [T8O0].>

### DF: DTC P1722 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT HIGH INPUT —


● DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>.

● WIRING DIAGRAM:




B2M2111

**11DF1 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between ECM and chassis ground.

**Connector & terminal**

**(B135) No. 4 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Repair battery short circuit in harness between ECM and TCM connector. After repair, replace ECM. <Ref. to 2-7 [W19A0].>
- NO** : Go to step **11DF2**.

**11DF2 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B135) No. 4 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 4 V?**
- YES** : Go to step **11DF5**.
- NO** : Go to step **11DF3**.

**11DF3 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure voltage between ECM connector and chassis ground.

**Connector & terminal**

**(B135) No. 4 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage less than 1 V?**
- YES** : Repair poor contact in ECM connector.
- NO** : Go to step **11DF4**.

**11DF4 : CHECK OUTPUT SIGNAL FROM ECM.**

Measure voltage between ECM and chassis ground.

**Connector & terminal**  
**(B135) No. 4 (+) — Chassis ground (-):**



- CHECK** : Does the voltage change from 1 V to 4 V while monitoring the value with voltage meter?
- YES** : Even if MIL lights up, the circuit has returned to a normal condition at this time.

**NOTE:**

In this case, repair the following:

- Poor contact in ECM connector
- Poor contact in TCM connector

**NO** : Contact with SOA service.


**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

**11DF5 : CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR.**

Measure voltage between TCM and chassis ground.

**Connector & terminal**  
**(B54) No. 4 (+) — Chassis ground (-):**



- CHECK** : Is the voltage more than 4 V?
- YES** : Go to step 11DF6.
- NO** : Repair open circuit in harness between ECM and TCM connector.

**11DF6 : CHECK POOR CONTACT.**

Check poor contact in TCM connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : Is there poor contact in TCM connector?
- YES** : Repair poor contact in TCM connector.
- NO** : Check TCM power supply line and grounding line.

**DG: DTC P1742 — AUTOMATIC TRANSMISSION DIAGNOSIS INPUT SIGNAL CIRCUIT MALFUNCTION —**


● **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

**CAUTION:**

After repair or replacement of faulty parts, conduct CLEAR MEMORY MODE <Ref. to 2-7 [T3D0].> and INSPECTION MODE <Ref. to 2-7 [T3E0].>

● **WIRING DIAGRAM:**



**11DG1 : CHECK DRIVING CONDITION.**

- 1) Start and warm-up the engine until the radiator fan makes one complete rotation.
- 2) Drive the vehicle.

**CHECK** : *Is AT shift control functioning properly?*

**YES** : Go to step **11DG2**.

**NO** : Replace TCM. <Ref. to 3-2 [W23A0].>

**11DG2 : CHECK ACCESSORY.**

**CHECK** : *Are car phone and/or CB installed on vehicle?*

**YES** : Repair grounding line of car phone or CB system.

**NO** : Replace TCM. <Ref. to 3-2 [W23A0].>

MEMO: