


## 5. Rear Brake Pad S405175

### A: REMOVAL S405175A18

- 1) Remove lock pin.




- 2) Raise caliper body.
- 3) Remove pad from support.

**NOTE:**

If brake pad is difficult to remove, use the same procedure as for front disc brake pad.

<Ref. to BR-16 REMOVAL, Front Brake Pad.>



### B: INSTALLATION S405175A11

- 1) Apply thin coat of Molykote AS880N (Part No. 26298AC000) to the frictional portion between pad and pad clip.
- 2) Install pad on support.
- 3) Install caliper body on support.

**Tightening torque:**

**39 N·m (4.0 kgf-m, 28.9 ft-lb)**

**NOTE:**

If it is difficult to push piston during pad replacement, loosen air bleeder to facilitate work.

## REAR BRAKE PAD

Brake

### C: INSPECTION S405175A10

Check pad thickness (including back metal).


**Pad thickness: A**

**Standard value**

**14.0 mm (0.551 in)**

**Wear limit**

**6.5 mm (0.256 in)**



#### CAUTION:

- Always replace the pads for both the left and right wheels at the same time. Also replace pad clips if they are twisted or worn.
- A wear indicator is provided on the inner disc brake pad. If the pad wears down to such an extent that the end of the wear indicator contacts the disc rotor, a squeaking sound is produced as the wheel rotates. If this sound is heard, replace the pad.
- Replace pad if there is oil or grease on it.