

9. Radiator Main Fan and Fan Motor \$146059

A: REMOVAL S146059A18


1) Disconnect battery ground cable.



- 2) Lift-up the vehicle.
- 3) Remove under cover.




- 4) Drain engine coolant completely. <Ref. to CO(H6)-18, Engine Coolant.>
- 5) Disconnect connectors of main and sub fan motor.




- (A) Main fan motor connector
- (B) Sub fan motor connector


- 6) Lower the vehicle.
- 7) Remove air intake duct.




8) Disconnect over flow hose.




9) Remove reservoir tank.



10) Disconnect radiator inlet hoses from radiator.




11) Remove radiator sub fan motor assembly.



12) Remove radiator main fan motor assembly.

NOTE:


When removing main fan assembly by lifting it upward, main fan shroud will cause interference with coolant suction area. In order to avoid this, shift the main fan assembly over to sub fan side before removing it.




B: INSTALLATION S146059A11

Install in the reverse order of removal.


Tightening torque: 4.9 N·m (0.50 kgf-m, 3.6 ft-lb)



Tightening torque: 4.9 N·m (0.50 kgf-m, 3.6 ft-lb)




Tightening torque: 4.9 N⋅m (0.50 kgf-m, 3.6 ft-lb)




C: DISASSEMBLY S146059A06


1) Remove clip which holds motor connector onto shroud.



2) Remove nut which holds fan itself onto fan motor and shroud assembly.



3) Remove screws which install fan motor onto shroud.




D: ASSEMBLY S146059A02


Assemble in the reverse order of disassembly.

Tightening torque:

4.4 N·m (0.45 kgf-m, 3.3 ft-lb)



Tightening torque: 7.5 N⋅m (0.76 kgf-m, 5.5 ft-lb)



E: INSPECTION S146059A10

- 1) Connect battery positive (+) terminal to terminal No. 2, and negative (-) terminal to terminal No. 1 of main fan motor connector.
- 2) Make sure the main fan motor operates properly. Replace it if it doesn't.

