

3. General Description S006001

A: CAUTION S006001A03

1. SUPPLEMENTAL RESTRAINT SYSTEM

“AIRBAG” S006001A0301

Airbag system wiring harness is routed near the ABS sensor, ABS control module and hydraulic control unit.

CAUTION:

- All Airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.
- Be careful not to damage Airbag system wiring harness when servicing the ABS sensor, ABS control module and hydraulic control unit.

B: INSPECTION S006001A10

Before performing diagnostics, check the following items which might affect ABS problems:

1. BATTERY S006001A1001

Measure battery voltage and specific gravity of electrolyte.

Standard voltage: 12 V, or more

Specific gravity: Above 1.260

2. BRAKE FLUID S006001A1002

- 1) Check brake fluid level.
- 2) Check brake fluid leakage.

3. HYDRAULIC UNIT S006001A1006

Check the hydraulic unit.

- With brake tester <Ref. to ABS-9, CHECKING THE HYDRAULIC UNIT ABS OPERATION WITH BRAKE TESTER, INSPECTION, ABS Control Module and Hydraulic Control Unit (ABSCM&H/U).>
- Without brake tester <Ref. to ABS-8, CHECKING THE HYDRAULIC UNIT ABS OPERATION BY PRESSURE GAUGE, INSPECTION, ABS Control Module and Hydraulic Control Unit (ABSCM&H/U).>

4. BRAKE DRAG S006001A1003

Check brake drag.

5. BRAKE PAD AND ROTOR S006001A1004

Check brake pad and rotor.



- Front <Ref. to BR-14, INSPECTION, Front Brake Pad.> and <Ref. to BR-15, INSPECTION, Front Disc Rotor.>
- Rear <Ref. to BR-19, INSPECTION, Rear Brake Pad.> and <Ref. to BR-24, INSPECTION, Rear Disc Brake Assembly.>

6. TIRE S006001A1005

Check tire specifications, tire wear and air pressure. <Ref. to WT-2, SPECIFICATIONS, General Description.>

C: PREPARATION TOOL S006001A17

1. SPECIAL TOOLS S006001A1701

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 B2M3876	24082AA190	CARTRIDGE	Troubleshooting for electrical systems.
 B2M3877	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems. <ul style="list-style-type: none"> ● English: 22771AA030 (Without printer) ● German: 22771AA070 (Without printer) ● French: 22771AA080 (Without printer) ● Spanish: 22771AA090 (Without printer)

2. GENERAL PURPOSE TOOLS S006001A1702

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance, voltage and ampere.
Oscilloscope	Used for measuring sensor.