

14. Diagnostic Procedure with Diagnostic Trouble Code (DTC) S004521

A: DTC 11 ENGINE SPEED SIGNAL S004521110



DIAGNOSIS:

Engine speed input signal circuit is open or shorted.

TROUBLE SYMPTOM:

- No lock-up (after engine warm-up).
- "AT OIL TEMP" warning light remains on when the vehicle speed is "0".

WIRING DIAGRAM:



B3M2219

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and ECM. 3) Measure the resistance of harness between TCM and ECM connector.</p> <p>Connector & terminal 2.5 L model without VDC system (B55) No. 4 — (B134) No. 30: 3.0 L model with VDC system (B55) No. 17 — (B136) No. 9: 3.0 L model without VDC system (B55) No. 4 — (B136) No. 9:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and ECM connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.</p> <p>Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 4 — Chassis ground: With VDC system (B55) No. 17 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and ECM connector.
3	PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 5.	Go to step 4.
4	<p>CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect the connectors to TCM and ECM. 2) Turn the ignition switch to ON (engine OFF). 3) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 4 (+) — Chassis ground (-): With VDC system (B55) No. 17 (+) — Chassis ground (-):</p>	Is the voltage 0 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and ECM.	Go to step 6.
5	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and ECM. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine, and turn the Subaru Select Monitor switch to ON. 4) Warm-up the engine until engine coolant temperature is above 80°C (176°F). 5) Engine idling. 6) Read the data of engine speed using the Subaru Select Monitor. ● Display shows engine speed signal value sent from ECM.</p>	Is the revolution value the same as the tachometer reading shown on the combination meter?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and ECM.	Go to step 6.
6	CHECK POOR CONTACT.	Is there poor contact in engine speed signal circuit?	Repair poor contact.	Go to step 7.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
7	CONFIRM DTC 11.	Replace the ECM with a new one. Does the trouble code appear again, after the memory has been cleared?	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>	Replace the ECM.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

B: DTC 27 ATF TEMPERATURE SENSOR S004521111


DIAGNOSIS:

Input signal circuit of TCM to ATF temperature sensor is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



B3M2220

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission and TCM. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 10 — (B11) No. 12: With VDC system (B54) No. 20 — (B11) No. 12:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR.</p> <p>Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 11 — (B11) No. 11: With VDC system (B54) No. 11 — (B11) No. 11:</p>	Is the resistance less than 1 Ω?	Go to step 3.	Repair open circuit in harness between TCM and transmission connector.
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR.</p> <p>Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 10 — Chassis ground: With VDC system (B54) No. 20 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 4.	Repair short circuit in harness between TCM and transmission connector.
4	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR.</p> <p>Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 11 — Chassis ground: With VDC system (B54) No. 11 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 5.	Repair short circuit in harness between TCM and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
5	<p>CHECK ATF TEMPERATURE SENSOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Connect the connectors to transmission and TCM.</p> <p>3) Turn the ignition switch to ON and start engine.</p> <p>4) Warm-up the transmission until the ATF temperature reaches to 80°C (176°F).</p> <p>NOTE:</p> <p>If ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature.</p> <p>5) Disconnect the connector from transmission.</p> <p>6) Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 11 — No. 12:</p>	Is the resistance between 275 and 375 Ω?	Go to step 6.	Go to step 11.
6	<p>CHECK ATF TEMPERATURE SENSOR.</p> <p>1) Turn the ignition switch to ON (engine OFF).</p> <p>2) Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 11 — No. 12:</p>	Does the resistance value increase while the ATF temperature decreases?	Go to step 7.	Go to step 11.
7	<p>PREPARE SUBARU SELECT MONITOR.</p>	Do you have a Subaru Select Monitor?	Go to step 9.	Go to step 8.
8	<p>CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect the connector to transmission.</p> <p>2) Warm-up the transmission until the ATF temperature is about 80°C (176°F).</p> <p>NOTE:</p> <p>If ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature.</p> <p>3) Measure the voltage between TCM connector terminal.</p> <p>Connector & terminal Without VDC system (B55) No. 11 (+) — No. 10 (-): With VDC system (B54) No. 11 (+) — No. 20 (-):</p>	Is the voltage between 0.4 and 0.9 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. Temporary poor contact of the connector or harness may be the case. Repair harness or contact in the ATF temperature sensor and transmission connector.	Go to step 10.
9	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connector to transmission.</p> <p>2) Turn the ignition switch to ON (engine OFF).</p>	Does the ATF temperature gradually decrease?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. Temporary poor contact of the connector or harness may be the case. Repair harness or contact in the ATF temperature sensor and transmission connector.	Go to step 10.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
10	CHECK POOR CONTACT.	Is there poor contact in ATF temperature sensor circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
11	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND ATF TEMPERATURE SENSOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission. 3) Remove the transmission connector from bracket. 4) Lift-up the vehicle and place safety stand. NOTE: On AWD models, raise all wheels off ground. 5) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 6) Remove the oil pan, and disconnect the connector from ATF temperature sensor connector. 7) Measure the resistance of harness between ATF temperature sensor and transmission connector. Connector & terminal (T4) No. 11 — (AT1) No. 2:	Is the resistance less than 1 Ω?	Go to step 12.	Repair open circuit in harness between ATF temperature sensor and transmission connector.
12	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND ATF TEMPERATURE SENSOR. Measure the resistance of harness between ATF temperature sensor and transmission connector. Connector & terminal (T4) No. 12 — (AT1) No. 1:	Is the resistance less than 1 Ω?	Go to step 13.	Repair open circuit in harness between ATF temperature sensor and transmission connector.
13	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND ATF TEMPERATURE SENSOR. Measure the resistance of harness between transmission connector and transmission ground. Connector & terminal (T4) No. 11 — Transmission ground:	Is the resistance more than 1 MΩ?	Go to step 14.	Repair short circuit in harness between ATF temperature sensor and transmission connector.
14	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND ATF TEMPERATURE SENSOR. Measure the resistance of harness between transmission connector and transmission ground. Connector & terminal (T4) No. 12 — Transmission ground:	Is the resistance more than 1 MΩ?	Replace the ATF temperature sensor. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>	Repair short circuit in harness between ATF temperature sensor and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

C: DTC 31 THROTTLE POSITION SENSOR S004521G62

DIAGNOSIS:

Input signal circuit of throttle position sensor is open or shorted.

TROUBLE SYMPTOM:








Shift point too high or too low; excessive shift shock; excessive tight corner "braking".

WIRING DIAGRAM:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

• 2.5 L ENGINE MODEL




B3M2221

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

● 3.0 L ENGINE MODEL



B3M2222

No.	Step	Check	Yes	No
1	CHECK ENGINE GROUND TERMINALS.	Have engine ground terminals been tightened?	Go to step 2.	Tighten the engine ground terminals.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
2	<p>CHECK GROUND CIRCUIT OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and engine ground.</p> <p>Connector & terminal 2.5 L engine model (B134) No. 27 — Engine ground: (B134) No. 8 — Engine ground: (B134) No. 7 — Engine ground: (B136) No. 21 — Engine ground: (B136) No. 22 — Engine ground: (B134) No. 35 — Engine ground: (B134) No. 34 — Engine ground: 3.0 L engine model (B134) No. 22 — Engine ground: (B136) No. 8 — Engine ground: (B136) No. 17 — Engine ground: (B136) No. 18 — Engine ground: (B137) No. 8 — Engine ground: (B137) No. 9 — Engine ground: (B137) No. 21 — Engine ground: (B137) No. 31 — Engine ground:</p>	Is the resistance less than 5 Ω?	Go to step 3.	Repair open circuit in harness between ECM connector and engine grounding terminal.
3	<p>CHECK THROTTLE POSITION SENSOR. 1) Disconnect the connector from throttle position sensor. 2) Measure the resistance between throttle position sensor connector receptacle's terminals.</p> <p>Terminals 2.5 L engine model No. 4 — No. 2: 3.0 L engine model No. 1 — No. 3:</p>	Is the resistance between 3.0 and 4.2 kΩ?	Go to step 4.	Replace the throttle position sensor.
4	<p>CHECK THROTTLE POSITION SENSOR. Measure the resistance between throttle position sensor connector receptacle's terminals.</p> <p>Terminals 2.5 L engine model No. 2 — No. 3: 3.0 L engine model No. 2 — No. 1:</p>	Is the resistance between 0.35 and 0.5 kΩ?	Go to step 5.	Replace the throttle position sensor.
5	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. 1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM and throttle position sensor connector.</p> <p>Connector & terminal 2.5 L engine model (B55) No. 2 — (E13) No. 3: 3.0 L engine model with VDC system (B54) No. 3 — (E13) No. 2: 3.0 L engine model without VDC system (B55) No. 2 — (E13) No. 2:</p>	Is the resistance less than 1 Ω?	Go to step 6.	Repair open circuit in harness between TCM and throttle position sensor connector, and poor contact in coupling connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
6	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. Measure the resistance of harness between TCM and throttle position sensor connector. <i>Connector & terminal</i> <i>Without VDC system</i> (B55) No. 1 — (E13) No. 4: <i>With VDC system</i> (B54) No. 2 — (E13) No. 4:</p>	Is the resistance less than 1 Ω?	Go to step 7.	Repair open circuit in harness between TCM and throttle position sensor connector, and poor contact in coupling connector.
7	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. Measure the resistance of harness between TCM connector and chassis ground. <i>Connector & terminal</i> <i>Without VDC system</i> (B55) No. 2 — Chassis ground: <i>With VDC system</i> (B54) No. 3 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 8.	Repair short circuit in harness between TCM and throttle position sensor connector.
8	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. Measure the resistance of harness between TCM connector and chassis ground. <i>Connector & terminal</i> <i>Without VDC system</i> (B55) No. 1 — Chassis ground: <i>With VDC system</i> (B54) No. 2 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 9.	Repair short circuit in harness between TCM and throttle position sensor connector.
9	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM and ECM connector. <i>Connector & terminal</i> <i>2.5 L engine model</i> (B55) No. 2 — (B136) No. 17: <i>3.0 L engine model with VDC system</i> (B54) No. 3 — (B135) No. 7: <i>3.0 L engine model without VDC system</i> (B55) No. 2 — (B135) No. 7:</p>	Is the resistance less than 1 Ω?	Go to step 10.	Repair open circuit in harness between TCM and ECM connector.
10	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM and ECM connector. <i>Connector & terminal</i> <i>2.5 L engine model</i> (B55) No. 1 — (B136) No. 15: <i>3.0 L engine model with VDC system</i> (B54) No. 2 — (B135) No. 9: <i>3.0 L engine model without VDC system</i> (B55) No. 1 — (B135) No. 9:</p>	Is the resistance less than 1 Ω?	Go to step 11.	Repair open circuit in harness between TCM and ECM connector.
11	PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 14.	Go to step 12.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
12	<p>CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM, throttle position sensor and ECM. 2) Turn the ignition switch to ON (engine OFF). 3) Close the throttle completely. 4) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 2 (+) — Chassis ground (-): With VDC system (B54) No. 3 (+) — Chassis ground (-):</p>	Is the voltage between approx. 0.5 V in throttle fully closed?	Go to step 13.	Go to step 18.
13	<p>CHECK INPUT SIGNAL FOR TCM. 1) Open the throttle completely. 2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 2 (+) — Chassis ground (-): With VDC system (B54) No. 3 (+) — Chassis ground (-):</p>	Is the voltage between approx. 4.3 V with throttle fully open?	Go to step 16.	Go to step 18.
14	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connectors to TCM, throttle position sensor and ECM. 2) Connect the Subaru Select Monitor to data link connector. 3) Turn the ignition switch to ON (engine OFF). 4) Turn the Subaru Select Monitor switch to ON. 5) Throttle fully closed. 6) Read the data of throttle position sensor using Subaru Select Monitor.</p> <p>● Throttle position sensor input signal is indicated.</p>	Is the value voltage between approx. 0.5 V?	Go to step 15.	Go to step 18.
15	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. Throttle fully open.</p> <p>NOTE: Must be changed correspondingly with accelerator pedal operation (from “released” to “depressed” position).</p>	Is the value voltage between approx. 4.3 V?	Go to step 18.	Go to step 17.
16	<p>CHECK INPUT SIGNAL FOR TCM (THROTTLE POSITION SENSOR POWER SUPPLY). Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 1 (+) — Chassis ground (-): With VDC system (B54) No. 2 (+) — Chassis ground (-):</p>	Is the voltage between 4.8 and 5.3 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in throttle position sensor circuit.	Go to step 18.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
17	CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR (THROTTLE POSITION SENSOR POWER SUPPLY). Read the data of throttle position sensor power supply using Subaru Select Monitor. <ul style="list-style-type: none">● Throttle position sensor power supply voltage is indicated.	Is the value voltage between 4.8 and 5.3 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in throttle position sensor circuit.	Go to step 18.
18	CHECK POOR CONTACT.	Is there poor contact in throttle position sensor circuit?	Repair the poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

D: DTC 33 FRONT VEHICLE SPEED SENSOR S004521113

DIAGNOSIS:

- The vehicle speed signal is abnormal.
- The circuit in combination meter is faulty.
- The harness connector between TCM and vehicle speed sensor is in short or open.



TROUBLE SYMPTOM:

- Erroneous idling.
- Engine stalls.
- Poor driving performance.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

WIRING DIAGRAM:



B3M2223

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 5 — (B11) No. 17: With VDC system (B55) No. 18 — (B11) No. 17:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 21 — (B11) No. 18: With VDC system (B54) No. 10 — (B11) No. 18:</p>	Is the resistance less than 1 Ω?	Go to step 3.	Repair open circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 21 — Chassis ground: With VDC system (B54) No. 10 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 4.	Repair short circuit in harness between TCM and transmission connector.
4	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 5 — Chassis ground: With VDC system (B55) No. 18 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 5.	Repair short circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
5	<p>CHECK FRONT VEHICLE SPEED SENSOR. Measure the resistance between transmission connector receptacle's terminals.</p> <p>Connector & terminal (T4) No. 17 — No. 18:</p>	Is the resistance between 450 and 650 Ω?	Go to step 6.	Replace the front vehicle speed sensor. <Ref. to AT-33, Front Vehicle Speed Sensor.>
6	PREPARE OSCILLOSCOPE.	Do you have an oscilloscope?	Go to step 9.	Go to step 7.
7	PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 10.	Go to step 8.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
8	<p>CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect all connectors. 2) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: On AWD models, raise all wheels off floor.</p> <p>3) Start the engine and set the vehicle in 20 km/h (12 MPH) condition.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p> <p>4) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal Without VDC system (B55) No. 5 (+) — (B54) No. 21 (-): With VDC system (B55) No. 18 (+) — (B54) No. 10 (-):</p>	Is the voltage more than AC 1 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the case. Repair harness or connector in the front vehicle speed sensor circuit.	Go to step 11.
9	<p>CHECK FRONT VEHICLE SPEED SENSOR USING OSCILLOSCOPE.</p> <p>1) Connect all connectors. 2) Lift-up the vehicle and place safety stands.</p> <p>NOTE: On AWD models, raise all wheels off ground.</p> <p>3) Set the oscilloscope to TCM connector terminals.</p> <p>Connector & terminal Without VDC system Positive probe; (B55) No. 5 Earth lead; (B55) No. 21 With VDC system Positive probe; (B55) No. 18 Earth lead; (B54) No. 10</p> <p>4) Start the engine, and drive the wheels slowly.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunctions. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system. <Ref. to ABS-21, Clear Memory Mode.></p> <p>5) Measure the signal voltage indicated on oscilloscope.</p>	Is the voltage more than AC 4 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the case. Repair harness or connector in the front vehicle speed sensor circuit.	Go to step 11.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
10	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect all connectors. 2) Connect the Subaru Select Monitor to data link connector. 3) Lift-up or raise the vehicle and place safety stands. NOTE: On AWD models, raise all wheels off floor. 4) Turn the ignition switch to ON and turn the Subaru Select Monitor switch to ON. 5) Start the engine. 6) Read the data of vehicle speed using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Compare the speedometer with Subaru Select Monitor indications. ● Vehicle speed is indicated in “km/h” or “MPH”. <p>7) Slowly increase the vehicle speed to 60 km/h or 37 MPH. NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p>	<p>Does the speedometer indication increase as the Subaru Select Monitor data increases?</p>	<p>Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor connector or harness may be the case. Repair harness or connector in the front vehicle speed sensor circuit.</p>	<p>Go to step 11.</p>
11	<p>CHECK POOR CONTACT.</p>	<p>Is there poor contact in front vehicle speed sensor circuit?</p>	<p>Repair poor contact.</p>	<p>Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

E: DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR S004521114





DIAGNOSIS:

Input signal circuit of TCM is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK TORQUE CONVERTER TURBINE SPEED SENSOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission. 3) Measure the resistance between transmission connector receptacle's terminals.</p> <p>Connector & terminal <i>(T4) No. 14 — No. 15:</i></p>	Is the resistance between 450 and 650 Ω ?	Go to step 2.	Replace the turbine speed sensor. <Ref. to AT-38, Torque Converter Turbine Speed Sensor.>
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal <i>Without VDC system</i> <i>(B55) No. 12 — (B11) No. 14:</i> <i>With VDC system</i> <i>(B55) No. 8 — (B11) No. 14:</i></p>	Is the resistance less than 1 Ω ?	Go to step 3.	Repair open circuit in harness between TCM and transmission connector.
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal <i>Without VDC system</i> <i>(B55) No. 21 — (B11) No. 15:</i> <i>With VDC system</i> <i>(B55) No. 9 — (B11) No. 15:</i></p>	Is the resistance less than 1 Ω ?	Go to step 4.	Repair open circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
4	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal <i>Without VDC system</i> <i>(B55) No. 21 — Chassis ground:</i> <i>With VDC system</i> <i>(B55) No. 9 — Chassis ground:</i></p>	Is the resistance more than 1 M Ω ?	Go to step 5.	Repair short circuit in harness between TCM and transmission connector.
5	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal <i>Without VDC system</i> <i>(B55) No. 12 — Chassis ground:</i> <i>With VDC system</i> <i>(B55) No. 8 — Chassis ground:</i></p>	Is the resistance more than 1 M Ω ?	Go to step 6.	Repair short circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
6	PREPARE OSCILLOSCOPE.	Do you have an oscilloscope?	Go to step 10.	Go to step 7.
7	PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 9.	Go to step 8.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
8	<p>CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Start the engine and move select lever to "P" or "N" range.</p> <p>3) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal Without VDC system (B55) No. 12 (+) — No. 21 (-): With VDC system (B55) No. 8 (+) — No. 9 (-):</p>	Is the voltage more than AC 1 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 11.
9	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Connect the Subaru Select Monitor to data link connector.</p> <p>3) Turn the ignition switch to ON and turn the Subaru Select Monitor switch to ON.</p> <p>4) Start the engine.</p> <p>5) Move the select lever to "P" or "N" range.</p> <p>6) Read the data of turbine speed using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Compare the tachometer with Subaru Select Monitor indications. 	Is the revolution value same as the tachometer reading shown on the combination meter?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 11.
10	<p>CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Set the oscilloscope to TCM connector terminals.</p> <p>Connector & terminal With VDC system Positive probe; (B55) No. 8 Earth lead; (B55) No. 9 Without VDC system Positive probe; (B55) No. 12 Earth lead; (B55) No. 21</p> <p>3) Start the engine and move the select lever to "P" or "N" range.</p>	Is the signal voltage more than AC 1 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 11.
11	<p>CHECK POOR CONTACT.</p>	Is there poor contact in torque converter turbine speed sensor circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

F: DTC 38 TORQUE CONTROL SIGNAL S004521G66


DIAGNOSIS:

- The signal circuit is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



B3M2225

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connectors from TCM and ECM.</p> <p>3) Measure the resistance of harness between TCM and ECM connector.</p> <p>Connector & terminal</p> <p>2.5 L engine model</p> <p>(B54) No. 21 — (B134) No. 17:</p> <p>(B54) No. 13 — (B134) No. 16:</p> <p>3.0 L engine model with VDC model</p> <p>(B56) No. 14 — (B135) No. 18:</p> <p>(B56) No. 5 — (B135) No. 19:</p> <p>3.0 L engine model without VDC model</p> <p>(B54) No. 21 — (B135) No. 18:</p> <p>(B54) No. 13 — (B135) No. 19:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and ECM connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal <i>Without VDC system</i> (B56) No. 21 — Chassis ground: (B54) No. 13 — Chassis ground:</p> <p><i>With VDC system</i> (B56) No. 14 — Chassis ground: (B56) No. 5 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and ECM connector.
3	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and ECM. 2) Turn the ignition switch to ON (engine OFF). 3) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal <i>Without VDC system</i> (B54) No. 21 (+) — Chassis ground (-): (B54) No. 13 (+) — Chassis ground (-):</p> <p><i>With VDC system</i> (B56) No. 14 (+) — Chassis ground (-): (B56) No. 5 (+) — Chassis ground (-):</p>	Is the voltage more than 4.8 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and ECM.	Go to step 4.
4	<p>CHECK POOR CONTACT.</p>	Is there poor contact in torque control signal circuit?	Repair poor contact.	Go to step 5.
5	<p>CHECK GROUND LINE BETWEEN TRANSMISSION AND BODY. Check the installing condition of ground line in transmission and body.</p>	Is there any dirt or rust at ground line installing point?	Remove dirt and rust.	Go to step 6.
6	<p>CHECK GROUND LINE BETWEEN TRANSMISSION AND BODY. Check the installing condition of ground line in transmission and body.</p> <p>Tightening torque: <i>13±3 N·m (1.3±0.3 kgf·m, 9.4±2.2 ft·lb)</i></p>	Is the tightening torque value within specification?	Go to step 7.	Tighten to specified torque.
7	<p>CHECK GROUND LINE INSIDE TRANSMISSION. 1) Drain the AT fluid and remove the oil pan. 2) Check the tightening torque value of ground line installing bolt.</p> <p>Tightening torque: <i>T: 8±1 N·m (0.8±0.1 kgf·m, 5.8±0.7 ft·lb)</i></p>	Is the tightening torque value within specification?	Go to step 9.	Tighten to specified torque.
8	<p>CHECK GROUND CIRCUIT OF ECM. <Ref. to AT-52, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></p>	Is there any trouble?	Repair ground terminal and/or ground circuit of ECM.	Go to step 9.
9	<p>RECHECK OUTPUT SIGNAL EMITTED FROM TCM. Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal <i>Without VDC system</i> (B54) No. 21 (+) — Chassis ground (-): (B54) No. 13 (+) — Chassis ground (-):</p> <p><i>With VDC system</i> (B56) No. 14 (+) — Chassis ground (-): (B56) No. 5 (+) — Chassis ground (-):</p>	Is each voltage more than 4.8 V?	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>	Replace the ECM.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

G: DTC 45 INTAKE MANIFOLD PRESSURE SIGNAL S004521116


DIAGNOSIS:

Input signal circuit of TCM from ECM is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



B3M2226

No.	Step	Check	Yes	No
1	CHECK ENGINE GROUND TERMINALS AND GROUND CIRCUIT OF ECM <Ref. to AT-52, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble?	Repair ground terminal and/or ground circuit of ECM.	Go to step 2.
2	CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and ECM. 3) Measure the resistance of harness between TCM and ECM connector. Connector & terminal 2.5 L engine model (B55) No. 20 — (B136) No. 11: 3.0 L engine model without VDC system (B55) No. 20 — (B135) No. 28: 3.0 L engine model with VDC system (B54) No. 10 — (B135) No. 28:	Is the resistance less than 1 Ω?	Go to step 3.	Repair open circuit in harness between TCM and ECM connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM connector and chassis ground. <i>Connector & terminal</i> <i>Without VDC system</i> (B55) No. 20 — Chassis ground: <i>With VDC system</i> (B54) No. 10 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 4.	Repair short circuit in harness between TCM and ECM connector.
4	<p>PREPARE SUBARU SELECT MONITOR.</p>	Do you have a Subaru Select Monitor?	Go to step 6.	Go to step 5.
5	<p>CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM and ECM. 2) Start the engine, and warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 3) Engine idling. 4) Measure the voltage between TCM connector and chassis ground. <i>Connector & terminal</i> <i>Without VDC system</i> (B55) No. 20 (+) — Chassis ground (-): <i>With VDC system</i> (B54) No. 10 (+) — Chassis ground (-):</p>	Is the voltage between 1.2 and 1.8 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and ECM.	Go to step 7.
6	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connectors to TCM and ECM. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine, and turn the Subaru Select monitor switch to ON. 4) Warm-up the engine until the engine coolant temperature is above 80°C (176°F). 5) Engine idling. 6) Read the data of intake manifold pressure signal using Subaru Select Monitor. ● Display shows the intake manifold pressure signal value sent from ECM.</p>	Is the value between 1.2 and 1.8 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and ECM.	Go to step 7.
7	<p>CHECK POOR CONTACT.</p>	Is there poor contact in intake manifold pressure signal circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

H: DTC 71 SHIFT SOLENOID 1 S004521117


DIAGNOSIS:

Output signal circuit of shift solenoid 1 is open or shorted.

TROUBLE SYMPTOM:

Does not shift.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and shift solenoid 1 connector.</p> <p>Connector & terminal Without VDC system (B54) No. 7 — (B11) No. 1: With VDC system (B54) No. 22 — (B11) No. 1:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 7 — Chassis ground: With VDC system (B54) No. 22 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and transmission connector.
3	<p>CHECK SHIFT SOLENOID 1. Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 1 — No. 16:</p>	Is the resistance between 10 and 16 Ω?	Go to step 4.	Go to step 7.
4	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Turn the ignition switch to ON (engine OFF). 3) Move the select lever to “D” range. 4) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 7 (+) — Chassis ground (-): With VDC system (B54) No. 22 (+) — Chassis ground (-):</p>	Is the voltage more than 9V?	Go to step 5.	Go to step 6.
5	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Move the select lever to “2” range. 2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 7 (+) — Chassis ground (-): With VDC system (B54) No. 22 (+) — Chassis ground (-):</p>	Is the voltage less than 1V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or contact in the TCM.	Go to step 6.
6	<p>CHECK POOR CONTACT.</p>	Is there poor contact in shift solenoid 1 circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
7	<p>CHECK SHIFT SOLENOID 1 (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket.</p> <p>2) Lift-up or raise the vehicle and support with safety stand.</p> <p>NOTE: On AWD models, raise all wheels off ground.</p> <p>3) Drain the automatic transmission fluid.</p> <p>CAUTION: Do not drain the automatic transmission fluid until it cools down.</p> <p>4) Remove the oil pan, and disconnect the connector from shift solenoid 1.</p> <p>5) Measure the resistance between shift solenoid 1 connector and transmission ground.</p> <p>Terminal No. 1 — Transmission ground:</p>	Is the resistance between 10 and 16 Ω ?	Go to step 8.	Replace the shift solenoid 1. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
8	<p>CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 1 AND TRANSMISSION.</p> <p>Measure the resistance of harness between shift solenoid 1 and transmission connector.</p> <p>Connector & terminal (AT5) No. 1 — (T4) No. 1:</p>	Is the resistance less than 1 Ω ?	Go to step 9.	Repair open circuit in harness between shift solenoid 1 and transmission connector.
9	<p>CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 1 AND TRANSMISSION.</p> <p>Measure the resistance of harness between shift solenoid 1 connector and transmission ground.</p> <p>Connector & terminal (T4) No. 1 — Transmission ground:</p>	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in shift solenoid 1 and transmission.	Repair short circuit harness between shift solenoid 1 and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

I: DTC 72 SHIFT SOLENOID 2 S004521118


DIAGNOSIS:

Output signal circuit of shift solenoid 2 is open or shorted.

TROUBLE SYMPTOM:

Does not shift.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and shift solenoid 2 connector.</p> <p>Connector & terminal Without VDC system (B54) No. 6 — (B11) No. 2: With VDC system (B54) No. 5 — (B11) No. 2:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 6 — Chassis ground: With VDC system (B54) No. 5 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and transmission connector.
3	<p>CHECK SHIFT SOLENOID 2. Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 2 — No. 16:</p>	Is the resistance between 10 and 16 Ω?	Go to step 4.	Go to step 6.
4	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Lift-up or raise the vehicle and support with safety stand. NOTE: On AWD models, raise all wheels off ground. 3) Start the engine and warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 4) Move the selector lever to "D", and slowly increase the vehicle speed to 50 km/h (31 MPH). NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.> 5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 6 (+) — Chassis ground (-): With VDC system (B54) No. 5 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 5.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
5	CHECK POOR CONTACT.	Is there poor contact in shift solenoid 2 circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
6	CHECK SHIFT SOLENOID 2 (IN TRANSMISSION). 1) Remove the transmission connector from bracket. 2) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 3) Remove the oil pan, and disconnect the connector from shift solenoid 2. 4) Measure the resistance between shift solenoid 2 connector and transmission ground. Connector & terminal No. 1 — Transmission ground:	Is the resistance between 10 and 16 Ω ?	Go to step 7.	Replace the shift solenoid 2 assembly. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
7	CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 2 AND TRANSMISSION. Measure the resistance of harness between shift solenoid 2 and transmission connector. Connector & terminal (AT6) No. 1 — (T4) No. 2:	Is the resistance less than 1 Ω ?	Go to step 8.	Repair open circuit in harness between shift solenoid 2 and transmission connector.
8	CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 2 AND TRANSMISSION. Measure the resistance of harness between shift solenoid 2 connector and transmission ground. Connector & terminal (T4) No. 2 — Transmission ground:	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in shift solenoid 2 and transmission.	Repair short circuit harness between shift solenoid 2 and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

J: DTC 73 LOW CLUTCH TIMING SOLENOID S004521119


DIAGNOSIS:

Output signal circuit of low clutch timing solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B54) No. 14 — (B11) No. 3: With VDC system (B54) No. 15 — (B11) No. 3:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and transmission ground.</p> <p>Connector & terminal Without VDC system (B54) No. 14 — Chassis ground: With VDC system (B54) No. 15 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and transmission connector.
3	<p>CHECK LOW CLUTCH TIMING SOLENOID. Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 3 — No. 16:</p>	Is the resistance between 10 and 16 Ω?	Go to step 4.	Go to step 7.
4	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Turn the ignition switch to ON (engine OFF). 3) Move the select lever to “D” range. 4) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 14 (+) — Chassis ground (-): With VDC system (B54) No. 15 (+) — Chassis ground (-):</p>	Is the voltage more than 9V?	Go to step 5.	Go to step 6.
5	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Move the select lever to “2” range. 2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 14 (+) — Chassis ground (-): With VDC system (B54) No. 15 (+) — Chassis ground (-):</p>	Is the voltage less than 1V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or contact in the TCM and transmission.	Go to step 6.
6	<p>CHECK POOR CONTACT.</p>	Is there poor contact in low clutch timing solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
7	<p>CHECK LOW CLUTCH TIMING SOLENOID (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket.</p> <p>2) Lift-up or raise the vehicle and support with safety stands.</p> <p>NOTE: On AWD models, raise all wheels off ground.</p> <p>3) Drain the automatic transmission fluid.</p> <p>CAUTION: Do not drain the automatic transmission fluid until it cools down.</p> <p>4) Remove the oil pan, and disconnect the connector from low clutch timing solenoid.</p> <p>5) Measure the resistance between low clutch timing solenoid connector and transmission ground.</p> <p><i>Terminal</i> <i>No. 1 — Transmission ground:</i></p>	Is the resistance between 10 and 16 Ω ?	Go to step 8.	Replace the low clutch timing solenoid. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
8	<p>CHECK HARNESS CONNECTOR BETWEEN LOW CLUTCH TIMING SOLENOID AND TRANSMISSION.</p> <p>Measure the resistance of harness between low clutch timing solenoid and transmission connector.</p> <p><i>Connector & terminal</i> <i>(AT9) No. 1 — (T4) No. 3:</i></p>	Is the resistance less than 1 Ω ?	Go to step 9.	Repair open circuit in harness between low clutch timing solenoid and transmission connector.
9	<p>CHECK HARNESS CONNECTOR BETWEEN LOW CLUTCH TIMING SOLENOID AND TRANSMISSION.</p> <p>Measure the resistance of harness between low clutch timing solenoid connector and transmission ground.</p> <p><i>Connector & terminal</i> <i>(T4) No. 3 — Transmission ground:</i></p>	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in low clutch timing solenoid and transmission.	Repair short circuit harness between low clutch timing solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

K: DTC 74 2-4 BRAKE TIMING SOLENOID S004521/20


DIAGNOSIS:

Output signal circuit of 2-4 brake timing solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B54) No. 5 — (B11) No. 4: With VDC system (B54) No. 16 — (B11) No. 4:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and transmission ground.</p> <p>Connector & terminal Without VDC system (B54) No. 5 — Chassis ground: With VDC system (B54) No. 16 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and transmission connector.
3	<p>CHECK 2-4 BRAKE TIMING SOLENOID. Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 4 — No. 16:</p>	Is the resistance between 10 and 16 Ω?	Go to step 4.	Go to step 7.
4	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Lift-up or raise the vehicle and support with safety stands. NOTE: On AWD models, raise all wheels off ground. 3) Start the engine and warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 4) Move the select lever to "1", and slowly increase vehicle speed to 10 km/h (6 MPH). NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.> 5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 5 (+) — Chassis ground (-): With VDC system (B54) No. 16 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V?	Go to step 5.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
5	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Move the select lever to "D", and slowly increase vehicle speed to 65 km/h (40 MPH). NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p> <p>2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 5 (+) — Chassis ground (-): With VDC system (B54) No. 16 (+) — Chassis ground (-):</p>	Is the voltage more than 9 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or contact in the transmission.	Go to step 6.
6	<p>CHECK POOR CONTACT.</p>	Is there poor contact in 2-4 brake timing solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
7	<p>CHECK 2-4 BRAKE TIMING SOLENOID (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket.</p> <p>2) Lift-up or raise the vehicle and support with safety stands.</p> <p>NOTE: On AWD models, raise all wheels off ground.</p> <p>3) Drain the automatic transmission fluid.</p> <p>CAUTION: Do not drain the automatic transmission fluid until it cools down.</p> <p>4) Remove the oil pan, and disconnect the connector from 2-4 brake timing solenoid.</p> <p>5) Measure the resistance between 2-4 brake timing solenoid connector and transmission ground.</p> <p>Terminal No. 1 — Transmission ground:</p>	Is the resistance between 10 and 16 Ω ?	Go to step 8.	Replace the 2-4 brake timing solenoid. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
8	<p>CHECK HARNESS CONNECTOR BETWEEN 2-4 BRAKE TIMING SOLENOID AND TRANSMISSION.</p> <p>Measure the resistance of harness between 2-4 brake timing solenoid and transmission connector.</p> <p>Connector & terminal (AT8) No. 1 — (T4) No. 4:</p>	Is the resistance less than 1 Ω ?	Go to step 9.	Repair open circuit in harness between 2-4 brake timing solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
9	<p>CHECK HARNESS CONNECTOR BETWEEN 2-4 BRAKE TIMING SOLENOID AND TRANSMISSION.</p> <p>Measure the resistance of harness between 2-4 brake timing solenoid connector and transmission ground.</p> <p>Connector & terminal (T4) No. 4 — Transmission ground:</p>	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in 2-4 brake timing solenoid and transmission.	Repair short circuit harness between 2-4 brake timing solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

L: DTC 75 LINE PRESSURE DUTY SOLENOID S004521/21



DIAGNOSIS:

Output signal circuit of line pressure duty solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



B3M2231

No.	Step	Check	Yes	No
1	CHECK VEHICLE.	Is the target model without VDC system?	Go to step 2.	Go to step 7.
2	CHECK RESISTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from dropping resistor. 3) Measure the resistance between dropping resistor terminal. Terminals No. 1 — No. 2:	Is the resistance between 9 and 15 Ω?	Go to step 3.	Replace the dropping resistor. <Ref. to AT-50, Dropping Resistor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR.</p> <p>1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM connector and dropping resistor connector.</p> <p>Connector & terminal (B54) No. 18 — (B4) No. 1:</p>	Is the resistance less than 1 Ω?	Go to step 4.	Repair open circuit in harness between TCM and dropping resistor connector.
4	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR.</p> <p>Measure the resistance of harness between dropping resistor connector and chassis ground.</p> <p>Connector & terminal (B4) No. 1 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 5.	Repair short circuit in harness between TCM and dropping resistor connector.
5	<p>CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR.</p> <p>1) Disconnect the connector from transmission. 2) Measure the resistance of harness between transmission and dropping resistor connector.</p> <p>Connector & terminal (B4) No. 2 — (B11) No. 5:</p>	Is the resistance less than 1 Ω?	Go to step 6.	Repair open circuit in harness between dropping resistor and transmission connector.
6	<p>CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR.</p> <p>Measure the resistance of harness between dropping resistor connector and chassis ground.</p> <p>Connector & terminal (B4) No. 2 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 7.	Repair short circuit in harness between dropping resistor and transmission connector.
7	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission and TCM. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal (B54) No. 9 — (B11) No. 5:</p>	Is the resistance less than 1 Ω?	Go to step 8.	Repair open circuit in harness between TCM and transmission connector.
8	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND CHASSIS GROUND.</p> <p>Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal (B54) No. 9 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 9.	Repair short circuit in harness between TCM and transmission connector.
9	<p>CHECK LINE PRESSURE DUTY SOLENOID.</p> <p>Measure the resistance between transmission connector receptacle's terminals.</p> <p>Terminal (T4) No. 5 — No. 16:</p>	Is the resistance between 2.0 and 4.5 Ω?	Go to step 10.	Go to step 16.
10	PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 13.	Go to step 11.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
11	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Connect all connectors. 2) Start the engine and warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 3) Turn the ignition switch to ON (engine OFF). 4) Move the select lever to "N". 5) Measure the voltage between TCM connector and chassis ground. Connector & terminal (B54) No. 9 (+) — Chassis ground (-):</p>	Is the voltage between 1.5 and 5.0 V with throttle fully closed?	Go to step 12.	Go to step 15.
12	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>Measure the voltage between TCM connector and chassis ground. Connector & terminal (B54) No. 9 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V with throttle fully open?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in transmission.	Go to step 15.
13	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine, and turn the Subaru Select Monitor switch to ON. 4) Warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 5) Stop the engine and turn the ignition switch to ON (engine OFF). 6) Move the select lever to "N". 7) Read the data of line pressure duty solenoid using Subaru Select Monitor. ● Line pressure duty solenoid is indicated in "%". 8) Throttle is fully closed.</p>	Is the value 100%?	Go to step 14.	Go to step 15.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
14	CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR. 1) Turn the ignition switch to ON (Engine OFF). 2) Throttle is fully open.	Is the value less than 25%?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in transmission.	Go to step 15.
15	CHECK POOR CONTACT.	Is there poor contact in line pressure duty solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
16	CHECK LINE PRESSURE DUTY SOLENOID (IN TRANSMISSION). 1) Remove the transmission connector from bracket. 2) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 3) Remove the oil pan, and disconnect the connector from line pressure duty solenoid. 4) Measure the resistance between line pressure duty solenoid connector and transmission ground. <i>Terminal</i> <i>No. 1 — Transmission ground:</i>	Is the resistance between 2.0 and 4.5 Ω?	Go to step 17.	Replace the line pressure duty solenoid. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
17	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND LINE PRESSURE DUTY SOLENOID. Measure the resistance of harness between line pressure duty solenoid and transmission connector. <i>Connector & terminal</i> <i>(T4) No. 5 — (AT2) No. 1:</i>	Is the resistance less than 1 Ω?	Go to step 18.	Repair open circuit in harness between line pressure duty solenoid and transmission connector.
18	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND LINE PRESSURE DUTY SOLENOID. Measure the resistance of harness between transmission connector and transmission ground. <i>Connector & terminal</i> <i>(T4) No. 5 — Transmission ground:</i>	Is the resistance more than 1 MΩ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in line pressure duty solenoid and transmission.	Repair short circuit in harness between line pressure duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

M: DTC 76 2-4 BRAKE DUTY SOLENOID S004521/22


DIAGNOSIS:

Output signal circuit of 2-4 brake duty solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



No.	Step	Check	Yes	No
1	CHECK VEHICLE.	Is the target model without VDC system?	Go to step 2.	Go to step 7.
2	CHECK RESISTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from dropping resistor. 3) Measure the resistance between dropping resistor terminal. Terminals No. 3 — No. 4:	Is the resistance between 9 and 15 Ω?	Go to step 3.	Replace the dropping resistor. <Ref. to AT-50, Dropping Resistor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR.</p> <p>1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM connector and dropping resistor connector.</p> <p>Connector & terminal (B54) No. 17 — (B4) No. 3:</p>	Is the resistance less than 1 Ω ?	Go to step 4.	Repair open circuit in harness between TCM and dropping resistor connector.
4	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR.</p> <p>Measure the resistance of harness between dropping resistor connector and chassis ground.</p> <p>Connector & terminal (B4) No. 3 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 5.	Repair short circuit in harness between TCM and dropping resistor connector.
5	<p>CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR.</p> <p>1) Disconnect the connector from transmission. 2) Measure the resistance of harness between transmission and dropping resistor connector.</p> <p>Connector & terminal (B4) No. 4 — (B11) No. 9:</p>	Is the resistance less than 1 Ω ?	Go to step 6.	Repair open circuit in harness between dropping resistor and transmission connector.
6	<p>CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR.</p> <p>Measure the resistance of harness between dropping resistor connector and chassis ground.</p> <p>Connector & terminal (B4) No. 4 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 7.	Repair short circuit in harness between dropping resistor and transmission connector.
7	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission and TCM. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B54) No. 8 — (B11) No. 9: With VDC system (B54) No. 18 — (B11) No. 9:</p>	Is the resistance less than 1 Ω ?	Go to step 8.	Repair open circuit in harness between TCM and transmission connector.
8	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND CHASSIS GROUND.</p> <p>Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 8 — Chassis ground: With VDC system (B54) No. 18 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 9.	Repair short circuit in harness between TCM and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
9	<p>CHECK 2-4 BRAKE DUTY SOLENOID. Measure the resistance between transmission connector receptacle's terminals.</p> <p>Terminal (T4) No. 16 — No. 9:</p>	Is the resistance between 2.0 and 4.5 Ω ?	Go to step 10.	Go to step 16.
10	<p>PREPARE SUBARU SELECT MONITOR.</p>	Do you have a Subaru Select Monitor?	Go to step 13.	Go to step 11.
11	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect all connectors. 2) Start the engine and warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 3) Turn the ignition switch to ON (engine OFF). 4) Move the select lever to "N". 5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 8 (+) — Chassis ground (-): With VDC system (B54) No. 18 (+) — Chassis ground (-):</p>	Is the voltage between 1.5 and 5.0 V with throttle fully closed?	Go to step 12.	Go to step 15.
12	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 8 (+) — Chassis ground (-): With VDC system (B54) No. 18 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V with throttle fully open?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in TCM and transmission.	Go to step 15.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
13	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect all connectors. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine, and turn the Subaru Select Monitor switch to ON. 4) Warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 5) Stop the engine and turn the ignition switch to ON (engine OFF). 6) Move the select lever to "N". 7) Read the data of 2-4 brake duty solenoid using Subaru Select Monitor. ● 2-4 brake duty solenoid is indicated in "%". 8) Throttle is fully closed.</p>	Is the value 100%?	Go to step 14.	Go to step 15.
14	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Turn the ignition switch to ON (Engine OFF). 2) Throttle is fully open.</p>	Is the value less than 25%?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in TCM and transmission.	Go to step 15.
15	<p>CHECK POOR CONTACT.</p>	Is there poor contact in 2-4 brake duty solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
16	<p>CHECK 2-4 BRAKE DUTY SOLENOID (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket. 2) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 3) Remove the oil pan, and disconnect the connector from 2-4 brake duty solenoid. 4) Measure the resistance between 2-4 brake duty solenoid connector and transmission ground. <i>Terminal</i> No. 1 — Transmission ground:</p>	Is the resistance between 2.0 and 4.5 Ω?	Go to step 17.	Replace the 2-4 brake duty solenoid. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
17	<p>CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND 2-4 BRAKE DUTY SOLENOID.</p> <p>Measure the resistance of harness between 2-4 brake duty solenoid and transmission connector.</p> <p><i>Connector & terminal (T4) No. 9 — (AT7) No. 1:</i></p>	Is the resistance less than 1 Ω ?	Go to step 18.	Repair open circuit in harness between 2-4 brake duty solenoid and transmission connector.
18	<p>CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND 2-4 BRAKE DUTY SOLENOID.</p> <p>Measure the resistance of harness between transmission connector and transmission ground.</p> <p><i>Connector & terminal (T4) No. 9 — Transmission ground:</i></p>	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in line pressure duty solenoid and transmission.	Repair short circuit in harness between 2-4 brake duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

N: DTC 77 LOCK-UP DUTY SOLENOID S004521/23


DIAGNOSIS:

Output signal circuit of lock-up duty solenoid is open or shorted.

TROUBLE SYMPTOM:

No "lock-up" (after engine warm-up).

WIRING DIAGRAM:



No.	Step	Check	Yes	No
1	CHECK DTC.	Do multiple trouble codes appear in the on-board diagnostics test mode?	Go to another trouble code.	Go to step 2.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B54) No. 16 — (B11) No. 13: With VDC system (B54) No. 7 — (B11) No. 13:</p>	Is the resistance less than 1 Ω?	Go to step 3.	Repair open circuit in harness between TCM and transmission connector.
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness connector between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 16 — Chassis ground: With VDC system (B54) No. 7 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 4.	Repair short circuit in harness between TCM and transmission connector.
4	<p>CHECK LOCK-UP DUTY SOLENOID. Measure the resistance between transmission connector receptacle's terminals.</p> <p>Connector & terminal (T4) No. 13 — No. 16:</p>	Is the resistance between 10 and 17 Ω?	Go to step 5.	Go to step 11.
5	<p>PREPARE SUBARU SELECT MONITOR.</p>	Do you have a Subaru Select Monitor?	Go to step 8.	Go to step 6.
6	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Lift-up the vehicle and place safety stand. NOTE: On AWD models, raise all wheels off ground. 3) Start the engine and warm-up the transmission until the ATF temperature is above 80°C (176°F). NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature. 4) Move the select lever to "D" and slowly increase the vehicle speed to 75 km/h (47 MPH). Wheels will lock-up. NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.> 5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 16 (+) — Chassis ground (-): With VDC system (B54) No. 7 (+) — Chassis ground (-):</p>	Is the voltage more than 8.5 V?	Go to step 7.	Go to step 10.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
7	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Return the engine to idling speed and move the select lever to "N".</p> <p>2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal</p> <p>Without VDC system (B54) No. 16 (+) — Chassis ground (-):</p> <p>With VDC system (B54) No. 7 (+) — Chassis ground (-):</p>	Is the voltage less than 0.5 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in TCM and transmission.	Go to step 10.
8	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up the vehicle and place safety stand.</p> <p>NOTE: On AWD models, raise all wheels off ground.</p> <p>3) Connect the Subaru Select Monitor to data link connector.</p> <p>4) Start the engine, and turn the Subaru Select Monitor switch to ON.</p> <p>5) Start the engine and warm-up the transmission until the ATF temperature is above 80°C (176°F).</p> <p>NOTE: If the ambient temperature is below 0°C (32°F), drive the vehicle until the ATF reaches its operating temperature.</p> <p>6) Read the data of lock-up duty solenoid using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Lock-up duty solenoid is indicated in "%". <p>7) Move the select lever to "D" and slowly increase the vehicle speed to 75 km/h (47 MPH). Wheels will lock-up.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p>	Is the value 95%?	Go to step 9.	Go to step 10.
9	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>Return the engine to idling speed and move the select lever to "N".</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p>	Is the value 5%?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in TCM and transmission.	Go to step 10.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
10	CHECK POOR CONTACT.	Is there poor contact in lock-up duty solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
11	CHECK LOCK-UP DUTY SOLENOID (IN TRANSMISSION). 1) Remove the transmission connector from bracket. 2) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 3) Remove the oil pan, and disconnect the connector from lock-up duty solenoid. 4) Measure the resistance between lock-up duty solenoid connector and transmission ground. <i>Terminal</i> <i>No. 1 — Transmission ground:</i>	Is the resistance between 10 and 17 Ω?	Go to step 12.	Replace the lock-up duty solenoid. <Ref. to AT-41, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
12	CHECK HARNESS CONNECTOR BETWEEN LOCK-UP DUTY SOLENOID AND TRANSMISSION. Measure the resistance of harness between lock-up duty solenoid and transmission connector. <i>Connector & terminal</i> <i>(T4) No. 13 — (AT3) No. 1:</i>	Is the resistance less than 1 Ω?	Go to step 13.	Repair open circuit in harness between TCM and transmission connector.
13	CHECK HARNESS CONNECTOR BETWEEN LOCK-UP DUTY SOLENOID AND TRANSMISSION. Measure the resistance of harness between transmission connector and transmission ground. <i>Connector & terminal</i> <i>(T4) No. 13 — Transmission ground:</i>	Is the resistance more than 1 MΩ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in lock-up duty solenoid and transmission.	Repair short circuit in harness between lock-up duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

O: DTC 79 TRANSFER DUTY SOLENOID S004521/24


DIAGNOSIS:

Output signal circuit of transfer duty solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive "braking" in tight corners.

WIRING DIAGRAM:



B3M2234

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B54) No. 15 — (B11) No. 6: With VDC system (B54) No. 6 — (B11) No. 6:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance harness connector between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 15 — Chassis ground: With VDC system (B54) No. 6 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair short circuit in harness between TCM and transmission connector.
3	<p>CHECK TRANSFER DUTY SOLENOID. Measure the resistance between transmission connector and transmission terminals.</p> <p>Connector & terminal (T4) No. 6 — No. 16:</p>	Is the resistance between 10 and 17 Ω?	Go to step 4.	Go to step 13.
4	<p>PREPARE SUBARU SELECT MONITOR.</p>	Do you have a Subaru Select Monitor?	Go to step 7.	Go to step 5.
5	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Turn the ignition switch to ON (engine OFF). 3) Throttle is fully closed. 4) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 15 (+) — Chassis ground (-): With VDC system (B54) No. 6 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V in "P" range?	Go to step 6.	Go to step 12.
6	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM. Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system (B54) No. 15 (+) — Chassis ground (-): With VDC system (B54) No. 6 (+) — Chassis ground (-):</p>	Is the voltage between 5 and 7 V in "D" range?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 12.
7	<p>CHECK VEHICLE</p>	Is the target model without VDC system?	Go to step 8.	Go to step 10.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
8	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Connect the Subaru Select Monitor to data link connector.</p> <p>3) Turn the ignition switch to ON (engine OFF) and turn the Subaru Select Monitor switch to ON.</p> <p>4) Move the select lever to "D" with throttle fully open (vehicle speed 0 km/h or 0 MPH).</p> <p>5) Read the data of transfer duty solenoid using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Transfer duty solenoid is indicated in "%". 	Is the value between 5 and 10%?	Go to step 9.	Go to step 12.
9	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Move the select lever to "D" with throttle fully closed (vehicle speed 0 km/h or 0 MPH).</p> <p>2) Read the data of transfer duty solenoid using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Transfer duty solenoid is indicated in "%". 	Is the value between approx. 60% and approx. 70%?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 12.
10	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect connectors to TCM and transmission.</p> <p>2) Connect Subaru Select Monitor to data link connector.</p> <p>3) Turn ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON.</p> <p>4) Move select lever to "D" with throttle fully open (vehicle speed 0 km/h or 0 MPH).</p> <p>5) Read data of transfer duty solenoid using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Transfer duty solenoid is indicated in "%". 	Is the value between 80 and 95%?	Go to step 11.	Go to step 12.
11	<p>CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Move select lever to "N" with throttle fully close (vehicle speed 0 km/h or 0 MPH).</p> <p>2) Rear data of transfer duty solenoid using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Transfer duty solenoid is indicated in "%". 	Is the value approx. 40%?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the transfer duty solenoid and TCM connector.	Go to step 12.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
12	CHECK POOR CONTACT.	Is there poor contact in transfer duty solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>
13	CHECK TRANSFER DUTY SOLENOID (IN TRANSMISSION). 1) Lift-up the vehicle and place safety stand. NOTE: On AWD models, raise all wheels off ground. 2) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 3) Remove the extension case, and disconnect the connector from transfer duty solenoid. 4) Measure the resistance between transfer duty solenoid connector and transmission ground. <i>Connector & terminal</i> <i>(AT4) No. 1 — Transmission ground:</i>	Is the resistance between 10 and 17 Ω ?	Go to step 14.	Replace the transfer duty solenoid.
14	CHECK HARNESS CONNECTOR BETWEEN TRANSFER DUTY SOLENOID AND TRANSMISSION. Measure the resistance of harness between transfer duty solenoid and transmission connector. <i>Connector & terminal</i> <i>(T4) No. 6 — (AT4) No. 1:</i>	Is the resistance less than 1 Ω ?	Go to step 15.	Repair open circuit in harness between transfer duty solenoid and transmission connector.
15	CHECK HARNESS CONNECTOR BETWEEN TRANSFER DUTY SOLENOID AND TRANSMISSION. Measure the resistance of harness between transmission connector and transmission ground. <i>Connector & terminal</i> <i>(T4) No. 6 — Transmission ground:</i>	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or contact in the transfer duty solenoid and transmission.	Repair short circuit in harness between transfer duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)


P: DTC 86 VDC COMMUNICATION SIGNAL

S004521J91

DIAGNOSIS:

Input signal circuit of TCM is open or shorted.

WIRING DIAGRAM:



B234

1	2	3	4	5	6
---	---	---	---	---	---

B56

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21		22	23	24		

F46

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27
28	29	30	31	32				

F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84

B3M2235

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	CHECK DTC.	Do multiple trouble codes appear in the on-board diagnostics test mode?	Go to another trouble code.	Go to step 2.
2	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect TCM and VDCCM connector. 3) Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 18 — (F87) No. 81:	Is the resistance less than 1 Ω?	Go to step 3.	Repair open circuit in harness between TCM and VDCCM, and poor contact in coupling connector.
3	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 9 — (F87) No. 83:	Is the resistance less than 1 Ω?	Go to step 4.	Repair open circuit in harness between TCM and VDCCM, and poor contact in coupling connector.
4	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 18 — Chassis ground:	Is the resistance less than 1 MΩ?	Go to step 5.	Repair short circuit in harness between TCM and VDCCM connector.
5	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 9 — Chassis ground:	Is the resistance less than 1 MΩ?	Go to step 6.	Repair short circuit in harness between TCM and VDCCM connector.
6	PREPARE OSCILLOSCOPE.	Do you have oscilloscope?	Go to step 8.	Go to step 7.
7	CHECK INPUT SIGNAL FOR TCM. 1) Connect TCM and VDCCM connector. 2) Turn ignition switch to ON (engine OFF). 3) Measure voltage between TCM connector and chassis ground. Connector & terminal (B56) No. 9 (+) — Chassis ground (-): (B56) No. 18 (+) — Chassis ground (-):	Does input voltage value change?	Go to step 10.	Repair poor contact in VDCCM.
8	CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE. 1) Connect TCM and VDCCM connector. 2) Set oscilloscope to TCM connector terminals. Connector & terminal Positive probe; (B56) No. 9 Earth lead; (B55) No. 9 3) Turn ignition switch to ON (engine OFF).	Check signal waveform pattern on oscilloscope. <Ref. AT-22, WAVEFORM, MEASUREMENT, Transmission Control Module (TCM) I/O Signal.> Is waveform pattern same as that shown in the figure?	Go to step 9.	Repair poor contact in VDCCM.
9	CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE. 1) Set oscilloscope to TCM connector terminals. Connector & terminal Positive probe; (B56) No. 18 Earth lead; (B55) No. 9 2) Turn ignition switch to ON (engine OFF).	Check signal waveform pattern on oscilloscope. <Ref. AT-22, WAVEFORM, MEASUREMENT, Transmission Control Module (TCM) I/O Signal.> Is waveform pattern same as that shown in the figure?	Go to step 10.	Repair poor contact in VDCCM.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
10	CHECK POOR CONTACT.	Is there poor contact in TCM?	Repair poor contact.	Replace TCM. <Ref. to AT-49, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

Q: DTC 93 REAR VEHICLE SPEED SENSOR S004521/25






DIAGNOSIS:

Input signal circuit of TCM is open or shorted.

TROUBLE SYMPTOM:

No lock-up or excessive tight corner "braking".

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
1	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 3 — (B11) No. 19: With VDC system (B55) No. 24 — (B11) No. 19:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system (B55) No. 21 — (B11) No. 20: With VDC system (B54) No. 19 — (B11) No. 20:</p>	Is the resistance less than 1 Ω?	Go to step 3.	Repair open circuit in harness between TCM and transmission, and poor contact in coupling connector.
3	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 3 — Chassis ground: With VDC system (B55) No. 24 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 4.	Repair short circuit in harness between TCM and transmission connector.
4	<p>CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system (B55) No. 21 — Chassis ground: With VDC system (B54) No. 19 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 5.	Repair short circuit in harness between TCM and transmission connector.
5	<p>CHECK REAR VEHICLE SPEED SENSOR. Measure the resistance between transmission connector receptacle's terminals.</p> <p>Connector & terminal (T4) No. 19 — No. 20:</p>	Is the resistance between 450 and 650 Ω?	Go to step 6.	Replace the rear vehicle speed sensor. <Ref. to AT-37, Rear Vehicle Speed Sensor.>
6	PREPARE OSCILLOSCOPE.	Do you have an oscilloscope?	Go to step 10.	Go to step 7.
7	PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 9.	Go to step 8.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
8	<p>CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: On AWD models, raise all wheels off floor.</p> <p>3) Start the engine and set vehicle in 20 km/h (12 MPH) condition.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p> <p>4) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal Without VDC system (B55) No. 3 (+) — (B55) No. 21 (-): With VDC system (B55) No. 24 (+) — (B54) No. 19 (-):</p>	<p>Is the voltage more than AC 1 V?</p>	<p>Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.</p>	<p>Go to step 11.</p>
9	<p>CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Connect the Subaru Select Monitor to data link connector.</p> <p>3) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>4) Turn the ignition switch to ON and turn the Subaru Select Monitor switch to ON.</p> <p>5) Start the engine.</p> <p>6) Read the data of vehicle speed using Subaru Select Monitor.</p> <ul style="list-style-type: none"> ● Compare the speedometer with Subaru Select Monitor indications. ● Vehicle speed is indicated in “km/h” or “MPH”. <p>7) Slowly increase the vehicle speed to 60 km/h or 37 MPH.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p>	<p>Does the speedometer indication increase as the Subaru Select Monitor data increases?</p>	<p>Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.</p>	<p>Go to step 11.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

Automatic Transmission (Diagnostics)

No.	Step	Check	Yes	No
10	<p>CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>3) Set the oscilloscope to TCM connector terminals.</p> <p>Connector & terminal With VDC system Positive probe; (B55) No. 24 Earth lead; (B54) No. 19 Without VDC system Positive probe; (B55) No. 3 Earth lead; (B55) No. 21</p> <p>4) Start the engine and set the vehicle in 20 km/h (12 MPH) condition.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When the AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-21, Clear Memory Mode.></p> <p>5) Measure the signal voltage indicated on oscilloscope.</p>	Is the signal voltage more than AC 1 V?	Even if the AT OIL TEMP warning lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in the TCM and transmission.	Go to step 11.
11	CHECK POOR CONTACT.	Is there poor contact in rear vehicle speed sensor circuit?	Repair poor contact.	Replace the TCM. <Ref. to AT-49, Transmission Control Module (TCM).>