

DROPPING RESISTOR

Automatic Transmission


20. Dropping Resistor S502218

A: REMOVAL S502218A18


NOTE:

Model without VDC system only

- 1) Disconnect battery ground cable.



- 2) Remove air intake duct.
- 3) Disconnect connector from dropping resistor.
- 4) Remove dropping resistor.




(A) Dropping resistor

B: INSTALLATION S502218A11

- 1) Install in the reverse order of removal.

Tightening torque:

7.5 N·m (0.76 kgf·m, 5.5 ft·lb)



(A) Dropping resistor

C: INSPECTION S502218A10

No.	Step	Check	Yes	No
1	CHECK RESISTOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from dropping resistor. 3) Measure resistance between dropping resistor terminal. Terminals No. 1 — No. 2:	Is the resistance between 9 and 15 Ω ?	Go to step 2.	Replace dropping resistor. <Ref. to 50, Dropping Resistor.>
2	CHECK RESISTOR. Measure resistance between dropping resistor terminal. Terminals No. 3 — No. 4:	Is the resistance between 9 and 15 Ω ?	Dropping resistor is normal.	Replace dropping resistor. <Ref. to 50, Dropping Resistor.>