

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

2. Combination Meter System

A: SCHEMATIC

1. COMBINATION METER

<Ref. to WI-86, SCHEMATIC, Combination Meter.>

2. OUTSIDE TEMPERATURE INDICATOR

<Ref. to WI-182, SCHEMATIC, Outside Temperature Display System.>

B: INSPECTION

CAUTION:

- When measuring voltage and resistance of the ECM, TCM, or each sensor, use a tapered pin with a diameter of less than 0.64 mm (0.025 in) in order to avoid poor contact. Do not insert the pin more than 2 mm (0.08 in).

1. SYMPTOM CHART

Symptom	Repair order	Reference
Combination meter assembly does not operate.	(1) Power supply (2) Ground circuit	<Ref. to IDI-5, CHECK POWER SUPPLY AND GROUND CIRCUIT, INSPECTION, Combination Meter System.>
Speedometer does not operate.	(1) (MT) Vehicle speed sensor (AT) Transmission control module (2) Harness (3) Speedometer	MT: <Ref. to IDI-6, CHECK VEHICLE SPEED SENSOR, INSPECTION, Combination Meter System.>
		AT: <Ref. to IDI-7, CHECK TRANSMISSION CONTROL MODULE, INSPECTION, Combination Meter System.>
Tachometer does not operate.	(1) Engine control module (2) Harness (3) Tachometer	<Ref. to IDI-8, CHECK ENGINE CONTROL MODULE, INSPECTION, Combination Meter System.>
Fuel gauge does not operate.	(1) Fuel level sensor (2) Harness (3) Fuel gauge	<Ref. to IDI-9, CHECK FUEL LEVEL SENSOR, INSPECTION, Combination Meter System.>
Water temperature gauge does not operate.	(1) Engine coolant temperature sensor (2) Harness (3) Water temperature gauge	<Ref. to IDI-10, CHECK ENGINE COOLANT TEMPERATURE SENSOR, INSPECTION, Combination Meter System.>
Outside temperature indicator does not operate.	(1) Ambient sensor (2) Harness (3) Combination meter	<Ref. to IDI-11, CHECK OUTSIDE TEMPERATURE INDICATOR, INSPECTION, Combination Meter System.>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

2. CHECK POWER SUPPLY AND GROUND CIRCUIT

Step	Value	Yes	No
1 CHECK POWER SUPPLY FOR COMBINATION METER. 1) Remove combination meter. <Ref. to IDI-12, REMOVAL, Combination Meter Assembly.> 2) Disconnect combination meter harness connector. 3) Turn ignition switch to ON. 4) Measure voltage between combination meter connector and chassis ground. Connector & terminal <i>(i12) No. 3 (+) — Chassis ground (-):</i> Does the measured value exceed the specified value?	10 V	Go to step 2.	Check harness for open or short between ignition relay and combination meter.
2 CHECK POWER SUPPLY FOR COMBINATION METER. Measure voltage between combination meter connector and chassis ground. Connector & terminal <i>(i12) No. 7 (+) — Chassis ground (-):</i> Does the measured value exceed the specified value?	10 V	Go to step 3.	Check harness for open or short between fuse and combination meter.
3 CHECK GROUND CIRCUIT OF COMBINATION METER. 1) Turn ignition switch to OFF. 2) Measure resistance of harness between combination meter connector and chassis ground. Connector & terminal <i>(i10) No. 20 (+) — Chassis ground (-):</i> Is the measured value less than the specified value?	10 Ω	Go to step 4.	Repair wiring harness.
4 CHECK GROUND CIRCUIT OF COMBINATION METER. Measure resistance of harness between combination meter connector and chassis ground. Connector & terminal <i>(i11) No. 16 (+) — Chassis ground (-):</i> Is the measured value less than the specified value?	10 Ω	Replace combination meter.	Repair wiring harness.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

3. CHECK VEHICLE SPEED SENSOR

Step	Value	Yes	No
<p>1 CHECK VEHICLE SPEED SENSOR.</p> <p>1) Lift-up the vehicle and support it with safety stands.</p> <p>2) Remove the combination meter with harness connector.</p> <p>3) Drive the vehicle at a speed greater than 20 km/h (12 MPH).</p> <p>Warning: Be careful not to get caught in the running wheels.</p> <p>4) Measure voltage between combination meter connector and chassis ground.</p> <p>Connector & terminal (i10) No. 13 (+) — Chassis ground (-): Is the measured value same as the specified value?</p>	0 V ↔ 5 V	Check speedometer. <Ref. to IDI-14, REMOVAL, Speedometer.>	Go to step 2.
<p>2 CHECK VEHICLE SPEED SENSOR POWER SUPPLY.</p> <p>1) Turn ignition switch to OFF.</p> <p>2) Disconnect vehicle speed sensor harness connector.</p> <p>3) Turn ignition switch to ON.</p> <p>4) Measure voltage between vehicle speed sensor connector and engine ground.</p> <p>Connector & terminal (B17) No. 3 (+) — Engine ground (-): Does the measured value exceed the specified value?</p>	10 V	Go to step 3.	Check harness for open or short between ignition relay and vehicle speed sensor.
<p>3 CHECK HARNESS BETWEEN VEHICLE SPEED SENSOR AND ENGINE GROUND.</p> <p>1) Turn ignition switch to OFF.</p> <p>2) Measure resistance between vehicle speed sensor connector and engine ground.</p> <p>Connector & terminal (B17) No. 2 — Engine ground: Is the measured value less than the specified value?</p>	10 Ω	Go to step 4.	Repair wiring harness.
<p>4 CHECK HARNESS BETWEEN VEHICLE SPEED SENSOR AND COMBINATION METER.</p> <p>1) Disconnect connector from combination meter.</p> <p>2) Measure resistance between vehicle speed sensor harness connector and combination meter harness connector.</p> <p>Connector & terminal (B17) No. 1 — (i10) No. 13: Is the measured value less than the specified value?</p>	10 Ω	Replace vehicle speed sensor.	Repair wiring harness.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

4. CHECK TRANSMISSION CONTROL MODULE

Step	Value	Yes	No
<p>1</p> <p>CHECK TRANSMISSION CONTROL MODULE SIGNAL.</p> <p>1) Lift-up the vehicle and support it with safety stands.</p> <p>2) Drive the vehicle faster than 10 km/h (6 MPH).</p> <p>Warning: Be careful not to get caught in the running wheels.</p> <p>3) Measure voltage between transmission control module connector and chassis ground.</p> <p>Connector & terminal With VDC: (B56) No. 17 (+) — Chassis ground (-): Without VDC: (B55) No. 13 (+) — Chassis ground (-):</p> <p>Is the measured value same as the specified value?</p>	<p>0 V ↔ 5 V</p>	<p>Go to step 2.</p>	<p>Check transmission control module. <Ref. to AT-2, Basic Diagnostic Procedure.></p>
<p>2</p> <p>CHECK HARNESS BETWEEN TRANSMISSION CONTROL MODULE AND COMBINATION METER.</p> <p>1) Turn ignition switch to OFF.</p> <p>2) Disconnect connector from transmission control module and combination meter.</p> <p>3) Measure resistance between transmission control module harness connector and combination meter harness connector.</p> <p>Connector & terminal With VDC: (B56) No. 17 — (i10) No. 13: Without VDC: (B55) No. 13 — (i10) No. 13:</p> <p>Is the measured value less than the specified value?</p>	<p>10 Ω</p>	<p>Check speed meter. <Ref. to IDI-14, REMOVAL, Speedometer.></p>	<p>Repair wiring harness.</p>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

5. CHECK ENGINE CONTROL MODULE

Step	Value	Yes	No
<p>1</p> <p>CHECK ENGINE CONTROL MODULE SIGNAL.</p> <p>1) Start the engine. 2) Measure voltage between engine control module connector and engine ground.</p> <p>Connector & terminal H6 model: (B136) No. 9 (+) — Engine ground (-): H4 model: (B134) No. 10 (+) — Engine ground (-):</p> <p>Is the measured value same as the specified value?</p>	<p>0 ↔ 14 V</p>	<p>Go to step 2.</p>	<p>Check engine control module. <Ref. to EN(H4SO)-2, Basic Diagnostic Procedure.> or <Ref. to EN(H6DO)-2, Basic Diagnostic Procedure.></p>
<p>2</p> <p>CHECK HARNESS BETWEEN COMBINATION METER AND ENGINE CONTROL MODULE.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect connector from engine control module and combination meter. 3) Measure resistance between engine control module harness connector and combination meter harness connector.</p> <p>Connector & terminal H6 model: (B136) No. 9 — (i11) No. 7: H4 model: (B134) No. 10 — (i11) No. 7:</p> <p>Is the measured value less than the specified value?</p>	<p>10 Ω</p>	<p>Check tachometer. <Ref. to IDI-15, REMOVAL, Tachometer.></p>	<p>Repair wiring harness.</p>

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

6. CHECK FUEL LEVEL SENSOR

Step	Value	Yes	No
<p>1 CHECK FUEL LEVEL SENSOR.</p> <p>1) Remove the fuel level sensor. <Ref. to FU(H4SO)-71, REMOVAL, Fuel Level Sensor.> or <Ref. to FU(H6DO)-72, REMOVAL, Fuel Level Sensor.></p> <p>2) Measure the resistance between the fuel level sensor terminals when setting the float to FULL and EMPTY position.</p> <p>Terminals No. 3 — No. 6</p> <p>Is the measured value within the specified range?</p>	<p>FULL: 0.5 — 2.5 Ω, EMPTY: 52.5 — 54.5 Ω</p>	Go to step 2.	Replace the fuel level sensor.
<p>2 CHECK FUEL SUB LEVEL SENSOR.</p> <p>1) Remove the fuel sub level sensor. <Ref. to FU(H4SO)-72, REMOVAL, Fuel Sub Level Sensor.> or <Ref. to FU(H6DO)-73, REMOVAL, Fuel Sub Level Sensor.></p> <p>2) Measure the resistance between the fuel sub level sensor terminals when setting the float to FULL and EMPTY position.</p> <p>Terminals No. 1 — No. 2</p> <p>Is the measured value within the specified range?</p>	<p>FULL: 0.5 — 2.5 Ω, EMPTY: 39.5 — 41.5 Ω</p>	Go to step 3.	Replace the fuel sub level sensor.
<p>3 CHECK HARNESS BETWEEN FUEL SUB LEVEL SENSOR AND COMBINATION METER.</p> <p>1) Disconnect the connector from the combination meter.</p> <p>2) Measure the resistance between the fuel sub level sensor harness connector terminal and combination meter harness connector terminal.</p> <p>Connector & terminal (R59) No. 1 — (I10) No. 3:</p> <p>Is the measured value less than the specified value?</p>	10 Ω	Go to step 4.	Repair wiring harness.
<p>4 CHECK HARNESS BETWEEN FUEL LEVEL SENSOR AND FUEL SUB LEVEL SENSOR.</p> <p>Measure the resistance between the fuel level sensor harness connector terminal and fuel sub level sensor harness connector terminal.</p> <p>Connector & terminal (R58) No. 6 — (R59) No. 2:</p> <p>Is the measured value less than the specified value?</p>	10 Ω	Go to step 5.	Repair wiring harness.
<p>5 CHECK FUEL LEVEL SENSOR GROUND CIRCUIT.</p> <p>Measure the resistance between the fuel level sensor harness connector terminal and chassis ground.</p> <p>Connector & terminal (R58) No. 3 — Chassis ground:</p> <p>Is the measured value less than the specified value?</p>	10 Ω	Check the fuel gauge. <Ref. to IDI-16, REMOVAL, Fuel Gauge.>	Repair wiring harness.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

7. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Step	Value	Yes	No
1 CHECK ENGINE COOLANT TEMPERATURE SENSOR. Check engine coolant temperature sensor. <Ref. to EN(H4SO)-2, Basic Diagnostic Procedure.>, or <Ref. to EN(H6DO)-2, Basic Diagnostic Procedure.> Is engine coolant temperature sensor OK?	Engine coolant temperature sensor is OK.	Go to step 2.	Replace engine coolant temperature sensor.
2 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND COMBINATION METER. 1) Turn ignition switch to OFF. 2) Disconnect connector from engine coolant temperature sensor and combination meter. 3) Measure resistance between engine coolant temperature sensor harness connector and combination meter harness connector. Connector & terminal Normal meter: (E8) No. 3 — (i12) No. 8:	10 Ω	Go to step 3.	Repair wiring harness.
3 CHECK WATER TEMPERATURE GAUGE GROUND CIRCUIT. Measure resistance between combination meter harness connector terminal and chassis ground. Connector & terminal (i12) No. 9 — Chassis ground: Is the measured value less than the specified value?	10 Ω	Check water temperature gauge. <Ref. to IDI-17, REMOVAL, Water Temperature Gauge.>	Repair wiring harness.

COMBINATION METER SYSTEM

INSTRUMENTATION/DRIVER INFO

8. CHECK OUTSIDE TEMPERATURE INDICATOR

Step	Value	Yes	No
1 CHECK POWER SUPPLY FOR AMBIENT SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from ambient sensor. 3) Turn ignition switch ON. 4) Measure voltage between ambient sensor harness connector terminal and chassis ground. Connector & terminal (F78) No. 1 (+) — Chassis ground (-): Does the measured value exceed the specified value?	4 V	Go to step 2.	Check harness for open or short between ambient sensor and combination meter.
2 CHECK AMBIENT SENSOR. 1) Turn ignition switch OFF. 2) Remove ambient sensor. 3) Check ambient sensor. <Ref. to IDI-18, INSPECTION, Ambient Sensor.> Is the ambient sensor OK?	Ambient sensor is OK.	Go to step 3.	Replace the ambient sensor.
3 CHECK HARNESS BETWEEN AMBIENT SENSOR AND COMBINATION METER. 1) Disconnect connector from combination meter. 2) Measure resistance between ambient sensor harness connector terminal and combination meter harness connector terminal. Connector & terminal (F78) No. 2 — (i10) No. 22: Is the measured value less than the specified value?	10 Ω	Go to step 4.	Repair wiring harness.
4 CHECK OUTSIDE TEMPERATURE INDICATOR. 1) Connect combination meter harness connector. 2) Connect a resistor (1.7 k Ω) between terminals of ambient sensor harness connector. 3) Turn ignition switch ON and check the outside temperature indicator display. Is the outside temperature indicator indicating the specified value?	25°C (77°F)	Outside temperature indicator is OK.	Replace combination meter printed circuit.