

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

14. Diagnostics Chart with Select Monitor

A: COMMUNICATION FOR INITIALIZING IMPOSSIBLE (SELECT MONITOR COMMUNICATION FAILURE)


DIAGNOSIS:

- Faulty harness connector

TROUBLE SYMPTOM:

- ABS warning light remains on.

WIRING DIAGRAM:



VDC00153

VDC-128

Vehicle-id:
SIE-id::A:Communication for Initializing Impossible
(Select Monitor Communication Failure)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK IGNITION SWITCH. 	Is ignition switch to ON?	Go to step 2.	Turn ignition switch to ON, and select VDCCM mode using the select monitor.
2 CHECK BATTERY. 1) Turn ignition switch to OFF. 2) Measure battery voltage. Does the measured value exceed the specified value?	11 V	Go to step 3.	Charge or replace battery.
3 CHECK BATTERY TERMINAL. Is there poor contact at battery terminal?	There is poor contact.	Repair or tighten battery terminal.	Go to step 4.
4 CHECK COMMUNICATION OF SELECT MONITOR. 1) Turn ignition switch to ON. 2) Using the select monitor, check whether communication to other systems can be executed normally. Are the name and year of the system displayed on the select monitor?	Displayed.	Go to step 9.	Go to step 5.
5 CHECK COMMUNICATION OF SELECT MONITOR. 1) Turn ignition switch to OFF. 2) Disconnect VDCCM connector. 3) Check whether communication to other systems can be executed normally. Are the name and year of the system displayed on the select monitor?	Displayed.	Go to step 10.	Go to step 6.
6 CHECK COMMUNICATION OF SELECT MONITOR. 1) Turn ignition switch to OFF. 2) Connect VDCCM module connector. 3) Disconnect cruise control module connector. 4) Check whether communication to other systems can be executed normally. Are the name and year of the system displayed on the select monitor? NOTE: If the vehicle is not equipped with cruise control: Go to step 7.	Displayed.	Inspect cruise control module.	Go to step 7.
7 CHECK HARNESS CONNECTOR BETWEEN EACH CONTROL MODULE AND DATA LINK CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect VDCCM, and cruise control module connectors. 3) Measure resistance between data link connector and chassis ground. Connector & terminal (B40) No. 5 — Chassis ground: (B40) No. 4 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 8.	Repair harness and connector between each control module and data link connector.

VDC-129

Vehicle-id:
 SIE-id::A:Communication for Initializing Impossible
 (Select Monitor Communication Failure)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
8 CHECK OUTPUT SIGNAL FOR VDCCM. 1) Turn ignition switch to ON. 2) Measure voltage between data link connector and chassis ground. Connector & terminal (B40) No. 5 — Chassis ground: (B40) No. 4 — Chassis ground: Is the measured value less than the specified value?	1 V	Repair harness and connector between each control module and data link connector.	Go to step 9.
9 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND DATA LINK CONNECTOR. Measure resistance between VDCCM connector and data link connector. Connector & terminal (F87) No. 11 — (B40) No. 5: (F87) No. 38 — (B40) No. 4: Does the measured value exceed the specified value?	0.5 Ω	Repair harness and connector between VDCCM and data link connector.	Go to step 10.
10 CHECK INSTALLATION OF VDCCM CONNECTOR. Turn ignition switch to OFF. Is VDCCM connector inserted into VDCCM until the clamp locks onto it?	VDCCM connector is connected and the clamp is locked.	Go to step 11.	Insert VDCCM connector into VDCCM until the clamp locks onto it.
11 CHECK POWER SUPPLY CIRCUIT. 1) Turn ignition switch to ON (engine OFF). 2) Measure ignition power supply voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 28 (+) — Chassis ground (-): Is the measured value less than the specified value?	10 V	Go to step 12.	Repair open circuit in harness between VDCCM and battery.
12 CHECK HARNESS CONNECTOR BETWEEN VDCCM AND CHASSIS GROUND. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM and transmission. 3) Measure resistance of harness between VDCCM and chassis ground. Connector & terminal (F87) No. 1 — Chassis ground: (F87) No. 55 — Chassis ground: Is the measured value less than the specified value? Does the measured value exceed the specified value?	1 Ω	Go to step 13.	Repair open circuit in harness between VDCCM and inhibitor side connector, and poor contact in coupling connector.
13 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in control module power supply, ground line and data link connector?	There is poor contact.	Repair connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-130

Vehicle-id:
 SIE-id::A:Communication for Initializing Impossible
 (Select Monitor Communication Failure)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

B: DTC 21 FRONT RIGHT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY

NOTE:

For diagnostic procedure, refer to DTC 27. <Ref. to VDC-132, DTC 27 REAR LEFT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY, Diagnostics Chart with Select Monitor.>

C: DTC 23 FRONT LEFT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY

NOTE:

For diagnostic procedure, refer to DTC 27. <Ref. to VDC-132, DTC 27 REAR LEFT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY, Diagnostics Chart with Select Monitor.>

D: DTC 25 REAR RIGHT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY

NOTE:

For diagnostic procedure, refer to DTC 27. <Ref. to VDC-132, DTC 27 REAR LEFT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY, Diagnostics Chart with Select Monitor.>

VDC-131

Vehicle-id:
SIE-id::B:DTC 21 Front Right ABS Sensor Circuit
Open or Shorted Battery

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

E: DTC 27 REAR LEFT ABS SENSOR CIRCUIT OPEN OR SHORTED BATTERY



DIAGNOSIS:

- Faulty ABS sensor (Broken wire, input voltage too high)
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



(F87)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00141

VDC-132

Vehicle-id:
SIE-id: :E:DTC 27 Rear Left ABS Sensor Circuit Open
or Shorted Battery

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK OUTPUT OF ABS SENSOR USING SELECT MONITOR. 1) Select "Current data display & Save" on the select monitor. 2) Read the ABS sensor output corresponding to the faulty system in the select monitor data display mode. Does the speed indicated on the display change in response to the speedometer reading during acceleration/deceleration when the steering wheel is in the straight-ahead position?	Change	Go to step 2.	Go to step 9.
2 CHECK INSTALLATION OF ABS SENSOR. Are the ABS sensor installation bolts tightened securely? Tightening torque: 32±10 N·m (3.3±1.0 kgf·m, 24±7 ft·lb)	Tightened securely.	Go to step 3.	Tighten ABS sensor installation bolts securely.
3 CHECK ABS SENSOR GAP. Measure tone wheel-to-pole piece gap over entire perimeter of the wheel. Is the measured value within the specified range?	Front wheel 0.3 - 0.8 mm (0.012 - 0.031 in) and Rear wheel 0.44 - 0.94 mm (0.0173 - 0.0370 in)	Go to step 4.	Adjust the gap. NOTE: Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.
4 CHECK TONE WHEEL RUNOUT. Measure tone wheel runout. Is the measured value less than the specified value?	0.05 mm (0.0020 in)	Go to step 5.	Repair tone wheel. Front <Ref. to VDC-30, Front Tone Wheel.> Rear <Ref. to VDC-31, Rear Tone Wheel.>
5 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connectors between VDCCM and ABS sensor?	There is poor contact.	Repair connector.	Go to step 6.
6 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same pattern.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 7.
7 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact. NOTE: Check harness and connectors between VDCCM and ABS sensor.

VDC-133

Vehicle-id:
 SIE-id::E:DTC 27 Rear Left ABS Sensor Circuit
 Open or Shorted Battery

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
8 CHECK ABS SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from ABS sensor. 3) Measure resistance of ABS sensor connector terminals. Terminal <i>Front RH No. 1 — No. 2:</i> <i>Front LH No. 1 — No. 2:</i> <i>Rear RH No. 1 — No. 2:</i> <i>Rear LH No. 1 — No. 2:</i> Is the measured value within the specified range?	1.0 — 1.5 kΩ	Go to step 9.	Replace ABS sensor. Front <Ref. to VDC-28, Front ABS Sensor.> Rear <Ref. to VDC-29, Rear ABS Sensor.>
9 CHECK BATTERY SHORT OF ABS SENSOR. 1) Disconnect connector from VDCCM. 2) Measure voltage between ABS sensor and chassis ground. Terminal <i>Front RH No. 1 (+) — Chassis ground (-):</i> <i>Front LH No. 1 (+) — Chassis ground (-):</i> <i>Rear RH No. 1 (+) — Chassis ground (-):</i> <i>Rear LH No. 1 (+) — Chassis ground (-):</i> Is the measured value less than the specified value?	1 V	Go to step 10.	Replace ABS sensor. Front <Ref. to VDC-28, Front ABS Sensor.> Rear <Ref. to VDC-29, Rear ABS Sensor.>
10 CHECK BATTERY SHORT OF ABS SENSOR. 1) Turn ignition switch to ON. 2) Measure voltage between ABS sensor and chassis ground. Terminal <i>Front RH No. 1 (+) — Chassis ground (-):</i> <i>Front LH No. 1 (+) — Chassis ground (-):</i> <i>Rear RH No. 1 (+) — Chassis ground (-):</i> <i>Rear LH No. 1 (+) — Chassis ground (-):</i> Is the measured value less than the specified value?	1 V	Go to step 11.	Replace ABS sensor. Front <Ref. to VDC-28, Front ABS Sensor.> Rear <Ref. to VDC-29, Rear ABS Sensor.>
11 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ABS SENSOR. 1) Turn ignition switch to OFF. 2) Connect connector to ABS sensor. 3) Measure resistance between VDCCM connector terminals. Connector & terminal <i>DTC 21 / (F87) No. 14 — No. 15:</i> <i>DTC 23 / (F87) No. 49 — No. 19:</i> <i>DTC 25 / (F87) No. 18 — No. 46:</i> <i>DTC 27 / (F87) No. 16 — No. 17:</i> Is the measured value within the specified range?	1.0 — 1.5 kΩ	Go to step 12.	Repair harness/connector between VDCCM and ABS sensor.

VDC-134

Vehicle-id:
 SIE-id::E:DTC 27 Rear Left ABS Sensor Circuit Open or Shorted Battery
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
12 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM connector and chassis ground. Connector & terminal DTC 21 / (F87) No. 14 (+) — Chassis ground (-): DTC 23 / (F87) No. 49 (+) — Chassis ground (-): DTC 25 / (F87) No. 18 (+) — Chassis ground (-): DTC 27 / (F87) No. 16 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 13.	Repair harness between VDCCM and ABS sensor.
13 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal DTC 21 / (F87) No. 14 (+) — Chassis ground (-): DTC 23 / (F87) No. 49 (+) — Chassis ground (-): DTC 25 / (F87) No. 18 (+) — Chassis ground (-): DTC 27 / (F87) No. 16 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 14.	Repair harness between VDCCM and ABS sensor.
14 CHECK INSTALLATION OF ABS SENSOR. Are the ABS sensor installation bolts tightened securely? Tightening torque: 32±10 N·m (3.3±1.0 kgf·m, 24±7 ft·lb)	Tightened securely.	Go to step 15.	Tighten ABS sensor installation bolts securely.
15 CHECK ABS SENSOR GAP. Measure tone wheel-to-pole piece gap over entire perimeter of the wheel. Is the measured value within the specified range?	Front wheel 0.3 - 0.8 mm (0.012 - 0.031 in) and Rear wheel 0.44 - 0.94 mm (0.0173 - 0.0370 in)	Go to step 16.	Adjust the gap. NOTE: Adjust the gap using spacers (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.
16 CHECK HUB AND TONE WHEEL RUNOUT. Measure hub and tone wheel runout. Is the measured value less than the specified value?	0.05 mm (0.0020 in)	Go to step 17.	Repair hub and tone wheel. Front <Ref. to VDC-28, Front ABS Sensor.> Rear <Ref. to VDC-29, Rear ABS Sensor.>
17 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between VDCCM and ABS sensor?	There is poor contact.	Repair connector.	Go to step 18.

VDC-135

Vehicle-id:
 SIE-id::E:DTC 27 Rear Left ABS Sensor Circuit
 Open or Shorted Battery

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
18 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same pattern.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 19.
19 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact. NOTE: Check harness and connectors between VDCCM and ABS sensor.

VDC-136

Vehicle-id:
 SIE-id::E:DTC 27 Rear Left ABS Sensor Circuit Open or Shorted Battery

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

F: DTC 22 FRONT RIGHT ABS SENSOR SIGNAL

NOTE:

For diagnostic procedure, refer to DTC 28. <Ref. to VDC-138, DTC 28 REAR LEFT ABS SENSOR SIGNAL, Diagnostics Chart with Select Monitor.>

G: DTC 24 FRONT LEFT ABS SENSOR SIGNAL

NOTE:

For diagnostic procedure, refer to DTC 28. <Ref. to VDC-138, DTC 28 REAR LEFT ABS SENSOR SIGNAL, Diagnostics Chart with Select Monitor.>

H: DTC 26 REAR RIGHT ABS SENSOR SIGNAL

NOTE:

For diagnostic procedure, refer to DTC 28. <Ref. to VDC-138, DTC 28 REAR LEFT ABS SENSOR SIGNAL, Diagnostics Chart with Select Monitor.>

VDC-137

Vehicle-id:
SIE-id: :F:DTC 22 Front Right ABS Sensor Signal

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

I: DTC 28 REAR LEFT ABS SENSOR SIGNAL



DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal)
- Faulty harness/connector

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



(F87)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00141

VDC-138

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK OUTPUT OF ABS SENSOR USING SELECT MONITOR. 1) Select "Current data display & Save" on the select monitor. 2) Read the ABS sensor output corresponding to the faulty system in the select monitor data display mode. Does the speed indicated on the display change in response to the speedometer reading during acceleration/deceleration when the steering wheel is in the straight-ahead position?	Change	Go to step 2.	Go to step 8.
2 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connectors between VDCCM and ABS sensor?	There is poor contact.	Repair connector.	Go to step 3.
3 CHECK SOURCES OF SIGNAL NOISE. Is the car telephone or the wireless transmitter properly installed?	Installed properly.	Go to step 4.	Properly install the car telephone or the wireless transmitter.
4 CHECK SOURCES OF SIGNAL NOISE. Are noise sources (such as an antenna) installed near the sensor harness?	Installed	Install the noise sources apart from the sensor harness.	Go to step 5.
5 CHECK SHIELD CIRCUIT. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Measure resistance between shield connector and chassis ground. Connector & terminal DTC 22 / (F45) No. 1 — Chassis ground: DTC 24 / (F45) No. 10 — Chassis ground: Is the measured value less than the specified value? NOTE: For the DTC 26 and 28, Go to step 6.	0.5 Ω	Go to step 6.	Repair shield harness.
6 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same pattern.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 7.
7 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary noise interference.
8 CHECK INSTALLATION OF ABS SENSOR. Tightening torque: 32±10 N·m (3.3±1.0 kgf·m, 24±7 ft·lb) Are the ABS sensor installation bolts tightened securely?	Tightened securely.	Go to step 9.	Tighten ABS sensor installation bolts securely.

VDC-139

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
9 CHECK ABS SENSOR GAP. Measure tone wheel to pole piece gap over entire perimeter of the wheel. Is the measured value within the specified range?	Front wheel 0.3 - 0.8 mm (0.012 - 0.031 in) and Rear wheel 0.44 - 0.94 mm (0.0173 - 0.0370 in)	Go to step 10.	Adjust the gap. NOTE: Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.
10 CHECK OSCILLOSCOPE. Is an oscilloscope available?	Available	Go to step 11.	Go to step 12.
11 CHECK ABS SENSOR SIGNAL. 1) Raise all four wheels of ground. 2) Turn ignition switch OFF. 3) Remove VDCCM connector cover. <Ref. to VDC-19, VDCCM Connector Cover.> 4) Connect the oscilloscope to the connector. 5) Turn ignition switch ON. 6) Rotate wheels and measure voltage at specified frequency. NOTE: When this inspection is completed, the VDCCM sometimes stores the DTC 29. Connector & terminal DTC 22 / (F87) No. 14 (+) — No. 15 (-): DTC 24 / (F87) No. 49 (+) — No. 19 (-): DTC 26 / (F87) No. 18 (+) — No. 46 (-): DTC 28 / (F87) No. 16 (+) — No. 17 (-): Is oscilloscope pattern smooth, as shown in figure?	Smooth pattern.	Go to step 15.	Go to step 12.
12 CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL. Remove disc rotor from hub in accordance with diagnostic trouble code. Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?	Dirt or foreign matter found.	Thoroughly remove dirt or other foreign matter.	Go to step 13.
13 CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL. Are there broken or damaged in the ABS sensor pole piece or the tone wheel?	Broken or damaged.	Replace ABS sensor or tone wheel. Front <Ref. to VDC-28, Front ABS Sensor.> and <Ref. to VDC-30, Front Tone Wheel.> Rear <Ref. to VDC-29, Rear ABS Sensor.> and <Ref. to VDC-31, Rear Tone Wheel.>	Go to step 14.
14 CHECK TONE WHEEL RUNOUT. Measure tone wheel runout. Is the measured value less than the specified value?	0.05 mm (0.0020 in)	Go to step 15.	Repair tone wheel. Front <Ref. to VDC-30, Front Tone Wheel.> Rear <Ref. to VDC-31, Rear Tone Wheel.>

VDC-140

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
15 CHECK RESISTANCE OF ABS SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from ABS sensor. 3) Measure resistance between ABS sensor connector terminals. Terminal <i>Front RH No. 1 — No. 2:</i> <i>Front LH No. 1 — No. 2:</i> <i>Rear RH No. 1 — No. 2:</i> <i>Rear LH No. 1 — No. 2:</i> Is the measured value within the specified range?	1.0 — 1.5 k Ω	Go to step 16.	Replace ABS sensor. Front <Ref. to VDC-28, Front ABS Sensor.> Rear <Ref. to VDC-29, Rear ABS Sensor.>
16 CHECK GROUND SHORT OF ABS SENSOR. Measure resistance between ABS sensor and chassis ground. Terminal <i>Front RH No. 1 — Chassis ground:</i> <i>Front LH No. 1 — Chassis ground:</i> <i>Rear RH No. 1 — Chassis ground:</i> <i>Rear LH No. 1 — Chassis ground:</i> Does the measured value exceed the specified value?	1 M Ω	Go to step 17.	Replace ABS sensor. Front <Ref. to VDC-28, Front ABS Sensor.> Rear <Ref. to VDC-29, Rear ABS Sensor.>
17 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ABS SENSOR. 1) Connect connector to ABS sensor. 2) Disconnect connector from VDCCM. 3) Measure resistance at VDCCM connector terminals. Connector & terminal <i>DTC 22 / (F87) No. 14 — No. 15:</i> <i>DTC 24 / (F87) No. 49 — No. 19:</i> <i>DTC 26 / (F87) No. 18 — No. 46:</i> <i>DTC 28 / (F87) No. 16 — No. 17:</i> Is the measured value within the specified range?	1.0 — 1.5 k Ω	Go to step 18.	Repair harness/connector between VDCCM and ABS sensor.
18 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM connector and chassis ground. Connector & terminal <i>DTC 22 / (F87) No. 14 — Chassis ground:</i> <i>DTC 24 / (F87) No. 49 — Chassis ground:</i> <i>DTC 26 / (F87) No. 18 — Chassis ground:</i> <i>DTC 28 / (F87) No. 16 — Chassis ground:</i> Does the measured value exceed the specified value?	1 M Ω	Go to step 19.	Repair harness/connector between VDCCM and ABS sensor.
19 CHECK GROUND CIRCUIT OF VDCCM. Measure resistance between VDCCM and chassis ground. Connector & terminal <i>(F87) No. 1 — Chassis ground:</i> <i>(F87) No. 55 — Chassis ground:</i> Is the measured value less than the specified value?	0.5 Ω	Go to step 20.	Repair VDCCM ground harness.

VDC-141

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
20 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between VDCCM and ABS sensor?	There is poor contact.	Repair connector.	Go to step 21.
21 CHECK SOURCES OF SIGNAL NOISE. Is the car telephone or the wireless transmitter properly installed?	Installed properly.	Go to step 22.	Properly install the car telephone or the wireless transmitter.
22 CHECK SOURCES OF SIGNAL NOISE. Are noise sources (such as an antenna) installed near the sensor harness?	Installed.	Install the noise sources apart from the sensor harness.	Go to step 23.
23 CHECK SHIELD CIRCUIT. 1) Connect all connectors. 2) Measure resistance between shield connector and chassis ground. Connector & terminal DTC 22 / (F45) No. 1 — Chassis ground: DTC 24 / (F45) No. 10 — Chassis ground: Is the measured value less than the specified value? NOTE: For the DTC 26 and 28, Go to step 25.	0.5 Ω	Go to step 24.	Repair shield harness.
24 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same pattern.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 25.
25 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary noise interference.

VDC-142

Vehicle-id:
SIE-id::I:DTC 28 Rear Left ABS Sensor Signal

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-143

Vehicle-id:
SIE-id: : I : DTC 28 Rear Left ABS Sensor Signal
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

J: DTC 29 ANY ONE OF FOUR ABS SENSOR SIGNAL



DIAGNOSIS:

- Faulty ABS sensor signal (noise, irregular signal, etc.)
- Faulty tone wheel
- Wheels turning freely for a long time

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



F87																															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55					
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83				

VDC00141

VDC-144

Vehicle-id:
SIE-id::J:DTC 29 Any One of Four ABS Sensor Signal

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK IF THE WHEELS HAVE TURNED FREELY. Check if the wheels have been turned freely for more than one minute, such as when the vehicle is jacked-up, under full-lock cornering or when tire is not in contact with road surface.	Turned freely over 1 minutes.	The VDC is normal. Erase the diagnostic trouble code. NOTE: When the wheels turn freely for a long time, such as when the vehicle is towed or jacked-up, or under full-lock cornering locked in full, this trouble code may sometimes occur.	Go to step 2.
2 CHECK TIRE SPECIFICATIONS. Are the tire specifications correct?	Turned freely over 1 minutes.	Go to step 3.	Replace tire.
3 CHECK WEAR OF TIRE. Is the tire worn excessively?	Worn excessively.	Replace tire.	Go to step 4.
4 CHECK TIRE PRESSURE. Is the tire pressure correct?	Correct tire pressure.	Go to step 5.	Adjust tire pressure.
5 CHECK INSTALLATION OF ABS SENSOR. Tightening torque: 32±10 N-m (3.3±1.0 kgf-m, 24±7 ft-lb) Are the ABS sensor installation bolts tightened securely?	Tightened securely.	Go to step 6.	Tighten ABS sensor installation bolts securely.
6 CHECK ABS SENSOR GAP. Measure tone wheel to pole piece gap over entire perimeter of the wheel. Is the measured value within the specified range?	Front wheel 0.3 - 0.8 mm (0.012 - 0.031 in) and Rear wheel 0.44 - 0.94 mm (0.0173 - 0.0370 in)	Go to step 7.	Adjust the gap. NOTE: Adjust the gap using spacer (Part No. 26755AA000). If spacers cannot correct the gap, replace worn sensor or worn tone wheel.
7 CHECK OSCILLOSCOPE. Is an oscilloscope available?	Available	Go to step 8.	Go to step 9.
8 CHECK ABS SENSOR SIGNAL. 1) Raise all four wheels of ground. 2) Turn ignition switch OFF. 3) Remove VDCCM connector cover. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect the oscilloscope to the connector. 5) Turn ignition switch ON. 6) Rotate wheels and measure voltage at specified frequency. <Ref. to ABS-15, WAVEFORM, Control Module I/O Signal.> NOTE: When this inspection is completed, the VDCCM sometimes stores the DTC 29. Connector & terminal (F49) No. 14 (+) — No. 15 (-) (Front RH): (F49) No. 49 (+) — No. 19 (-) (Front LH): (F49) No. 18 (+) — No. 46 (-) (Rear RH): (F49) No. 16 (+) — No. 17 (-) (Rear LH): Is oscilloscope pattern smooth, as shown in figure?	Smooth pattern.	Go to step 12.	Go to step 9.

VDC-145

Vehicle-id:
 SIE-id::J:DTC 29 Any One of Four ABS Sensor
 Signal
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
9 CHECK CONTAMINATION OF ABS SENSOR OR TONE WHEEL. Remove disc rotor from hub. Is the ABS sensor pole piece or the tone wheel contaminated by dirt or other foreign matter?	Dirt or foreign matter found.	Thoroughly remove dirt or other foreign matter.	Go to step 10.
10 CHECK DAMAGE OF ABS SENSOR OR TONE WHEEL. Are there broken or damaged teeth in the ABS sensor pole piece or the tone wheel?	Broken or damaged.	Replace ABS sensor or tone wheel. Front <Ref. to VDC-28, Front ABS Sensor.> and <Ref. to VDC-30, Front Tone Wheel.> Rear <Ref. to VDC-29, Rear ABS Sensor.> and <Ref. to VDC-31, Rear Tone Wheel.>	Go to step 11.
11 CHECK TONE WHEEL RUNOUT. Measure tone wheel runout. Is the measured value less than the specified value?	0.05 mm (0.0020 in)	Go to step 12.	Repair tone wheel. Front <Ref. to VDC-30, Front Tone Wheel.> Rear <Ref. to VDC-31, Rear Tone Wheel.>
12 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same pattern.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 13.
13 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-146

Vehicle-id:
 SIE-id::J:DTC 29 Any One of Four ABS Sensor Signal

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

K: DTC 31 FR HOLD VALVE MALFUNCTION (FRONT RIGHT INLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 62. <Ref. to VDC-148, DTC 62 NORMAL OPENING VALVE 1 MALFUNCTION (SECONDARY CUT VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

L: DTC 33 FL HOLD VALVE MALFUNCTION (FRONT LEFT INLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 62. <Ref. to VDC-148, DTC 62 NORMAL OPENING VALVE 1 MALFUNCTION (SECONDARY CUT VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

M: DTC 35 RR HOLD VALVE MALFUNCTION (REAR RIGHT INLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 62. <Ref. to VDC-148, DTC 62 NORMAL OPENING VALVE 1 MALFUNCTION (SECONDARY CUT VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

N: DTC 37 RL HOLD VALVE MALFUNCTION (REAR LEFT INLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 62. <Ref. to VDC-148, DTC 62 NORMAL OPENING VALVE 1 MALFUNCTION (SECONDARY CUT VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

O: DTC 61 NORMAL OPENING VALVE 2 MALFUNCTION (PRIMARY CUT VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 62. <Ref. to VDC-148, DTC 62 NORMAL OPENING VALVE 1 MALFUNCTION (SECONDARY CUT VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

VDC-147

Vehicle-id:
SIE-id: :K:DTC 31 FR Hold Valve Malfunction (Front Right Inlet Valve Malfunction)
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

P: DTC 62 NORMAL OPENING VALVE 1 MALFUNCTION (SECONDARY CUT VALVE MALFUNCTION)



DIAGNOSIS:

- Faulty harness/connector
- Faulty solenoid valve in VDCH/U

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



(F87)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00142

VDC-148

Vehicle-id:
SIE-id::P:DTC 62 Normal Opening Valve 1 Malfunction (Secondary Cut Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
<p>1</p> <p>CHECK RESISTANCE OF SOLENOID VALVE.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect two connectors (VDC1, F91) from VDCH/U. 3) Measure resistance between VDCH/U connector terminals.</p> <p>Connector & terminal</p> <p>DTC 31/(VDC5) No. 5 — (VDC2) No. 2: DTC 33/(VDC5) No. 8 — (VDC2) No. 2: DTC 35/(VDC5) No. 7 — (VDC2) No. 2: DTC 37/(VDC5) No. 6 — (VDC2) No. 2: DTC 61/(VDC5) No. 9 — (VDC2) No. 2: DTC 62/(VDC5) No. 12 — (VDC2) No. 2:</p> <p>Is the measured value within the specified range?</p>	8.04 — 9.04 Ω	Go to step 2.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
<p>2</p> <p>CHECK GROUND SHORT OF SOLENOID VALVE.</p> <p>Measure resistance between VDCH/U connector and chassis ground.</p> <p>Connector & terminal</p> <p>DTC 31/(VDC5) No. 5 — Chassis ground: DTC 33/(VDC5) No. 8 — Chassis ground: DTC 35/(VDC5) No. 7 — Chassis ground: DTC 37/(VDC5) No. 6 — Chassis ground: DTC 61/(VDC5) No. 9 — Chassis ground: DTC 62/(VDC5) No. 12 — Chassis ground:</p> <p>Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 3.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
<p>3</p> <p>CHECK BATTERY SHORT OF SOLENOID VALVE.</p> <p>1) Disconnect connector from VDCCM. 2) Measure voltage between VDCH/U connector and chassis ground.</p> <p>Connector & terminal</p> <p>DTC 31/(VDC5) No. 5 (+) — Chassis ground (-): DTC 33/(VDC5) No. 8 (+) — Chassis ground (-): DTC 35/(VDC5) No. 7 (+) — Chassis ground (-): DTC 37/(VDC5) No. 6 (+) — Chassis ground (-): DTC 61/(VDC5) No. 9 (+) — Chassis ground (-): DTC 62/(VDC5) No. 12 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 4.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-149

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
<p>4 CHECK BATTERY SHORT OF SOLENOID VALVE.</p> <p>1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground.</p> <p>Connector & terminal DTC 31/(VDC5) No. 5 (+) — Chassis ground (-): DTC 33/(VDC5) No. 8 (+) — Chassis ground (-): DTC 35/(VDC5) No. 7 (+) — Chassis ground (-): DTC 37/(VDC5) No. 6 (+) — Chassis ground (-): DTC 61/(VDC5) No. 9 (+) — Chassis ground (-): DTC 62/(VDC5) No. 12 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 5.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
<p>5 CHECK BATTERY SHORT OF HARNESS.</p> <p>1) Turn ignition switch to OFF. 2) Measure voltage between VDCCM connector and chassis ground.</p> <p>Connector & terminal DTC 31/(F87) No. 30 (+) — Chassis ground (-): DTC 33/(F87) No. 24 (+) — Chassis ground (-): DTC 35/(F87) No. 23 (+) — Chassis ground (-): DTC 37/(F87) No. 31 (+) — Chassis ground (-): DTC 61/(F87) No. 25 (+) — Chassis ground (-): DTC 62/(F87) No. 26 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 6.	Repair harness between VDCCM and VDCH/U.
<p>6 CHECK BATTERY SHORT OF HARNESS.</p> <p>1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground.</p> <p>Connector & terminal DTC 31/(F87) No. 30 (+) — Chassis ground (-): DTC 33/(F87) No. 24 (+) — Chassis ground (-): DTC 35/(F87) No. 23 (+) — Chassis ground (-): DTC 37/(F87) No. 31 (+) — Chassis ground (-): DTC 61/(F87) No. 25 (+) — Chassis ground (-): DTC 62/(F87) No. 26 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 7.	Repair harness between VDCCM and VDCH/U.

VDC-150

Vehicle-id:
SIE-id::P:DTC 62 Normal Opening Valve 1 Malfunction (Secondary Cut Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Measure resistance between VDCCM connector and chassis ground. Connector & terminal <i>DTC 31/(F87) No. 30 — Chassis ground:</i> <i>DTC 33/(F87) No. 24 — Chassis ground:</i> <i>DTC 35/(F87) No. 23 — Chassis ground:</i> <i>DTC 37/(F87) No. 31 — Chassis ground:</i> <i>DTC 61/(F87) No. 25 — Chassis ground:</i> <i>DTC 62/(F87) No. 26 — Chassis ground:</i> Does the measured value exceed the specified value?	1 M Ω	Go to step 8.	Repair harness between VDCCM and VDCH/U.
8 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND VDCH/U. 1) Connect connector (F91) to VDCH/U. 2) Measure resistance between VDCCM connector and VDCH/U connector. Connector & terminal <i>DTC 31/(F87) No. 30 — (VDC2) No. 2:</i> <i>DTC 33/(F87) No. 24 — (VDC2) No. 2:</i> <i>DTC 35/(F87) No. 23 — (VDC2) No. 2:</i> <i>DTC 37/(F87) No. 31 — (VDC2) No. 2:</i> <i>DTC 61/(F87) No. 25 — (VDC2) No. 2:</i> <i>DTC 62/(F87) No. 26 — (VDC2) No. 2:</i> Is the measured value within the specified range?	7 — 10 Ω	Go to step 9.	Repair harness/connector between VDCCM and VDCH/U.
9 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between VDCCM and VDCH/U?	There is poor contact.	Repair connector.	Go to step 10.
10 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Repair VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 11.
11 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-151

Vehicle-id:
 SIE-id::P:DTC 62 Normal Opening Valve 1 Malfunction (Secondary Cut Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Q: DTC 32 FR PRESSURE REDUCING VALVE MALFUNCTION (FRONT RIGHT OUTLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 64. <Ref. to VDC-154, DTC 64 NORMAL CLOSING VALVE 1 MALFUNCTION (SECONDARY SUCTION VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

R: DTC 34 FL PRESSURE REDUCING VALVE MALFUNCTION (FRONT LEFT OUTLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 64. <Ref. to VDC-154, DTC 64 NORMAL CLOSING VALVE 1 MALFUNCTION (SECONDARY SUCTION VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

S: DTC 36 RR PRESSURE REDUCING VALVE MALFUNCTION (REAR RIGHT OUTLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 64. <Ref. to VDC-154, DTC 64 NORMAL CLOSING VALVE 1 MALFUNCTION (SECONDARY SUCTION VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

T: DTC 38 RL PRESSURE REDUCING VALVE MALFUNCTION (REAR LEFT OUTLET VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 64. <Ref. to VDC-154, DTC 64 NORMAL CLOSING VALVE 1 MALFUNCTION (SECONDARY SUCTION VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

U: DTC 63 NORMAL CLOSING VALVE 2 MALFUNCTION (PRIMARY SUCTION VALVE MALFUNCTION)

NOTE:

For diagnostic procedure, refer to DTC 64. <Ref. to VDC-154, DTC 64 NORMAL CLOSING VALVE 1 MALFUNCTION (SECONDARY SUCTION VALVE MALFUNCTION), Diagnostics Chart with Select Monitor.>

VDC-152

Vehicle-id:
SIE-id::Q:DTC 32 FR Pressure Reducing Valve Malfunction (Front Right Outlet Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-153

Vehicle-id:
SIE-id: :U:DTC 63 Normal Closing Valve 2 Malfunc-
tion (Primary Suction Valve Malfunction)

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

V: DTC 64 NORMAL CLOSING VALVE 1 MALFUNCTION (SECONDARY SUCTION VALVE MALFUNCTION)



DIAGNOSIS:

- Faulty harness/connector
- Faulty solenoid valve in VDCH/U

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00142

VDC-154

Vehicle-id:
SIE-id: :V:DTC 64 Normal Closing Valve 1 Malfunction
(Secondary Suction Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
<p>1</p> <p>CHECK RESISTANCE OF SOLENOID VALVE.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect two connectors (VDC1, F91) from VDCH/U. 3) Measure resistance between VDCH/U connector terminals.</p> <p>Connector & terminal DTC 32/(VDC5) No. 1 — (VDC2) No. 2: DTC 34/(VDC5) No. 4 — (VDC2) No. 2: DTC 36/(VDC5) No. 3 — (VDC2) No. 2: DTC 38/(VDC5) No. 2 — (VDC2) No. 2: DTC 63/(VDC5) No. 10 — (VDC2) No. 2: DTC 64/(VDC5) No. 11 — (VDC2) No. 2:</p> <p>Is the measured value within the specified range?</p>	3.8 — 4.8 Ω	Go to step 2.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
<p>2</p> <p>CHECK GROUND SHORT OF SOLENOID VALVE.</p> <p>Measure resistance between VDCH/U connector and chassis ground.</p> <p>Connector & terminal DTC 32/(VDC5) No. 1 — Chassis ground: DTC 34/(VDC5) No. 4 — Chassis ground: DTC 36/(VDC5) No. 3 — Chassis ground: DTC 38/(VDC5) No. 2 — Chassis ground: DTC 63/(VDC5) No. 10 — Chassis ground: DTC 64/(VDC5) No. 11 — Chassis ground:</p> <p>Does the measured value exceed the specified value?</p>	1 MΩ	Go to step 3.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
<p>3</p> <p>CHECK BATTERY SHORT OF SOLENOID VALVE.</p> <p>1) Disconnect connector from VDCCM. 2) Measure voltage between VDCH/U connector and chassis ground.</p> <p>Connector & terminal DTC 32/(VDC5) No. 1 (+) — Chassis ground (-): DTC 34/(VDC5) No. 4 (+) — Chassis ground (-): DTC 36/(VDC5) No. 3 (+) — Chassis ground (-): DTC 38/(VDC5) No. 2 (+) — Chassis ground (-): DTC 63/(VDC5) No. 10 (+) — Chassis ground (-): DTC 64/(VDC5) No. 11 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 4.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-155

Vehicle-id:
SIE-id: :V:DTC 64 Normal Closing Valve 1 Malfunction (Secondary Suction Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
<p>4 CHECK BATTERY SHORT OF SOLENOID VALVE.</p> <p>1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground.</p> <p>Connector & terminal DTC 32/(VDC5) No. 1 (+) — Chassis ground (-): DTC 34/(VDC5) No. 4 (+) — Chassis ground (-): DTC 36/(VDC5) No. 3 (+) — Chassis ground (-): DTC 38/(VDC5) No. 2 (+) — Chassis ground (-): DTC 63/(VDC5) No. 10 (+) — Chassis ground (-): DTC 64/(VDC5) No. 11 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 5.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
<p>5 CHECK BATTERY SHORT OF HARNESS.</p> <p>1) Turn ignition switch to OFF. 2) Measure voltage between VDCCM connector and chassis ground.</p> <p>Connector & terminal DTC 32/(F87) No. 3 (+) — Chassis ground (-): DTC 34/(F87) No. 51 (+) — Chassis ground (-): DTC 36/(F87) No. 50 (+) — Chassis ground (-): DTC 38/(F87) No. 4 (+) — Chassis ground (-): DTC 63/(F87) No. 29 (+) — Chassis ground (-): DTC 64/(F87) No. 2 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 6.	Repair harness between VDCCM and VDCH/U.
<p>6 CHECK BATTERY SHORT OF HARNESS.</p> <p>1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground.</p> <p>Connector & terminal DTC 32/(F87) No. 3 (+) — Chassis ground (-): DTC 34/(F87) No. 51 (+) — Chassis ground (-): DTC 36/(F87) No. 50 (+) — Chassis ground (-): DTC 38/(F87) No. 4 (+) — Chassis ground (-): DTC 63/(F87) No. 29 (+) — Chassis ground (-): DTC 64/(F87) No. 2 (+) — Chassis ground (-):</p> <p>Is the measured value less than the specified value?</p>	1 V	Go to step 7.	Repair harness between VDCCM and VDCH/U.

VDC-156

Vehicle-id:
SIE-id: :V:DTC 64 Normal Closing Valve 1 Malfunction
(Secondary Suction Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Measure resistance between VDCCM connector and chassis ground. Connector & terminal <i>DTC 32/(F87) No. 3 — Chassis ground:</i> <i>DTC 34/(F87) No. 51 — Chassis ground:</i> <i>DTC 36/(F87) No. 50 — Chassis ground:</i> <i>DTC 38/(F87) No. 4 — Chassis ground:</i> <i>DTC 63/(F87) No. 29 — Chassis ground:</i> <i>DTC 64/(F87) No. 2 — Chassis ground:</i> Does the measured value exceed the specified value?	1 M Ω	Go to step 8.	Repair harness between VDCCM and VDCH/U.
8 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND VDCH/U. 1) Connect connector (F91) to VDCH/U. 2) Measure resistance between VDCCM connector and VDCH/U connector. Connector & terminal <i>DTC 32/(F87) No. 3 — (VDC2) No. 1:</i> <i>DTC 34/(F87) No. 51 — (VDC2) No. 1:</i> <i>DTC 36/(F87) No. 50 — (VDC2) No. 1:</i> <i>DTC 38/(F87) No. 4 — (VDC2) No. 1:</i> <i>DTC 63/(F87) No. 29 — (VDC2) No. 1:</i> <i>DTC 64/(F87) No. 2 — (VDC2) No. 1:</i> Is the measured value within the specified range?	3 — 6 Ω	Go to step 9.	Repair harness/connector between VDCCM and VDCH/U.
9 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between VDCCM and VDCH/U?	Tightened securely.	Repair connector.	Go to step 10.
10 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	There is poor contact.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 11.
11 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Same DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-157

Vehicle-id:
 SIE-id: :V:DTC 64 Normal Closing Valve 1 Malfunction (Secondary Suction Valve Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

W: DTC 41 ELECTRICAL CONTROL MODULE (VDC CONTROL MODULE MALFUNCTION)


DIAGNOSIS:

- Faulty VDCCM

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC-158

Vehicle-id:
SIE-id::W:DTC 41 Electrical Control Module (VDC Control Module Malfunction)

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GROUND CIRCUIT OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 1 — Chassis ground: (F87) No. 55 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Repair VDCCM ground harness.
2 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between battery, ignition switch and VDCCM?	There is poor contact.	Repair connector.	Go to step 3.
3 CHECK SOURCES OF SIGNAL NOISE. Is the car telephone or the wireless transmitter properly installed?	Tightened securely.	Go to step 4.	Properly install the car telephone or the wireless transmitter.
4 CHECK SOURCES OF SIGNAL NOISE. Are noise sources (such as an antenna) installed near the sensor harness?	Installed properly.	Install the noise sources apart from the sensor harness.	Go to step 5.
5 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 6.
6 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-159

Vehicle-id:
 SIE-id: :W:DTC 41 Electrical Control Module (VDC Control Module Malfunction)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

X: DTC 42 POWER SUPPLY VOLTAGE LOW


DIAGNOSIS:

- Power source voltage of the VDCCM is low.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC-160

Vehicle-id:
SIE-id: :X:DTC 42 Power Supply Voltage Low

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GENERATOR. 1) Start engine. 2) Idling after warm-up. 3) Measure voltage between generator B terminal and chassis ground. Terminal Generator B terminal — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Go to step 2.	Repair generator.
2 CHECK BATTERY TERMINAL. Turn ignition switch to OFF. Are the positive and negative battery terminals tightly clamped?	Clamped securely.	Go to step 3.	Tighten the clamp of terminal.
3 CHECK INPUT VOLTAGE OF VDCCM. 1) Disconnect connector from VDCCM. 2) Run the engine at idle. 3) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 28 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 4.	Repair harness connector between battery, ignition switch and VDCCM.
4 CHECK GROUND CIRCUIT OF VDCCM. 1) Turn ignition switch to OFF. 2) Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 1 — Chassis ground: (F87) No. 55 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Go to step 5.	Repair VDCCM ground harness.
5 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between generator, battery and VDCCM?	There is poor contact.	Repair connector.	Go to step 6.
6 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 7.
7 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-161

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Y: DTC 43 AET COMMUNICATION LINE MALFUNCTION


DIAGNOSIS:

- AET communication line is broken or short circuited.

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-162

Vehicle-id:
SIE-id: :Y:DTC 43 AET Communication Line Malfunction
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Disconnect connector from ECM. 4) Measure resistance between VDCCM connector and ECM. Connector & terminal (F87) No. 21 — (B134) No. 12: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Repair harness/connector between VDCCM and ECM.
2 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 21 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 3.	Repair harness/connector between VDCCM and ECM.
3 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM connector and chassis ground. Terminal (F87) No. 21 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 4.	Repair harness/connector between VDCCM and ECM.
4 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Terminal (F87) No. 21 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 5.	Repair harness/connector between VDCCM and ECM.
5 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Connect connector to ECM. 3) Turn ignition switch to ON. 4) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 21 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Go to step 9.
6 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between ECM and VDCCM?	Tightened securely.	Repair connector.	Go to step 7.
7 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	There is poor contact.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 8.

VDC-163

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
8 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Same DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.
9 CHECK ECM. 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector terminal and chassis ground. Connector & terminal (B134) No. 12 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Repair harness/connector between ECM and VDCCM.	Go to step 10.
10 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector ECM?	There is poor contact.	Repair connector.	Go to step 11.
11 CHECK ENGINE. Is the engine functioning normally?	Operates properly.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair engine.

VDC-164

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-165

Vehicle-id:
SIE-id::Y:DTC 43 AET Communication Line Mal-
function
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Z: DTC 43 AEB COMMUNICATION LINE MALFUNCTION


DIAGNOSIS:

- AEB communication line is broken or short circuited.

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-166

Vehicle-id:
SIE-id: :Z:DTC 43 AEB Communication Line Malfunction

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Disconnect connector from ECM. 4) Measure resistance between VDCCM connector and ECM. Connector & terminal (F87) No. 43 — (B134) No. 4: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Repair harness/connector between VDCCM and ECM.
2 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 43 — Chassis ground: Does the measured value exceed the specified value?	1 M Ω	Go to step 3.	Repair harness/connector between VDCCM and ECM.
3 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 43 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 4.	Repair harness/connector between VDCCM and ECM.
4 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 43 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 5.	Repair harness/connector between VDCCM and ECM.
5 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Connect connector to ECM. 3) Turn ignition switch to ON. 4) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 43 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Go to step 9.
6 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between ECM and VDCCM?	Tightened securely.	Repair connector.	Go to step 7.
7 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	There is poor contact.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 8.

VDC-167

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
8 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Same DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.
9 CHECK ECM. 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector terminal and chassis ground. Connector & terminal (B134) No. 4 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Repair harness/connector between ECM and VDCCM.	Go to step 10.
10 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector ECM?	There is poor contact.	Repair connector.	Go to step 11.
11 CHECK ENGINE. Is the engine functioning normally?	Operates properly.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair engine.

VDC-168

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-169

Vehicle-id:
SIE-id::Z:DTC 43 AEB Communication Line Mal-
function
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AA:DTC 43 AEC COMMUNICATION LINE MALFUNCTION


DIAGNOSIS:

- AEC communication line is broken or short circuited.

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-170

Vehicle-id:
SIE-id::AA:DTC 43 AEC Communication Line Malfunction
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Disconnect connector from ECM. 4) Measure resistance between VDCCM connector and ECM. Connector & terminal (F87) No. 8 — (B134) No. 11: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Repair harness/connector between VDCCM and ECM.
2 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 8 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 3.	Repair harness/connector between VDCCM and ECM.
3 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 8 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 4.	Repair harness/connector between VDCCM and ECM.
4 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 8 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 5.	Repair harness/connector between VDCCM and ECM.
5 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Connect connector to ECM. 3) Turn ignition switch to ON. 4) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 8 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Go to step 9.
6 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between ECM and VDCCM?	Tightened securely.	Repair connector.	Go to step 7.
7 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	There is poor contact.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 8.

VDC-171

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
8 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Same DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.
9 CHECK ECM. 1) Turn ignition switch to ON. 2) Measure voltage between ECM connector terminal and chassis ground. Connector & terminal (B134) No. 11 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Repair harness/connector between ECM and VDCCM.	Go to step 10.
10 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector ECM?	There is poor contact.	Repair connector.	Go to step 11.
11 CHECK ENGINE. Is the engine functioning normally?	Operates properly.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair engine.

VDC-172

Vehicle-id:
 SIE-id::AA:DTC 43 AEC Communication Line Malfunction
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-173

Vehicle-id:
SIE-id::AA:DTC 43 AEC Communication Line Mal-
function

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AB:DTC 44 TCM COMMUNICATION CIRCUIT


DIAGNOSIS:

- Communication with AT control faults

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-174

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK RESISTANCE OF HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect two connectors from TCM. 3) Measure resistance between TCM connector terminals. Connector & terminal (B56) No. 9 — No. 18: Is the measured value within the specified range?	57 — 63 Ω	Go to step 2.	Repair harness between TCM and VDCCM.
2 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in TCM connectors?	There is poor contact.	Repair connector.	Go to step 3.
3 CHECK TCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace TCM. <Ref. to AT-75, Transmission Control Module (TCM).>	Go to step 4.
4 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-175

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AC:DTC 45 INCORRECT VDC CONTROL MODULE

DIAGNOSIS:

- Control module out of specification

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

Step	Value	Yes	No
1 CHECK VDCCM SPECIFICATIONS. Check the VDCCM identification mark. VDCCM identification mark P Does the VDCCM identification mark agree with the vehicle specifications?	Agree.	Go to step 2.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
2 CHECK TCM SPECIFICATIONS. Check the TCM identification mark. TCM identification mark ZV Does the TCM identification mark agree with the vehicle specifications?	Agree.	Go to step 3.	Replace TCM. <Ref. to AT-75, Transmission Control Module (TCM).>
3 CHECK TCM. 1) Replace TCM. <Ref. to AT-75, Transmission Control Module (TCM).> 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Go to step 4.	The original TCM has been faulty.
4 CHECK TCM. Is the same diagnostic trouble code as in the current diagnosis still being output?	Is the same diagnostic trouble code as in the current diagnosis still being output?	Go to step 5.	Proceed with the diagnosis corresponding to the diagnostic trouble code.
5 CHECK VDCCM. 1) Install original TCM. 2) Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).> 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Go to step 6.	The original VDCCM has been faulty.
6 CHECK VDCCM. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace TCM. <Ref. to AT-75, Transmission Control Module (TCM).>	Proceed with the diagnosis corresponding to the diagnostic trouble code.

VDC-176

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AD:DTC 45 TCM MALFUNCTION SPECIFICATIONS

DIAGNOSIS:

- Control module out of specification

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

	Step	Value	Yes	No
1	CHECK AT SYSTEM. 1) Start the engine. 2) Check AT system diagnostic trouble code. Is the AT system diagnostic trouble code is same with the specification?	Indicated.	Repair AT system.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-177

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AE:DTC 46 ABNORMAL VOLTAGE OF 5 V POWER SUPPLY


DIAGNOSIS:

- 5 volt power supply is abnormal.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00147

VDC-178

Vehicle-id:
SIE-id::AE:DTC 46 Abnormal Voltage of 5 V Power Supply

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GROUND SHORT OF SENSOR AND HARNESS. 1) Turn ignition switch OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 63 — Chassis ground (Lateral G sensor): (F87) No. 78 — Chassis ground (Pressure sensor): Does the measured value exceed the specified value?	1 MΩ	Go to step 3.	Go to step 2.
2 CHECK GROUND SHORT OF HARNESS. 1) Disconnect connector from faulty sensors. 2) Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 63 — Chassis ground (Lateral G sensor): (F87) No. 78 — Chassis ground (Pressure sensor): Does the measured value exceed the specified value?	1 MΩ	Replace faulty sensors.	Repair or replace harness connector between VDCCM and faulty sensor.
3 CHECK BATTERY SHORT OF SENSOR AND HARNESS. Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 63 (+) — Chassis ground (-) (Lateral G sensor): (F87) No. 78 (+) — Chassis ground (-) (Pressure sensor): Is the measured value less than the specified value?	0.5 V	Go to step 4.	Go to step 5.
4 CHECK BATTERY SHORT OF SENSOR AND HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 63 (+) — Chassis ground (-) (Lateral G sensor): (F87) No. 78 (+) — Chassis ground (-) (Pressure sensor): Is the measured value less than the specified value?	0.5 V	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 5.
5 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect connector from faulty sensors. 3) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 63 (+) — Chassis ground (-) (Lateral G sensor): (F87) No. 78 (+) — Chassis ground (-) (Pressure sensor): Is the measured value less than the specified value?	0.5 V	Go to step 6.	Repair or replace harness connector between VDCCM and faulty sensor.

VDC-179

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

6	Step	Value	Yes	No
	<p>CHECK BATTERY SHORT OF HARNESS.</p> <p>1) Turn ignition switch to ON.</p> <p>2) Measure voltage between VDCCM and chassis ground.</p> <p>Connector & terminal</p> <p>(F87) No. 63 (+) — Chassis ground (-) (Lateral G sensor):</p> <p>(F87) No. 78 (+) — Chassis ground (-) (Pressure sensor):</p> <p>Is the measured value less than the specified value?</p>	0.5 V	Replace faulty sensor.	Repair or replace harness connector between VDCCM and faulty sensor.

VDC-180

Vehicle-id:
 SIE-id::AE:DTC 46 Abnormal Voltage of 5 V Power Supply
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-181

Vehicle-id:
SIE-id: :AE:DTC 46 Abnormal Voltage of 5 V Power
Supply
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AF:DTC 47 IMPROPER CAN COMMUNICATION


DIAGNOSIS:

- CAN communication line is broken or short circuited.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC-182

Vehicle-id:
SIE-id: :AF:DTC 47 Improper CAN Communication

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS BETWEEN VDCCM, STEERING ANGLE SENSOR AND TCM. 1) Turn ignition switch OFF. 2) Disconnect connector from VDCCM, TCM and steering angle sensor. 3) Measure resistance between VDCCM, TCM and steering angle sensor. Connector & terminal (F87) No. 83 — (B56) No. 9: (F87) No. 81 — (B56) No. 18: (F87) No. 83 — (B231) No. 2: (F87) No. 81 — (B231) No. 1: Is the measured value less than the specified value?	0.5 Ω	Go to step 3.	Go to step 2.
2 CHECK HARNESS BETWEEN STEERING ANGLE SENSOR AND TCM. Measure resistance between TCM and steering angle sensor. Connector & terminal (B56) No. 9 — (B231) No. 2: (B56) No. 18 — (B231) No. 1: Is the measured value less than the specified value?	0.5 Ω	Repair or replace harness connector between VDCCM and steering angle sensor.	Repair or replace harness connector between TCM and steering angle sensor.
3 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 83 — Chassis ground: (F87) No. 81 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 4.	Repair or replace harness connector between VDCCM, TCM and steering angle sensor.
4 CHECK BATTERY SHORT OF SENSOR. Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 83 — Chassis ground: (F87) No. 81 — Chassis ground: Is the measured value less than the specified value?	0.5 V	Go to step 5.	Repair or replace harness connector between VDCCM, TCM and steering angle sensor.
5 CHECK BATTERY SHORT OF SENSOR. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 83 — Chassis ground: (F87) No. 81 — Chassis ground: Is the measured value less than the specified value?	0.5 V	Go to step 6.	Repair or replace harness connector between VDCCM, TCM and steering angle sensor.
6 CHECK STEERING ANGLE SENSOR. 1) Turn ignition switch to OFF. 2) Connect connector to steering angle sensor. 3) Measure resistance between VDCCM connector terminals. Connector & terminal (F87) No. 83 — No. 81: Is the measured value within the specified range?	114 — 126 Ω	Go to step 8.	Go to step 7.

VDC-183

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in steering angle sensor?	There is poor contact.	Replace steering angle sensor.	Repair or replace steering angle sensor connector.
8 CHECK VDCCM. 1) Connect connector to VDCCM. 2) Disconnect connector from steering angle sensor. 3) Measure resistance between steering angle sensor connector terminals. Connector & terminal (B231) No. 1 — No. 2: Is the measured value within the specified range?	114 — 126 Ω	Go to step 10.	Go to step 9.
9 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in steering angle sensor?	There is poor contact.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Repair or replace VDCCM connector.
10 CHECK TCM. 1) Connect connector to TCM. 2) Disconnect connector from VDCCM. 3) Measure resistance between steering angle sensor terminals. Connector & terminal (B231) No. 1 — No. 2: Does the measured value exceed the specified value?	1 MΩ	Go to step 12.	Go to step 11.
11 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in steering angle sensor?	There is poor contact.	Replace TCM. <Ref. to AT-75, Transmission Control Module (TCM).>	Repair or replace TCM connector.
12 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Are other diagnostic trouble codes being output?	Other DTC indicated.	Go to step 13.	A temporary poor contact.
13 CHECK DIAGNOSTIC TROUBLE CODE. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Go to step 14.	Proceed with the diagnosis corresponding to the diagnostic trouble code.
14 CHECK AT SYSTEM DIAGNOSTIC TROUBLE CODE. Is the AT system diagnostic trouble code is same with the specification?	DTC 86	Replace steering angle sensor.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-184

Vehicle-id:
 SIE-id::AF:DTC 47 Improper CAN Communication

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-185

Vehicle-id:
SIE-id: :AF:DTC 47 Improper CAN Communication

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AG:DTC 48 IMPROPER EAC COMMUNICATION


DIAGNOSIS:

- EAC communication line is broken or short circuited.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00148

VDC-186

Vehicle-id:
SIE-id: :AG:DTC 48 Improper EAC Communication

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS BETWEEN ECM AND VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM and ECM. 3) Measure resistance between VDCCM and ECM. Connector & terminal (F87) No. 45 — (B136) No. 12: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Repair or replace open circuit between VDCCM and ECM.
2 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM and ECM. Connector & terminal (F87) No. 45 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 3.	Repair or replace ground short circuit between VDCCM and ECM.
3 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 45 — Chassis ground: Is the measured value less than the specified value?	0.5 V	Go to step 4.	Repair or replace battery short circuit between VDCCM and ECM.
4 CHECK INPUT VOLTAGE FROM ECM. 1) Turn ignition switch to OFF. 2) Connect connector to VDCCM. 3) Turn ignition switch to ON. 4) Measure voltage between ECM and chassis ground. Connector & terminal (B136) No. 12 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Go to step 5.
5 CHECK POOR CONTACT IN ECM CONNECTORS. Is there poor contact in ECM connector?	There is poor contact.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair or replace ECM connector.
6 ERASE MEMORY. 1) Connect all connectors. 2) Erase the memory. Can the memory be erased?	Can be erased.	Go to step 7.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
7 CHECK DIAGNOSTIC TROUBLE CODE. 1) Perform inspection mode. 2) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	A temporary poor contact.

VDC-187

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AH:DTC 48 EAS COMMUNICATION LINE GROUNDING SHORTED


DIAGNOSIS:

- EAS communication line is short circuited.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00148

VDC-188

Vehicle-id:
SIE-id: :AH:DTC 48 EAS Communication Line Grounding Shorted

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM and ECM. 3) Measure resistance between VDCCM and ECM. Connector & terminal (F87) No. 75 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 2.	Repair or replace ground short circuit between VDCCM and ECM.
2 CHECK INPUT VOLTAGE FROM ECM. 1) Connect connector to VDCCM. 2) Turn ignition switch to ON. 3) Measure voltage between ECM and chassis ground. Connector & terminal (B136) No. 11 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 4.	Go to step 3.
3 CHECK POOR CONTACT IN ECM CONNECTORS. Is there poor contact in ECM connector?	There is poor contact.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair or replace ECM connector.
4 ERASE MEMORY. 1) Connect all connectors. 2) Erase the memory. Can the memory be erased?	Can be erased.	Go to step 5.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
5 CHECK DIAGNOSTIC TROUBLE CODE. 1) Perform inspection mode. 2) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	A temporary poor contact.

VDC-189

Vehicle-id:
 SIE-id::AH:DTC 48 EAS Communication Line
 Grounding Shorted
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AI: DTC 48 ERRONEOUS COMMUNICATION FROM EGI TO VDC


DIAGNOSIS:

- EAS communication line is broken or short circuited.
- EAC communication line is broken or short circuited.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00148

VDC-190

Vehicle-id:
SIE-id::AI:DTC 48 Erroneous Communication From
EGI to VDC

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK HARNESS BETWEEN ECM AND VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM and ECM. 3) Measure resistance between VDCCM and ECM. Connector & terminal (F87) No. 75 — (B136) No. 11: (F87) No. 45 — (B136) No. 12: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Repair or replace open circuit between VDCCM and ECM.
2 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 75 — Chassis ground: (F87) No. 45 — Chassis ground: Is the measured value less than the specified value?	0.5 V	Go to step 3.	Repair or replace battery short circuit between VDCCM and ECM.
3 CHECK INPUT VOLTAGE FROM ECM. 1) Turn ignition switch to OFF. 2) Connect connector to VDCCM. 3) Turn ignition switch to ON. 4) Measure voltage between ECM and chassis ground. Connector & terminal (B136) No. 11 (+) — Chassis ground (-): (B136) No. 12 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 5.	Go to step 4.
4 CHECK POOR CONTACT IN ECM CONNECTORS. Is there poor contact in ECM connector?	There is poor contact.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	Repair or replace ECM connector.
5 ERASE MEMORY. 1) Connect all connectors. 2) Erase the memory. Can the memory be erased?	Can be erased.	Go to step 6.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
6 CHECK DIAGNOSTIC TROUBLE CODE. 1) Perform inspection mode. 2) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace ECM. <Ref. to FU(H6DO)-46, Engine Control Module.>	A temporary poor contact.

VDC-191

Vehicle-id:
 SIE-id::AI:DTC 48 Erroneous Communication
 From EGI to VDC

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AJ:DTC 49 ABNORMAL ENGINE SPEED SIGNAL


DIAGNOSIS:

- Engine speed signal line is broken or short circuited.

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-192

Vehicle-id:
SIE-id: :AJ:DTC 49 Abnormal Engine Speed Signal

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK TACHOMETER OPERATION IN COMBINATION METER. Does tachometer operate normally?	Operates properly.	Go to step 2.	Repair tachometer.
2 CHECK HARNESS BETWEEN VDCCM AND ECM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM and ECM. 3) Measure resistance between VDCCM connector and ECM. Connector & terminal (F87) No. 9 — (B136) No. 9: Is the measured value less than the specified value?	0.5 Ω	Go to step 3.	Repair harness connector between VDCCM and ECM.
3 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connectors between VDCCM and ECM?	There is poor contact.	Repair connector.	Go to step 4.
4 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 5.
5 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-193

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AK:DTC 51 VALVE RELAY

DIAGNOSIS:

- Faulty valve relay


NOTE:

When DTC 74 inspection is carried out, DTC 51 is memorized.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00150

VDC-194

Vehicle-id:
SIE-id: :AK:DTC 51 Valve Relay

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK RESISTANCE OF VALVE RELAY. 1) Turn ignition switch to OFF. 2) Remove valve relay from relay box. 3) Measure resistance between valve relay terminals. Terminals No. 85 — No. 86: Is the measured value within the specified range?	93 — 113 Ω	Go to step 2.	Replace valve relay.
2 CHECK CONTACT POINT OF VALVE RELAY. 1) Connect battery to valve relay terminals No. 85 and No. 86. 2) Measure resistance between valve relay terminals. Terminals No. 30 — No. 87: Is the measured value less than the specified value?	0.5 Ω	Go to step 3.	Replace valve relay.
3 CHECK CONTACT POINT OF VALVE RELAY. Measure resistance between valve relay terminals. Terminals No. 30 — No. 87a: Does the measured value exceed the specified value?	1 M Ω	Go to step 4.	Replace valve relay.
4 CHECK CONTACT POINT OF VALVE RELAY. 1) Disconnect battery from valve relay terminals. 2) Measure resistance between valve relay terminals. Terminals No. 30 — No. 87: Does the measured value exceed the specified value?	1 M Ω	Go to step 5.	Replace valve relay.
5 CHECK CONTACT POINT OF VALVE RELAY. Measure resistance between valve relay terminals. Terminals No. 30 — No. 87a: Is the measured value less than the specified value?	0.5 Ω	Go to step 6.	Replace valve relay.
6 CHECK SHORT OF VALVE RELAY. Measure resistance between valve relay terminals. Terminals No. 86 — No. 87: No. 86 — No. 87a: Does the measured value exceed the specified value?	1 M Ω	Go to step 7.	Replace valve relay.

VDC-195

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK POWER SUPPLY FOR VALVE RELAY. 1) Disconnect connector (F89) from relay box. 2) Turn ignition switch to ON. 3) Measure voltage between relay box connector and chassis ground. Connector & terminal (F89) No. 1 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 8 .	Repair harness between battery and relay box connector. Check fuse No. 8.
8 CHECK OPEN CIRCUIT AND GROUND SHORT IN POWER SUPPLY CIRCUIT OF RELAY BOX. 1) Disconnect connector (VDC1) from VDCH/U. 2) Connect connector (F89) to relay box. 3) Turn ignition switch to ON. 4) Measure voltage of relay box. Connector & terminal (VDC6) No. 87 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Go to step 9 .	Replace relay box and check fuse No. 8.
9 CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX. 1) Turn ignition switch to OFF. 2) Disconnect connector (F90) from relay box. 3) Measure resistance between relay box connector and valve relay installing point. Connector & terminal (VDC4) No. 5 — (VDC6) No. 85: (VDC4) No. 1 — (VDC6) No. 86: Is the measured value less than the specified value?	0.5 Ω	Go to step 10 .	Replace relay box.
10 CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX. Measure resistance between relay box connector and chassis ground. Connector & terminal (VDC4) No. 5 — Chassis ground: (VDC4) No. 1 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 11 .	Replace relay box and check fuse SBF6.
11 CHECK OPEN CIRCUIT IN CONTROL SYSTEM HARNESS OF VALVE RELAY. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM connector and relay box connector. Connector & terminal (F87) No. 47 — (F90) No. 5: (F87) No. 27 — (F90) No. 1: Is the measured value less than the specified value?	0.5 Ω	Go to step 12 .	Repair harness between VDCCM and relay box.

VDC-196

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
12 CHECK GROUND SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY. Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 47 — Chassis ground: (F87) No. 27 — Chassis ground: Does the measured value exceed the specified value?	1 M Ω	Go to step 13.	Repair harness between VDCCM and relay box.
13 CHECK OPEN CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX. Measure resistance between VDCH/U connector and valve relay installing point. Connector & terminal (VDC1) No. 2 — (VDC6) No. 30: Is the measured value less than the specified value?	0.5 Ω	Go to step 14.	Replace relay box.
14 CHECK GROUND SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX. Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (VDC1) No. 2 — Chassis ground: Does the measured value exceed the specified value?	1 M Ω	Go to step 15.	Replace relay box and check fuse No. 8.
15 CHECK RESISTANCE OF INLET AND CUT SOLENOID VALVES. 1) Disconnect connector from VDCH/U. 2) Measure resistance between VDCH/U connector terminals. Connector & terminal (VDC5) No. 8 — (VDC2) No. 2: (VDC5) No. 5 — (VDC2) No. 2: (VDC5) No. 6 — (VDC2) No. 2: (VDC5) No. 7 — (VDC2) No. 2: (VDC5) No. 9 — (VDC2) No. 2: (VDC5) No. 12 — (VDC2) No. 2: Is the measured value within the specified range?	8.04 — 9.04 Ω	Go to step 16.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
16 CHECK RESISTANCE OF OUTLET SOLENOID VALVE. Measure resistance between VDCH/U connector terminals. Connector & terminal (VDC5) No. 4 — (VDC2) No. 2: (VDC5) No. 1 — (VDC2) No. 2: (VDC5) No. 2 — (VDC2) No. 2: (VDC5) No. 3 — (VDC2) No. 2: (VDC5) No. 10 — (VDC2) No. 2: (VDC5) No. 11 — (VDC2) No. 2: Is the measured value within the specified range?	4.04 — 4.54 Ω	Go to step 17.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-197

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
17 CHECK GROUND SHORT OF SOLENOID VALVE. Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (VDC2) No. 2 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 18.	Replace VDCH/U and check all fuses. <Ref. to VDC-8, VDC Control Module (VDCCM).>
18 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 30 — Chassis ground: (F87) No. 24 — Chassis ground: (F87) No. 23 — Chassis ground: (F87) No. 31 — Chassis ground: (F87) No. 26 — Chassis ground: (F87) No. 25 — Chassis ground: (F87) No. 3 — Chassis ground: (F87) No. 51 — Chassis ground: (F87) No. 50 — Chassis ground: (F87) No. 4 — Chassis ground: (F87) No. 2 — Chassis ground: (F87) No. 29 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 19.	Repair harness between VDCH/U and VDCCM.
19 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND VDCH/U. 1) Connect connector (F91) to VDCH/U. 2) Measure resistance between VDCCM connector and VDCH/U Connector & terminal (F87) No. 30 — (VDC2) No. 2: (F87) No. 24 — (VDC2) No. 2: (F87) No. 23 — (VDC2) No. 2: (F87) No. 31 — (VDC2) No. 2: (F87) No. 26 — (VDC2) No. 2: (F87) No. 25 — (VDC2) No. 2: Is the measured value within the specified range?	8.0 — 10.0 Ω	Go to step 20.	Repair harness/connector between VDCH/U and VDCCM.
20 CHECK HARNESS/CONNECTOR BETWEEN VDCCM AND VDCH/U. Measure resistance between VDCCM connector terminals. Connector & terminal (F87) No. 3 — (VDC2) No. 2: (F87) No. 51 — (VDC2) No. 2: (F87) No. 50 — (VDC2) No. 2: (F87) No. 4 — (VDC2) No. 2: (F87) No. 2 — (VDC2) No. 2: (F87) No. 29 — (VDC2) No. 2: Is the measured value within the specified range?	4.0 — 6.0 Ω	Go to step 21.	Repair harness/connector between VDCH/U and VDCCM.
21 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector between VDCCM and VDCH/U?	There is poor contact.	Repair connector.	Go to step 22.

VDC-198

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
22 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 23 .
23 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-199

Vehicle-id:
SIE-id: :AK:DTC 51 Valve Relay

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AL:DTC 51 VALVE RELAY ON FAILURE

DIAGNOSIS:

- Faulty valve relay


NOTE:

When DTC 74 inspection is carried out, DTC 51 is memorized.

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00150

VDC-200

Vehicle-id:
SIE-id: :AL:DTC 51 Valve Relay on Failure

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK CONTACT POINT OF VALVE RELAY. 1) Turn ignition switch to OFF. 2) Remove valve relay from relay box. 3) Connect battery to valve relay terminals No. 85 and No. 86. 4) Measure resistance between valve relay terminals. Terminals No. 30 — No. 87: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Replace valve relay.
2 CHECK CONTACT POINT OF VALVE RELAY. Measure resistance between valve relay terminals. Terminals No. 30 — No. 87a: Does the measured value exceed the specified value?	1 M Ω	Go to step 3.	Replace valve relay.
3 CHECK CONTACT POINT OF VALVE RELAY. 1) Disconnect battery from valve relay terminals. 2) Measure resistance between valve relay terminals. Terminals No. 30 — No. 87: Does the measured value exceed the specified value?	1 M Ω	Go to step 4.	Replace valve relay.
4 CHECK CONTACT POINT OF VALVE RELAY. Measure resistance between valve relay terminals. Terminals No. 30 — No. 87a: Is the measured value less than the specified value?	0.5 Ω	Go to step 5.	Replace valve relay.
5 CHECK SHORT OF VALVE RELAY. Measure resistance between valve relay terminals. Terminals No. 86 — No. 87: No. 86 — No. 87a: Does the measured value exceed the specified value?	1 M Ω	Go to step 6.	Replace valve relay.
6 CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX. 1) Disconnect connector (F90) from relay box. 2) Measure voltage between relay box connector and chassis ground. Connector & terminal (VDC4) No. 5 (+) — Chassis ground (-): (VDC4) No. 1 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 7.	Replace relay box. Check fuse No. 8 and SBF3.

VDC-201

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (VDC4) No. 5 (+) — Chassis ground (-): (VDC4) No. 1 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 8 .	Replace relay box. Check fuse No. 8 and SBF3.
8 CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Disconnect connector from VDCH/U. 4) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 27 (+) — Chassis ground (-): (F87) No. 47 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 9 .	Repair harness between VDCCM and relay box and check all fuses.
9 CHECK BATTERY SHORT IN CONTROL SYSTEM HARNESS OF VALVE RELAY. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 27 (+) — Chassis ground (-): (F87) No. 47 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 10 .	Repair harness between VDCCM and relay box and check all fuses.
10 CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX. 1) Disconnect connector VDC1 from relay box. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (VDC1) No. 2 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 11 .	Replace relay box.
11 CHECK BATTERY SHORT IN CONTACT POINT CIRCUIT OF RELAY BOX. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (VDC1) No. 2 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 12 .	Replace relay box.

VDC-202

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
12 CHECK BATTERY SHORT OF SOLENOID VALVE. 1) Turn ignition switch to OFF. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (VDC2) No. 2 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 13.	Replace VDCH/U and check all fuses. <Ref. to VDC-8, VDC Control Module (VDCCM).>
13 CHECK BATTERY SHORT OF SOLENOID VALVE. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (VDC2) No. 2 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 14.	Replace VDCH/U and check all fuses. <Ref. to VDC-8, VDC Control Module (VDCCM).>
14 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 30 (+) — Chassis ground (-): (F87) No. 24 (+) — Chassis ground (-): (F87) No. 23 (+) — Chassis ground (-): (F87) No. 31 (+) — Chassis ground (-): (F87) No. 26 (+) — Chassis ground (-): (F87) No. 25 (+) — Chassis ground (-): (F87) No. 3 (+) — Chassis ground (-): (F87) No. 51 (+) — Chassis ground (-): (F87) No. 50 (+) — Chassis ground (-): (F87) No. 4 (+) — Chassis ground (-): (F87) No. 2 (+) — Chassis ground (-): (F87) No. 29 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 15.	Repair harness between VDCH/U and VDCCM and check all fuses.
15 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 30 (+) — Chassis ground (-): (F87) No. 24 (+) — Chassis ground (-): (F87) No. 23 (+) — Chassis ground (-): (F87) No. 31 (+) — Chassis ground (-): (F87) No. 26 (+) — Chassis ground (-): (F87) No. 25 (+) — Chassis ground (-): (F87) No. 3 (+) — Chassis ground (-): (F87) No. 51 (+) — Chassis ground (-): (F87) No. 50 (+) — Chassis ground (-): (F87) No. 4 (+) — Chassis ground (-): (F87) No. 2 (+) — Chassis ground (-): (F87) No. 29 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 16.	Repair harness between VDCH/U and VDCCM and check all fuses.

VDC-203

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
16 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connector between VDCCM and VDCH/U?	There is poor contact.	Repair connector.	Go to step 17.
17 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 18.
18 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-204

Vehicle-id:
SIE-id: :AL:DTC 51 Valve Relay on Failure

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-205

Vehicle-id:
SIE-id: :AL:DTC 51 Valve Relay on Failure
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AM:DTC 52 MOTOR AND MOTOR RELAY OFF FAILURE



DIAGNOSIS:

- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00155

VDC-206

Vehicle-id:
SIE-id: :AM:DTC 52 Motor and Motor Relay off Failure

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK CONTACT POINT OF MOTOR RELAY. 1) Turn ignition switch to OFF. 2) Remove motor relay from relay box. 3) Measure resistance between motor relay terminals. Terminals No. 30 — No. 87: Does the measured value exceed the specified value?	1 MΩ	Go to step 2.	Replace motor relay.
2 CHECK SHORT OF MOTOR RELAY. Measure resistance between motor relay terminals. Terminals No. 85 — No. 30: No. 85 — No. 87: Does the measured value exceed the specified value?	1 MΩ	Go to step 3.	Replace motor relay.
3 CHECK GROUND SHORT IN CIRCUIT OF RELAY BOX. 1) Disconnect connector (F90) from relay box. 2) Measure resistance between relay box connector unit and chassis ground. Connector & terminal (VDC4) No. 4 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 4.	Replace relay box.
4 CHECK BATTERY SHORT IN CIRCUIT OF RELAY BOX. Measure voltage between relay box connector and chassis ground. Connector & terminal (VDC4) No. 6 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 5.	Replace relay box.
5 CHECK BATTERY SHORT IN CIRCUIT OF RELAY BOX. 1) Turn ignition switch to ON. 2) Measure voltage between relay box connector and chassis ground. Connector & terminal (VDC4) No. 6 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 6.	Replace relay box.
6 CHECK GROUND SHORT IN HARNESS BETWEEN RELAY BOX AND VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 22 — Chassis ground: Is the measured value less than the specified value?	1 MΩ	Go to step 7.	Repair harness between VDCCM and relay box. Check fuse SBF holder.

VDC-207

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK BATTERY SHORT IN HARNESS BETWEEN RELAY BOX AND VDCCM. Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 10 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 8 .	Repair harness between VDCCM and relay box.
8 CHECK BATTERY SHORT IN HARNESS BETWEEN RELAY BOX AND VDCCM. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 10 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 9 .	Repair harness between VDCCM and relay box.
9 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connector between VDCH/U, relay box and VDCCM?	There is poor contact.	Repair connector.	Go to step 10 .
10 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 11 .
11 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-208

Vehicle-id:
SIE-id: :AM:DTC 52 Motor and Motor Relay off Failure

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-209

Vehicle-id:
SIE-id::AM:DTC 52 Motor and Motor Relay off Failure
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AN:DTC 52 MOTOR AND MOTOR RELAY ON FAILURE



DIAGNOSIS:

- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00155

VDC-210

Vehicle-id:
SIE-id: :AN:DTC 52 Motor and Motor Relay on Failure

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK RESISTANCE OF MOTOR RELAY. 1) Turn ignition switch to OFF. 2) Remove motor relay from relay box. 3) Measure resistance between motor relay terminals. Terminals No. 85 — No. 86: Is the measured value within the specified range?	70 — 90 Ω	Go to step 2.	Replace motor relay.
2 CHECK CONTACT POINT OF MOTOR RELAY. 1) Connect battery to motor relay terminals No. 85 and No. 86. 2) Measure resistance between motor relay terminals. Terminals No. 30 — No. 87: Is the measured value less than the specified value?	0.5 Ω	Go to step 3.	Replace motor relay.
3 CHECK SHORT OF MOTOR RELAY. Measure resistance between motor relay terminals. Terminals No. 85 — No. 30: No. 85 — No. 87: Does the measured value exceed the specified value?	1 M Ω	Go to step 4.	Replace motor relay.
4 CHECK INPUT VOLTAGE OF RELAY BOX. 1) Disconnect connector (F89) from relay box. 2) Disconnect connector from VDCCM. 3) Turn ignition switch to ON. 4) Measure voltage between relay box connector and chassis ground. Connector & terminal (F89) No. 2 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 5.	Repair harness/connector between battery and relay box, and check fuse SBF holder.
5 CHECK INPUT VOLTAGE OF MOTOR RELAY. 1) Turn ignition switch to OFF. 2) Connect connector (F89) to relay box. 3) Turn ignition switch to ON. 4) Measure voltage between relay box and chassis ground. Connector & terminal (VDC7) No. 87 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Replace relay box.

VDC-211

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
6 CHECK OPEN CIRCUIT IN CONTACT POINT CIRCUIT OF RELAY BOX. 1) Turn ignition switch to OFF. 2) Disconnect connectors (VDC2, F90) from relay box. 3) Measure resistance between relay box connector unit and motor relay installing portion. Connector & terminal (VDC1) No. 1 — (VDC7) No. 30: Is the measured value less than the specified value?	0.5 Ω	Go to step 7.	Replace relay box.
7 CHECK OPEN CIRCUIT IN MONITOR SYSTEM CIRCUIT OF RELAY BOX. Measure resistance between relay box connector and motor relay installing point. Connector & terminal (VDC4) No. 6 — (VDC7) No. 30: Is the measured value less than the specified value?	0.5 Ω	Go to step 8.	Replace relay box.
8 CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX. Measure resistance between motor relay installing point and relay box connector. Connector & terminal (VDC4) No. 4 — (VDC7) No. 86: Is the measured value less than the specified value?	0.5 Ω	Go to step 9.	Replace relay box.
9 CHECK OPEN CIRCUIT IN CONTROL CIRCUIT OF RELAY BOX. 1) Remove valve relay from relay box. 2) Measure resistance between motor relay installing point and valve relay installing point. Connector & terminal (VDC7) No. 85 — (VDC6) No. 30: Is the measured value less than the specified value?	0.5 Ω	Go to step 10.	Replace relay box.
10 CHECK GROUND SHORT IN CIRCUIT OF RELAY BOX. Measure resistance between relay box connector and chassis ground. Connector & terminal (VDC4) No. 4 — Chassis ground: (VDC4) No. 6 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 11.	Replace relay box.
11 CHECK BATTERY SHORT IN CIRCUIT OF RELAY BOX. Measure voltage between relay box connector and chassis ground. Connector & terminal (VDC4) No. 6 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 12.	Replace relay box.

VDC-212

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
12 CHECK BATTERY SHORT IN CIRCUIT OF RELAY BOX. 1) Turn ignition switch to ON. 2) Measure voltage between relay box connector and chassis ground. Connector & terminal (VDC4) No. 6 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 13.	Replace relay box.
13 CHECK OPEN CIRCUIT IN RELAY CONTROL SYSTEM HARNESS. Measure resistance between VDCCM connector and relay box connector. Connector & terminal (F87) No. 22 — (F90) No. 4: (F87) No. 10 — (F90) No. 6: Is the measured value less than the specified value?	0.5 Ω	Go to step 14.	Repair harness connector between VDCCM and relay box.
14 CHECK GROUND SHORT IN HARNESS BETWEEN RELAY BOX AND VDCCM. Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 22 — Chassis ground: (F87) No. 10 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 15.	Repair harness between VDCCM and relay box. Check fuse SBF holder.
15 CHECK BATTERY SHORT IN HARNESS BETWEEN RELAY BOX AND VDCCM. Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 10 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 16.	Repair harness between VDCCM and relay box. Check fuse SBF holder.
16 CHECK BATTERY SHORT IN HARNESS BETWEEN RELAY BOX AND VDCCM. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM connector and chassis ground. Connector & terminal (F87) No. 10 (+) — Chassis ground (-): Is the measured value less than the specified value?	1 V	Go to step 17.	Repair harness between VDCCM and relay box. Check fuse SBF holder.
17 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connector between VDCH/U, relay box and VDCCM?	There is poor contact.	Repair connector.	Go to step 18.
18 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 19.

VDC-213

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
19 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-214

Vehicle-id:
SIE-id: :AN:DTC 52 Motor and Motor Relay on Failure
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-215

Vehicle-id:
SIE-id: :AN:DTC 52 Motor and Motor Relay on Failure
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AO:DTC 52 MOTOR MALFUNCTION



DIAGNOSIS:

- Faulty motor
- Faulty motor relay
- Faulty harness connector

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



(F87)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00155

VDC-216

Vehicle-id:
SIE-id: :AO:DTC 52 Motor Malfunction

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK CONTACT POINT OF MOTOR RELAY. 1) Turn ignition switch to OFF. 2) Remove motor relay from relay box. 3) Connect battery to motor relay terminals No. 85 and No. 86. 4) Measure resistance between motor relay terminals. Terminals No. 30 — No. 87: Is the measured value less than the specified value?	0.5 Ω	Go to step 2.	Replace motor relay.
2 CHECK CONTACT POINT OF MOTOR RELAY. 1) Disconnect battery from motor relay terminals. 2) Measure resistance between motor relay terminals. Terminals No. 30 — No. 87: Does the measured value exceed the specified value?	1 M Ω	Go to step 3.	Replace motor relay.
3 CHECK INPUT VOLTAGE OF RELAY BOX. 1) Disconnect connector (F89) from relay box. 2) Disconnect connector from VDCCM. 3) Turn ignition switch to ON. 4) Measure voltage between relay box connector and chassis ground. Connector & terminal (F89) No. 2 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 4.	Repair harness/connector between battery and relay box, and check fuse SBF holder.
4 CHECK INPUT VOLTAGE OF MOTOR RELAY. 1) Turn ignition switch to OFF. 2) Connect connector (F89) to relay box. 3) Turn ignition switch to ON. 4) Measure voltage between relay box and chassis ground. Connector & terminal (VDC7) No. 87 (+) — Chassis ground (-): Is the measured value within the specified range?	10 — 15 V	Go to step 5.	Replace relay box.
5 CHECK CONDITION OF MOTOR GROUND. Tightening torque: 32\pm10 N·m (3.3\pm1.0 kgf·m, 24\pm7 ft·lb) Is the motor ground terminal tightly clamped?	Clamped securely.	Go to step 6.	Tighten the clamp of motor ground terminal.

VDC-217

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
6 CHECK VDCCM MOTOR DRIVE TERMINAL. 1) Turn ignition switch OFF. 2) Remove VDC connector cover. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 3) Connect all connectors. 4) Install motor relay. 5) Operate the ABS check sequence. <Ref. to VDC-16, ABS Sequence Control.> 6) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 22 (+) — No. 1 (-): Does the voltage drop from between 10 V and 13 V to less than 1.5 V, and rise to between 10 V and 13 V again when carrying out the check sequence?	Drop from 10 — 13 V to less than 1.5 V, and rise to 10 — 13 V again when carrying out the check sequence.	Go to step 7.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
7 CHECK MOTOR OPERATION. Operate the check sequence. <Ref. to VDC-19, VDC Sequence Control.> Can motor revolution noise (buzz) be heard when carrying out the check sequence?	Noise heard	Go to step 8.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
8 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connector between VDCH/U, relay box and VDCCM?	There is poor contact.	Repair connector.	Go to step 9.
9 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 10.
10 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-218

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-219

Vehicle-id:
SIE-id: :A0:DTC 52 Motor Malfunction

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AP:DTC 71 STEERING ANGLE SENSOR OFFSET IS TOO BIG.


DIAGNOSIS:

- Faulty steering angle sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-220

Vehicle-id:
SIE-id: :AP:DTC 71 Steering Angle Sensor Offset is too Big.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK THE STEERING WHEEL. 1) Drive the vehicle on a flat road. 2) Stop the vehicle in a straight line. 3) Check the angle of steering wheel. Is the measured value less than the specified value?	5°	Go to step 2.	Perform centering alignment of steering wheel.
2 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 3.
3 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-221

Vehicle-id:
 SIE-id: :AP:DTC 71 Steering Angle Sensor Offset is too Big.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AQ:DTC 71 CHANGE RANGE OF STEERING ANGLE SENSOR IS TOO BIG.


DIAGNOSIS:

- Faulty steering angle sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC00146

VDC-222

Vehicle-id:
SIE-id: :AQ:DTC 71 Change Range of Steering Angle
Sensor is too Big.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 2.
2 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-223

Vehicle-id:
 SIE-id: :AQ:DTC 71 Change Range of Steering Angle Sensor is too Big.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AR:DTC 71 STEERING ANGLE SENSOR MALFUNCTION


DIAGNOSIS:

- Faulty steering angle sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



VDC-224

Vehicle-id:
SIE-id: :AR:DTC 71 Steering Angle Sensor Malfunction

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK THE STEERING WHEEL. 1) Drive the vehicle on a flat road. 2) Stop the vehicle in a straight line. 3) Check the angle of steering wheel. Is the measured value less than the specified value?	5°	Go to step 2.	Perform centering alignment of steering.
2 CHECK OUTPUT OF STEERING ANGLE SENSOR USING SELECT MONITOR. 1) Select "Current data display & Save" on the select monitor. 2) Read steering angle sensor output on the select monitor display. Does the steering angle sensor output (value) change on the monitor display when the steering wheel is turned in either direction?	Change	Go to step 3.	Replace steering angle sensor.
3 CHECK RUNNING FIELD. Check if the vehicle was driven on banked road surfaces or sandy surfaces (not dirt road surfaces). Was the vehicle driven on banked road surfaces or sandy surfaces (not dirt road surfaces)?	Driven.	Driving on banked road surfaces or sandy surfaces (not dirt road surfaces) sometimes results in a VDCCM memory trouble code.	Go to step 4.
4 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 5.
5 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-225

Vehicle-id:
 SIE-id: :AR:DTC 71 Steering Angle Sensor Malfunction
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AS:DTC 71 NO SIGNAL FROM STEERING ANGLE SENSOR


DIAGNOSIS:

- Faulty steering angle sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00146

VDC-226

Vehicle-id:
SIE-id::AS:DTC 71 No Signal from Steering Angle Sensor

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK POWER SUPPLY OF STEERING ANGLE SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from steering angle sensor. 3) Turn ignition switch to ON. 4) Measure voltage between steering angle sensor and chassis ground. Connector & terminal (B231) No. 4 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Go to step 4.	Go to step 2.
2 CHECK OUTPUT VOLTAGE OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover for VDCCM connector. <Ref. to VDC-19, VDC Sequence Control.> 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 27 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Repair harness between yaw rate sensor and VDCCM.	Go to step 3.
3 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in yaw rate sensor connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
4 CHECK GROUND CIRCUIT OF STEERING ANGLE SENSOR. Measure resistance between steering sensor and chassis ground. Connector & terminal (B231) No. 3 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Go to step 5.	Repair steering angle sensor ground harness.
5 CHECK HARNESS OF STEERING ANGLE SENSOR. 1) Connect connector to steering angle sensor. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM connector terminals. Connector & terminal (F87) No. 81 — No. 83: Is the measured value within the specified range?	114 — 126 Ω	Repair harness between steering angle sensor and VDCCM.	Go to step 6.
6 CHECK STEERING ANGLE SENSOR. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Go to step 8.	Go to step 7.

VDC-227

Vehicle-id:
 SIE-id::AS:DTC 71 No Signal from Steering Angle
 Sensor

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.
8 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Replace steering angle sensor. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 9 .
9 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	The original steering angle sensor has been faulty.

VDC-228

Vehicle-id:
 SIE-id::AS:DTC 71 No Signal from Steering Angle Sensor
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-229

Vehicle-id:
SIE-id::AS:DTC 71 No Signal from Steering Angle
Sensor
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AT:DTC 72 ABNORMAL YAW RATE SENSOR OUTPUT



DIAGNOSIS:

- Faulty yaw rate sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00151

VDC-230

Vehicle-id:
SIE-id::AT:DTC 72 Abnormal Yaw Rate Sensor Output
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK RUNNING FIELD. Was the vehicle driven on banked road surfaces or sandy surfaces (not dirt road surfaces)?	Driven.	Driving on banked road surfaces or sandy surfaces (not dirt road surfaces) sometimes results in a VDCCM memory diagnostic trouble code.	Go to step 2.
2 CHECK INSTALLATION OF YAW RATE AND LATERAL G SENSOR. Check installation of yaw rate and lateral G sensor. Is the yaw rate and lateral G sensor fixed securely?	Fixed securely.	Go to step 3.	Install yaw rate and lateral G sensor securely.
3 CHECK OUTPUT OF YAW RATE AND LATERAL G SENSOR USING SELECT MONITOR. 1) Drive the vehicle on a flat road. 2) Stop the vehicle in a straight line. 3) Select "Current data display & Save" on the select monitor. 4) Read yaw rate and lateral G sensor output on the select monitor display. Is the measured value within the specified range?	0±5.25 deg/s	Go to step 4.	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>
4 CHECK OUTPUT OF STEERING ANGLE SENSOR USING SELECT MONITOR. 1) Drive the vehicle on a flat road. 2) Stop the vehicle in a straight line. 3) Select "Current data display & Save" on the select monitor. 4) Read steering angle sensor output on the select monitor display. Is the measured value within the specified range?	0±2.5 deg	Go to step 5.	Perform centering alignment of steering wheel.
5 CHECK YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch to OFF. 2) Connect all connectors. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Go to step 6.	Go to step 7.
6 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.
7 CHECK VDCCM. 1) Turn ignition switch to OFF. 2) Replace yaw rate and lateral G sensor. 3) Erase the memory. 4) Perform inspection mode. 5) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 8.

VDC-231

Vehicle-id:
 SIE-id::AT:DTC 72 Abnormal Yaw Rate Sensor Output
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
8 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	The original yaw rate and lateral G sensor has been faulty.

VDC-232

Vehicle-id:
SIE-id::AT:DTC 72 Abnormal Yaw Rate Sensor Output
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-233

Vehicle-id:
SIE-id::AT:DTC 72 Abnormal Yaw Rate Sensor
Output
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AU:DTC 72 VOLTAGE INPUTTED TO YAW RATE SENSOR EXCEEDS SPECIFICATION.



DIAGNOSIS:

- Faulty yaw rate sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00151

VDC-234

Vehicle-id:
SIE-id: :AU:DTC 72 Voltage Inputted to Yaw Rate Sensor Exceeds Specification.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK POWER SUPPLY OF YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from yaw rate and lateral G sensor. 3) Turn ignition switch to ON. 4) Measure voltage between yaw rate and lateral G sensor and chassis ground. Connector & terminal (R100) No. 3 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Go to step 4.	Go to step 2.
2 CHECK OUTPUT VOLTAGE OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover for VDCCM connector. <Ref. to VDC-19, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 63 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Repair harness between yaw rate and lateral G sensor and VDCCM.	Go to step 3.
3 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in yaw rate and lateral G sensor connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
4 CHECK HARNESS OF YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM and yaw rate and lateral G sensor. Connector & terminal (F87) No. 65 — (R100) No. 4: Is the measured value less than the specified value?	0.5 Ω	Go to step 5.	Repair harness between yaw rate and lateral G sensor and VDCCM.
5 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 65 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 6.	Repair harness between yaw rate and lateral G sensor and VDCCM.
6 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 65 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 7.	Repair harness between yaw rate and lateral G sensor and VDCCM.

VDC-235

Vehicle-id:
 SIE-id::AU:DTC 72 Voltage Inputted to Yaw Rate Sensor Exceeds Specification.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 65 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>	Repair harness between yaw rate and lateral G sensor and VDCCM.

VDC-236

Vehicle-id:
 SIE-id: :AU:DTC 72 Voltage Inputted to Yaw Rate Sensor Exceeds Specification.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-237

Vehicle-id:
SIE-id::AU:DTC 72 Voltage Inputted to Yaw Rate
Sensor Exceeds Specification.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AV:DTC 72 ABNORMAL YAW RATE SENSOR REFERENCE VOLTAGE



DIAGNOSIS:

- Faulty yaw rate sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00151

VDC-238

Vehicle-id:
SIE-id: :AV:DTC 72 Abnormal Yaw Rate Sensor Reference Voltage

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK POWER SUPPLY OF YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from yaw rate and lateral G sensor. 3) Turn ignition switch to ON. 4) Measure voltage between yaw rate and lateral G sensor and chassis ground. Connector & terminal (R100) No. 3 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Go to step 4.	Go to step 2.
2 CHECK OUTPUT VOLTAGE OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover for VDCCM connector. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 63 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Repair harness between yaw rate and lateral G sensor and VDCCM.	Go to step 3.
3 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in yaw rate and lateral G sensor connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
4 CHECK HARNESS OF YAW RATE AND LATERAL G SENSOR. 1) Disconnect connector from VDCCM. 2) Measure resistance between VDCCM and yaw rate and lateral G sensor. Connector & terminal (F87) No. 66 — (R100) No. 1: Is the measured value less than the specified value?	0.5 Ω	Go to step 5.	Repair harness between yaw rate and lateral G sensor and VDCCM.
5 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM and chassis ground. Connector & terminal Does the measured value exceed the specified value? (F87) No. 66 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 6.	Repair harness between yaw rate and lateral G sensor and VDCCM.
6 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 66 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 7.	Repair harness between yaw rate and lateral G sensor and VDCCM.

VDC-239

Vehicle-id:
 SIE-id::AV:DTC 72 Abnormal Yaw Rate Sensor
 Reference Voltage
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 66 — Chassis ground: Is the measured value less than the specified value?	0.5 V	Go to step 8 .	Repair harness between yaw rate and lateral G sensor and VDCCM.
8 CHECK YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch to OFF. 2) Install yaw rate and lateral G sensor to body. 3) Remove VDCCM connector cover. <Ref. to VDC-19, VDCCM Connector Cover.> 4) Connect all connectors. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 66 (+) — No. 64 (-): Is the measured value within the specified range?	2.1 — 2.9 V	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>

VDC-240

Vehicle-id:
 SIE-id: :AV:DTC 72 Abnormal Yaw Rate Reference Voltage
 ~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-241

Vehicle-id:
SIE-id::AV:DTC 72 Abnormal Yaw Rate Sensor
Reference Voltage
~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AW:DTC 72 CHANGE RANGE OF YAW RATE SENSOR SIGNAL IS TOO BIG.



DIAGNOSIS:

- Faulty yaw rate sensor

TROUBLE SYMPTOM:

- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00151

VDC-242

Vehicle-id:
SIE-id: :AW:DTC 72 Change Range of Yaw Rate Sensor Signal is too Big.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK RUNNING FIELD. Was the vehicle driven on surfaces with holes or bumps at high speeds?	Driven.	When driving on surfaces with holes or bumps at high speeds, VDCCM sometimes records trouble codes in memory.	Go to step 2.
2 CHECK INSTALLATION OF YAW RATE AND LATERAL G SENSOR. Check installation of yaw rate and lateral G sensor. Is the yaw rate and lateral G sensor fixed securely?	Fixed securely.	Go to step 3.	Install yaw rate and lateral G sensor securely.
3 CHECK POWER SUPPLY OF YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch OFF. 2) Disconnect connector from yaw rate and lateral G sensor. 3) Turn ignition switch to ON. 4) Measure voltage between yaw rate and lateral G sensor and chassis ground. Connector & terminal (R100) No. 3 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Go to step 4.
4 CHECK OUTPUT VOLTAGE OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover for VDCCM connector. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 63 — Chassis ground: Is the measured value within the specified range?	10 — 15 V	Repair harness between yaw rate and lateral G sensor and VDCCM.	Go to step 5.
5 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in yaw rate and lateral G sensor connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
6 CHECK GROUND CIRCUIT OF YAW RATE AND LATERAL G SENSOR. Measure resistance between yaw rate and lateral G sensor and chassis ground. Connector & terminal (R100) No. 6 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Go to step 9.	Go to step 7.

VDC-243

Vehicle-id:
 SIE-id::AW:DTC 72 Change Range of Yaw Rate
 Sensor Signal is too Big.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK GROUND CIRCUIT OF VDCCM. 1) Disconnect connector from VDCCM. 2) Remove cover from VDCCM connector. <Ref. to VDC-19, VDCCM Connector Cover.> 3) Connect connector to VDCCM. 4) Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 64 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Repair harness between yaw rate and lateral G sensor and VDCCM.	Go to step 8.
8 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in VDCCM connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
9 CHECK HARNESS OF YAW RATE AND LATERAL G SENSOR. 1) Disconnect connector from VDCCM. 2) Measure resistance between VDCCM and yaw rate and lateral G sensor. Connector & terminal (F87) No. 65 — (R100) No. 4: (F87) No. 66 — (R100) No. 1: (F87) No. 67 — (R100) No. 2: Is the measured value less than the specified value?	0.5 Ω	Go to step 10.	Repair harness between yaw rate and lateral G sensor and VDCCM.
10 CHECK GROUND SHORT OF HARNESS. Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 65 — Chassis ground: (F87) No. 66 — Chassis ground: (F87) No. 67 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 11.	Repair harness between yaw rate and lateral G sensor and VDCCM.
11 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 65 (+) — Chassis ground (-): (F87) No. 66 (+) — Chassis ground (-): (F87) No. 67 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 12.	Repair harness between yaw rate and lateral G sensor and VDCCM.
12 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCCM and chassis ground. Connector & terminal (F87) No. 65 — Chassis ground: (F87) No. 66 — Chassis ground: (F87) No. 67 — Chassis ground: Is the measured value less than the specified value?	0.5 V	Go to step 13.	Repair harness between yaw rate and lateral G sensor and VDCCM.

VDC-244

Vehicle-id:
 SIE-id::AW:DTC 72 Change Range of Yaw Rate Sensor Signal is too Big.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
13 CHECK YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch to OFF. 2) Install yaw rate and lateral G sensor to body. 3) Connect all connectors. 4) Turn ignition switch to ON. 5) Measure voltage between yaw rate and lateral G sensor connector terminals. Connector & terminal (F87) No. 66 (+) — No. 64 (-): Is the measured value within the specified range?	2.1 — 2.9 V	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>

VDC-245

Vehicle-id:
 SIE-id::AW:DTC 72 Change Range of Yaw Rate Sensor Signal is too Big.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

AX:DTC 73 LATERAL G SENSOR OFFSET IS TOO BIG.

NOTE:

For diagnostic procedure, refer to DTC 73. <Ref. to VDC-248, DTC 73 EXCESSIVE LATERAL G SENSOR SIGNAL, Diagnostics Chart with Select Monitor.>

AY:DTC 73 ABNORMAL LATERAL G SENSOR OUTPUT

NOTE:

For diagnostic procedure, refer to DTC 73. <Ref. to VDC-248, DTC 73 EXCESSIVE LATERAL G SENSOR SIGNAL, Diagnostics Chart with Select Monitor.>

AZ:DTC 73 CHANGE RANGE OF LATERAL G SENSOR IS TOO BIG.

NOTE:

For diagnostic procedure, refer to DTC 73. <Ref. to VDC-248, DTC 73 EXCESSIVE LATERAL G SENSOR SIGNAL, Diagnostics Chart with Select Monitor.>

VDC-246

Vehicle-id:
SIE-id: :AX:DTC 73 Lateral G Sensor Offset is too Big.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-247

Vehicle-id:
SIE-id::AZ:DTC 73 Change Range of Lateral G
Sensor is too Big.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BA:DTC 73 EXCESSIVE LATERAL G SENSOR SIGNAL



DIAGNOSIS:

- Faulty lateral G sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



(F87)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00151

VDC-248

Vehicle-id:
SIE-id: :BA:DTC 73 Excessive Lateral G Sensor Signal

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK INSTALLATION OF YAW RATE AND LATERAL G SENSOR. Check installation of yaw rate and lateral G sensor. Is the yaw rate and lateral G sensor fixed securely?	Fixed securely.	Go to step 2.	Install yaw rate and lateral G sensor securely.
2 CHECK OUTPUT OF LATERAL G SENSOR USING SELECT MONITOR. 1) Stop the vehicle on a flat road. 2) Select "Current data display & Save" on the select monitor. 3) Read yaw rate and lateral G sensor output on the select monitor display. Is the measured value within the specified range?	2.3 — 2.7 V	Go to step 3.	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>
3 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connector between VDCCM and yaw rate and lateral G sensor?	There is poor contact.	Repair connector.	Go to step 4.
4 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 5.
5 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-249

Vehicle-id:
 SIE-id: :BA:DTC 73 Excessive Lateral G Signal

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BB:DTC 73 VOLTAGE INPUTTED TO LATERAL G SENSOR EXCEEDS SPECIFICATION.



DIAGNOSIS:

- Faulty lateral G sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



F87

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83

VDC00151

VDC-250

Vehicle-id:
SIE-id: :BB:DTC 73 Voltage Inputted to Lateral G Sensor Exceeds Specification.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK OUTPUT OF YAW RATE AND LATERAL G SENSOR USING SELECT MONITOR. 1) Stop the vehicle on a flat road. 2) Select "Current data display & Save" on the select monitor. 3) Read yaw rate and lateral G sensor output on the select monitor display. Is the measured value within the specified range?	2.3 — 2.7 V	Go to step 2.	Go to step 5.
2 CHECK POOR CONTACT IN CONNECTORS. Turn ignition switch to OFF. Is there poor contact in connector between VDCCM and yaw rate and lateral G sensor?	There is poor contact.	Repair connector.	Go to step 3.
3 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 4.
4 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.
5 CHECK INPUT VOLTAGE OF YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch to OFF. 2) Remove console box. 3) Disconnect connector from yaw rate and lateral G sensor. 4) Turn ignition switch to ON. 5) Measure voltage between yaw rate and lateral G sensor connector terminals. Connector & terminal (R100) No. 3 (+) — No. 6 (-): Is the measured value within the specified range?	10 — 15 V	Go to step 6.	Repair harness/connector between yaw rate and lateral G sensor and VDCCM.
6 CHECK YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch to OFF. 2) Measure resistance between yaw rate and lateral G sensor terminals. Terminals No. 3 — No. 5: Is the measured value within the specified range?	4.3 — 4.9 kΩ	Go to step 7.	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>

VDC-251

Vehicle-id:
 SIE-id::BB:DTC 73 Voltage Inputted to Lateral G Sensor Exceeds Specification.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK OPEN CIRCUIT IN YAW RATE AND LATERAL G SENSOR OUTPUT HARNESS AND GROUND HARNESS. 1) Connect connector to yaw rate and lateral G sensor. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCCM connector terminals. Connector & terminal (F87) No. 70 — No. 64: Is the measured value within the specified range?	4.3 — 4.9 kΩ	Go to step 8.	Repair harness/connector between yaw rate and lateral G sensor and VDCCM.
8 CHECK GROUND SHORT IN YAW RATE AND LATERAL G SENSOR HARNESS. 1) Disconnect connector from yaw rate and lateral G sensor. 2) Measure resistance between VDCCM connector and chassis ground. Connector & terminal (F87) No. 63 — Chassis ground: (F87) No. 70 — Chassis ground: (F87) No. 64 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 9.	Repair harness between yaw rate and lateral G sensor and VDCCM.
9 CHECK YAW RATE AND LATERAL G SENSOR. 1) Turn ignition switch to OFF. 2) Remove yaw rate and lateral G sensor from vehicle. 3) Connect connector to yaw rate and lateral G sensor. 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between yaw rate and lateral G sensor connector terminals. Connector & terminal (R100) No. 5 (+) — No. 6 (-): Is the measured value within the specified range when yaw rate and lateral G sensor is horizontal?	2.3 — 2.7 V	Go to step 10.	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>
10 CHECK YAW RATE AND LATERAL G SENSOR. Measure voltage between yaw rate and lateral G sensor connector terminals. Connector & terminal (R100) No. 5 (+) — No. 6 (-): Is the measured value within the specified range when yaw rate and lateral G sensor is inclined 90° to left?	3.3 — 3.7 V	Go to step 11.	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>
11 CHECK YAW RATE AND LATERAL G SENSOR. Measure voltage between yaw rate and lateral G sensor connector terminals. Connector & terminal (R100) No. 5 (+) — No. 6 (-): Is the measured value within the specified range when yaw rate and lateral G sensor is inclined 90° to right?	1.3 — 1.7 V	Go to step 12.	Replace yaw rate and lateral G sensor. <Ref. to VDC-22, Yaw Rate and Lateral G Sensor.>

VDC-252

Vehicle-id:
 SIE-id: :BB:DTC 73 Voltage Inputted to Lateral G Sensor Exceeds Specification.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
12 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector between VDCCM and yaw rate and lateral G sensor?	There is poor contact.	Repair connector.	Go to step 13 .
13 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same pattern.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 14 .
14 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-253

Vehicle-id:
 SIE-id::BB:DTC 73 Voltage Inputted to Lateral G Sensor Exceeds Specification.

~

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BC:DTC 74 VOLTAGE INPUTTED TO PRESSURE SENSOR 1 EXCEEDS SPECIFICATION. (PRIMARY PRESSURE SENSOR)


DIAGNOSIS:

- Faulty primary pressure sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC-254

Vehicle-id:
SIE-id: :BC:DTC 74 Voltage Inputted to Pressure Sensor 1 Exceeds Specification. (Primary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GROUND CIRCUIT OF PRESSURE SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector (F91) from VDCH/U. 3) Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 15 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Go to step 4.	Go to step 2.
2 CHECK GROUND CIRCUIT OF VDCCM. 1) Disconnect connector from VDCCM. 2) Remove cover from VDCCM. <Ref. to VDC-19, VDCCM Connector Cover.> 3) Connect connector to VDCCM. 4) Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 76 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Replace harness between VDCH/U and VDCCM.	Go to step 3.
3 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in VDCCM connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
4 CHECK POWER SUPPLY OF PRESSURE SENSOR. NOTE: When this inspection is carried out, DTC 51 ABNORMAL VALVE RELAY is memorized, but this does not indicate valve relay malfunction. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector terminals. Connector & terminal (F91) No. 16 (+) — No. 15 (-): Is the measured value within the specified range?	4.75 — 5.25 V	Go to step 7.	Go to step 5.
5 CHECK POWER SUPPLY OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover from VDCCM. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 78 (+) — No. 76 (-): Is the measured value within the specified range?	4.75 — 5.25 V	Repair harness between VDCH/U and VDCCM.	Go to step 6.
6 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in VDCCM connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-255

Vehicle-id:
 SIE-id::BC:DTC 74 Voltage Inputted to Pressure Sensor 1 Exceeds Specification. (Primary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 8.	Repair harness between VDCH/U and VDCCM.
8 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 9.	Repair harness between VDCH/U and VDCCM.
9 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 10.	Repair harness between VDCH/U and VDCCM.
10 CHECK INPUT VOLTAGE OF PRESSURE SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover from VDCCM. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Connect all connectors. 6) Turn ignition switch to ON. 7) Do not depress brake pedal. 8) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 77 (+) — No. 76 (-): Is the measured value within the specified range?	0.48 — 0.72 V	Go to step 11.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
11 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector between VDCCM and pressure sensor?	There is poor contact.	Repair connector.	Go to step 12.
12 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 13.
13 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-256

Vehicle-id:
 SIE-id: :BC:DTC 74 Voltage Inputted to Pressure Sensor 1 Exceeds Specification. (Primary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

MEMO:

VDC-257

Vehicle-id:
SIE-id::BC:DTC 74 Voltage Inputted to Pressure
Sensor 1 Exceeds Specification. (Primary Pressure
Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BD:DTC 74 VOLTAGE INPUTTED TO PRESSURE SENSOR 2 EXCEEDS SPECIFICATION. (SECONDARY PRESSURE SENSOR)


DIAGNOSIS:

- Faulty secondary pressure sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC00152

VDC-258

Vehicle-id:
SIE-id: :BD:DTC 74 Voltage Inputted to Pressure Sensor 2 Exceeds Specification. (Secondary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GROUND CIRCUIT OF PRESSURE SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector (F91) from VDCH/U. 3) Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 15 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Go to step 4.	Go to step 2.
2 CHECK GROUND CIRCUIT OF VDCCM. 1) Disconnect connector from VDCCM. 2) Remove cover from VDCCM. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 3) Connect connector to VDCCM. 4) Measure resistance between VDCCM and chassis ground. Connector & terminal (F87) No. 76 — Chassis ground: Is the measured value less than the specified value?	0.5 Ω	Replace harness between VDCH/U and VDCCM.	Go to step 3.
3 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in VDCCM connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>
4 CHECK POWER SUPPLY OF PRESSURE SENSOR. NOTE: When this inspection is carried out, DTC 51 ABNORMAL VALVE RELAY is memorized, but this does not indicate valve relay malfunction. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector terminals. Connector & terminal (F91) No. 16 (+) — No. 15 (-): Is the measured value within the specified range?	4.75 — 5.25 V	Go to step 7.	Go to step 5.
5 CHECK POWER SUPPLY OF VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover from VDCCM. <Ref. to VDC-19, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Turn ignition switch to ON. 6) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 78 (+) — No. 76 (-): Is the measured value within the specified range?	4.75 — 5.25 V	Repair harness between VDCH/U and VDCCM.	Go to step 6.
6 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in VDCCM connector?	There is poor contact.	Repair or replace VDCCM connector.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>

VDC-259

Vehicle-id:
 SIE-id::BD:DTC 74 Voltage Inputted to Pressure Sensor 2 Exceeds Specification. (Secondary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 14 — Chassis ground: Does the measured value exceed the specified value?	1 MΩ	Go to step 8.	Repair harness between VDCH/U and VDCCM.
8 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 14 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 9.	Repair harness between VDCH/U and VDCCM.
9 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 (+) — Chassis ground (-): (F91) No. 14 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 10.	Repair harness between VDCH/U and VDCCM.
10 CHECK INPUT VOLTAGE OF PRESSURE SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover from VDCCM. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Connect all connectors. 6) Turn ignition switch to ON. 7) Do not depress brake pedal. 8) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 36 (+) — No. 76 (-): Is the measured value within the specified range?	0.48 — 0.72 V	Go to step 11.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
11 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector between VDCCM and pressure sensor?	There is poor contact.	Repair connector.	Go to step 12.
12 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 13.
13 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-260

Vehicle-id:
 SIE-id: :BD:DTC 74 Voltage Inputted to Pressure Sensor 2 Exceeds Specification. (Secondary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BE:DTC 74 PRESSURE SENSOR 1 OFFSET IS TOO BIG. (PRIMARY PRESSURE SENSOR)

NOTE:

For diagnostic procedure, refer to DTC 74. <Ref. to VDC-262, DTC 74 PRESSURE SENSOR 2 OFFSET IS TOO BIG. (SECONDARY PRESSURE SENSOR), Diagnostics Chart with Select Monitor.>

VDC-261

Vehicle-id:
SIE-id: :BE:DTC 74 Pressure Sensor 1 Offset is too Big. (Primary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BF:DTC 74 PRESSURE SENSOR 2 OFFSET IS TOO BIG. (SECONDARY PRESSURE SENSOR)


DIAGNOSIS:

- Faulty pressure sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC-262

Vehicle-id:
SIE-id::BF:DTC 74 Pressure Sensor 2 Offset is too Big. (Secondary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK DRIVING TECHNIC. Check the driver's technic. Are the accelerator and brake pedals depressed simultaneously while driving?	Depressed.	The VDC is normal. Erase the diagnostic trouble code. NOTE: Driving the vehicle with both the accelerator pedal and brake pedal depressed may store a diagnostic trouble code in the memory.	Go to step 2.
2 CHECK OUTPUT OF PRESSURE SENSOR USING SELECT MONITOR. 1) Select "Current data display & Save" on the select monitor. 2) Read pressure sensor output on the select monitor display. Is the measured value within the specified range when brake pedal is depressed?	0.48 — 0.72 V	Go to step 3.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
3 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 4.
4 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-263

Vehicle-id:
 SIE-id: :BF:DTC 74 Pressure Sensor 2 Offset is too Big. (Secondary Pressure Sensor)

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

BG:DTC 74 DIFFERENTIAL PRESSURE OF PRESSURE SENSOR IS TOO BIG.


DIAGNOSIS:

- Faulty pressure sensor

TROUBLE SYMPTOM:

- ABS does not operate.
- VDC does not operate.

WIRING DIAGRAM:



VDC-264

Vehicle-id:
SIE-id::BG:DTC 74 Differential Pressure of Pressure
Sensor is too Big.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
1 CHECK GROUND SHORT OF HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Disconnect connector (F91) from VDCH/U. 4) Measure resistance between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 — Chassis ground: (F91) No. 14 — Chassis ground: Does the measured value exceed the specified value?	1 M Ω	Go to step 2.	Repair harness between VDCH/U and VDCCM.
2 CHECK BATTERY SHORT OF HARNESS. Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 (+) — Chassis ground (-): (F91) No. 14 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 3.	Repair harness between VDCH/U and VDCCM.
3 CHECK BATTERY SHORT OF HARNESS. 1) Turn ignition switch to ON. 2) Measure voltage between VDCH/U connector and chassis ground. Connector & terminal (F91) No. 13 (+) — Chassis ground (-): (F91) No. 14 (+) — Chassis ground (-): Is the measured value less than the specified value?	0.5 V	Go to step 4.	Repair harness between VDCH/U and VDCCM.
4 CHECK INPUT VOLTAGE OF PRESSURE SENSOR. 1) Turn ignition switch to OFF. 2) Disconnect connector from VDCCM. 3) Remove cover from VDCCM. <Ref. to VDC-19, REMOVE, VDCCM Connector Cover.> 4) Connect connector to VDCCM. 5) Connect all connectors. 6) Turn ignition switch to ON. 7) Do not depress brake pedal. 8) Measure voltage between VDCCM connector terminals. Connector & terminal (F87) No. 77 (+) — No. 76 (-): (F87) No. 36 (+) — No. 76 (-): Is the measured value within the specified range?	0.48 — 0.72 V	Go to step 5.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
5 CHECK BRAKE FLUID LEAKAGE. Inspect fluid leakage between brake master cylinder and VDCH/U. Does brake fluid leak?	Fluid leaks.	Retighten or replace.	Go to step 6.
6 CHECK BRAKE MASTER CYLINDER. Inspect brake master cylinder hydraulic pressure. <Ref. to BR-29, OPERATION CHECK (WITH GAUGES), INSPECTION, Brake Booster.> Is hydraulic pressure normal?	Normal.	Go to step 7.	Replace master cylinder.

VDC-265

Vehicle-id:
 SIE-id::BG:DTC 74 Differential Pressure of Pressure Sensor is too Big.

DIAGNOSTICS CHART WITH SELECT MONITOR

VDC (DIAGNOSTICS)

Step	Value	Yes	No
7 CHECK BRAKE PEDAL STROKE. Measure the stroke between non-forced pedal position and forced pedal position with 50 kg (110 lb). Is the measured value less than the specified value?	95 mm (3.74 in)	Go to step 8.	Perform bleeding from brake system.
8 CHECK INPUT VOLTAGE OF PRESSURE SENSOR. 1) Depress the brake pedal with 50 kg (110 lb). 2) Measure voltage between VDCCM connector terminals. Connector & terminal A (F87) No. 77 (+) — No. 76 (-): B (F87) No. 36 (+) — No. 76 (-): Does the voltage difference between A and B exceed the specified value?	0.2 V	Go to step 9.	Replace VDCH/U. <Ref. to VDC-8, VDC Control Module (VDCCM).>
9 CHECK POOR CONTACT IN CONNECTORS. Is there poor contact in connector between VDCCM and pressure sensor?	There is poor contact.	Repair connector.	Go to step 10.
10 CHECK VDCCM. 1) Connect all connectors. 2) Erase the memory. 3) Perform inspection mode. 4) Read out the diagnostic trouble code. Is the same diagnostic trouble code as in the current diagnosis still being output?	Same DTC indicated.	Replace VDCCM. <Ref. to VDC-8, VDC Control Module (VDCCM).>	Go to step 11.
11 CHECK ANY OTHER DIAGNOSTIC TROUBLE CODES APPEARANCE. Are other diagnostic trouble codes being output?	Other DTC indicated.	Proceed with the diagnosis corresponding to the diagnostic trouble code.	A temporary poor contact.

VDC-266

Vehicle-id:
 SIE-id::BG:DTC 74 Differential Pressure of Pressure Sensor is too Big.