


IGNITION COIL AND IGNITOR ASSEMBLY

IGNITION


3. Ignition Coil and Ignitor Assembly

A: REMOVAL

- 1) Disconnect battery ground cable.




- 2) Disconnect spark plug cords from ignition coil and ignitor assembly.
- 3) Disconnect connector from ignition coil and ignitor assembly.



- (A) Spark plug cord
- (B) Connector
- (C) Ignition coil and ignitor ASSY

- 4) Remove ignition coil and ignitor assembly.



B: INSTALLATION


- 1) Install in the reverse order of removal.

Tightening torque:

6.4 N·m (0.65 kgf-m, 4.7 ft-lb)

CAUTION:

Be sure to connect spark plug cords to their proper positions. Failure to do so will damage unit.



C: INSPECTION

Using accurate tester, inspect the following items, and replace if defective.

- 1) Primary resistance
- 2) Secondary coil resistance

CAUTION:

If the resistance is extremely low, this indicates the presence of a short-circuit.

Specified resistance:


[Primary side]

Between terminal No. 1 and No. 2

$0.73 \Omega \pm 10\%$

Between terminal No. 2 and No. 4

$0.73 \Omega \pm 10\%$



IGNITION COIL AND IGNITOR ASSEMBLY

IGNITION


[Secondary side]

Between (A) and (B)

12.8 kΩ±15%

Between (C) and (D)

12.8 kΩ±15%



3) Insulation between primary terminal and case:
10 MΩ or more.

IG(H4SO)-8