

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

4AT(H4SO)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	4
3. General Description	5
4. Electrical Components Location.....	8
5. Transmission Control Module (TCM) I/O Signal	13
6. Subaru Select Monitor.....	27
7. Read Diagnostic Trouble Code (DTC)	30
8. Inspection Mode	32
9. Clear Memory Mode.....	33
10. AT OIL TEMP Warning Light Display.....	34
11. List of Diagnostic Trouble Code (DTC)	35
12. Diagnostic Procedure for AT OIL TEMP Warning Light	37
13. Diagnostic Procedure for Select Monitor Communication.....	46
14. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	50
15. Diagnostic Procedure without Diagnostic Trouble Code (DTC)	142
16. Symptom Related Diagnostic.....	174

BASIC DIAGNOSTIC PROCEDURE

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

Step	Check	Yes	No
1 CHECK PRE-INSPECTION. 1) Ask the customer when and how trouble occurred using interview checklist. <Ref. to 4AT(H4SO)-4, Check List for Interview.> 2) Before performing the diagnosis, inspect following items which might influence the AT problems. •General inspection <Ref. to 4AT(H4SO)-5, INSPECTION, General Description.> •Make sure that each harness connector connections are tight. •Visually inspect the harness and check for any damage. •Oil leak •Stall speed test <Ref. to 4AT-34, Stall Test.> •Line pressure test <Ref. to 4AT-36, Line Pressure Test.> •Transfer clutch pressure test <Ref. to 4AT-38, Transfer Clutch Pressure Test.> •Time lag test <Ref. to 4AT-35, Time Lag Test.> •Road test <Ref. to 4AT-33, Road Test.> •Inhibitor switch <Ref. to 4AT-51, Inhibitor Switch.>	Is the unit that might influence AT problem normal?	Go to step 2.	Repair or replace each item.
2 CHECK AT OIL TEMP WARNING LIGHT. Turn the ignition switch to ON.	Does the AT OIL TEMP warning light illuminate?	Go to step 4.	Go to step 3.
3 CHECK AT OIL TEMP WARNING LIGHT. 1) Turn the ignition switch to OFF. 2) Repair the AT OIL TEMP warning light circuit or power supply and ground line circuit. <Ref. to 4AT(H4SO)-37, Diagnostic Procedure for AT OIL TEMP Warning Light.> 3) Turn the ignition switch to ON.	Is the AT OIL TEMP warning light illuminate?	Go to step 4.	Go to step 5.
4 CHECK INDICATION OF DTC. Calling up the DTC. Without Subaru Select Monitor <Ref. to 4AT(H4SO)-30, WITHOUT SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code (DTC).> With Subaru Select Monitor <Ref. to 4AT(H4SO)-31, WITH SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code (DTC).> NOTE: If the communication function of select monitor cannot be executed normally, check the communication circuit. <Ref. to 4AT(H4SO)-46, COMMUNICATION FOR INITIALIZING IMPOSSIBLE, Diagnostic Procedure for Select Monitor Communication.>	Is the DTC displayed?	Go to step 6. NOTE: Record all DTC.	Go to step 5.

BASIC DIAGNOSTIC PROCEDURE

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>5 PERFORM THE GENERAL DIAGNOSTICS.</p> <p>1) Inspect using “Diagnostic Procedure without DTC”. <Ref. to 4AT(H4SO)-142, Diagnostic Procedure without Diagnostic Trouble Code (DTC).></p> <p>2) Inspect using “Symptom Related Diagnostic”. <Ref. to 4AT(H4SO)-174, Symptom Related Diagnostic.></p> <p>3) Perform the clear memory mode. Without Subaru Select Monitor <Ref. to 4AT(H4SO)-33, WITH SUBARU SELECT MONITOR, OPERATION, Clear Memory Mode.> With Subaru Select Monitor <Ref. to 4AT(H4SO)-33, WITHOUT SUBARU SELECT MONITOR, OPERATION, Clear Memory Mode.></p> <p>4) Perform the inspection mode. <Ref. to 4AT(H4SO)-32, Inspection Mode.></p> <p>5) Calling up the DTC. Without Subaru Select Monitor <Ref. to 4AT(H4SO)-30, WITHOUT SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code (DTC).> With Subaru Select Monitor <Ref. to 4AT(H4SO)-31, WITH SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code (DTC).></p>	Is the DTC displayed?	Complete the diagnosis.	Go to step 6.
<p>6 PERFORM THE DIAGNOSIS.</p> <p>1) Inspect using “Diagnostics Chart with DTC”. <Ref. to 4AT(H4SO)-50, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></p> <p>NOTE: For DTC table, refer to “List of Diagnostic Trouble Code (DTC)”. <Ref. to 4AT(H4SO)-35, List of Diagnostic Trouble Code (DTC).></p> <p>2) Repair the trouble cause.</p> <p>3) Perform the clear memory mode. Without Subaru Select Monitor <Ref. to 4AT(H4SO)-33, WITH SUBARU SELECT MONITOR, OPERATION, Clear Memory Mode.> With Subaru Select Monitor <Ref. to 4AT(H4SO)-33, WITHOUT SUBARU SELECT MONITOR, OPERATION, Clear Memory Mode.></p> <p>4) Perform the inspection mode. <Ref. to 4AT(H4SO)-32, Inspection Mode.></p> <p>5) Calling up the DTC. Without Subaru Select Monitor <Ref. to 4AT(H4SO)-30, WITHOUT SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code (DTC).> With Subaru Select Monitor <Ref. to 4AT(H4SO)-31, WITH SUBARU SELECT MONITOR, OPERATION, Read Diagnostic Trouble Code (DTC).></p>	Is the DTC displayed?	Complete the diagnosis.	Inspect using “Diagnostics Procedure with Diagnostic Trouble Code (DTC)”. <Ref. to 4AT(H4SO)-50, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

GENERAL DESCRIPTION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

3. General Description

A: CAUTION

- **Supplemental Restraint System “Airbag”**

The airbag system wiring harness is routed near the transmission control module (TCM).

CAUTION:

- All airbag system wiring harness and connectors are colored yellow. Do not use an electrical test equipment on these circuit.
- Be careful not to damage the airbag system wiring harness when performing diagnostics and servicing the TCM.
- **Measurement**

When measuring the voltage and resistance of ECM, TCM or each sensor, use a tapered pin with diameter of less than 0.64 mm (0.025 in) in order to avoid poor contact. Do not insert the pin more than 0.65 mm (0.256 in).

B: INSPECTION

1. BATTERY

Measure the battery voltage and specific gravity of electrolyte.

Standard voltage: 12 V or more

Specific gravity: Above 1.260


2. TRANSMISSION GROUND

Make sure that the ground terminal bolt is tightened securely.

- **Chassis side**


Tightening torque:

13 N·m (1.3 kgf-m, 9.4 ft-lb)



3. ATF LEVEL


Make sure that ATF level is in the specification. <Ref. to 4AT-31, INSPECTION, Automatic Transmission Fluid.>



- (A) Level gauge
- (B) “HOT” side
- (C) Upper level
- (D) Lower level
- (E) “COLD” side

4. FRONT DIFFERENTIAL OIL LEVEL

Make sure that the front differential oil level is in specification. <Ref. to 4AT-32, INSPECTION, Differential Gear Oil.>



- (A) Upper level
- (B) Lower level

GENERAL DESCRIPTION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)


5. OPERATION OF SHIFT SELECT LEVER

Make sure there is no abnormal noise, dragging or contact pattern in each select lever range.


WARNING:

Stop the engine while checking operation of selector lever.

- Without SPORT shift



- With SPORT shift





GENERAL DESCRIPTION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

C: PREPARATION TOOL

1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST24082AA230	24082AA230	CARTRIDGE	Troubleshooting for electrical systems.
 ST22771AA030	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems.

2. GENERAL PURPOSE TOOLS

TOOL NAME	REMARKS
Circuit Tester	Used for measuring resistance, voltage and ampere.
Oscilloscope	Used for measuring sensor.


ELECTRICAL COMPONENTS LOCATION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

4. Electrical Components Location

A: LOCATION

1. CONTROL MODULE



AT-00624


- (1) Engine control module (ECM)
- (2) AT OIL TEMP warning light (AT diagnostic indicator light)
- (3) Transmission control module (TCM) (Without VDC system and SPORT shift)

- (4) Transmission control module (TCM) (With VDC system or SPORT shift)
- (5) Data link connector

- (6) Vehicle dynamic control module (With VDC system)

ELECTRICAL COMPONENTS LOCATION


AUTOMATIC TRANSMISSION (DIAGNOSTICS)







ELECTRICAL COMPONENTS LOCATION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

2. SENSOR




- | | | |
|---|---|--|
| (1) Throttle position sensor
(Except 2.5 L U5 model) | (5) Rear vehicle speed sensor
(Without VDC system and SPORT shift) | (8) ATF temperature sensor
(Non-TURBO model) |
| (2) Throttle position sensor
(3.0 L model) | (6) Rear vehicle system sensor (With
VDC system or SPORT shift) | (9) Dropping resistor (With VDC system
or SPORT shift) |
| (3) Front vehicle speed sensor | (7) Torque converter turbine speed
signal | (10) Accelerator pedal position sensor
(2.5 L U5 model) |
| (4) Inhibitor switch | | |



ELECTRICAL COMPONENTS LOCATION


AUTOMATIC TRANSMISSION (DIAGNOSTICS)




AT-00633




AT-00637



AT-00634



AT-00638




AT-01663

SUBARU

ELECTRICAL COMPONENTS LOCATION


AUTOMATIC TRANSMISSION (DIAGNOSTICS)

3. SOLENOID




AT-00639

- | | | |
|---------------------------------|--------------------------------|---|
| (1) Solenoid 1 | (4) Low clutch timing solenoid | (7) 2-4 brake timing solenoid |
| (2) Solenoid 2 | (5) Lock-up duty solenoid | (8) Transfer duty solenoid |
| (3) Line pressure duty solenoid | (6) 2-4 brake duty solenoid | (9) SPORT shift solenoid (With SPORT shift) |



AT-00640



AT-00335


TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

5. Transmission Control Module (TCM) I/O Signal

A: ELECTRICAL SPECIFICATION

1. WITH VDC SYSTEM OR SPORT SHIFT



AT-00568

Check with ignition switch ON.						
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)	
Back-up power supply	B56	1	Ignition switch OFF	10 — 13	—	
Ignition power supply	B54	23	Ignition switch ON (with engine OFF)	10 — 13	—	
	B54	24				
Inhibitor switch	"P" range switch	B55	1	Select lever in "P" range	Less than 1	—
				Select lever in any other than "P" range (except "N" range)	More than 8	
	"N" range switch	B55	14	Select lever in "N" range	Less than 1	—
				Select lever in any other than "N" range (except "P" range)	More than 8	
	"R" range switch	B55	3	Select lever in "R" range	Less than 1	—
				Select lever in any other than "R" range	More than 8	
	"D" range switch	B55	4	Select lever in "D" range	Less than 1	—
				Select lever in any other than "D" range	More than 8	
	"3" range switch	B55	5	Select lever in "3" range	Less than 1	—
				Select lever in any other than "3" range	More than 8	
	"2" range switch	B55	6	Select lever in "2" range	Less than 1	—
				Select lever in any other than "2" range	More than 8	
	"1" range switch	B55	7	Select lever in "1" range	Less than 1	—
				Select lever in any other than "1" range	More than 8	
Brake switch	B55	12	Brake pedal depressed.	More than 10.5	—	
			Brake pedal released.	Less than 1		

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Check with ignition switch ON.					
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
AT OIL TEMP warning light	B56	10	Light ON	Less than 1	—
			Light OFF	More than 9	
Throttle position sensor (Except U5 model)	B54	3	Throttle fully closed.	0.2 — 1.0	—
			Throttle fully open.	4.2 — 4.7	
Throttle position sensor power supply (Except U5 model)	B54	2	Ignition switch ON (with engine OFF)	4.8 — 5.3	—
Accelerator pedal position sensor (U5 model)	B54	3	Throttle fully closed	0.2 — 1.0	—
			Throttle fully open.	4.2 — 4.7	
Accelerator pedal position sensor supply (U5 model)	B54	2	Ignition switch ON	4.8 — 5.3	—
ATF temperature sensor	B54	11	ATF temperature 20°C (68°F)	1.6 — 2.0	2.1 k — 2.9 k
			ATF temperature 80°C (176°F)	0.4 — 0.9	275 — 375
Rear vehicle speed sensor	B55	24	Vehicle stopped.	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Front vehicle speed sensor	B55	18	Vehicle stopped.	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Torque converter turbine speed sensor	B55	8	Engine idling after warm-up. (D range)	0	450 — 650
			Engine idling after warm-up. (N range)	More than 1 (AC range)	
Vehicle speed output signal	B56	17	Vehicle speed at most 10 km/h (6 MPH)	Less than 1 ← → More than 4	—
Engine speed signal (Except U5 model)	B55	17	Ignition switch ON (with engine OFF)	More than 10.5	—
			Ignition switch ON (with engine ON)	8 — 11	
Cruise set signal	B55	22	When cruise control is set. (SET lamp ON)	Less than 1	—
			When cruise control is not set. (SET lamp OFF)	More than 6.5	
Torque control signal 1 (Except U5 model)	B56	5	Ignition switch ON (with engine ON)	More than 4	—
Torque control signal 2 (Except U5 model)	B56	14	Ignition switch ON (with engine ON)	More than 4	—
Torque control cut signal (Except U5 model)	B55	10	Ignition switch ON	8	—
Mass air flow signal (Except U5 model)	B54	1	Engine idling after warm-up.	0.9 — 1.4	—
Shift solenoid 1	B54	22	1st or 4th gear	More than 9	10 — 16
			2nd or 3rd gear	Less than 1	
Shift solenoid 2	B54	5	1st or 2nd gear	More than 9	10 — 16
			3rd or 4th gear	Less than 1	
Line pressure duty solenoid	B54	9	Ignition switch ON (with engine OFF). Throttle fully closed after warm-up.	1.5 — 4.0	2.0 — 4.5
			Ignition switch ON (with engine OFF). Throttle fully open after warm-up.	Less than 0.5	
Lock-up duty solenoid	B54	7	When lock up occurs.	More than 8.5	10 — 17
			When lock up is released.	Less than 0.5	

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Check with ignition switch ON.					
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
VDC communication signal + (With VDC)	B56	9	Ignition switch ON	(+) — (-) Pulse signal	—
VDC communication signal – (With VDC)	B56	18		(+) — (-) Pulse signal	—
CAN communication signal + (U5 model)	B56	9	Ignition switch ON	Pulse signal	—
CAN communication signal – (U5 model)	B56	18		Pulse signal	—
Transfer duty solenoid	B54	6	Throttle fully closed.	More than 8.5	10 — 17
			Throttle fully open.	Less than 0.5	
2-4 brake duty solenoid	B54	18	Throttle fully closed (with engine OFF) after warm-up.	1.5 — 5.0	2.0 — 4.5
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
2-4 brake timing solenoid	B54	16	1st gear	Less than 1	10 — 16
			3rd gear	More than 9	
Low clutch timing solenoid	B54	15	2nd gear	Less than 1	10 — 16
			4th gear	More than 9	
ABS signal (Without VDC system)	B55	21	ABS switch ON	Less than 1	—
			ABS switch OFF	6.5 — 15	—
Sensor ground line 1	B54	20	—	0	Less than 1
Sensor ground line 2	B55	9	—	0	Less than 1
System ground line	B56	19	—	0	Less than 1
	B54	21			
Sensor ground line 3	B54	10	—	0	Less than 1
Sensor ground line 4	B54	19	—	0	Less than 1
AT diagnosis signal	B56	21	Ignition switch ON	Less than 1 ← → More than 4	—
Data link signal (Subaru Select Monitor)	B56	15	—	—	—
SPORT shift solenoid (with SPORT shift)	B54	14	SPORT shift activated	More than 8	10 — 17
			SPORT shift deactivated	Less than 1	
SPORT shift mode switch (with SPORT shift)	B55	15	SPORT shift mode switch ON	Less than 1	—
			SPORT shift mode switch OFF	More than 8	
Shift up switch (with SPORT shift)	B55	13	Shift up switch ON	Less than 1	—
			Shift up switch OFF	More than 8	
Shift down switch (with SPORT shift)	B55	2	Shift down switch ON	Less than 1	—
			Shift down switch OFF	More than 8	
Buzzer (with SPORT shift)	B56	21	ON	Less than 1	—
			OFF	More than 8	
SPORT shift indicator (with SPORT shift)	B56	12	SPORT shift mode OFF	More than 4	—
			Shift down indicator ON	Less than 1	
SPORT shift indicator (with SPORT shift)	B56	13	SPORT shift mode OFF	More than 4	—
			SPORT shift mode with 4th gear	Less than 1	
SPORT shift indicator (with SPORT shift)	B56	3	SPORT shift mode OFF	More than 4	—
			SPORT shift mode with 2nd and 3rd gear	Less than 1	
SPORT shift indicator (with SPORT shift)	B56	4	SPORT shift mode OFF	More than 4	—
			SPORT shift mode with 1st and 3rd gear	Less than 1	

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Check with ignition switch ON.					
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
Rear vehicle speed sensor	B55	3	Vehicle stopped.	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Front vehicle speed sensor	B55	5	Vehicle stopped	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Torque converter turbine speed sensor	B55	12	Engine idling after warm-up ("D" range)	0	450 — 650
			Engine idling after warm-up ("N" range)	More than 1 (AC range)	
Vehicle speed output signal	B55	13	Vehicle speed at most 10 km/h (6 MPH)	Less than 1 ← → More than 4	—
Engine speed signal	B55	4	Ignition switch ON (with engine OFF)	0	—
			Ignition switch ON (with engine ON)	0 — 13 or more	
Cruise set signal	B54	11	When cruise control is set (SET light ON)	Less than 1	—
			When cruise control is not set (SET light OFF)	More than 6.5	
Torque control signal 1	B54	13	Ignition switch ON (with engine ON)	More than 4.0	—
Torque control signal 2	B54	21	Ignition switch ON (with engine ON)	More than 4.0	—
Torque control cut signal	B54	2	Ignition switch ON	8	—
Intake manifold pressure signal	B55	20	Engine idling after warm-up.	0.4 — 1.6	—
Shift solenoid 1	B54	7	1st or 4th gear	More than 9	10 — 16
			2nd or 3rd gear	Less than 1	
Shift solenoid 2	B54	6	1st or 2nd gear	More than 9	10 — 16
			3rd or 4th gear	Less than 1	
Line pressure duty solenoid	B54	9	Ignition switch ON (with engine OFF). Throttle fully closed after warm-up.	1.5 — 4.0	2.0 — 4.5
			Ignition switch ON (with engine OFF). Throttle fully open after warm-up.	Less than 1	
Dropping resistor	B54	18	Throttle fully closed (with engine OFF) after warm-up.	More than 8.5	9 — 15
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
Lock-up duty solenoid	B54	16	When lock up occurs.	More than 8.5	10 — 17
			When lock up is released.	Less than 0.5	
Transfer duty solenoid	B54	15	Fuse on FWD switch	More than 8.5	10 — 17
			Fuse removed from FWD switch (with throttle fully open and with select lever in 1st gear).	Less than 0.5	
2-4 brake duty solenoid	B54	8	Throttle fully closed (with engine OFF) after warm-up.	1.5 — 5.0	2.0 — 4.5
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
2-4 brake dropping resistor	B54	17	Throttle fully closed (with engine OFF) after warm-up.	More than 8.5	9 — 15
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
2-4 brake timing solenoid	B54	5	1st gear	Less than 1	10 — 16
			3rd gear	More than 9	
Low clutch timing solenoid	B54	14	2nd gear	Less than 1	10 — 16
			4th gear	More than 9	

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL


AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Check with ignition switch ON.					
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
Sensor ground line 1	B55	10	—	0	Less than 1
Sensor ground line 2	B55	21	—	0	Less than 1
System ground line	B55	9	—	0	Less than 1
		19			
FWD switch	B55	14	Fuse removed.	More than 9	—
			Fuse installed.	Less than 1	
FWD indicator light	B54	12	Fuse ONFWD switch	Less than 1	—
			Fuse removed from FWD switch	More than 9	
AT diagnosis signal (Pulse signal)	B54	4	Ignition switch ON	Less than 1 ← → More than 4	—
Data link signal (Subaru Select Monitor)	B55	7	—	—	—

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

3. WITHOUT SPORT SHIFT (U5 MODEL)



AT-00641

Check with ignition switch ON.						
Content		Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
Back-up power supply		B55	24	Ignition switch OFF	10 — 13	—
Ignition power supply		B54	23	Ignition switch ON (with engine OFF)	10 — 13	—
		B54	24			
Inhibitor switch	“P” range switch	B55	3	Select lever in “P” range	Less than 1	—
				Select lever in any other than “P” range (except “N” range)	More than 8	
	“N” range switch	B55	2	Select lever in “N” range	Less than 1	—
				Select lever in any other than “N” range (except “P” range)	More than 8	
	“R” range switch	B55	13	Select lever in “R” range	Less than 1	—
				Select lever in any other than “R” range	More than 8	
	“D” range switch	B55	4	Select lever in “D” range	Less than 1	—
				Select lever in any other than “D” range	More than 8	
	“3” range switch	B55	14	Select lever in “3” range	Less than 1	—
				Select lever in any other than “3” range	More than 8	
	“2” range switch	B55	6	Select lever in “2” range	Less than 1	—
				Select lever in any other than “2” range	More than 8	
	“1” range switch	B55	22	Select lever in “1” range	Less than 1	—
				Select lever in any other than “1” range	More than 8	
Brake switch		B55	5	Brake pedal depressed.	More than 10.5	—
				Brake pedal released.	Less than 1	
ABS signal		B55	15	ABS switch ON	Less than 1	—
				ABS switch OFF	More than 6.5	
AT OIL TEMP warning light		B54	5	Light ON	Less than 1	—
				Light OFF	More than 9	
Accelerator pedal position sensor		B54	4	Throttle fully closed.	0.2 — 1.0	—
				Throttle fully open.	4.2 — 4.7	
Accelerator pedal position sensor power supply		B54	3	Ignition switch ON (With engine OFF)	4.8 — 5.3	—

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Check with ignition switch ON.					
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
ATF temperature sensor	B54	12	ATF temperature 20°C (68°F)	1.6 — 2.0	2.1 k — 2.9 k
			ATF temperature 80°C (176°F)	0.4 — 0.9	275 — 375
Rear vehicle speed sensor	B54	2	Vehicle stopped.	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Front vehicle speed sensor	B55	11	Vehicle stopped	0	450 — 650
			Vehicle speed at least 20 km/h (12 MPH)	More than 1 (AC range)	
Torque converter turbine speed sensor	B54	1	Engine idling after warm-up ("D" range)	0	450 — 650
			Engine idling after warm-up ("N" range)	More than 1 (AC range)	
Vehicle speed output signal	B55	8	Vehicle speed at most 10 km/h (6 MPH)	Less than 1 ← → More than 4	—
Shift solenoid 1	B54	7	1st or 4th gear	More than 9	10 — 16
			2nd or 3rd gear	Less than 1	
Shift solenoid 2	B54	6	1st or 2nd gear	More than 9	10 — 16
			3rd or 4th gear	Less than 1	
Line pressure duty solenoid	B54	9	Ignition switch ON (with engine OFF). Throttle fully closed after warm-up.	1.5 — 4.0	2.0 — 4.5
			Ignition switch ON (with engine OFF). Throttle fully open after warm-up.	Less than 1	
Lock-up duty solenoid	B54	18	When lock up occurs.	More than 8.5	10 — 17
			When lock up is released.	Less than 0.5	
Transfer duty solenoid	B54	17	Fuse on FWD switch	More than 8.5	10 — 17
			Fuse removed from FWD switch (with throttle fully open and with select lever in 1st gear).	Less than 0.5	
2-4 brake duty solenoid	B54	8	Throttle fully closed (with engine OFF) after warm-up.	1.5 — 5.0	2.0 — 4.5
			Throttle fully open (with engine OFF) after warm-up.	Less than 0.5	
2-4 brake timing solenoid	B54	16	1st gear	Less than 1	10 — 16
			3rd gear	More than 9	
Low clutch timing solenoid	B54	15	2nd gear	Less than 1	10 — 16
			4th gear	More than 9	
Sensor ground line 1	B54	11	—	0	Less than 1
Sensor ground line 2	B54	10	—	0	Less than 1
Sensor ground line 3	B55	21	—	0	Less than 1
Sensor ground line 4	B55	10	—	0	Less than 1
		9	—	0	
System ground line	B55	19	—	0	Less than 1
		9	—	0	
FWD switch	B54	21	Fuse removed.	More than 9	—
			Fuse installed.	Less than 1	
FWD indicator light	B55	17	Fuse ON FWD switch	Less than 1	—
			Fuse removed from FWD switch	More than 9	
CAN communication signal (+)	B54	14	—	Pulse signal	—
CAN communication signal (-)	B54	13	—	Pulse signal	—
AT diagnosis signal	B54	22	Ignition switch ON	Less than 1 ← → More than 4	—

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)


Check with ignition switch ON.					
Content	Connector No.	Terminal No.	Measuring conditions	Voltage (V)	Resistance to body (ohms)
Data link signal (Subaru Select Monitor)	B55	7	—	—	—

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

B: SCHEMATIC

1. EXCEPT U5 MODEL



AT-00643

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL


AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- | | | |
|---|--------------------------------------|---|
| (1) Transmission control module | (20) "P" range indicator light | (45) Torque converter turbine speed sensor |
| (2) Ignition switch | (21) "R" range indicator light | (46) ATF temperature sensor |
| (3) Brake switch | (22) "N" range indicator light | (47) Shift solenoid 1 |
| (4) Brake light | (23) "D" range indicator light | (48) Shift solenoid 2 |
| (5) Ignition relay | (24) "3" range indicator light | (49) 2-4 brake timing solenoid |
| (6) Buzzer (with SPORT shift) | (25) "2" range indicator light | (50) 2-4 brake duty solenoid |
| (7) SPORT shift indicator (with SPORT shift) | (26) "1" range indicator light | (51) 2-4 brake dropping resistor (without VDC system and SPORT shift) |
| (8) Speedometer | (27) "P" range switch | (52) Line pressure duty solenoid |
| (9) Cruise control module | (28) "R" range switch | (53) Line pressure dropping resistor (without VDC system and SPORT shift) |
| (10) ABS control module (without VDC system) | (29) "N" range switch | (54) Lock-up duty solenoid |
| (11) VDC control module (with VDC system) | (30) "D" range switch | (55) Low clutch timing solenoid |
| (12) Steering angle sensor (with VDC system) | (31) "3" range switch | (56) Transfer duty solenoid |
| (13) FWD indicator light (without VDC system and SPORT shift) | (32) "2" range switch | (57) SPORT shift solenoid (with SPORT shift) |
| (14) "AT OIL TEMP" warning light | (33) "1" range switch | |
| (15) FWD switch (without VDC system and SPORT shift) | (34) Data link connector | |
| (16) SPORT shift (with SPORT shift) | (35) Throttle position sensor | |
| (17) SPORT shift mode switch | (36) Engine speed signal | |
| (18) Up switch | (37) Torque control cut signal | |
| (19) Down switch | (38) Torque control signal 2 | |
| | (39) Torque control signal 1 | |
| | (40) Intake manifold pressure signal | |
| | (41) AT diagnosis signal | |
| | (42) Engine control module | |
| | (43) Front vehicle speed sensor | |
| | (44) Rear vehicle speed sensor | |

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

2. U5 MODEL



AT-01664

TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- | | | |
|--|--|--|
| (1) Transmission control module | (17) Down switch | (35) Engine control module |
| (2) Ignition switch | (18) "P" range indicator light | (36) Front vehicle speed sensor |
| (3) Brake switch | (19) "R" range indicator light | (37) Rear vehicle speed sensor |
| (4) Brake light | (20) "N" range indicator light | (38) Torque converter turbine speed sensor |
| (5) Ignition relay | (21) "D" range indicator light | (39) ATF temperature sensor |
| (6) Buzzer (with SPORT shift) | (22) "3" range indicator light | (40) Shift solenoid 1 |
| (7) SPORT shift indicator (with SPORT shift) | (23) "2" range indicator light | (41) Shift solenoid 2 |
| (8) Speedometer | (24) "1" range indicator light | (42) 2-4 brake timing solenoid |
| (9) Cruise control module | (25) "P" range switch | (43) 2-4 brake duty solenoid |
| (10) ABS control module | (26) "R" range switch | (44) Line pressure duty solenoid |
| (11) FWD indicator light (without SPORT shift) | (27) "N" range switch | (45) Lock-up duty solenoid |
| (12) "AT OIL TEMP" warning light | (28) "D" range switch | (46) Low clutch timing solenoid |
| (13) FWD switch (without SPORT shift) | (29) "3" range switch | (47) Transfer duty solenoid |
| (14) SPORT shift (with SPORT shift) | (30) "2" range switch | (48) SPORT shift solenoid (with SPORT shift) |
| (15) SPORT shift mode switch | (31) "1" range switch | |
| (16) Up switch | (32) Data link connector | |
| | (33) Accelerator pedal position sensor | |
| | (34) CAN communication signal | |


TRANSMISSION CONTROL MODULE (TCM) I/O SIGNAL

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

C: MEASUREMENT

Only for models with VDC system, measure input/output signal voltage.

1. WAVEFORM



AT-00644

- (A) Can communication line
- (B) Terminal No.:
(B56) No. 9 — (B55) No. 9
- (C) Terminal No.:
(B56) No. 18 — (B55) No. 9

SUBARU SELECT MONITOR

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

6. Subaru Select Monitor

A: OPERATION


1. READ DIAGNOSTIC TROUBLE CODE (DTC)

1) Prepare the Subaru Select Monitor kit.




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge into Subaru Select Monitor.
<Ref. to 4AT(H4SO)-7, PREPARATION TOOL, General Description.>



4) Connect the Subaru Select Monitor to data link connector.

(1) Data link connector located in the lower portion of instrument panel (on driver's side).




(2) Connect the diagnosis cable to data link connector.

NOTE:

Do not connect scan tools except for Subaru Select Monitor and OBD-II general scan tool.

5) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) POWER switch

6) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.

7) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.

8) Press the [YES] key after the information of transmission type is displayed.

9) On the «Transmission Diagnosis» display screen, select the {DTC Display} and press the [YES] key.

10) On the «DTC Display» display screen, select the {Memorized DTC} and press the [YES] key.

NOTE:

- For detailed operation procedure, refer to the Subaru Select Monitor OPERATION MANUAL.

- For details concerning the DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to 4AT(H4SO)-35, List of Diagnostic Trouble Code (DTC).>

2. READ CURRENT DATA

1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.

2) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.

3) Press the [YES] key after the information of transmission type is displayed.

4) On the «Transmission Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.

5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.

SUBARU SELECT MONITOR

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

6) Using the scroll key, move the display screen up or down until desired data is shown.

- A list of the support data is shown in the following table.

Contents	Display	Unit of measure
Battery voltage	Battery Voltage	V
Rear vehicle speed sensor signal	Rear Wheel Speed	km/h or MPH
Front vehicle speed sensor signal	Front Wheel Speed	km/h or MPH
Engine speed signal	Engine Speed	rpm
Automatic transmission fluid temperature signal	ATF Temp.	°C or °F
Throttle position sensor	Throttle Sensor Voltage	V
Gear position	Gear Position	—
Line pressure control duty ratio	Line Pressure Duty Ratio	%
Lock up clutch control duty ratio	Lock Up Duty Ratio	%
Transfer clutch control duty ratio (AWD model)	Transfer Duty Ratio	%
Power supply for throttle position sensor	Throttle Sensor Power	V
Torque converter turbine speed signal	Turbine Revolution Speed	rpm
2-4 brake timing pressure control duty ratio	Brake Clutch Duty Ratio	%
Intake manifold pressure sensor voltage	Mani. Pressure Voltage	V
Throttle position	Throttle Opening Angle	%
Up shift signal (With SPORT Shift)	Up switch	ON or OFF
Down shift signal (With SPORT Shift)	Down switch	ON or OFF
SPORT shift mode signal (With SPORT Shift)	Tip mode switch	ON or OFF
2 wheel drive switch signal	FWD Switch	ON or OFF
Stop light switch signal	Stop Light Switch	ON or OFF
Anti lock brake system signal	ABS Signal	ON or OFF
Cruise control system signal	Cruise Control Signal	ON or OFF
Parking range signal	P Range Signal	ON or OFF
Neutral range signal	N Range Signal	ON or OFF
Reverse range signal	R Range Signal	ON or OFF
Drive range signal	D Range Signal	ON or OFF
3rd range signal	3rd Range Signal	ON or OFF
2nd range signal	2nd Range Signal	ON or OFF
1st range signal	1st Range Signal	ON or OFF
Shift control solenoid 1	Shift Solenoid #1	ON or OFF
Shift control solenoid 2	Shift Solenoid #2	ON or OFF
Torque control output signal #1 (Except U5)	Torque Control Signal 1	ON or OFF
Torque control output signal #2 (Except U5)	Torque Control Signal 2	ON or OFF
Torque control cut signal (Except U5)	Torque Control Cut Sig.	ON or OFF
2-4 brake timing control solenoid valve	2-4 Brake Timing Sol.	ON or OFF
Low clutch timing control solenoid valve	Low Clutch Timing Sol.	ON or OFF
Automatic transmission diagnosis indicator lamp	Diagnosis Lamp	ON or OFF
Automatic transmission fluid temperature lamp	ATF Temperature Lamp	ON or OFF

NOTE:

For detailed operation procedure, refer to the Subaru Select Monitor OPERATION MANUAL.

3. CLEAR MEMORY MODE

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of transmission type is displayed.
- 4) On the «Transmission Diagnosis» display screen, select the {Clear Memory} and press the [YES] key.
- 5) When the “Done” and “Turn Ignition Switch OFF” are shown on display screen, turn the Subaru Select Monitor and ignition switch to OFF.

NOTE:

For detailed operation procedure, refer to the Subaru Select Monitor OPERATION MANUAL.

READ DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

7. Read Diagnostic Trouble Code (DTC)

A: OPERATION

1. WITHOUT SUBARU SELECT MONITOR

Step	Check	Yes	No
1 PERFORM READ DTC. 1) Warm-up the engine. 2) Turn the ignition switch to OFF. 3) Turn the ignition switch to ON. 4) Start the engine. 5) Drive the vehicle at speeds greater than 20 km/h (12 MPH). 6) Stop the vehicle. 7) The brake pedal depressed and move select lever to 1 range. 8) Turn the ignition switch to OFF. 9) Turn the ignition switch to ON. 10) Move the select lever "2" range. 11) Move the select lever "1" range. 12) Move the select lever "2" range. 13) Move the select lever "3" range. 14) Move the select lever "D" range.	Does the AT OIL TEMP warning light blink at 4 Hz intervals? NOTE: Blinks every 0.125 (1/8) seconds (until the ignition switch is turned OFF).	Repair the power supply and ground circuit. <Ref. to 4AT(H4SO)-42, CHECK POWER SUPPLY AND GROUND LINE, Diagnostic Procedure for AT OIL TEMP Warning Light.>	Go to step 2.
2 CHECK AT OIL TEMP WARNING LIGHT.	Does the AT OIL TEMP warning light blink at 2 Hz intervals? NOTE: Blinks every 0.25 (1/4) seconds (until ignition switch is turned to OFF).	The AT system is normal.	Go to step 3.
3 CHECK AT OIL TEMP WARNING LIGHT.	Is the DTC outputted by the blink of AT OIL TEMP warning light?	Inspect the problem corresponding with DTC. NOTE: Record all DTCs.	Go to step 4.
4 CHECK AT OIL TEMP WARNING LIGHT.	Does the AT OIL TEMP warning light remain illuminated?	Repair the AT OIL TEMP warning light circuit <Ref. to 4AT(H4SO)-37, Diagnostic Procedure for AT OIL TEMP Warning Light.>, or Inspect inhibitor switch, wiring, TCM, etc.	Calling up the DTC again.


READ DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

• The way of reading DTC

The AT OIL TEMP warning light flashes the code corresponding to faulty part.

The long segment (1.2 sec on) indicates a “ten”, and the short segment (0.2 sec on) signifies a “one”.



(1) Normal code
(2) DTC 11

(3) DTC 11 and 23

(4) Unit: Seconds

2. WITH SUBARU SELECT MONITOR

Refer to Subaru Select Monitor for information about how to obtain and understand DTC. <Ref. to 4AT(H4SO)-27, OPERATION, Subaru Select Monitor.>

INSPECTION MODE

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

8. Inspection Mode

A: OPERATION

Shift the select lever to D range, and drive continuously for 10 seconds or more at 60 km/h (37 MPH).

WARNING:

Observe the road traffic law.

9. Clear Memory Mode

A: OPERATION

1. WITHOUT SUBARU SELECT MONITOR

Current DTC shown on display are cleared by turning the ignition switch to OFF after conducting on-board diagnostics operation. Previous DTC, however, cannot be cleared since they are stored in the TCM memory which is operating on back-up power supply. These DTC can be cleared by removing the specified TCM connector for at least two minutes.

CLEAR MEMORY:

Without VDC system and SPORT shift

Remove the TCM connector (B55) for at least two minutes.

With VDC system or SPORT shift

Remove the TCM connector (B56) for at least two minutes.

- TCM connector is located in the line to memory back-up power supply of TCM. Removal of this connector clears the previous DTC stored in TCM memory.
- Be sure to remove TCM connector for at least the specified length of time. Otherwise, the DTC may not be cleared.

2. WITH SUBARU SELECT MONITOR

Refer to Subaru Select Monitor for information about how to clear DTC.

<Ref. to 4AT(H4SO)-29, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>


AT OIL TEMP WARNING LIGHT DISPLAY

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

10.AT OIL TEMP Warning Light Display

A: INSPECTION

When any on-board diagnostics item is malfunctioning, the display on AT OIL TEMP warning light blinks from the time malfunction is detected after starting the engine until ignition switch is turned to OFF. The malfunctioning part or unit can be determined by a DTC during on-board diagnostics operation. Problems which occurred previously can also be identified through the memory function. If the AT OIL TEMP warning light does not show a problem (although a problem is occurring), the problem can be determined by checking the performance characteristics of each sensor using select monitor. The AT OIL TEMP warning light signal is as shown in the figure.



(1) Ignition switch (engine OFF)

(2) Normal

(3) 2 secs

(4) Abnormal (Trouble occurs)

(5) 0.25 secs

(6) Blink

(7) Normal (ATF temperature is low)

(8) ATF temperature is high

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

11. List of Diagnostic Trouble Code (DTC)

A: LIST

DTC	Item	Content of diagnosis	Index
11	Engine speed signal	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-50, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
27	ATF temperature sensor	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-54, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
31	Throttle position sensor (Except U5 model)	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-60, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
	Accelerator pedal position sensor (U5 model)		
33	Front vehicle speed sensor	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-70, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
36	Torque converter turbine speed sensor	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-76, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
38	Torque control signal	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-80, DTC 38 TORQUE CONTROL SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
45	Intake manifold pressure signal	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-84, DTC 45 INTAKE MANIFOLD PRESSURE SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
71	Shift solenoid 1	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-86, DTC 71 SHIFT SOLENOID 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
72	Shift solenoid 2	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-90, DTC 72 SHIFT SOLENOID 2, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
73	Low clutch timing solenoid	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-94, DTC 73 LOW CLUTCH TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
74	2-4 brake timing solenoid	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-98, DTC 74 2-4 BRAKE TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
75	Line pressure duty solenoid	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-102, DTC 75 LINE PRESSURE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
76	2-4 brake duty solenoid	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-108, DTC 76 2-4 BRAKE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
77	Lock-up duty solenoid	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-114, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
78	SPORT shift solenoid	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-120, DTC 78 SPORT SHIFT SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
79	Transfer duty solenoid	Detects open or shorted output signal circuit.	<Ref. to 4AT(H4SO)-124, DTC 79 TRANSFER DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
86	CAN communication signal	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-130, DTC 86 CAN COMMUNICATION SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

DTC	Item	Content of diagnosis	Index
93	Rear vehicle speed sensor	Detects open or shorted input signal circuit.	<Ref. to 4AT(H4SO)-136, DTC 93 REAR VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

12.Diagnostic Procedure for AT OIL TEMP Warning Light

A: AT OIL TEMP WARNING LIGHT DOES NOT COME ON OR GO OFF

DIAGNOSIS:

The AT OIL TEMP warning light circuit is open or shorted.

TROUBLE SYMPTOM:








- When the ignition switch is turned to ON (engine OFF), AT OIL TEMP warning light does not illuminate.
- When the on-board diagnostics is performed, AT OIL TEMP warning light remains illuminated.

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

WIRING DIAGRAM:

- Except 2.5L U5 model and 3.0L model










AT-00646

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- 2.5L U5 model



AT-01665

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No	
1	CHECK AT OIL TEMP WARNING LIGHT. Turn the ignition switch to ON (engine OFF).	Does the AT OIL TEMP warning light illuminate?	Go to step 3 .	Go to step 2 .
2	CHECK AT OIL TEMP WARNING LIGHT. 1) Turn the ignition switch to OFF. 2) Remove the combination meter.	Is the AT OIL TEMP warning light bulb OK?	Go to step 4 .	Check the combination meter.
3	CHECK AT OIL TEMP WARNING LIGHT. Perform "Read Diagnostic Trouble Code (DTC)". <Ref. to 4AT(H4SO)-30, Read Diagnostic Trouble Code (DTC).>	Does the AT OIL TEMP warning light blink?	A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM, inhibitor switch and combination meter.	Go to step 9 .
4	CHECK FUSE (No. 5). Remove the fuse (No. 5).	Is the fuse (No. 5) blown out?	Replace the fuse (No. 5). If replaced fuse (No. 5) is blown out easily, repair short circuit in harness between fuse (No. 5) and combination meter.	Go to step 5 .
5	CHECK HARNESS CONNECTOR BETWEEN COMBINATION METER AND IGNITION SWITCH. 1) Turn the ignition switch to ON (engine OFF). 2) Measure the voltage between combination meter connector and chassis ground. Connector & terminal (i12) No. 3 (+) — Chassis ground (-):	Is the voltage more than 9 V?	Go to step 6 .	Repair the open circuit in harness between combination meter and battery.
6	CHECK COMBINATION METER. Measure the voltage between combination meter connector and chassis ground. Connector & terminal (i12) No. 14 (+) — Chassis ground (-):	Is the voltage less than 9 V?	Repair the combination meter. <Ref. to IDI-13, Combination Meter Assembly.>	Go to step 7 .
7	CHECK OPEN CIRCUIT OF HARNESS. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from combination meter connector. 3) Measure the resistance of harness between combination meter. Connector & terminal With VDC system or SPORT shift (B56) No. 11 — (i12) No. 14: Without SPORT shift (Except U5 model) (B54) No. 3 — (i12) No. 14: Without SPORT shift (U5 model) (B54) No. 5 — (i12) No. 14:	Is the resistance less than 1 Ω ?	Go to step 8 .	Repair the open circuit in harness between TCM and combination meter, and poor contact in coupling connector.

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>8 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connector to TCM and combination meter. 2) Turn the ignition switch to ON (engine OFF). 3) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without SPORT shift (Except U5 model) (B54) No. 3 (+) — Chassis ground (-): Without SPORT shift (Except U5 model) (B54) No. 5 (+) — Chassis ground (-): With VDC system or SPORT shift (B56) No. 11 (+) — Chassis ground (-):</p>	<p>Is the voltage less than 1 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM.</p>	<p>Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).></p>
<p>9 CHECK INHIBITOR SWITCH. 1) Connect the Subaru Select Monitor to data link connector. 2) Turn the ignition switch to ON. 3) Turn the Subaru Select Monitor to ON. 4) Read the data of range switch using Subaru Select Monitor. •Range switch is indicated in ON ↔ OFF.</p>	<p>When each range is selected, does the LED of Subaru Select Monitor light up?</p>	<p>Go to step 10.</p>	<p>Check the inhibitor switch circuit. <Ref. to 4AT(H4SO)-148, CHECK INHIBITOR SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).></p>
<p>10 CHECK SHORT CIRCUIT OF HARNESS. 1) Disconnect the connector from TCM. 2) Remove the combination meter. 3) Disconnect the connector from combination meter. 4) Measure the resistance of harness connector between TCM and chassis ground. Connector & terminal Without SPORT shift (Except U5 model) (B54) No. 13 — Chassis ground: Without SPORT shift (U5 model) (B54) No. 5 — Chassis ground: With VDC system or SPORT shift (B56) No. 11 — Chassis ground:</p>	<p>Is the resistance less than 1 MΩ?</p>	<p>Check the TCM power supply and ground line. <Ref. to 4AT(H4SO)-42, CHECK POWER SUPPLY AND GROUND LINE, Diagnostic Procedure for AT OIL TEMP Warning Light.></p>	<p>Repair the short circuit in harness between combination meter connector and TCM connector.</p>



DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

B: CHECK POWER SUPPLY AND GROUND LINE

WIRING DIAGRAM:

- Except U5 model




AT-00647

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT


AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model

OV : WITHOUT SPORT SHIFT
WV : WITH SPORT SHIFT



A: **B54** B: **B55** : **OV**
 A: **B54** C: **B56** : **WV** TCM



AT-01666

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK BATTERY TERMINAL. Turn the ignition switch to OFF.	Is there poor contact at battery terminal?	Repair or tighten the battery terminal.	Go to step 2.
2 CHECK POWER SUPPLY OF TCM. 1) Disconnect the connector from TCM. 2) Turn the ignition switch to ON. 3) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without SPORT shift (Except U5 model) (B55) No. 6 (+) — Chassis ground (-): With SPORT shift for (U5 model) (B55) No. 24 (+) — Chassis ground (-): With VDC system or SPORT shift (B56) No. 1 (+) — Chassis ground (-):	Is the voltage 10 — 13 V?	Go to step 4.	Go to step 3.
3 CHECK FUSE (NO. 4). Remove the fuse (No. 4).	Is the fuse (No. 4) blown out?	Replace the fuse (No. 4). If replaced fuse (No. 4) has blown out easily, repair short circuit in harness between fuse (No. 4) and TCM.	Repair the open circuit in harness between fuse (No. 4) and TCM, or fuse (No. 4) and battery, and poor contact in coupling connector.
4 CHECK IGNITION POWER SUPPLY CIRCUIT. 1) Turn the ignition switch to ON (engine OFF). 2) Measure the ignition power supply voltage between TCM connector and chassis ground. Connector & terminal (B54) No. 23 (+) — Chassis ground (-): (B54) No. 24 (+) — Chassis ground (-):	Is the voltage 10 — 13 V?	Go to step 6.	Go to step 5.
5 CHECK FUSE (NO. 11). Remove the fuse (No. 11).	Is the fuse (No. 11) blown out?	Replace the fuse (No. 11). If replaced fuse (No. 11) has blown out easily, repair short circuit in harness between fuse (No. 11) and TCM.	Repair the open circuit in harness between fuse (No. 4) and TCM, or fuse (No. 4) and battery, and poor contact in coupling connector.
6 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without SPORT shift (Except U5 model) (B54) No. 21 — (B11) No. 16: (B56) No. 19 — (B11) No. 16: Without SPORT shift (U5 model) (B55) No. 9 — (B11) No. 16: (B55) No. 19 — (B11) No. 16: With VDC system or SPORT shift (B56) No. 19 — (B11) No. 16: (B54) No. 21 — (B11) No. 16:	Is the resistance less than 1 Ω ?	Go to step 7.	Repair the open circuit in harness between TCM, transmission harness connector, and poor contact in coupling connector.

DIAGNOSTIC PROCEDURE FOR AT OIL TEMP WARNING LIGHT

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
7 CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND TRANSMISSION GROUND. Measure the resistance of harness between transmission and transmission ground. Connector & terminal (T4) No. 16 — Transmission ground:	Is the resistance less than 1 Ω ?	Go to step 8 .	Repair the open circuit in harness between transmission and transmission ground.
8 CHECK POOR CONTACT IN CONNECTORS.	Is there poor contact in control module power supply, ground line and data link connector?	Repair the connector.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

13. Diagnostic Procedure for Select Monitor Communication

A: COMMUNICATION FOR INITIALIZING IMPOSSIBLE

DIAGNOSIS:


- Faulty harness connector

TROUBLE SYMPTOM:

- Select monitor communication failure

WIRING DIAGRAM:


- Except U5 model



DIAGNOSTIC PROCEDURE FOR SELECT MONITOR COMMUNICATION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



AT-01666

DIAGNOSTIC PROCEDURE FOR SELECT MONITOR COMMUNICATION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK SUBARU SELECT MONITOR POWER SUPPLY CIRCUIT. Measure the voltage between data link connector and chassis ground. Connector & terminal (B40) No. 1 (+) — Chassis ground (-):	Is the voltage more than 10 V?	Go to step 2.	Repair the harness and connector between battery and data link connector, and poor contact in coupling connector.
2 CHECK SUBARU SELECT MONITOR GROUND CIRCUIT. Measure the resistance of harness between data link connector and chassis ground. Connector & terminal (B40) No. 12 — Chassis ground: (B40) No. 13 — Chassis ground:	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between data link connector and ground terminal, and poor contact in coupling connector.
3 CHECK COMMUNICATION OF SELECT MONITOR. 1) Turn the ignition switch to ON. 2) Using the Subaru Select Monitor, check whether communication to engine systems can be executed normally.	Are the name and year of system displayed on Subaru Select Monitor?	Go to step 8.	Go to step 4.
4 CHECK COMMUNICATION OF SELECT MONITOR. 1) Turn the ignition switch to OFF. 2) Disconnect the TCM connector. 3) Check whether communication to engine systems can be executed normally.	Are the name and year of system displayed on Subaru Select Monitor?	Go to step 6.	Go to step 5.
5 CHECK COMMUNICATION OF SELECT MONITOR. 1) Turn the ignition switch to OFF. 2) Connect the TCM connector. 3) Disconnect the ECM connector. 4) Check whether communication to transmission systems can be executed normally.	Are the name and year of system displayed on Subaru Select Monitor?	Inspect the ECM.	Go to step 6.
6 CHECK HARNESS CONNECTOR BETWEEN EACH CONTROL MODULE AND DATA LINK CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the TCM, ECM, ABSCM&H/U, cruise control module and immobilizer control module connectors. 3) Measure the resistance between TCM connector and chassis ground. Connector & terminal (B40) No. 10 — Chassis ground: (B40) No. 6 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 7.	Repair the harness and connector between each control module and data link connector.
7 CHECK OUTPUT SIGNAL FOR TCM. 1) Turn the ignition switch to ON. 2) Measure the voltage between TCM and chassis ground. Connector & terminal (B40) No. 10 (+) — Chassis ground (-): (B40) No. 6 (+) — Chassis ground (-):	Is the voltage more than 1 V?	Repair the harness and connector between each control module and data link connector.	Go to step 8.

DIAGNOSTIC PROCEDURE FOR SELECT MONITOR COMMUNICATION

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
8 CHECK HARNESS/CONNECTOR BETWEEN TCM AND DATA LINK CONNECTOR. Measure the resistance between TCM connector and data link connector. <i>Connector & terminal</i> <i>Without VDC system and SPORT shift (B55) No. 7 — (B40) No. 10:</i> <i>With VDC system or SPORT shift (B56) No. 15 — (B40) No. 10:</i>	Is the resistance less than 0.5 Ω ?	Go to step 9 .	Repair the harness and connector between TCM and data link connector.
9 CHECK HARNESS/CONNECTOR BETWEEN TCM AND DATA LINK CONNECTOR. Measure the resistance between TCM and data link connector. <i>Connector & terminal</i> <i>Without SPORT shift (Except U5 model) (B54) No. 22 — (B40) No. 6:</i> <i>Without SPORT shift (U5 model) (B55) No. 8 — (B40) No. 6:</i> <i>With VDC system or SPORT shift (B56) No. 24 — (B40) No. 6:</i>	Is the resistance more than 1 M Ω ?	Go to step 10 .	Repair the harness and connector between TCM and data link connector.
10 CHECK INSTALLATION OF TCM CONNECTOR. Turn the ignition switch to OFF.	Is the TCM connector inserted into TCM?	Go to step 11 .	Insert the TCM connector into TCM.
11 CHECK POOR CONTACT IN CONNECTORS.	Is there poor contact in control module and data link connector?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

14. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

A: DTC 11 ENGINE SPEED SIGNAL


DIAGNOSIS:

The engine speed input signal circuit is open or shorted.

TROUBLE SYMPTOM:

- No lock-up (after engine warm-up).
- The AT OIL TEMP warning light remains on when vehicle speed is "0".

WIRING DIAGRAM:



AT-00648

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and ECM. 3) Measure the resistance of harness between TCM and ECM connector. Connector & terminal 2.5 L model without SPORT shift (B55) No. 4 — (B134) No. 10: 2.5 L model with SPORT shift (B55) No. 17 — (B135) No. 10: 3.0 L model without VDC system (B55) No. 4 — (B136) No. 9: 3.0 L model with VDC system (B55) No. 17 — (B137) No. 9:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and ECM connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (B55) No. 4 — Chassis ground: With VDC system or SPORT shift (B55) No. 17 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 3.	Repair the short circuit in harness between TCM and ECM connector.
3 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 5.	Go to step 4.
4 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM and ECM. 2) Turn the ignition switch to ON (engine OFF). 3) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (B55) No. 4 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 17 (+) — Chassis ground (-):	Is the voltage more than 10.5 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and ECM.	Go to step 6.
5 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connectors to TCM and ECM. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine and turn Subaru Select Monitor switch to ON. 4) Warm-up the engine until engine coolant temperature is above 80°C (176°F). 5) Idle the engine. 6) Read the data of engine speed using Subaru Select Monitor. •Display shows the engine speed signal value sent from ECM.	Is the revolution value same as tachometer reading shown on combination meter?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and ECM.	Go to step 6.
6 CHECK POOR CONTACT.	Is there poor contact in engine speed signal circuit?	Repair the poor contact.	Go to step 7.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
7 CONFIRM DTC 11.	Replace the ECM with a new one. Does the DTC appear again, after memory has been cleared?	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>	Replace the ECM.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

B: DTC 27 ATF TEMPERATURE SENSOR

DIAGNOSIS:


The input signal circuit of TCM to ATF temperature sensor is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:


- Except U5 model



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



AT-01667

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission and TCM. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (B55) No. 10 — (B11) No. 12: With VDC system or SPORT shift (B54) No. 20 — (B11) No. 12:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR. Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without SPORT shift (Except U5 model) (B55) No. 11 — (B11) No. 11: Without SPORT shift (U5 model) (B54) No. 12 — (B11) No. 12: With VDC system or SPORT shift (B54) No. 11 — (B11) No. 11:	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between TCM and transmission connector.
3 CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR. Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (B55) No. 10 — Chassis ground: With VDC system or SPORT shift (B54) No. 20 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 4.	Repair the short circuit in harness between TCM and transmission connector.
4 CHECK HARNESS CONNECTOR BETWEEN TCM AND ATF TEMPERATURE SENSOR. Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal Without SPORT shift (Except U5 model) (B55) No. 11 — Chassis ground: Without SPORT shift (Except U5 model) (B54) No. 12 — Chassis ground: With VDC system or SPORT shift (B54) No. 11 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 5.	Repair the short circuit in harness between TCM and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>5 CHECK ATF TEMPERATURE SENSOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Connect the connectors to transmission and TCM.</p> <p>3) Turn the ignition switch to ON and start engine.</p> <p>4) Warm-up the transmission until ATF temperature reaches to 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>5) Disconnect the connector from transmission.</p> <p>6) Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 11 — No. 12:</p>	<p>Is the resistance 275 — 375 Ω?</p>	<p>Go to step 6.</p>	<p>Replace the ATF temperature sensor. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.></p>
<p>6 CHECK ATF TEMPERATURE SENSOR.</p> <p>1) Turn the ignition switch to ON (engine OFF).</p> <p>2) Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 11 — No. 12:</p>	<p>Does the resistance value increase while ATF temperature decreases?</p>	<p>Go to step 7.</p>	<p>Replace the ATF temperature sensor. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.></p>
<p>7 PREPARE SUBARU SELECT MONITOR.</p>	<p>Do you have a Subaru Select Monitor?</p>	<p>Go to step 9.</p>	<p>Go to step 8.</p>
<p>8 CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect the connector to transmission.</p> <p>2) Warm-up the transmission until ATF temperature is about 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>3) Measure the voltage between TCM connector terminal.</p> <p>Connector & terminal Without SPORT shift (Except U5 model) (B55) No. 11 (+) — No. 10 (-): Without SPORT shift (U5 model) (B54) No. 12 (+) — (B55) No. 10 (-): With VDC system or SPORT shift (B54) No. 11 (+) — No. 20 (-):</p>	<p>Is the voltage 0.4 — 0.9 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. Temporary poor contact of the connector or harness may be the cause. Repair the harness or contact in ATF temperature sensor and transmission connector.</p>	<p>Go to step 10.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
9 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connector to transmission. 2) Turn the ignition switch to ON (engine OFF).	Does the ATF temperature gradually decrease?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. Temporary poor contact of the connector or harness may be the cause. Repair the harness or contact in ATF temperature sensor and transmission connector.	Go to step 10.
10 CHECK POOR CONTACT.	Is there poor contact in ATF temperature sensor circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

C: DTC 31 THROTTLE POSITION SENSOR

DIAGNOSIS:












The input signal circuit of throttle position sensor is open or shorted.

TROUBLE SYMPTOM:

Shift point too high or too low; excessive shift shock; excessive tight corner "braking".

WIRING DIAGRAM:


- 2.5L U5 model



AT-03367

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- 3.0 L model



AT-00651

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No	
1	CHECK VEHICLE.	Go to step 20 .	Tighten the engine ground terminals.	
2	CHECK ENGINE GROUND TERMINALS.	Go to step 3 .	Tighten the engine ground terminals.	
3	CHECK GROUND CIRCUIT OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and engine ground. Connector & terminal EXCEPT 3.0 L MODEL <i>(B134) No. 7 — Engine ground:</i> <i>(B134) No. 35 — Engine ground:</i> <i>(B136) No. 5 — Engine ground:</i> <i>(B136) No. 16 — Engine ground:</i> <i>(B136) No. 26 — Engine ground:</i> <i>(B135) No. 21 — Engine ground:</i> <i>(B137) No. 14 — Engine ground:</i> 3.0 L MODEL <i>(B134) No. 22 — Engine ground:</i> <i>(B136) No. 8 — Engine ground:</i> <i>(B136) No. 17 — Engine ground:</i> <i>(B136) No. 18 — Engine ground:</i> <i>(B137) No. 8 — Engine ground:</i> <i>(B137) No. 9 — Engine ground:</i> <i>(B137) No. 21 — Engine ground:</i> <i>(B137) No. 31 — Engine ground:</i>	Is the resistance less than 5 Ω ?	Go to step 4 .	Repair the open circuit in harness between ECM connector and engine grounding terminal.
4	CHECK THROTTLE POSITION SENSOR. 1) Disconnect the connector from throttle position sensor. 2) Measure the resistance between throttle position sensor connector receptacle's terminals. Terminals 2.5 L MODEL <i>No. 4 — No. 2:</i> 3.0 L MODEL <i>No. 1 — No. 2:</i>	Is the resistance 3.0 — 4.2 k Ω ?	Go to step 5 .	Replace the throttle position sensor.
5	CHECK THROTTLE POSITION SENSOR. Measure the resistance between throttle position sensor connector receptacle's terminals. Terminals 2.5 L MODEL <i>No. 2 — No. 3:</i> 3.0 L MODEL <i>No. 1 — No. 2:</i>	Is the resistance 0.35 — 0.5 k Ω ?	Go to step 6 .	Replace the throttle position sensor.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>6 CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. 1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM and throttle position sensor connector.</p> <p>Connector & terminal 2.5 L MODEL without SPORT shift (B55) No. 2 — (E13) No. 3: 2.5 L MODEL with SPORT shift (B54) No. 3 — (E13) No. 3: 3.0 L MODEL without VDC system (B55) No. 2 — (E13) No. 2: 3.0 L MODEL with VDC system (B54) No. 3 — (E13) No. 2:</p>	Is the resistance less than 1 Ω ?	Go to step 7.	Repair the open circuit in harness between TCM and throttle position sensor connector, and poor contact in coupling connector.
<p>7 CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. Measure the resistance of harness between TCM and throttle position sensor connector.</p> <p>Connector & terminal 2.5 L MODEL without SPORT shift (B55) No. 1 — (E13) No. 4: 2.5 L MODEL with SPORT shift (B54) No. 2 — (E13) No. 4: 3.0 L MODEL without VDC system (B55) No. 1 — (E13) No. 3: 3.0 L MODEL with VDC system (B54) No. 2 — (E13) No. 3:</p>	Is the resistance less than 1 Ω ?	Go to step 8.	Repair the open circuit in harness between TCM and throttle position sensor connector, and poor contact in coupling connector.
<p>8 CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (B55) No. 2 — Chassis ground: With VDC system or SPORT shift (B54) No. 3 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 9.	Repair the short circuit in harness between TCM and throttle position sensor connector.
<p>9 CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR. Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal With VDC system or SPORT shift (B54) No. 2 — Chassis ground: Without VDC system and SPORT shift (B55) No. 1 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 10.	Repair the short circuit in harness between TCM and throttle position sensor connector.
<p>10 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM and ECM connector.</p> <p>Connector & terminal 2.5 L MODEL without SPORT shift (B55) No. 2 — (B135) No. 19: 2.5 L MODEL with SPORT shift (B54) No. 3 — (B135) No. 19: 3.0 L MODEL with VDC system (B54) No. 3 — (B135) No. 7: 3.0 L MODEL without VDC system (B55) No. 2 — (B135) No. 7:</p>	Is the resistance less than 1 Ω ?	Go to step 11.	Repair the open circuit in harness between TCM and ECM connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
11 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM and ECM connector. Connector & terminal <i>2.5 L MODEL without SPORT shift (B55) No. 1 — (B135) No. 13:</i> <i>2.5 L MODEL with SPORT shift (B54) No. 2 — (B135) No. 13:</i> <i>3.0 L MODEL with VDC system (B54) No. 2 — (B135) No. 9:</i> <i>3.0 L MODEL without VDC system (B55) No. 1 — (B135) No. 9:</i>	Is the resistance less than 1 Ω ?	Go to step 12.	Repair the open circuit in harness between TCM and ECM connector.
12 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 15.	Go to step 13.
13 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM, throttle position sensor and ECM. 2) Turn the ignition switch to ON (engine OFF). 3) Close the throttle completely. 4) Measure the voltage between TCM connector and chassis ground. Connector & terminal <i>Without VDC system and SPORT shift (B55) No. 2 (+) — Chassis ground (-):</i> <i>With VDC system or SPORT shift (B54) No. 3 (+) — Chassis ground (-):</i>	Is the voltage 0.2 — 1.0 V?	Go to step 14.	Go to step 19.
14 CHECK INPUT SIGNAL FOR TCM. 1) Open the throttle completely and hold it. 2) Measure the voltage between TCM connector and chassis ground. Connector & terminal <i>Without VDC system and SPORT shift (B55) No. 2 (+) — Chassis ground (-):</i> <i>With VDC system or SPORT shift (B54) No. 3 (+) — Chassis ground (-):</i>	Is the voltage 4.2 — 4.7 V?	Go to step 19.	Go to step 19.
15 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connectors to TCM, throttle position sensor and ECM. 2) Connect the Subaru Select Monitor to data link connector. 3) Turn the ignition switch to ON (engine OFF). 4) Turn the Subaru Select Monitor switch to ON. 5) Throttle fully closed. 6) Read the data of throttle position sensor using Subaru Select Monitor. •Throttle position sensor input signal is indicated.	Is the value voltage 0.2 — 1.0 V?	Go to step 16.	Go to step 19.
16 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. Throttle fully open. NOTE: Must be changed correspondingly with the accelerator pedal operation (from “released” to “depressed” position).	Is the value voltage 4.2 — 4.7 V?	Go to step 17.	Go to step 18.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
17 CHECK INPUT SIGNAL FOR TCM (THROTTLE POSITION SENSOR POWER SUPPLY). Measure the voltage between TCM connector and chassis ground. Connector & terminal <i>Without VDC system and SPORT shift</i> (B55) No. 1 (+) — Chassis ground (-): <i>With VDC system or SPORT shift</i> (B54) No. 2 (+) — Chassis ground (-):	Is the voltage 4.8 — 5.3 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in throttle position sensor circuit.	Go to step 19.
18 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR (THROTTLE POSITION SENSOR POWER SUPPLY). Read the data of throttle position sensor power supply using Subaru Select Monitor. •Throttle position sensor power supply voltage is indicated.	Is the value voltage 4.8 — 5.3 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in throttle position sensor circuit.	Go to step 19.
19 CHECK POOR CONTACT.	Is there poor contact in throttle position sensor circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
20 CHECK ENGINE GROUND TERMINALS.	Are engine ground terminals tightened?	Go to step 21.	Tighten the engine terminals.
21 CHECK GROUND TERMINAL OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and engine ground. Connector & terminal (B134) No. 7 — Engine ground: (B136) No. 8 — Engine ground: (B136) No. 17 — Engine ground: (B136) No. 18 — Engine ground: (B84) No. 1 — Engine ground: (B84) No. 8 — Engine ground: (B84) No. 9 — Engine ground: (B84) No. 21 — Engine ground: (B84) No. 31 — Engine ground:	Is the resistance less than 5 Ω ?	Go to step 22.	Repair open circuit in harness between ECM connector and engine grounding terminal.
22 CHECK ACCELERATOR PEDAL POSITION SENSOR. 1) Disconnect connector from accelerator pedal position sensor. 2) Measure the resistance between accelerator pedal position sensor connectors. Connector & terminal No. 1 — No. 6:	Is the resistance within 0.75 to 3.15 k Ω ?	Go to step 23.	Replace the accelerator position sensor.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
23 CHECK ACCELERATOR POSITION SENSOR. Measure the resistance between accelerator pedal position sensor connector receptacle's terminals. <i>Connector & terminal</i> <i>No. 2 — No. 6:</i>	Is the resistance within 0.15 to 0.63 k Ω ?	Go to step 24.	Replace the accelerator position sensor.
24 CHECK HARNESS CONNECTOR BETWEEN TCM AND ACCELERATOR PEDAL POSITION SENSOR. 1) Disconnect connector from TCM. 2) Measure the resistance of harness between TCM and accelerator pedal position sensor connector. <i>Connector & terminal</i> <i>Without SPORT shift</i> <i>(B54) No. 3 — (B315) No. 1:</i> <i>(B54) No. 4 — (B315) No. 2:</i> <i>With SPORT shift</i> <i>(B54) No. 2 — (B315) No. 1:</i> <i>(B54) No. 3 — (B315) No. 2:</i>	Is the resistance less than 1 Ω ?	Go to step 25.	Repair open circuit in harness between TCM and throttle position sensor connector, and poor contact in coupling connector.
25 CHECK HARNESS CONNECTOR BETWEEN TCM AND ACCELERATOR PEDAL POSITION SENSOR. Measure the resistance of harness between TCM and chassis ground. <i>Connector & terminal</i> <i>Without SPORT shift</i> <i>(B54) No. 3 — Chassis ground:</i> <i>(B54) No. 4 — Chassis ground:</i> <i>With SPORT shift</i> <i>(B54) No. 2 — Chassis ground:</i> <i>(B54) No. 3 — Chassis ground:</i>	Is the resistance more than 1 M Ω ?	Go to step 26.	Repair short circuit in harness between TCM connector and throttle sensor connector.
26 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. 1) Disconnect connector from ECM. 2) Measure the resistance between TCM connector and ECU connector. <i>Connector & terminal</i> <i>Without SPORT shift</i> <i>(B54) No. 3 — (B136) No. 8:</i> <i>(B54) No. 4 — (B136) No. 9:</i> <i>With SPORT shift</i> <i>(B54) No. 2 — (B135) No. 9:</i> <i>(B54) No. 3 — (B136) No. 8:</i>	Is the resistance less than 1 Ω ?	Go to step 27.	Repair open circuit in harness between TCM and ECM connector, and poor contact in coupling connector.
27 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 30.	Go to step 28.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
28 CHECK INPUT SIGNAL FOR TCM. 1) Connect all connectors. 2) Turn the ignition switch to ON (engine OFF). 3) Close the throttle completely. 4) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without SPORT shift (B54) No. 3 (+) — Chassis ground (-): (B54) No. 4 (+) — Chassis ground (-): With SPORT shift (B54) No. 2 (+) — Chassis ground (-): (B54) No. 3 (+) — Chassis ground (-):	Is the voltage within 0.2 to 1.0 V?	Go to step 29.	Go to step 34.
29 CHECK INPUT SIGNAL FOR TCM. 1) Open the throttle completely and hold it. 2) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without SPORT shift (B54) No. 3 (+) — Chassis ground (-): (B54) No. 4 (+) — Chassis ground (-): With SPORT shift (B54) No. 2 (+) — Chassis ground (-): (B54) No. 3 (+) — Chassis ground (-):	Is the voltage within 4.2 to 4.7 V?	Go to step 32.	Go to step 34.
30 CHECK TCM INPUT SIGNAL USING SUBARU SELECT MONITOR. 1) Connect all connector. 2) Connect Subaru Select Monitor to data link connector. 3) Turn the ignition to ON (engine OFF). 4) Turn the Subaru Select Monitor switch to ON. 5) Accelerator pedal fully closed. 6) Read the data of accelerator pedal position sensor using Subaru Select Monitor. •Accelerator pedal position sensor input signal is indicated.	Is the voltage within 0.2 to 1.0 V?	Go to step 31.	Go to step 34.
31 CHECK TCM INPUT SIGNAL USING SUBARU SELECT MONITOR. 1) Accelerator pedal fully open. 2) Read the data of accelerator pedal position sensor using Subaru Select Monitor. •Accelerator pedal position sensor input signal is indicated.	Is the voltage within 4.2 to 4.7 V?	Go to step 34.	Go to step 33.
32 CHECK INPUT SIGNAL FOR TCM (ACCELERATOR PEDAL POSITION SENSOR SUPPLY). Measure the voltage between TCM connector and chassis ground. Connector & terminal Without SPORT shift (B54) No. 3 (+) — Chassis ground (-): (B54) No. 4 (+) — Chassis ground (-): With SPORT shift (B54) No. 2 (+) — Chassis ground (-): (B54) No. 3 (+) — Chassis ground (-):	Is the voltage within 4.8 to 5.3 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness maybe the cause. Repair the harness or connector in accelerator pedal position sensor circuit.	Go to step 34.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
33 CHECK TCM INPUT SIGNAL USING SUBARU SELECT MONITOR (ACCELERATOR PEDAL POSITION SENSOR POWER SUPPLY). Read the data of accelerator pedal position sensor using Subaru Select Monitor. •Accelerator pedal position sensor power supply voltage is indicated.	Is the voltage within 4.8 to 5.3 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness maybe the cause. Repair the harness or connector in accelerator pedal position sensor circuit.	Go to step 34 .
34 CHECK POOR CONTACT.	Is there poor contact in accelerator pedal position sensor circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

D: DTC 33 FRONT VEHICLE SPEED SENSOR

DIAGNOSIS:

- The vehicle speed signal is abnormal.
- The circuit in combination meter is faulty.
- The harness connector between TCM and vehicle speed sensor is in short or open.

TROUBLE SYMPTOM:



- Erroneous idling.
- Engine stalls.
- Poor driving performance.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

WIRING DIAGRAM:

- Except U5 model





AT-00652

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



AT-01670

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 5 — (B11) No. 17: Without SPORT shift (U5 model) (B55) No. 11 — (B11) No. 17: With VDC system or SPORT shift (B55) No. 18 — (B11) No. 17:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (B55) No. 21 — (B11) No. 18: With VDC system or SPORT shift (B54) No. 10 — (B11) No. 18:	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
3 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (B55) No. 21 — Chassis ground: With VDC system or SPORT shift (B54) No. 10 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 4.	Repair the short circuit in harness between TCM and transmission connector.
4 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 5 — Chassis ground: Without SPORT shift (U5 model) (B55) No. 11 — Chassis ground: With VDC system or SPORT shift (B55) No. 18 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 5.	Repair the short circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
5 CHECK FRONT VEHICLE SPEED SENSOR. Measure the resistance between transmission connector receptacle's terminals. Connector & terminal (T4) No. 17 — No. 18:	Is the resistance 450 — 650 Ω ?	Go to step 6.	Replace the front vehicle speed sensor. <Ref. to 4AT-55, Front Vehicle Speed Sensor.>
6 PREPARE OSCILLOSCOPE.	Do you have an oscilloscope?	Go to step 9.	Go to step 7.
7 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 10.	Go to step 8.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>8 CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect all connectors.</p> <p>2) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>3) Start the engine and set vehicle in 20 km/h (12 MPH) condition.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>4) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 5 (+) — (B55) No. 21 (-): Without SPORT shift (U5 model) (B55) No. 11 (+) — (B55) No. 21 (-): With VDC system or SPORT shift (B55) No. 18 (+) — (B54) No. 10 (-):</p>	<p>Is the voltage more than AC 1 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact or harness may be the cause. Repair the harness or connector in the front vehicle speed sensor circuit.</p>	<p>Go to step 11.</p>
<p>9 CHECK FRONT VEHICLE SPEED SENSOR USING OSCILLOSCOPE.</p> <p>1) Connect all connectors.</p> <p>2) Lift-up the vehicle and place safety stand.</p> <p>NOTE: Raise all wheels off ground.</p> <p>3) Set the oscilloscope to TCM connector terminals.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) Positive probe; (B55) No. 5: Without SPORT shift (U5 model) Positive probe; (B55) No. 11: Ground lead; (B55) No. 21: With VDC system or SPORT shift Positive probe; (B55) No. 18: Ground lead; (B54) No. 10:</p> <p>4) Start the engine, and drive the wheels slowly.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunctions. When AT control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>5) Measure the signal voltage indicated on oscilloscope.</p>	<p>Is the voltage more than AC 4 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact or harness may be the cause. Repair the harness or connector in front vehicle speed sensor circuit.</p>	<p>Go to step 11.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>10 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect all connectors. 2) Connect the Subaru Select Monitor to data link connector. 3) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>4) Turn the ignition switch to ON and turn Subaru Select Monitor switch to ON. 5) Start the engine. 6) Read the data of vehicle speed using Subaru Select Monitor.</p> <p>•Compare the speedometer with Subaru Select Monitor indications. •Vehicle speed is indicated in “km/h” or “MPH”.</p> <p>7) Slowly increase the vehicle speed to 60 km/h or 37 MPH.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p>	<p>Does the speedometer indication increase as Subaru Select Monitor data increases?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor connector or harness may be the cause. Repair the harness or connector in front vehicle speed sensor circuit.</p>	<p>Go to step 11.</p>
<p>11 CHECK POOR CONTACT.</p>	<p>Is there poor contact in front vehicle speed sensor circuit?</p>	<p>Repair the poor contact.</p>	<p>Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

E: DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR

DIAGNOSIS:





The input signal circuit of TCM is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:

- Except U5 model








AT-00653

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



AT-01671

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK TORQUE CONVERTER TURBINE SPEED SENSOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission. 3) Measure the resistance between transmission connector receptacle's terminals. Connector & terminal (T4) No. 14 — No. 15:	Is the resistance 450 — 650 Ω ?	Go to step 2.	Replace the turbine speed sensor. <Ref. to 4AT-61, Torque Converter Turbine Speed Sensor.>
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 12 — (B11) No. 14: Without SPORT shift (U5 model) (B54) No. 1 — (B11) No. 14: With VDC system or SPORT shift (B55) No. 8 — (B11) No. 14:	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between TCM and transmission connector.
3 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 21 — (B11) No. 15: Without SPORT shift (U5 model) (B54) No. 10 — (B11) No. 15: With VDC system or SPORT shift (B55) No. 9 — (B11) No. 15:	Is the resistance less than 1 Ω ?	Go to step 4.	Repair the open circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
4 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 21 — Chassis ground: Without SPORT shift (U5 model) (B54) No. 10 — Chassis ground: With VDC system or SPORT shift (B55) No. 9 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 5.	Repair the short circuit in harness between TCM and transmission connector.
5 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 12 — Chassis ground: With VDC system or SPORT shift (B54) No. 1 — Chassis ground: With VDC system or SPORT shift (B55) No. 8 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 6.	Repair the short circuit in harness between TCM and transmission connector, and poor contact in coupling connector.
6 PREPARE OSCILLOSCOPE.	Do you have an oscilloscope?	Go to step 10.	Go to step 7.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
7 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 9 .	Go to step 8 .
8 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM and transmission. 2) Start the engine and move select lever to "P" or "N" range. 3) Measure the voltage between TCM connector terminals. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 12 (+) — No. 21 (-): Without SPORT shift (U5 model) (B55) No. 1 (+) — (B54) No. 1 (-): With VDC system or SPORT shift (B55) No. 8 (+) — No. 9 (-):	Is the voltage more than AC 1 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 11 .
9 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connectors to TCM and transmission. 2) Connect the Subaru Select Monitor to data link connector. 3) Turn the ignition switch to ON and turn Subaru Select Monitor switch to ON. 4) Start the engine. 5) Move the select lever to "P" or "N" range. 6) Read the data of turbine speed using Subaru Select Monitor. •Compare the tachometer with Subaru Select Monitor indications.	Is the revolution value same as the tachometer reading shown on the combination meter?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 11 .
10 CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE. 1) Connect the connectors to TCM and transmission. 2) Set the oscilloscope to TCM connector terminals. Connector & terminal Without VDC system and SPORT shift (Except U5 model) Positive probe; (B55) No. 12: Ground lead; (B55) No. 21: Without SPORT shift (U5 model) Positive probe; (B55) No. 1: Ground lead; (B55) No. 10: With VDC system or SPORT shift Positive probe; (B55) No. 8: Ground lead; (B55) No. 9: 3) Start the engine and move select lever to "P" or "N" range.	Is the signal voltage more than AC 1 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 11 .
11 CHECK POOR CONTACT.	Is there poor contact in torque converter turbine speed sensor circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

F: DTC 38 TORQUE CONTROL SIGNAL


DIAGNOSIS:

- The signal circuit is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



AT-00654

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and ECM. 3) Measure the resistance of harness between TCM and ECM connector.</p> <p>Connector & terminal 2.5 L model without SPORT shift (B54) No. 21 — (B136) No. 18: (B54) No. 13 — (B136) No. 1: 2.5 L model with SPORT shift (B56) No. 14 — (B136) No. 18: (B56) No. 5 — (B136) No. 1: 3.0 L model without VDC system (B54) No. 21 — (B134) No. 18: (B54) No. 13 — (B134) No. 19: 3.0 L model with VDC system (B56) No. 14 — (B134) No. 18: (B56) No. 5 — (B134) No. 19:</p>	Is the resistance less than 1 Ω?	Go to step 2.	Repair the open circuit in harness between TCM and ECM connector.
<p>2 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.</p> <p>Measure the resistance of harness between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (B54) No. 21 — Chassis ground: (B54) No. 13 — Chassis ground: With VDC system or SPORT shift (B56) No. 14 — Chassis ground: (B56) No. 5 — Chassis ground:</p>	Is the resistance more than 1 MΩ?	Go to step 3.	Repair the short circuit in harness between TCM and ECM connector.
<p>3 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Connect the connectors to TCM and ECM. 2) Turn the ignition switch to ON (engine OFF). 3) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal Without VDC system and SPORT shift (B54) No. 21 (+) — Chassis ground (-): (B54) No. 13 (+) — Chassis ground (-): With VDC system or SPORT shift (B56) No. 14 (+) — Chassis ground (-): (B56) No. 5 (+) — Chassis ground (-):</p>	Is the voltage more than 4.8 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and ECM.	Go to step 4.
<p>4 CHECK POOR CONTACT.</p>	Is there poor contact in torque control signal circuit?	Repair the poor contact.	Go to step 5.
<p>5 CHECK GROUND LINE BETWEEN TRANSMISSION AND BODY.</p> <p>Check installing condition of the ground line in transmission and body.</p>	Is there any dirt or rust at the ground line installing point?	Remove dirt and rust.	Go to step 6.
<p>6 CHECK GROUND LINE BETWEEN TRANSMISSION AND BODY.</p> <p>Check installing condition of the ground line in transmission and body.</p> <p>Tightening torque: 10 — 16 N·m (1.0 — 1.6 kgf·m, 7.2 — 11.6 ft·lb)</p>	Is the tightening torque value within specification?	Go to step 7.	Tighten to the specified torque.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
7 CHECK GROUND LINE INSIDE TRANSMISSION. 1) Drain the ATF and remove oil pan. 2) Check the tightening torque value of ground line installing bolt. Tightening torque: <i>7 — 9 N·m (0.7 — 0.9 kgf-m, 5.1 — 6.5 ft-lb)</i>	Is the tightening torque value within specification?	Go to step 9 .	Tighten to the specified torque.
8 CHECK GROUND CIRCUIT OF ECM. <Ref. to 4AT(H4SO)-60, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble?	Repair the ground terminal and/or ground circuit of ECM.	Go to step 9 .
9 RECHECK OUTPUT SIGNAL EMITTED FROM TCM. Measure the voltage between TCM connector and chassis ground. Connector & terminal <i>Without VDC system and SPORT shift</i> <i>(B54) No. 21 (+) — Chassis ground (-):</i> <i>(B54) No. 13 (+) — Chassis ground (-):</i> <i>With VDC system or SPORT shift</i> <i>(B56) No. 14 (+) — Chassis ground (-):</i> <i>(B56) No. 5 (+) — Chassis ground (-):</i>	Is each voltage more than 4 V?	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>	Replace the ECM.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

G: DTC 45 INTAKE MANIFOLD PRESSURE SIGNAL


DIAGNOSIS:

The input signal circuit of TCM from ECM is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



AT-00655

Step	Check	Yes	No	
1	CHECK ENGINE GROUND TERMINALS AND GROUND CIRCUIT OF ECM <Ref. to 4AT(H4SO)-60, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Is there any trouble?	Repair the ground terminal and/or ground circuit of ECM.	Go to step 2.
2	CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and ECM. 3) Measure the resistance of harness between TCM and ECM connector. Connector & terminal 3.0 L model with VDC system (B54) No. 1 - (B135) No. 28: 3.0 L model without VDC system (B54) No. 20 - (B135) No. 28: 2.5 L model with SPORT shift (B54) No. 1 - (B135) No. 2: 2.5 L model without SPORT shift (B54) No. 20 - (B135) No. 2:	Is the resistance less than 1 Ω?	Go to step 3.	Repair the open circuit in harness between TCM and ECM connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
3 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal With VDC system or SPORT shift (B54) No. 1 - Chassis ground: Without VDC system and SPORT shift (B54) No. 20 - Chassis ground:	Is the resistance more than 1 MΩ?	Go to step 4.	Repair the short circuit in harness between TCM and ECM connector.
4 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 6.	Go to step 5.
5 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM and ECM. 2) Start the engine, and warm-up the transmission until ATF temperature is above 80°C (176°F). NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature. 3) Idle the engine. 4) Measure the voltage between TCM connector and chassis ground. Connector & terminal With VDC system or SPORT shift (B54) No. 1 (+) - Chassis ground (-): Without VDC system and SPORT shift (B54) No. 20 (+) - Chassis ground (-):	Is the voltage 0.4 — 1.6 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and ECM.	Go to step 7.
6 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR. 1) Connect the connectors to TCM and ECM. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine, and turn Subaru Select Monitor switch to ON. 4) Warm-up the engine until engine coolant temperature is above 80°C (176°F). 5) Idle the engine. 6) Read the data of intake manifold pressure signal using Subaru Select Monitor. •Display shows the intake manifold pressure signal value sent from ECM.	Is the value voltage 0.4 — 1.6 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and ECM.	Go to step 7.
7 CHECK POOR CONTACT.	Is there poor contact in intake manifold pressure signal circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

H: DTC 71 SHIFT SOLENOID 1


DIAGNOSIS:

The output signal circuit of shift solenoid 1 is open or shorted.

TROUBLE SYMPTOM:

Does not shift.

WIRING DIAGRAM:



AT-00656

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and shift solenoid 1 connector. Connector & terminal Without VDC system and SPORT shift (B54) No. 7 — (B11) No. 1: With VDC system or SPORT shift (B54) No. 22 — (B11) No. 1:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (B54) No. 7 — Chassis ground: With VDC system or SPORT shift (B54) No. 22 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 3.	Repair the short circuit in harness between TCM and transmission connector.
3 CHECK SHIFT SOLENOID 1. Measure the resistance between transmission connector terminals. Connector & terminal (T4) No. 1 — No. 16:	Is the resistance 10 — 16 Ω ?	Go to step 4.	Go to step 7.
4 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Turn the ignition switch to ON (engine OFF). 3) Move the select lever to “D” range. 4) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (B54) No. 7 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 22 (+) — Chassis ground (-):	Is the voltage more than 9 V?	Go to step 5.	Go to step 6.
5 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Move the select lever to “2” range. 2) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (B54) No. 7 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 22 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or contact in TCM.	Go to step 6.
6 CHECK POOR CONTACT.	Is there poor contact in shift solenoid 1 circuit?	Repair poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>7</p> <p>CHECK SHIFT SOLENOID 1 (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket.</p> <p>2) Lift-up or raise the vehicle and support with safety stand.</p> <p>NOTE: Raise all wheels off ground.</p> <p>3) Drain the ATF.</p> <p>CAUTION: Do not drain the ATF until it cools down.</p> <p>4) Remove the oil pan, and disconnect connector from shift solenoid 1.</p> <p>5) Measure the resistance between shift solenoid 1 connector and transmission ground.</p> <p>Terminals No. 1 — Transmission ground:</p>	<p>Is the resistance 10 — 16 Ω?</p>	<p>Go to step 8.</p>	<p>Replace the shift solenoid 1. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.></p>
<p>8</p> <p>CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 1 AND TRANSMISSION.</p> <p>Measure the resistance of harness between shift solenoid 1 and transmission connector.</p> <p>Connector & terminal (T4) No. 1 — (AT5) No. 1:</p>	<p>Is the resistance less than 1 Ω?</p>	<p>Go to step 9.</p>	<p>Repair the open circuit in harness between shift solenoid 1 and transmission connector.</p>
<p>9</p> <p>CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 1 AND TRANSMISSION.</p> <p>Measure the resistance of harness between shift solenoid 1 connector and transmission ground.</p> <p>Connector & terminal (T4) No. 1 — Transmission ground:</p>	<p>Is the resistance more than 1 MΩ?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in shift solenoid 1 and transmission.</p>	<p>Repair the short circuit harness between shift solenoid 1 and transmission connector.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

I: DTC 72 SHIFT SOLENOID 2


DIAGNOSIS:

The output signal circuit of shift solenoid 2 is open or shorted.

TROUBLE SYMPTOM:

Does not shift.

WIRING DIAGRAM:



AT-00657

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and shift solenoid 2 connector. <i>Connector & terminal</i> <i>Without VDC system and SPORT shift</i> <i>(B54) No. 6 — (B11) No. 2:</i> <i>With VDC system or SPORT shift</i> <i>(B54) No. 5 — (B11) No. 2:</i>	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and transmission ground. <i>Connector & terminal</i> <i>Without VDC system and SPORT shift</i> <i>(B54) No. 6 — Chassis ground:</i> <i>With VDC system or SPORT shift</i> <i>(B54) No. 5 — Chassis ground:</i>	Is the resistance more than 1 $M\Omega$?	Go to step 3.	Repair the short circuit in harness between TCM and transmission connector.
3 CHECK SHIFT SOLENOID 2. Measure the resistance between transmission connector terminals. <i>Connector & terminal</i> <i>(T4) No. 2 — No. 16:</i>	Is the resistance 10 — 16 Ω ?	Go to step 4.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>4 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up or raise the vehicle and support with safety stand.</p> <p>NOTE: Raise all wheels off ground.</p> <p>3) Start the engine and warm-up the transmission until ATF temperature is above 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>4) Move the selector lever to "D" range, and slowly increase vehicle speed to 50 km/h (31 MPH).</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (B54) No. 6 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 5 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 5.
<p>5 CHECK POOR CONTACT.</p>	Is there poor contact in shift solenoid 2 circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
<p>6 CHECK SHIFT SOLENOID 2 (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket.</p> <p>2) Drain the ATF.</p> <p>CAUTION: Do not drain the ATF until it cools down.</p> <p>3) Remove the oil pan, and disconnect connector from shift solenoid 2.</p> <p>4) Measure the resistance between shift solenoid 2 connector and transmission ground.</p> <p>Terminals No. 1 — Transmission ground:</p>	Is the resistance 10 — 16 Ω?	Go to step 7.	Replace the shift solenoid 2. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
<p>7 CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 2 AND TRANSMISSION.</p> <p>Measure the resistance of harness between shift solenoid 2 and transmission connector.</p> <p>Connector & terminal (AT6) No. 1 — (T4) No. 2:</p>	Is the resistance less than 1 Ω?	Go to step 8.	Repair the open circuit in harness between shift solenoid 2 and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>8 CHECK HARNESS CONNECTOR BETWEEN SHIFT SOLENOID 2 AND TRANSMISSION. Measure the resistance of harness between shift solenoid 2 connector and transmission ground. <i>Connector & terminal</i> <i>(T4) No. 2 — Transmission ground:</i></p>	<p>Is the resistance more than 1 MΩ?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in shift solenoid 2 and transmission.</p>	<p>Repair the short circuit harness between shift solenoid 2 and transmission connector.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 14 — (B11) No. 3: U5 model and with VDC system or SPORT shift (B54) No. 15 — (B11) No. 3:</p>	<p>Is the resistance less than 1 Ω?</p>	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
<p>2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>Measure the resistance of harness between TCM connector and transmission ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 14 — Chassis ground: U5 model and with VDC system or SPORT shift (B54) No. 15 — Chassis ground:</p>	<p>Is the resistance more than 1 MΩ?</p>	Go to step 3.	Repair the short circuit in harness between TCM and transmission connector.
<p>3 CHECK LOW CLUTCH TIMING SOLENOID.</p> <p>Measure the resistance between transmission connector terminals.</p> <p>Connector & terminal (T4) No. 3 — No. 16:</p>	<p>Is the resistance 10 — 16 Ω?</p>	Go to step 4.	Go to step 7.
<p>4 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Connect the connectors to TCM and transmission. 2) Turn the ignition switch to ON (engine OFF). 3) Move the select lever to "D" range. 4) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 14 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B54) No. 15 (+) — Chassis ground (-):</p>	<p>Is the voltage more than 9 V?</p>	Go to step 5.	Go to step 6.
<p>5 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Set the select lever to "2" range. 2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 14 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B54) No. 15 (+) — Chassis ground (-):</p>	<p>Is the voltage less than 1 V?</p>	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or contact in TCM and transmission.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
6 CHECK POOR CONTACT.	Is there poor contact in low clutch timing solenoid circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
7 CHECK LOW CLUTCH TIMING SOLENOID (IN TRANSMISSION). 1) Remove the transmission connector from bracket. 2) Lift-up or raise the vehicle and support with safety stand. NOTE: Raise all wheels off ground. 3) Drain the ATF. CAUTION: Do not drain the ATF until it cools down. 4) Remove the oil pan, and disconnect connector from low clutch timing solenoid. 5) Measure the resistance between low clutch timing solenoid connector and transmission ground. Terminals No. 1 — Transmission ground:	Is the resistance 10 — 16 Ω ?	Go to step 8.	Replace the low clutch timing solenoid. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
8 CHECK HARNESS CONNECTOR BETWEEN LOW CLUTCH TIMING SOLENOID AND TRANSMISSION. Measure the resistance of harness between low clutch timing solenoid and transmission connector. Connector & terminal (AT9) No. 1 — (T4) No. 3:	Is the resistance less than 1 Ω ?	Go to step 9.	Repair the open circuit in harness between low clutch timing solenoid and transmission connector.
9 CHECK HARNESS CONNECTOR BETWEEN LOW CLUTCH TIMING SOLENOID AND TRANSMISSION. Measure the resistance of harness between low clutch timing solenoid connector and transmission ground. Connector & terminal (T4) No. 3 — Transmission ground:	Is the resistance more than 1 M Ω ?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in low clutch timing solenoid and transmission.	Repair the short circuit harness between low clutch timing solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
 AUTOMATIC TRANSMISSION (DIAGNOSTICS)

K: DTC 74 2-4 BRAKE TIMING SOLENOID


DIAGNOSIS:

The output signal circuit of 2-4 brake timing solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 5 — (B11) No. 4: U5 model and With VDC system or SPORT shift (B54) No. 16 — (B11) No. 4:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal Except U5 model, without VDC system and SPORT shift (B54) No. 5 — Chassis ground: U5 model and with VDC system or SPORT shift (B54) No. 16 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 3.	Repair the short circuit in harness between TCM and transmission connector.
3 CHECK 2-4 BRAKE TIMING SOLENOID. Measure the resistance between transmission connector terminals. Connector & terminal (T4) No. 4 — No. 16:	Is the resistance 10 — 16 Ω ?	Go to step 4.	Go to step 7.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>4 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up or raise the vehicle and support with safety stand.</p> <p>NOTE: Raise all wheels off ground.</p> <p>3) Start the engine and warm-up the transmission until ATF temperature is above 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>4) Move the selector lever to "1" range, and slowly increase vehicle speed to 10 km/h (6 MPH).</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 5 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B54) No. 16 (+) — Chassis ground (-):</p>	<p>Is the voltage less than 1 V?</p>	<p>Go to step 5.</p>	<p>Go to step 6.</p>
<p>5 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Move the selector lever to "D" range, and slowly increase vehicle speed to 65 km/h (40 MPH).</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 5 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B54) No. 16 (+) — Chassis ground (-):</p>	<p>Is the voltage more than 9 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or contact in transmission.</p>	<p>Go to step 6.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
6 CHECK POOR CONTACT.	Is there poor contact in 2-4 brake timing solenoid circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
7 CHECK 2-4 BRAKE TIMING SOLENOID (IN TRANSMISSION). 1) Remove the transmission connector from bracket. 2) Lift-up or raise the vehicle and support with safety stand. NOTE: Raise all wheels off ground. 3) Drain the ATF. CAUTION: Do not drain the ATF until it cools down. 4) Remove the oil pan, and disconnect connector from 2-4 brake timing solenoid. 5) Measure the resistance between 2-4 brake timing solenoid connector and transmission ground. Terminals No. 1 — Transmission ground:	Is the resistance 10 — 16 Ω?	Go to step 8.	Replace the 2-4 brake timing solenoid. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
8 CHECK HARNESS CONNECTOR BETWEEN 2-4 BRAKE TIMING SOLENOID AND TRANSMISSION. Measure the resistance of harness between 2-4 brake timing solenoid and transmission connector. Connector & terminal (AT8) No. 1 — (T4) No. 4:	Is the resistance less than 1 Ω?	Go to step 9.	Repair the open circuit in harness between 2-4 brake timing solenoid and transmission connector.
9 CHECK HARNESS CONNECTOR BETWEEN 2-4 BRAKE TIMING SOLENOID AND TRANSMISSION. Measure the resistance of harness between 2-4 brake timing solenoid connector and transmission ground. Connector & terminal (T4) No. 4 — Transmission ground:	Is the resistance more than 1 MΩ?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in 2-4 brake timing solenoid and transmission.	Repair the short circuit harness between 2-4 brake timing solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

L: DTC 75 LINE PRESSURE DUTY SOLENOID


DIAGNOSIS:

Output signal circuit of line pressure duty solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1	CHECK VEHICLE.	Go to step 7.	Go to step 2.
2	CHECK RESISTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from dropping resistor. 3) Measure the resistance between dropping resistor terminal. Terminals No. 1 — No. 2:	Go to step 3.	Replace the dropping resistor. <Ref. to 4AT-81, Dropping Resistor.>
3	CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR. 1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM connector and dropping resistor connector. Connector & terminal (B54) No. 18 — (B4) No. 1:	Go to step 4.	Repair open circuit in harness between TCM and dropping resistor connector.
4	CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR. Measure the resistance of harness between dropping resistor connector and chassis ground. Connector & terminal (B4) No. 1 — Chassis ground:	Go to step 5.	Repair short circuit in harness between TCM and dropping resistor connector.
5	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR. 1) Disconnect the connector from transmission. 2) Measure the resistance of harness between transmission and dropping resistor connector. Connector & terminal (B4) No. 2 — (B11) No. 5:	Go to step 6.	Repair open circuit in harness between dropping resistor and transmission connector.
6	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR. Measure the resistance of harness between dropping resistor connector and chassis ground. Connector & terminal (B4) No. 2 — Chassis ground:	Go to step 7.	Repair short circuit in harness between dropping resistor and transmission connector.
7	CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission and TCM. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal (B54) No. 9 — (B11) No. 5:	Go to step 8.	Repair the open circuit in harness between TCM and transmission connector.
8	CHECK HARNESS CONNECTOR BETWEEN TCM AND CHASSIS GROUND. Measure the resistance of harness between TCM and chassis ground. Connector & terminal (B54) No. 9 — Chassis ground:	Go to step 9.	Repair the short circuit in harness between TCM and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
9 CHECK LINE PRESSURE DUTY SOLENOID. Measure the resistance between transmission connector receptacle's terminals. <i>Terminals</i> <i>(T4) No. 5 — No. 16:</i>	Is the resistance between 2.0 and 4.5 Ω ?	Go to step 10.	Go to step 16.
10 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 13.	Go to step 11.
11 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect all connectors. 2) Start the engine and warm-up the transmission until ATF temperature is above 80°C (176°F). NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature. 3) Turn the ignition switch to ON (engine OFF). 4) Move the select lever to "N" range. 5) Throttle fully closed. 6) Measure the voltage between TCM connector and chassis ground. <i>Connector & terminal</i> <i>(B54) No. 9 (+) — Chassis ground (-):</i>	Is the voltage 1.5 — 5.0 V?	Go to step 12.	Go to step 15.
12 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Throttle fully open and hold it. 2) Measure the voltage between TCM connector and chassis ground. <i>Connector & terminal</i> <i>(B54) No. 9 (+) — Chassis ground (-):</i>	Is the voltage less than 1 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in transmission.	Go to step 15.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>13 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Connect the Subaru Select Monitor to data link connector.</p> <p>3) Start the engine and turn Subaru Select Monitor switch to ON.</p> <p>4) Warm-up the transmission until ATF temperature is above 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>5) Stop the engine and turn ignition switch to ON (engine OFF).</p> <p>6) Move the select lever to “N” range.</p> <p>7) Throttle is fully closed.</p> <p>•Line pressure duty solenoid is indicated in “%”.</p> <p>8) Read the data of line pressure duty solenoid using Subaru Select Monitor.</p>	Is the value 100%?	Go to step 14.	Go to step 15.
<p>14 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Turn the ignition switch to ON (engine OFF).</p> <p>2) Throttle is fully open.</p>	Is the value less than 25%?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in transmission.	Go to step 15.
<p>15 CHECK POOR CONTACT.</p>	Is there poor contact in line pressure duty solenoid circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
<p>16 CHECK LINE PRESSURE DUTY SOLENOID (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket.</p> <p>2) Drain the ATF.</p> <p>CAUTION: Do not drain the ATF until it cools down.</p> <p>3) Remove the oil pan, and disconnect connector from line pressure duty solenoid.</p> <p>4) Measure the resistance between line pressure duty solenoid connector and transmission ground.</p> <p>Terminals No. 1 — Transmission ground:</p>	Is the resistance 2.0 — 4.5 Ω?	Go to step 17.	Replace the line pressure duty solenoid. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>17 CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND LINE PRESSURE DUTY SOLENOID. Measure the resistance of harness between line pressure duty solenoid and transmission connector. <i>Connector & terminal</i> <i>(T4) No. 5 — (AT2) No. 1:</i></p>	Is the resistance less than 1 Ω ?	Go to step 18 .	Repair the open circuit in harness between line pressure duty solenoid and transmission connector.
<p>18 CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND LINE PRESSURE DUTY SOLENOID. Measure the resistance of harness between transmission connector and transmission ground. <i>Connector & terminal</i> <i>(T4) No. 5 — Transmission ground:</i></p>	Is the resistance more than 1 $M\Omega$?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in line pressure duty solenoid and transmission.	Repair the short circuit in harness between line pressure duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

M: DTC 76 2-4 BRAKE DUTY SOLENOID


DIAGNOSIS:

Output signal circuit of 2-4 brake duty solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive shift shock.

WIRING DIAGRAM:



AT-01673

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1	CHECK VEHICLE.	Go to step 2.	Go to step 7.
2	CHECK RESISTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from dropping resistor. 3) Measure the resistance between dropping resistor terminal. Terminals No. 3 — No. 4:	Go to step 3.	Replace the dropping resistor. <Ref. to 4AT-81, Dropping Resistor.>
3	CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR. 1) Disconnect the connector from TCM. 2) Measure the resistance of harness between TCM connector and dropping resistor connector. Connector & terminal (B54) No. 17 — (B4) No. 3:	Go to step 4.	Repair open circuit in harness between TCM and dropping resistor connector.
4	CHECK HARNESS CONNECTOR BETWEEN TCM AND DROPPING RESISTOR. Measure the resistance of harness between dropping resistor connector and chassis ground. Connector & terminal (B4) No. 3 — Chassis ground:	Go to step 5.	Repair short circuit in harness between TCM and dropping resistor connector.
5	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR. 1) Disconnect the connector from transmission. 2) Measure the resistance of harness between transmission and dropping resistor connector. Connector & terminal (B4) No. 4 — (B11) No. 9:	Go to step 6.	Repair open circuit in harness between dropping resistor and transmission connector.
6	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND DROPPING RESISTOR. Measure the resistance of harness between dropping resistor connector and chassis ground. Connector & terminal (B4) No. 4 — Chassis ground:	Go to step 7.	Repair short circuit in harness between dropping resistor and transmission connector.
7	CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission and TCM. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 8 — (B11) No. 9: U5 model and with VDC system or SPORT shift (B54) No. 18 — (B11) No. 9:	Go to step 8.	Repair the open circuit in harness between TCM and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
8 CHECK HARNESS CONNECTOR BETWEEN TCM AND CHASSIS GROUND. Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 8 — Chassis ground: Without SPORT shift (U5 model) (B54) No. 8 — Chassis ground: With VDC system or SPORT shift (B54) No. 18 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 9.	Repair the short circuit in harness between TCM and transmission connector.
9 CHECK 2-4 BRAKE DUTY SOLENOID. Measure the resistance between transmission connector receptacle's terminals. Terminals (T4) No. 16 — No. 9:	Is the resistance 2.0 — 4.5 Ω ?	Go to step 10.	Go to step 16.
10 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 13.	Go to step 11.
11 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect all connectors. 2) Start the engine and warm-up the transmission until ATF temperature is above 80°C (176°F). NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature. 3) Turn the ignition switch to ON (engine OFF). 4) Move the select lever to "N" range. 5) Throttle fully closed. 6) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 8 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B54) No. 18 (+) — Chassis ground (-):	Is the voltage 1.5 — 5.0 V?	Go to step 12.	Go to step 15.
12 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Throttle fully open and hold it. 2) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 8 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B54) No. 18 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 15.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
13 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR. 1) Connect all connectors. 2) Connect the Subaru Select Monitor to data link connector. 3) Start the engine and turn Subaru Select Monitor switch to ON. 4) Warm-up the transmission until ATF temperature is above 80°C (176°F). NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature. 5) Stop the engine and turn ignition switch to ON (engine OFF). 6) Move the select lever to "N" range. 7) Throttle is fully closed. •2-4 brake duty solenoid is indicated in "%". 8) Read the data of 2-4 brake duty solenoid using Subaru Select Monitor.	Is the value 100%?	Go to step 14.	Go to step 15.
14 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR. 1) Turn the ignition switch to ON (engine OFF). 2) Throttle is fully open.	Is the value less than 25%?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 15.
15 CHECK POOR CONTACT.	Is there poor contact in 2-4 brake duty solenoid circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
16 CHECK 2-4 BRAKE DUTY SOLENOID (IN TRANSMISSION). 1) Remove the transmission connector from bracket. 2) Drain the ATF. CAUTION: Do not drain the ATF until it cools down. 3) Remove the oil pan, and disconnect connector from 2-4 brake duty solenoid. 4) Measure the resistance between 2-4 brake duty solenoid connector and transmission ground. Terminals No. 1 — Transmission ground:	Is the resistance 2.0 — 4.5 Ω?	Go to step 17.	Replace the 2-4 brake duty solenoid. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
17	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND 2-4 BRAKE DUTY SOLENOID. Measure the resistance of harness between 2-4 brake duty solenoid and transmission connector. Connector & terminal (T4) No. 9 — (AT7) No. 1:	Is the resistance less than 1 Ω ?	Go to step 18 . Repair the open circuit in harness between 2-4 brake duty solenoid and transmission connector.
18	CHECK HARNESS CONNECTOR BETWEEN TRANSMISSION AND 2-4 BRAKE DUTY SOLENOID. Measure the resistance of harness between transmission connector and transmission ground. Connector & terminal (T4) No. 9 — Transmission ground:	Is the resistance more than 1 $M\Omega$?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in line pressure duty solenoid and transmission. Repair the short circuit in harness between 2-4 brake duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

N: DTC 77 LOCK-UP DUTY SOLENOID

DIAGNOSIS:


The output signal circuit of lock-up duty solenoid is open or shorted.

TROUBLE SYMPTOM:

No "lock-up" (after engine warm-up).

WIRING DIAGRAM:

- Except U5 model



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK DTC.	Do multiple DTCs appear in the on-board diagnostics test mode?	Go to another DTC.	Go to step 2.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 16 — (B11) No. 13: Without SPORT shift (U5 model) (B54) No. 18 — (B11) No. 13: With VDC system or SPORT shift (B54) No. 7 — (B11) No. 13:	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between TCM and transmission connector.
3 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance of harness connector between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 16 — Chassis ground: Without SPORT shift (U5 model) (B54) No. 18 — Chassis ground: With VDC system or SPORT shift (B54) No. 7 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 4.	Repair the short circuit in harness between TCM and transmission connector.
4 CHECK LOCK-UP DUTY SOLENOID. Measure the resistance between transmission connector receptacle's terminals. Connector & terminal (T4) No. 13 — No. 16:	Is the resistance 10 — 17 Ω ?	Go to step 5.	Go to step 11.
5 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 8.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>6 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up the vehicle and place safety stand.</p> <p>NOTE: Raise all wheels off ground.</p> <p>3) Start the engine and warm-up the transmission until ATF temperature is above 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>4) Move the selector lever to “D” range and slowly increase vehicle speed to 75 km/h (47 MPH). Wheels will lock-up.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>5) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 16 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B54) No. 18 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 7 (+) — Chassis ground (-):</p>	Is the voltage more than 8.5 V?	Go to step 7.	Go to step 10.
<p>7 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Return the engine to idling speed and move select lever to “N” range.</p> <p>2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 16 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B54) No. 18 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 7 (+) — Chassis ground (-):</p>	Is the voltage less than 0.5 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 10.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>8 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up the vehicle and place safety stand.</p> <p>NOTE: Raise all wheels off ground.</p> <p>3) Connect the Subaru Select Monitor to data link connector.</p> <p>4) Start the engine and turn Subaru Select Monitor switch to ON.</p> <p>5) Start the engine and warm-up the transmission until ATF temperature is above 80°C (176°F).</p> <p>NOTE: If ambient temperature is below 0°C (32°F), drive the vehicle until ATF reaches its operating temperature.</p> <p>6) Read the data of lock-up duty solenoid using Subaru Select Monitor.</p> <p>•Lock-up duty solenoid is indicated in “%”.</p> <p>7) Move the selector lever to “D” range and slowly increase vehicle speed to 75 km/h (47 MPH). Wheels will lock-up.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p>	Is the value 95%?	Go to step 9.	Go to step 10.
<p>9 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>Return the engine to idling speed and move selector lever to “N” range.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p>	Is the value 5%?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 10.
<p>10 CHECK POOR CONTACT.</p>	Is there poor contact in lock-up duty solenoid circuit?	Repair poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>11 CHECK LOCK-UP DUTY SOLENOID (IN TRANSMISSION).</p> <p>1) Remove the transmission connector from bracket. 2) Drain the ATF.</p> <p>CAUTION: Do not drain the ATF until it cools down.</p> <p>3) Remove the oil pan and disconnect connector from lock-up duty solenoid. 4) Measure the resistance between lock-up duty solenoid connector and transmission ground.</p> <p>Terminals No. 1 — Transmission ground:</p>	Is the resistance 10 — 17 Ω?	Go to step 12.	Replace the lock-up duty solenoid. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.>
<p>12 CHECK HARNESS CONNECTOR BETWEEN LOCK-UP DUTY SOLENOID AND TRANSMISSION.</p> <p>Measure the resistance of harness between lock-up duty solenoid and transmission connector.</p> <p>Connector & terminal (T4) No. 13 — (AT3) No. 1:</p>	Is the resistance less than 1 Ω?	Go to step 13.	Repair the open circuit in harness between TCM and transmission connector.
<p>13 CHECK HARNESS CONNECTOR BETWEEN LOCK-UP DUTY SOLENOID AND TRANSMISSION.</p> <p>Measure the resistance of harness between transmission connector and transmission ground.</p> <p>Connector & terminal (T4) No. 13 — Transmission ground:</p>	Is the resistance more than 1 MΩ?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in lock-up duty solenoid and transmission.	Repair the short circuit in harness between lock-up duty solenoid and transmission connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

O: DTC 78 SPORT SHIFT SOLENOID


DIAGNOSIS:

Output signal circuit of SPORT shift solenoid is open or shorted.

TROUBLE SYMPTOM:

Engine brake is effected when select lever is in "D" or "3" range with 1st gear.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn ignition switch to OFF. 2) Disconnect connector from TCM and transmission. 3) Measure resistance of harness between TCM and SPORT shift solenoid connector. Connector & terminal (B54) No. 14 — (B11) No. 8:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure resistance of harness between TCM connector and chassis ground. Connector & terminal (B54) No. 14 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 3.	Repair short circuit in harness between TCM and transmission connector.
3 CHECK SHIFT SOLENOID 1. Measure resistance between transmission connector terminals. Connector & terminal (T4) No. 8 — No. 16:	Is the resistance 10 - 16 Ω ?	Go to step 4.	Go to step 7.
4 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect connectors to TCM and transmission. 2) Turn ignition switch to ON (engine OFF). 3) Measure voltage between TCM connector and chassis ground. Connector & terminal (B54) No. 14 (+) — Chassis ground (-):	Is the voltage more than 9 V?	Go to step 5.	Go to step 6.
5 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Move select lever to SPORT shift mode. 2) Measure voltage between TCM connector and chassis ground. Connector & terminal (B54) No. 14 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Even if AT OIL TEMP warning light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or contact in the TCM.	Go to step 6.
6 CHECK POOR CONTACT.	Is there poor contact in SPORT shift solenoid circuit?	Repair poor contact.	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>7 CHECK SPORT SHIFT SOLENOID (IN TRANSMISSION).</p> <p>1) Remove transmission connector from bracket.</p> <p>2) Lift-up or raise the vehicle and support with safety stand.</p> <p>NOTE: On AWD models, raise all wheels off ground.</p> <p>3) Drain automatic transmission fluid.</p> <p>CAUTION: Do not drain the automatic transmission fluid until it cools down.</p> <p>4) Remove oil pan, and disconnect connector from SPORT shift solenoid.</p> <p>5) Measure resistance between SPORT shift solenoid connector and transmission ground.</p> <p>Terminal No. 1 — Transmission ground:</p>	<p>Is the resistance 10 - 16 Ω?</p>	<p>Go to step 8.</p>	<p>Replace SPORT shift solenoid. <Ref. to 4AT-72, Shift Solenoids, Duty Solenoids and ATF Temperature Sensor.></p>
<p>8 CHECK HARNESS CONNECTOR BETWEEN SPORT SHIFT SOLENOID AND TRANSMISSION.</p> <p>Measure resistance of harness between SPORT shift solenoid and transmission connector.</p> <p>Connector & terminal (AT10) No. 1 — (T4) No. 8:</p>	<p>Is the resistance less than 1 Ω?</p>	<p>Go to step 9.</p>	<p>Repair open circuit in harness between SPORT shift solenoid and transmission connector.</p>
<p>9 CHECK HARNESS CONNECTOR BETWEEN SPORT SHIFT SOLENOID AND TRANSMISSION.</p> <p>Measure resistance of harness between SPORT shift solenoid connector and transmission ground.</p> <p>Connector & terminal (T4) No. 8 — Transmission ground:</p>	<p>Is the resistance more than 1 MΩ?</p>	<p>Even if AT OIL TEMP warning light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair harness or connector in SPORT shift solenoid and transmission.</p>	<p>Repair short circuit harness between SPORT shift solenoid and transmission connector.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

P: DTC 79 TRANSFER DUTY SOLENOID

DIAGNOSIS:


The output signal circuit of transfer duty solenoid is open or shorted.

TROUBLE SYMPTOM:

Excessive "braking" in tight corners.

WIRING DIAGRAM:

- Except U5 model



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 15 — (B11) No. 6: Without SPORT shift (U5 model) (B54) No. 17 — (B11) No. 6: With VDC system or SPORT shift (B54) No. 6 — (B11) No. 6:	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION. Measure the resistance harness connector between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 15 — Chassis ground: Without SPORT shift (U5 model) (B54) No. 17 — Chassis ground: With VDC system or SPORT shift (B54) No. 6 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 3.	Repair the short circuit in harness between TCM and transmission connector.
3 CHECK TRANSFER DUTY SOLENOID. Measure the resistance between transmission connector and transmission terminals. Connector & terminal (T4) No. 6 — No. 16:	Is the resistance 10 — 17 Ω ?	Go to step 4.	Go to step 10.
4 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 7.	Go to step 5.
5 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect the connectors to TCM and transmission. 2) Turn the ignition switch to ON (engine OFF). 3) Throttle is fully closed. 4) Move the select lever to "P" range. 5) Measure the voltage between TCM connector and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 15 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B54) No. 17 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 6 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 6.	Go to step 9.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>6 CHECK OUTPUT SIGNAL EMITTED FROM TCM.</p> <p>1) Move the select lever to “D” range. 2) Measure the voltage between TCM connector and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 15 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B54) No. 17 (+) — Chassis ground (-): With VDC system or SPORT shift (B54) No. 6 (+) — Chassis ground (-):</p>	Is the voltage more than 8.5 V?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.	Go to step 9.
<p>7 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission. 2) Connect the Subaru Select Monitor to data link connector. 3) Turn the ignition switch to ON (engine OFF) and turn Subaru Select Monitor switch to ON. 4) Move the select lever to “D” range with throttle fully open (vehicle speed 0 km/h or 0 MPH). 5) Read the data of transfer duty solenoid using Subaru Select Monitor.</p> <p>•Transfer duty solenoid is indicated in “%”.</p>	Is the value 80 — 95%?	Go to step 8.	Go to step 9.
<p>8 CHECK OUTPUT SIGNAL EMITTED FROM TCM USING SUBARU SELECT MONITOR.</p> <p>1) Move the select lever to “N” range with throttle fully close (vehicle speed 0 km/h or 0 MPH). 2) Read the data of transfer duty solenoid using Subaru Select Monitor.</p> <p>•Transfer duty solenoid is indicated in “%”.</p>	Is the value approx. 5 — 10%?	Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in transfer duty solenoid and TCM connector.	Go to step 9.
<p>9 CHECK POOR CONTACT.</p>	Is there poor contact in transfer duty solenoid circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>10 CHECK TRANSFER DUTY SOLENOID (IN TRANSMISSION). 1) Lift-up the vehicle and place safety stand. NOTE: Raise all wheels off ground. 2) Drain the automatic transmission fluid. CAUTION: Do not drain the automatic transmission fluid until it cools down. 3) Remove the extension case and disconnect connector from transfer duty solenoid. 4) Measure the resistance between transfer duty solenoid connector and transmission ground. Connector & terminal (AT4) No. 1 — Transmission ground:</p>	<p>Is the resistance 10 — 17 Ω?</p>	<p>Go to step 11.</p>	<p>Replace the transfer duty solenoid.</p>
<p>11 CHECK HARNESS CONNECTOR BETWEEN TRANSFER DUTY SOLENOID AND TRANSMISSION. Measure the resistance of harness between transfer duty solenoid and transmission connector. Connector & terminal (T4) No. 6 — (AT4) No. 1:</p>	<p>Is the resistance less than 1 Ω?</p>	<p>Go to step 12.</p>	<p>Repair the open circuit in harness between transfer duty solenoid and transmission connector.</p>
<p>12 CHECK HARNESS CONNECTOR BETWEEN TRANSFER DUTY SOLENOID AND TRANSMISSION. Measure the resistance of harness between transmission connector and transmission ground. Connector & terminal (T4) No. 6 — Transmission ground:</p>	<p>Is the resistance more than 1 MΩ?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or contact in transfer duty solenoid and transmission.</p>	<p>Repair the short circuit in harness between transfer duty solenoid and transmission connector.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)






Q: DTC 86 CAN COMMUNICATION SIGNAL

DIAGNOSIS:

Input signal circuit of TCM is open or shorted.

WIRING DIAGRAM:

- With VDC system




AT-00665

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



B134

1	2	3	4	5	6	7	
8	9	10	11	12	13	14	15
16	17	18	19	20	21	22	

B54

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21				22	23	24

AT-01676

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1	CHECK VEHICLE. Is vehicle being diagnosed for models with VDC system?	Go to step 2 .	Go to step 12 .
2	CHECK TROUBLE CODE. Do multiple trouble codes appear in the on-board diagnostics test mode?	Go to another trouble code.	Go to step 2 .
3	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. 1) Turn ignition switch to OFF. 2) Disconnect connector from TCM and VDCCM. 3) Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 18 — (F87) No. 81: Is the measured value less than the specified value?	Go to step 3 .	Repair open circuit in harness between TCM and VDCCM, and poor contact in coupling connector.
4	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 9 — (F87) No. 83: Is the measured value less than the specified value?	Go to step 4 .	Repair open circuit in harness between TCM and VDCCM, and poor contact in coupling connector.
5	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 18 — Chassis ground: Does the measured value exceed the specified value?	Go to step 5 .	Repair short circuit in harness between TCM and VDCCM connector.
6	CHECK HARNESS CONNECTOR BETWEEN TCM AND VDCCM. Measure resistance of harness between TCM and VDCCM connector. Connector & terminal (B56) No. 9 — Chassis ground: Is the measured value less than the specified value?	Go to step 6 .	Repair short circuit in harness between TCM and VDCCM connector.
7	PREPARE OSCILLOSCOPE. Do you have oscilloscope?	Go to step 8 .	Go to step 7 .
8	CHECK INPUT SIGNAL FOR TCM. 1) Connect connectors to TCM and VDCCM. 2) Turn ignition switch to ON (engine OFF). 3) Measure voltage between TCM connector and chassis ground. Connector & terminal (B56) No. 9 (+) — Chassis ground (-): (B56) No. 18 (+) — Chassis ground (-): Does input voltage value change?	Go to step 10 .	Repair poor contact in VDCCM.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
9 CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE. 1) Set oscilloscope to TCM connector terminals. Connector & terminal Positive probe; (B56) No. 9 Ground; (B55) No. 9 2) Turn ignition switch to ON (engine OFF). Check signal waveform pattern on oscilloscope. <Ref. to 4AT(H4SO)-26, WAVEFORM, MEASUREMENT, Transmission Control Module (TCM) I/O Signal.> Is waveform pattern same as that shown in the figure?	Waveform pattern is same as that shown in the figure.	Go to step 9.	Repair poor contact in VDCCM.
10 CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE. 1) Set oscilloscope to TCM connector terminals. Connector & terminal Positive probe; (B56) No. 18 Ground; (B55) No. 9 2) Turn ignition switch to ON (engine OFF). Check signal waveform pattern on oscilloscope. <Ref. to 4AT(H4SO)-26, WAVEFORM, MEASUREMENT, Transmission Control Module (TCM) I/O Signal.> Is waveform pattern same as that shown in the figure?	Waveform pattern is same as that shown in the figure.	Go to step 10.	Repair poor contact in VDCCM.
11 CHECK POOR CONTACT. Is there poor contact in TCM?	There is poor contact.	Repair poor contact.	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
12 CHECK DIAGNOSIS CODE. Connect connectors to TCM and VDCCM.	Any other diagnosis trouble code is indicated.	Go on other diagnosis trouble code.	Go to step 13.
13 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. 1) Turn the ignition switch to OFF. 2) Disconnect connector from TCM and ECM. 3) Measure the resistance of harness between TCM and ECM. Connector & terminal Without SPORT shift (B54) No. 13 — (B134) No. 10: With SPORT shift (B56) No. 18 — (B134) No. 10:	Is the resistance less than 1 Ω ?	Go to step 14.	Repair open circuit in harness between TCM and ECM, and poor contact in connect connector.
14 CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM. Measure the resistance of harness between TCM and ECM. Connector & terminal Without SPORT shift (B54) No. 14 — (B134) No. 3: With SPORT shift (B56) No. 9 — (B134) No. 3:	Is the resistance less than 1 Ω ?	Go to step 15.	Repair open circuit in harness between TCM and ECM, and poor contact in connect connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

R: DTC 93 REAR VEHICLE SPEED SENSOR

DIAGNOSIS:






The input signal circuit of TCM is open or shorted.

TROUBLE SYMPTOM:

No lock-up or excessive tight corner "braking".

WIRING DIAGRAM:

- Except U5 model








AT-00666

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



AT-01677

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and transmission. 3) Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 3 — (B11) No. 19: Without SPORT shift (U5 model) (B55) No. 11 — (B11) No. 19: With VDC system or SPORT shift (B55) No. 24 — (B11) No. 19:</p>	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between TCM and transmission connector.
<p>2 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>Measure the resistance of harness between TCM and transmission connector.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 21 — (B11) No. 20: Without SPORT shift (U5 model) (B54) No. 11 — (B11) No. 20: With VDC system or SPORT shift (B54) No. 19 — (B11) No. 20:</p>	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between TCM and transmission, and poor contact in coupling connector.
<p>3 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 3 — Chassis ground: Without SPORT shift (U5 model) (B55) No. 11 — Chassis ground: With VDC system or SPORT shift (B55) No. 24 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 4.	Repair the short circuit in harness between TCM and transmission connector.
<p>4 CHECK HARNESS CONNECTOR BETWEEN TCM AND TRANSMISSION.</p> <p>Measure the resistance of harness between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 21 — Chassis ground: Without SPORT shift (U5 model) (B54) No. 11 — Chassis ground: With VDC system or SPORT shift (B54) No. 19 — Chassis ground:</p>	Is the resistance more than 1 $M\Omega$?	Go to step 5.	Repair the short circuit in harness between TCM and transmission connector.
<p>5 CHECK REAR VEHICLE SPEED SENSOR.</p> <p>Measure the resistance between transmission connector receptacle's terminals.</p> <p>Connector & terminal (T4) No. 19 — No. 20:</p>	Is the resistance 450 — 650 Ω ?	Go to step 6.	Replace the rear vehicle speed sensor. <Ref. to 4AT-60, Rear Vehicle Speed Sensor.>
6 PREPARE OSCILLOSCOPE.	Do you have an oscilloscope?	Go to step 10.	Go to step 7.
7 PREPARE SUBARU SELECT MONITOR.	Do you have a Subaru Select Monitor?	Go to step 9.	Go to step 8.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>8 CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>3) Start the engine and set vehicle in 20 km/h (12 MPH) condition.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>4) Measure the voltage between TCM connector terminals.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 3 (+) — (B55) No. 21 (-): Without SPORT shift (U5 model) (B55) No. 11 (+) — (B54) No. 11 (-): With VDC system or SPORT shift (B55) No. 24 (+) — (B54) No. 19 (-):</p>	<p>Is the voltage more than AC 1 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.</p>	<p>Go to step 11.</p>
<p>9 CHECK INPUT SIGNAL FOR TCM USING SUBARU SELECT MONITOR.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Connect the Subaru Select Monitor to data link connector.</p> <p>3) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>4) Turn the ignition switch to ON and turn Subaru Select Monitor switch to ON.</p> <p>5) Start the engine.</p> <p>6) Read the data of vehicle speed using Subaru Select Monitor.</p> <p>•Compare the speedometer with Subaru Select Monitor indications.</p> <p>•Vehicle speed is indicated in “km/h” or “MPH”.</p> <p>7) Slowly increase the vehicle speed to 60 km/h or 37 MPH.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p>	<p>Does the speedometer indication increase as the Subaru Select Monitor data increases?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.</p>	<p>Go to step 11.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>10 CHECK INPUT SIGNAL FOR TCM USING OSCILLOSCOPE.</p> <p>1) Connect the connectors to TCM and transmission.</p> <p>2) Lift-up or raise the vehicle and place safety stands.</p> <p>NOTE: Raise all wheels off floor.</p> <p>3) Set the oscilloscope to TCM connector terminals.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) Positive probe; (B55) No. 3: Ground lead; (B55) No. 21: Without SPORT shift (U5 model) Positive probe; (B55) No. 11: Ground lead; (B54) No. 11: With VDC system or SPORT shift Positive probe; (B55) No. 24: Ground lead; (B54) No. 19:</p> <p>4) Start the engine and set vehicle in 20 km/h (12 MPH) condition.</p> <p>NOTE: The speed difference between front and rear wheels may light the ABS warning light, but this indicates no malfunction. When AT control diagnosis is finished, perform the ABS memory clearance procedure of on-board diagnostics system. <Ref. to ABS-22, Clear Memory Mode.></p> <p>5) Measure the signal voltage indicated on oscilloscope.</p>	<p>Is the signal voltage more than AC 1 V?</p>	<p>Even if the AT OIL TEMP warning light illuminates, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in TCM and transmission.</p>	<p>Go to step 11.</p>
<p>11 CHECK POOR CONTACT.</p>	<p>Is there poor contact in rear vehicle speed sensor circuit?</p>	<p>Repair the poor contact.</p>	<p>Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:



15. Diagnostic Procedure without Diagnostic Trouble Code (DTC)

A: CHECK FWD SWITCH

DIAGNOSIS:

- The LED does not come on even if FWD switch is ON.
- The FWD switch circuit is open or short.

WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No	
1	CHECK VEHICLE.	Is vehicle being diagnosed for models with VDC system or SPORTS shift?	Go to step CHECK BRAKE SWITCH. <Ref. to 4AT(H4SO)-146, CHECK BRAKE SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>	Go to step 2.
2	CHECK FWD SWITCH. Connect Select Monitor to data link connector, and display the LED monitor.	When the fuse is inserted to FWD switch, does LED light up?	Go to step CHECK BRAKE SWITCH. <Ref. to 4AT(H4SO)-146, CHECK BRAKE SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>	Go to step 3.
3	CHECK FWD INDICATOR LIGHT. 1) Turn the ignition switch to OFF. 2) Remove the combination meter.	Is the FWD indicator light bulb OK?	Go to step 4.	Check the FWD indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>
4	CHECK HARNESS CONNECTOR BETWEEN TCM AND FWD SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM. 3) Measure the resistance of harness between TCM and FWD switch connector. Connector & terminal Except U5 model (B55) No. 14 — (F27) No. 36: U5 model (B54) No. 21 — (F27) No. 36:	Is the resistance less than 1 Ω ?	Go to step 5.	Repair the open circuit in harness between TCM and FWD switch connector.
5	CHECK HARNESS CONNECTOR BETWEEN FWD SWITCH AND CHASSIS GROUND. Measure the resistance of harness between FWD switch and chassis ground. Connector & terminal (F27) No. 35 — Chassis ground:	Is the resistance less than 1 Ω ?	Go to step 6.	Repair the open circuit in harness between FWD switch connector and chassis ground.
6	CHECK HARNESS CONNECTOR BETWEEN TCM AND FWD SWITCH. Measure the resistance of harness connector between TCM and body to make sure that circuit does not short. Connector & terminal Except U5 model (B55) No. 14 — Chassis ground: U5 model (B54) No. 21 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 7.	Repair the short circuit in harness between TCM and FWD switch connector.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
7 CHECK INPUT SIGNAL FOR TCM. 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM. 3) Turn the ignition switch to ON. 4) Measure the signal voltage for TCM while installing the fuse to FWD switch connector. Connector & terminal Except U5 model (B55) No. 14 (+) — Chassis ground (-): U5 model (B55) No. 21 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 8.	Go to step 12.
8 CHECK INPUT SIGNAL FOR TCM. Measure the signal voltage for TCM while removing the fuse from FWD switch connector. Connector & terminal Except U5 model (B55) No. 14 (+) — Chassis ground (-): U5 model (B54) No. 21 (+) — Chassis ground (-):	Is the voltage 6 — 9.1 V?	Go to step 9.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
9 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and combination meter. 3) Measure the resistance of harness between TCM and diagnosis connector. Connector & terminal Except U5 model (B54) No. 12 — (i12) No. 11: U5 model (B55) No. 17 — (i12) No. 11:	Is the resistance less than 1 Ω ?	Go to step 10.	Repair the open circuit in harness between TCM and combination meter and poor contact in connector.
10 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. Measure the resistance of harness connector between TCM and chassis ground to make sure that circuit does not short. Connector & terminal Except U5 model (B54) No. 12 — Chassis ground: U5 model (B55) No. 17 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 11.	Repair the short circuit in harness between TCM and combination meter connector.
11 CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and combination meter. 3) Turn the ignition switch to ON. 4) Measure the signal voltage for TCM while installing the fuse to FWD switch connector. Connector & terminal Except U5 model (B54) No. 12 (+) — Chassis ground (-): U5 model (B55) No. 17 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 12.	Go to step 13.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
12 CHECK OUTPUT SIGNAL EMITTED FROM TCM. Measure the signal voltage for TCM while removing the fuse from FWD switch connector. Connector & terminal <i>Except U5 model</i> (B54) No. 12 (+) — Chassis ground (-): U5 model (B55) No. 17 (+) — Chassis ground (-):	Is the voltage 6 — 9.1 V?	Go to step 13.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
13 CHECK POOR CONTACT.	Is there poor contact in FWD switch circuit?	Repair the poor contact.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

B: CHECK BRAKE SWITCH

Step	Check	Yes	No
1 CHECK BRAKE SWITCH.	When the brake pedal is depressed, does LED light up?	Go to step CHECK CRUISE CONTROL SWITCH. <Ref. to 4AT(H4SO)-147, CHECK CRUISE CONTROL SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>	Check the brake switch circuit.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

C: CHECK CRUISE CONTROL SWITCH

Step	Check	Yes	No
1 CHECK CRUISE CONTROL SWITCH.	When the cruise control is set, does LED light up?	Go to step CHECK INHIBITOR SWITCH. <Ref. to 4AT(H4SO)-148, CHECK INHIBITOR SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>	Check the cruise control. Turbo and U5 model <Ref. to CC(H4DOTC)-2, Basic Diagnostic Procedure.> Except turbo and U5 model <Ref. to CC(H4SO)-2, Basic Diagnostic Procedure.>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

D: CHECK INHIBITOR SWITCH

DIAGNOSIS:

The input signal circuit of inhibitor switch is open or shorted.

TROUBLE SYMPTOM:









- Shift characteristics are erroneous.
- Engine brake is not effected when selector lever is in “3” range.
- Engine brake is not effected when selector lever is in “2” range.
- Engine brake is not effected when selector lever is in “1” range.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

WIRING DIAGRAM:

- Except U5 model










AT-00668

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

- U5 model



AT-01679

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No	
1	CHECK "P" RANGE SWITCH.	When the "P" range is selected, does LED light up?	Go to step 2.	Go to step 22.
2	CHECK INDICATOR LIGHT.	Does the combination meter "P" range indicator illuminate?	Go to step 3.	Go to step 26.
3	CHECK "P" RANGE SWITCH.	When the "R" range is selected, does "P" range LED light up?	Go to step 28.	Go to step 4.
4	CHECK "R" RANGE SWITCH.	When the "R" range is selected, does LED light up?	Go to step 5.	Go to step 29.
5	CHECK INDICATOR LIGHT.	Does the combination meter "R" range indicator illuminate?	Go to step 6.	Go to step 32.
6	CHECK "R" RANGE SWITCH.	When the "N" range is selected, does "R" range LED light up?	Go to step 34.	Go to step 7.
7	CHECK "N" RANGE SWITCH.	When the "N" range is selected, does LED light up?	Go to step 8.	Go to step 35.
8	CHECK INDICATOR LIGHT.	Does the combination meter "N" range indicator illuminate?	Go to step 9.	Go to step 38.
9	CHECK "N" RANGE SWITCH.	When the "D" range is selected, does "N" range LED light up?	Go to step 40.	Go to step 10.
10	CHECK "D" RANGE SWITCH.	When the "D" range is selected, does LED light up?	Go to step 11.	Go to step 41.
11	CHECK INDICATOR LIGHT.	Does the combination meter "D" range indicator illuminate?	Go to step 12.	Go to step 44.
12	CHECK "D" RANGE SWITCH.	When the "3" range is selected, does "D" range LED light up?	Go to step 46.	Go to step 13.
13	CHECK "3" RANGE SWITCH.	When the "3" range is selected, does LED light up?	Go to step 14.	Go to step 47.
14	CHECK INDICATOR LIGHT.	Does the combination meter "3" range indicator illuminate?	Go to step 15.	Go to step 50.
15	CHECK "3" RANGE SWITCH.	When the "2" range is selected, does "3" range LED light up?	Go to step 52.	Go to step 16.
16	CHECK "2" RANGE SWITCH.	When the "2" range is selected, does LED light up?	Go to step 17.	Go to step 53.
17	CHECK INDICATOR LIGHT.	Does the combination meter "2" range indicator illuminate?	Go to step 18.	Go to step 56.
18	CHECK "2" RANGE SWITCH.	When the "1" range is selected, does "2" range LED light up?	Go to step 58.	Go to step 19.
19	CHECK "1" RANGE SWITCH.	When the "1" range is selected, does LED light up?	Go to step 20.	Go to step 59.
20	CHECK INDICATOR LIGHT.	Does the combination meter "1" range indicator illuminate?	Go to step 21.	Go to step 62.
21	CHECK "1" RANGE SWITCH.	When the "2" range is selected, does "1" range LED light UP?	Go to step 64.	Go to step Check SPORT SHIFT SWITCH. <Ref. to 4AT(H4SO)-164, CHECK SPORT SHIFT SWITCH., Diagnostic Procedure without Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>22 CHECK HARNESS CONNECTOR BETWEEN INHIBITOR SWITCH AND CHASSIS GROUND.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from inhibitor switch. 3) Measure the resistance of harness between inhibitor switch and chassis ground.</p> <p>Connector & terminal (T7) No. 5 — Chassis ground:</p>	Is the resistance less than 1 Ω ?	Go to step 23.	Repair the open circuit in harness between inhibitor switch connector and chassis ground, and poor contact in coupling connector.
<p>23 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 23 — (T7) No. 9: Without SPORT shift (U5 model) (B55) No. 3 — (T7) No. 9: With VDC system or SPORT shift (B55) No. 1 — (T7) No. 9:</p>	Is the resistance less than 1 Ω ?	Go to step 24.	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.
<p>24 CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to "P" range. 5) Measure the voltage between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 23 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 3 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 1 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V?	Go to step 25.	Go to step 65.
<p>25 CHECK INPUT SIGNAL FOR TCM.</p> <p>1) Position the select lever to any other than "P" range. 2) Measure the voltage between TCM and chassis ground.</p> <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 23 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 3 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 1 (+) — Chassis ground (-):</p>	Is the voltage more than 8 V?	Go to step 65.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
26 CHECK "P" RANGE INDICATOR LIGHT BULB. 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the "P" range indicator light bulb from combination meter.	Is the "P" range indicator light bulb OK?	Go to step 27.	Replace the "P" range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>
27 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 23 — (i12) No. 14: Without SPORT shift (U5 model) (B55) No. 3 — (i11) No. 1: With VDC system or SPORT shift (B55) No. 1 — (i12) No. 14:	Is the resistance more than 1 Ω ?	Go to step 65.	Repair the open circuit in harness between TCM connector and combination meter, and poor contact in coupling connector.
28 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 23 — Chassis ground: Without SPORT shift (U5 model) (B55) No. 3 — Chassis ground: With VDC system or SPORT shift (B55) No. 1 — Chassis ground:	Is the resistance less than 1 $M\Omega$?	Go to step 29.	Repair the ground short circuit in "P" range circuit.
29 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 17 — (T7) No. 8: Without SPORT shift (U5 model) (B55) No. 13 — (T7) No. 8: With VDC system or SPORT shift (B55) No. 3 — (T7) No. 8:	Is the resistance less than 1 Ω ?	Go to step 30.	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>30 CHECK INPUT SIGNAL FOR TCM.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to "R" range. 5) Measure the voltage between TCM and chassis ground. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 17 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 13 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 3 (+) — Chassis ground (-):</p>	<p>Is the voltage less than 1 V?</p>	<p>Go to step 31.</p>	<p>Go to step 65.</p>
<p>31 CHECK INPUT SIGNAL FOR TCM.</p> <ol style="list-style-type: none"> 1) Position the select lever to any other than "R" range. 2) Measure the voltage between TCM and chassis ground. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 17 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 13 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 3 (+) — Chassis ground (-):</p>	<p>Is the voltage more than 8 V?</p>	<p>Go to step 65.</p>	<p>Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).></p>
<p>32 CHECK "R" RANGE INDICATOR LIGHT BULB.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the "R" range indicator light bulb from combination meter. 	<p>Is "R" range indicator light bulb OK?</p>	<p>Go to step 33.</p>	<p>Replace the "R" range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.></p>
<p>33 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER.</p> <ol style="list-style-type: none"> 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 17 — (i11) No. 2: Without SPORT shift (U5 model) (B55) No. 13 — (i11) No. 2: With VDC system or SPORT shift (B55) No. 3 — (i11) No. 2:</p>	<p>Is the resistance less than 1 Ω?</p>	<p>Go to step 65.</p>	<p>Repair the open circuit in harness between TCM connector and combination meter, and poor contact in TCM connector.</p>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
34 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) <i>(B55) No. 17 — Chassis ground:</i> Without SPORT shift (U5 model) <i>(B55) No. 13 — Chassis ground:</i> With VDC system or SPORT shift <i>(B55) No. 3 — Chassis ground:</i>	Is the resistance more than 1 MΩ?	Go to step 35.	Repair the ground short circuit in "R" range circuit.
35 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) <i>(B55) No. 22 — (T7) No. 10:</i> Without SPORT shift (U5 model) <i>(B55) No. 2 — (T7) No. 10:</i> With VDC system or SPORT shift <i>(B55) No. 14 — (T7) No. 10:</i>	Is the resistance less than 1 Ω?	Go to step 36.	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.
36 CHECK INPUT SIGNAL FOR TCM. 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to "N" range. 5) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) <i>(B55) No. 22 (+) — Chassis ground (-):</i> Without SPORT shift (U5 model) <i>(B55) No. 2 (+) — Chassis ground (-):</i> With VDC system or SPORT shift <i>(B55) No. 14 (+) — Chassis ground (-):</i>	Is the voltage less than 1 V?	Go to step 37.	Go to step 65.
37 CHECK INPUT SIGNAL FOR TCM. 1) Position the select lever to any other than "N" range. 2) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) <i>(B55) No. 22 (+) — Chassis ground (-):</i> Without SPORT shift (U5 model) <i>(B55) No. 2 (+) — Chassis ground (-):</i> With VDC system or SPORT shift <i>(B55) No. 14 (+) — Chassis ground (-):</i>	Is the voltage more than 8 V?	Go to step 65.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
38 CHECK "N" RANGE INDICATOR LIGHT BULB. 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the "N" range indicator light bulb from combination meter.	Is the "N" range indicator light bulb OK?	Go to step 39 .	Replace the "N" range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>
39 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 22 — (i12) No. 12: Without SPORT shift (U5 model) (B39) No. 2 — (i11) No. 3: With VDC system or SPORT shift (B55) No. 14 — (i1) No. 3:	Is the resistance less than 1 Ω ?	Go to step 65 .	Repair the open circuit in harness between TCM connector and combination meter, and poor contact in TCM connector.
40 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 22 — Chassis ground: Without SPORT shift (U5 model) (B55) No. 2 — Chassis ground: With VDC system or SPORT shift (B55) No. 14 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 41 .	Repair the ground short circuit in "N" range circuit.
41 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 8 — (T7) No. 3: U5 model and with VDC system or SPORT shift (B55) No. 4 — (T7) No. 3:	Is the resistance less than 1 Ω ?	Go to step 42 .	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
<p>42 CHECK INPUT SIGNAL FOR TCM.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to "D" range. 5) Measure the voltage between TCM and chassis ground. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 8 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B55) No. 4 (+) — Chassis ground (-):</p>	Is the voltage less than 1 V?	Go to step 43.	Go to step 65.
<p>43 CHECK INPUT SIGNAL FOR TCM.</p> <ol style="list-style-type: none"> 1) Position select lever to any other than "D" range. 2) Measure the voltage between TCM and chassis ground. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 8 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B55) No. 4 (+) — Chassis ground (-):</p>	Is the voltage more than 8 V?	Go to step 65.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
<p>44 CHECK "D" RANGE INDICATOR LIGHT BULB.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the "D" range indicator light bulb from combination meter. 	Is the "D" range indicator light bulb OK?	Go to step 45.	Replace the "D" range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>
<p>45 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER.</p> <ol style="list-style-type: none"> 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 8 — (i11) No. 4: U5 model and with VDC system or SPORT shift (B55) No. 4 — (i11) No. 4:</p>	Is the resistance less than 1 Ω ?	Go to step 65.	Repair the open circuit in harness between TCM connector and combination meter, and TCM connector.
<p>46 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. <p>Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 8 — Chassis ground: U5 model and with VDC system or SPORT shift (B55) No. 4 — Chassis ground:</p>	Is the resistance more than 1 M Ω ?	Go to step 47.	Repair the ground short circuit in "D" range circuit.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
47 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 18 — (T7) No. 11: Without SPORT shift (U5 model) (B55) No. 14 — (T7) No. 11: With VDC system or SPORT shift (B55) No. 5 — (T7) No. 11:	Is the resistance less than 1 Ω ?	Go to step 48.	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.
48 CHECK INPUT SIGNAL FOR TCM. 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to “3” range. 5) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 18 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 14 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 5 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 49.	Go to step 65.
49 CHECK INPUT SIGNAL FOR TCM. 1) Position the select lever to any other than “3” range. 2) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 18 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 14 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 5 (+) — Chassis ground (-):	Is the voltage more than 8 V?	Go to step 65.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
50 CHECK “3” RANGE INDICATOR LIGHT BULB. 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the “3” range indicator light bulb from combination meter.	Is the “3” range indicator light bulb OK?	Go to step 51.	Replace the “3” range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
51 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 18 — (i11) No. 11: Without SPORT shift (U5 model) (B55) No. 14 — (i11) No. 11: With VDC system or SPORT shift (B55) No. 5 — (i11) No. 11:	Is the resistance more than 1 Ω ?	Go to step 65.	Repair the open circuit in harness between TCM connector and combination meter, and poor contact in TCM connector.
52 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B55) No. 18 — Chassis ground: Without SPORT shift (U5 model) (B55) No. 14 — Chassis ground: With VDC system or SPORT shift (B55) No. 5 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 53.	Repair the ground short circuit in "3" range circuit.
53 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 10 — (T7) No. 4: U5 model and with VDC system or SPORT shift (B55) No. 6 — (T7) No. 4:	Is the resistance less than 1 Ω ?	Go to step 54.	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.
54 CHECK INPUT SIGNAL FOR TCM. 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to "2" range. 5) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 10 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B55) No. 6 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 55.	Go to step 65.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
55 CHECK INPUT SIGNAL FOR TCM. 1) Position the select lever to any other than "2" range. 2) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 10 (+) — Chassis ground (-): U5 model and with VDC system or SPORT shift (B55) No. 6 (+) — Chassis ground (-):	Is the voltage more than 8 V?	Go to step 65.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
56 CHECK "2" RANGE INDICATOR LIGHT BULB. 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the "2" range indicator light bulb from combination meter.	Is the "2" range indicator light bulb OK?	Go to step 57.	Replace the "2" range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>
57 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 10 — (i11) No. 12: U5 model and with VDC system or SPORT shift (B55) No. 6 — (i11) No. 12:	Is the resistance less than 1 Ω ?	Go to step 65.	Repair the open circuit in harness between TCM and combination meter, and poor contact in TCM connector.
58 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 10 — Chassis ground: U5 model and with VDC system or SPORT shift (B55) No. 6 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 59.	Repair the ground short circuit in "2" range circuit.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
59 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and inhibitor switch. 3) Measure the resistance of harness between TCM and inhibitor switch connector. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 1 — (T7) No. 6: Without SPORT shift (U5 model) (B55) No. 22 — (T7) No. 6: With VDC system or SPORT shift (B55) No. 7 — (T7) No. 6:	Is the resistance less than 1 Ω ?	Go to step 60.	Repair the open circuit in harness between TCM and inhibitor switch connector, and poor contact in coupling connector.
60 CHECK INPUT SIGNAL FOR TCM. 1) Turn the ignition switch to OFF. 2) Connect the connector to TCM and inhibitor switch. 3) Turn the ignition switch to ON. 4) Move the select lever to "1" range. 5) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 1 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 22 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 7 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 61.	Go to step 65.
61 CHECK INPUT SIGNAL FOR TCM. 1) Position the select lever to any other than "1" range. 2) Measure the voltage between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) (B54) No. 1 (+) — Chassis ground (-): Without SPORT shift (U5 model) (B55) No. 22 (+) — Chassis ground (-): With VDC system or SPORT shift (B55) No. 7 (+) — Chassis ground (-):	Is the voltage more than 8 V?	Go to step 65.	Replace the TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
62 CHECK "1" RANGE INDICATOR LIGHT BULB. 1) Turn the ignition switch to OFF. 2) Remove the combination meter. 3) Remove the "1" range indicator light bulb from combination meter.	Is the "1" range indicator light bulb OK?	Go to step 63.	Replace the "1" range indicator light bulb. <Ref. to IDI-13, Combination Meter Assembly.>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
63 CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Disconnect the connectors from TCM and combination meter. 2) Measure the resistance of harness between TCM and combination meter. Connector & terminal Without VDC system and SPORT shift (Except U5 model) <i>(B54) No. 1 — (i11) No. 5:</i> Without SPORT shift (U5 model) <i>(B55) No. 22 — (i11) No. 5:</i> With VDC system or SPORT shift <i>(B55) No. 7 — (i11) No. 5:</i>	Is the resistance less than 1Ω?	Go to step 65.	Repair the open circuit in harness between TCM and combination meter, poor contact in TCM connector.
64 CHECK HARNESS CONNECTOR BETWEEN TCM AND INHIBITOR SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM, inhibitor switch and combination meter. 3) Measure the resistance of harness between TCM and chassis ground. Connector & terminal Without VDC system and SPORT shift (Except U5 model) <i>(B54) No. 1 — Chassis ground:</i> Without SPORT shift (U5 model) <i>(B55) No. 22 — Chassis ground:</i> With VDC system or SPORT shift <i>(B55) No. 7 — Chassis ground:</i>	Is the resistance more than 1 MΩ?	Go to step 65.	Repair the ground short circuit in “1” range circuit.
65 CHECK POOR CONTACT.	Is there poor contact in inhibitor switch circuit?	Repair the poor contact.	Adjust the inhibitor switch and select cable. <Ref. to 4AT-51, ADJUSTMENT, Inhibitor Switch.> and <Ref. to CS-31, Select Cable.>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
 AUTOMATIC TRANSMISSION (DIAGNOSTICS)

E: CHECK SPORT SHIFT SWITCH.


DIAGNOSIS:

SPORT shift switch input signal circuit is open or shorted.

TROUBLE SYMPTOM:

- No SPORT shift mode occurs.
- Does not shift gears in SPORT shift mode.

WIRING DIAGRAM:



AT-00669

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1	CHECK VEHICLE.	Go to step 2 .	Go to step SYMPTOM RELATED DIAGNOSTIC. <Ref. to 4AT(H4SO)-174, Symptom Related Diagnostic.>
2	CHECK SPORT SHIFT SWITCH.	Go to step 3 .	Go to step 5 .
3	CHECK SPORT SHIFT SWITCH.	Go to step 4 .	Go to step 12 .
4	CHECK SPORT SHIFT SWITCH.	Go to step CHECK SPORT SHIFT INDICATOR. <Ref. to 4AT(H4SO)-170, CHECK SPORT SHIFT INDICATOR., Diagnostic Procedure without Diagnostic Trouble Code (DTC).>	Go to step 19 .
5	CHECK SPORT SHIFT SWITCH GROUND LINE. 1) Turn ignition switch to OFF. 2) Disconnect connector from SPORT shift switch. 3) Measure resistance of harness between SPORT shift switch connector and chassis ground. Connector & terminal (B237) No. 4 — Chassis ground:	Go to step 6 .	Repair open circuit in harness between SPORT shift switch and chassis ground.
6	CHECK SPORT SHIFT SWITCH. Measure resistance between SPORT shift switch terminals. Connector & terminal (B237) No. 4 — No. 5:	Go to step 7 .	Replace lever plate assembly.
7	CHECK SPORT SHIFT SWITCH. 1) Move select lever to SPORT shift mode. 2) Measure resistance between SPORT shift switch terminals. Connector & terminal (B237) No. 4 — No. 5:	Go to step 8 .	Replace lever plate assembly.
8	CHECK HARNESS CONNECTOR BETWEEN TCM AND SPORT SHIFT SWITCH. 1) Disconnect connector from TCM. 2) Measure resistance of harness between TCM connector and SPORT shift switch connector. Connector & terminal (B237) No. 5 — (B56) No. 15:	Go to step 9 .	Repair open circuit in harness between SPORT shift switch connector and TCM connector and poor contact in coupling connector.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
9 CHECK HARNESS CONNECTOR BETWEEN TCM AND SPORT SHIFT SWITCH. 1) Disconnect connector from TCM. 2) Measure resistance of harness between SPORT shift switch connector and chassis ground. Connector & terminal (B237) No. 5 — Chassis ground:	Is the resistance more than 1 M Ω ?	Go to step 10.	Repair short circuit in harness between SPORT shift switch connector and TCM connector.
10 CHECK INPUT SIGNAL FOR TCM. 1) Connect connector to TCM and SPORT shift switch. 2) Turn ignition switch to ON. (Engine is stopped.) 3) Move select lever to normal mode. 4) Measure signal voltage for TCM. Connector & terminal (B56) No. 15 (+) — Chassis ground (-):	Is the voltage more than 9 V?	Go to step 11.	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
11 CHECK INPUT SIGNAL FOR TCM. 1) Move select lever to SPORT shift mode. 2) Measure signal voltage for TCM. Connector & terminal (B56) No. 15 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 26.	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
12 CHECK SPORT SHIFT SWITCH GROUND LINE. 1) Turn ignition switch to OFF. 2) Disconnect connector from SPORT shift switch. 3) Measure resistance of harness between SPORT shift switch connector and chassis ground. Connector & terminal (B237) No. 6 — Chassis ground:	Is the resistance less than 1 Ω ?	Go to step 13.	Repair open circuit in harness between SPORT shift switch and chassis ground.
13 CHECK SPORT SHIFT SWITCH. 1) Measure resistance between SPORT shift switch terminals. Connector & terminal (B237) No. 6 — No. 2:	Is the resistance more than 1 M Ω ?	Go to step 14.	Replace guide plate assembly.
14 CHECK SPORT SHIFT SWITCH. 1) Move select lever to SPORT shift mode. 2) Measure resistance between SPORT shift switch terminals. Connector & terminal (B237) No. 6 — No. 2:	Is the resistance less than 1 Ω ?	Go to step 15.	Replace guide plate assembly.
15 CHECK HARNESS CONNECTOR BETWEEN TCM AND SPORT SHIFT SWITCH. 1) Disconnect connector from TCM. 2) Measure resistance of harness between TCM connector and SPORT shift switch connector. Connector & terminal (B237) No. 2 — (B56) No. 13:	Is the resistance less than 1 Ω ?	Go to step 16.	Repair open circuit in harness between SPORT shift switch connector and TCM connector and poor contact in coupling connector.
16 CHECK HARNESS CONNECTOR BETWEEN TCM AND SPORT SHIFT SWITCH. 1) Disconnect connector from TCM. 2) Measure resistance of harness between SPORT shift switch connector and chassis ground. Connector & terminal (B237) No. 2 — Chassis ground:	Is the resistance less than 1 M Ω ?	Go to step 17.	Repair short circuit in harness between SPORT shift switch connector and TCM connector.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
17 CHECK INPUT SIGNAL FOR TCM. 1) Connect connector to TCM and SPORT shift switch. 2) Turn ignition switch to ON. (Engine is stopped.) 3) Measure signal voltage for TCM. Connector & terminal (B56) No. 13 (+) — Chassis ground (-):	Is the voltage more than 9 V?	Go to step 18 .	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
18 CHECK INPUT SIGNAL FOR TCM. 1) Move select lever to shift up side. 2) Measure signal voltage for TCM. Connector & terminal (B56) No. 13 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 26 .	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
19 CHECK SPORT SHIFT SWITCH GROUND LINE. 1) Turn ignition switch to OFF. 2) Disconnect connector from SPORT shift switch. 3) Measure resistance of harness between SPORT shift switch connector and chassis ground. Connector & terminal (B237) No. 3 — Chassis ground:	Is the resistance less than 1 Ω ?	Go to step 20 .	Repair open circuit in harness between SPORT shift switch and chassis ground.
20 CHECK SPORT SHIFT SWITCH. Measure resistance between SPORT shift switch terminals. Connector & terminal (B237) No. 3 — No. 1:	Is the resistance more than 1 M Ω ?	Go to step 21 .	Replace guide plate assembly.
21 CHECK SPORT SHIFT SWITCH. 1) Move select lever to SPORT shift mode. 2) Measure resistance between SPORT shift switch terminals. Connector & terminal (B237) No. 3 — No. 1:	Is the resistance less than 1 Ω ?	Go to step 22 .	Replace guide plate assembly.
22 CHECK HARNESS CONNECTOR BETWEEN TCM AND SPORT SHIFT SWITCH. 1) Disconnect connector from TCM. 2) Measure resistance of harness between TCM connector and SPORT shift switch connector. Connector & terminal (B237) No. 1 — (B56) No. 2:	Is the resistance less than 1 Ω ?	Go to step 23 .	Repair open circuit in harness between SPORT shift switch connector and TCM connector and poor contact in coupling connector.
23 CHECK HARNESS CONNECTOR BETWEEN TCM AND SPORT SHIFT SWITCH. 1) Disconnect connector from TCM. 2) Measure resistance of harness between SPORT shift switch connector and chassis ground. Connector & terminal (B237) No. 1 — Chassis ground:	Is the resistance less than 1 M Ω ?	Go to step 24 .	Repair short circuit in harness between SPORT shift switch connector and TCM connector.
24 CHECK INPUT SIGNAL FOR TCM. 1) Connect connector to TCM and SPORT shift switch. 2) Turn ignition switch to ON. (Engine is stopped.) 3) Measure signal voltage for TCM. Connector & terminal (B56) No. 2 (+) — Chassis ground (-):	Is the voltage more than 9 V?	Go to step 25 .	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
25 CHECK INPUT SIGNAL FOR TCM. 1) Move select lever to shift up side. 2) Measure signal voltage for TCM. Connector & terminal (B56) No. 2 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Go to step 26 .	Replace TCM. <Ref. to 4AT-79, Transmission Control Module (TCM).>
26 CHECK POOR CONTACT. Is there poor contact in SPORT shift switch circuit?	There is poor contact.	Repair poor contact.	Intermittent poor contact in SPORT shift switch circuit connector or harness

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

MEMO:

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

F: CHECK SPORT SHIFT INDICATOR.






DIAGNOSIS:

SPORT shift indicator output signal circuit is open or shorted.

TROUBLE SYMPTOM:

- SPORT shift indicator does not illuminate or remains illuminated.
- SPORT shift indicator display does not change.

WIRING DIAGRAM:



AT-01680

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No	
1	CHECK SPORT SHIFT INDICATOR.	Does SPORT shift indicator operate normally when driving in SPORT shift mode?	<Ref. to 4AT(H4SO)-172, CHECK BUZZER., Diagnostic Procedure without Diagnostic Trouble Code (DTC).>	Go to step 2.
2	CHECK COMBINATION METER.	Do meters and indicators other than SPORT shift indicator operate normally?	Go to step 3.	Check combination meter.
3	CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. 1) Turn ignition switch to OFF. 2) Disconnect connector from TCM and combination meter. 3) Measure resistance of harness between TCM and combination meter. Connector & terminal (B56) No. 3 — (i10) No. 24: (B56) No. 4 — (i10) No. 21: (B56) No. 12 — (i10) No. 26: (B56) No. 13 — (i10) No. 25:	Is the resistance less than 1 Ω ?	Go to step 4.	Repair open circuit in harness between TCM and combination meter connector and poor contact in coupling connector.
4	CHECK HARNESS CONNECTOR BETWEEN TCM AND COMBINATION METER. Measure resistance between TCM and chassis ground. Connector & terminal (B56) No. 3 — Chassis ground: (B56) No. 4 — Chassis ground: (B56) No. 12 — Chassis ground: (B56) No. 13 — Chassis ground:	Is the resistance more than 1 $M\Omega$?	Go to step 5.	Repair short circuit in harness between TCM and combination meter connector.
5	CHECK OUTPUT SIGNAL EMITTED FROM TCM. 1) Connect connector to TCM and combination meter. 2) Turn ignition switch to ON. (Engine is stopped.) 3) Measure voltage between TCM and chassis ground. Connector & terminal (B56) No. 3 (+) — Chassis ground (-): (B56) No. 4 (+) — Chassis ground (-): (B56) No. 12 (+) — Chassis ground (-): (B56) No. 13 (+) — Chassis ground (-):	Is the voltage more than 4 V?	Go to step 6.	Replace combination meter.
6	CHECK POOR CONTACT. Is there poor contact in SPORT shift indicator circuit?	There is poor contact.	Repair poor contact.	Replace TCM.

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

G: CHECK BUZZER.


DIAGNOSIS:

Buzzer output signal circuit is open or shorted.

TROUBLE SYMPTOM:

Buzzer remains sounded.

WIRING DIAGRAM:



B56

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21				22	23	24

i10

1	2	3	4	5	6	7	8	9	10	11	12	13	14		
15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

B36

A1	A2	A3	A4	A5	A6
B1	B2	B3	B4	B5	B6
C1	C2	C3	C4	C5	C6
D1	D2	D3	D4	D5	D6
E1	E2		E4	E5	E6
F1					F6
G1					G6
H1					H6
I1					I6
J1					J6
K1					K6
L1	L2		L4	L5	L6
M1	M2	N3	M4	M5	M6
N2		O3	N4	N5	N6
O1	O2		O4	O5	O6
P1	P2	P3	P4	P5	P6

DIAGNOSTIC PROCEDURE WITHOUT DIAGNOSTIC TROUBLE CODE (DTC)
AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS BETWEEN TCM AND COMBINATION METER. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from combination meter and TCM. 3) Measure the resistance between TCM connector and chassis ground. Connector & terminal (B56) No. 21 — Chassis ground:	Is the resistance more than 1 MΩ?	Go to step 2.	Repair the short circuit in harness between TCM and combination meter connector.
2 CHECK COMBINATION METER. 1) Connect the connector to combination meter. 2) Turn the ignition switch to ON. (Engine is stopped.)	Does the buzzer sound?	Replace the combination meter.	Go to step 3.
3 CHECK POOR CONTACT.	Is there poor contact in buzzer circuit?	Repair the poor contact.	Replace the TCM.

SYMPTOM RELATED DIAGNOSTIC

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

16.Symptom Related Diagnostic

A: INSPECTION

Symptom	Problem parts
Starter does not rotate when select lever is in "P" or "N" range; starter rotates when select lever is in "R", "D", "3" or "2" range.	<ul style="list-style-type: none"> • Inhibitor switch • Select cable • Select lever • Starter motor and harness
Abnormal noise when select lever is in "P" or "N" range.	<ul style="list-style-type: none"> • Strainer • Transfer duty solenoid • Oil pump • Drive plate • ATF level too high or too low
Hissing noise occurs during standing start.	<ul style="list-style-type: none"> • Strainer • ATF level too high or too low
Noise occurs while driving in "D1".	<ul style="list-style-type: none"> • Final gear • Planetary gear • Reduction gear • Differential gear oil level too high or too low
Noise occurs while driving in "D2".	
Noise occurs while driving in "D3".	<ul style="list-style-type: none"> • Final gear • Low & reverse brake • Reduction gear • Differential gear oil level too high or too low
Noise occurs while driving in "D4".	<ul style="list-style-type: none"> • Final gear • Low & reverse brake • Planetary gear • Reduction gear • Differential gear oil level too high or too low
Engine stalls while shifting from one range to another.	<ul style="list-style-type: none"> • Control valve • Lock-up damper • Engine performance • Input shaft
Vehicle moves when select lever is in "N" range.	<ul style="list-style-type: none"> • TCM • Low clutch
Shock occurs when select lever is moved from "N" to "D" range.	<ul style="list-style-type: none"> • TCM • Harness • Control valve • ATF deterioration
Excessive time lag occurs when select lever is moved from "N" to "D" range.	<ul style="list-style-type: none"> • Control valve • Low clutch • Line pressure duty solenoid • Seal ring • Front gasket transmission case
Shock occurs when select lever is moved from "N" to "R" range.	<ul style="list-style-type: none"> • TCM • Harness • Control valve • ATF deterioration
Excessive time lag occurs when select lever is moved from "N" to "R" range.	<ul style="list-style-type: none"> • Control valve • Low & reverse clutch • Reverse clutch • Line pressure duty solenoid • Seal ring • Front gasket transmission case
Vehicle does not start in any shift range (engine stalls).	<ul style="list-style-type: none"> • Parking brake mechanism • Planetary gear

SYMPTOM RELATED DIAGNOSTIC

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Symptom	Problem parts
Vehicle does not start in any shift range (engine revving up).	<ul style="list-style-type: none"> • Strainer • Line pressure duty solenoid • Control valve • Drive pinion • Hypoid gear • Axle shaft • Differential gear • Oil pump • Input shaft • Output shaft • Planetary gear • Drive plate • ATF level too low • Front gasket transmission case
Vehicle does not start in "R" range only (engine revving up).	<ul style="list-style-type: none"> • Select cable • Select lever • Control valve • Low & reverse clutch • Reverse clutch
Vehicle does not start in "R" range only (engine stalls).	<ul style="list-style-type: none"> • Low clutch • 2-4 brake • Planetary gear • Parking brake mechanism
Vehicle does not start in "D", "3" range only (engine revving up).	<ul style="list-style-type: none"> • Low clutch • One-way clutch
Vehicle does not start in "D", "3" or "2" range only (engine revving up).	<ul style="list-style-type: none"> • Low clutch
Vehicle does not start in "D", "3" or "2" range only (engine stalls).	<ul style="list-style-type: none"> • Reverse clutch
Vehicle starts in "R" range only (engine revving up).	<ul style="list-style-type: none"> • Control valve
Acceleration during standing starts is poor (high stall rpm).	<ul style="list-style-type: none"> • Control valve • Low clutch • Reverse clutch • ATF level too low • Front gasket transmission case • Differential gear oil level too high or too low
Acceleration during standing starts is poor (low stall rpm).	<ul style="list-style-type: none"> • Oil pump • Torque converter one-way clutch • Engine performance
Acceleration is poor when select lever is in "D", "3" or "2" range (normal stall rpm).	<ul style="list-style-type: none"> • TCM • Control valve • High clutch • 2-4 brake • Planetary gear
Acceleration is poor when select lever is in "R" (normal stall rpm).	<ul style="list-style-type: none"> • Control valve • High clutch • 2-4 brake • Planetary gear
No shift occurs from 1st to 2nd gear.	<ul style="list-style-type: none"> • TCM • Rear vehicle speed sensor • Front vehicle speed sensor • Throttle position sensor • Shift solenoid 1 • Control valve • 2-4 brake
No shift occurs from 2nd to 3rd gear.	<ul style="list-style-type: none"> • TCM • Control valve • High clutch • Shift solenoid 2

SYMPTOM RELATED DIAGNOSTIC

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Symptom	Problem parts
No shift occurs from 3rd to 4th gear.	<ul style="list-style-type: none"> • TCM • Shift solenoid 1 • ATF temperature sensor • Control valve • 2-4 brake
Engine brake is not effected when select lever is in "3" range.	<ul style="list-style-type: none"> • Inhibitor switch • TCM • Throttle position sensor • Control valve
Engine brake is not effected when select lever is in "3" or "2" range.	<ul style="list-style-type: none"> • Control valve
Engine brake is not effected when select lever is in "1" range.	<ul style="list-style-type: none"> • Control valve • Low & reverse brake
Shift characteristics are erroneous.	<ul style="list-style-type: none"> • Inhibitor switch • TCM • Front vehicle speed sensor • Rear vehicle speed sensor • Throttle position sensor • Control valve • Ground earth
No lock-up occurs.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • ATF temperature sensor • Control valve • Lock-up facing • Engine speed signal
Parking brake is not effected.	<ul style="list-style-type: none"> • Select cable • Select lever • Parking mechanism
Shift lever cannot be moved or is hard to move from "P" range.	
ATF spurts out.	<ul style="list-style-type: none"> • ATF level too high
Differential oil spurts out.	<ul style="list-style-type: none"> • Differential gear oil too high
Differential oil level changes excessively.	<ul style="list-style-type: none"> • Seal pipe • Double oil seal
Odor is produced from ATF supply pipe.	<ul style="list-style-type: none"> • High clutch • 2-4 brake • Low & reverse clutch • Reverse clutch • Lock-up facing • ATF deterioration
Shock occurs from 1st to 2nd gear.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • 2-4 brake duty solenoid • ATF temperature sensor • Line pressure duty solenoid • Control valve • 2-4 brake • ATF deterioration • Engine performance • 2-4 brake timing solenoid
Slippage occurs from 1st to 2nd gear.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • 2-4 brake duty solenoid • ATF temperature sensor • Line pressure duty solenoid • Control valve • 2-4 brake • 2-4 brake timing solenoid • High clutch

SYMPTOM RELATED DIAGNOSTIC

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Symptom	Problem parts
Shock occurs from 2nd to 3rd gear.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • 2-4 brake duty solenoid • ATF temperature sensor • Line pressure duty solenoid • Control valve • High clutch • 2-4 brake • ATF deterioration • Engine performance • 2-4 brake timing solenoid
Slippage occurs from 2nd to 3rd gear.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • 2-4 brake duty solenoid • ATF temperature sensor • Line pressure duty solenoid • Control valve • High clutch • 2-4 brake • 2-4 brake timing solenoid
Shock occurs from 3rd to 4th gear.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • 2-4 brake duty solenoid • ATF temperature sensor • Line pressure duty solenoid • Control valve • 2-4 brake timing solenoid • 2-4 brake • ATF deterioration • Engine performance • Low clutch timing solenoid • Low clutch
Slippage occurs from 3rd to 4th gear.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • 2-4 brake duty solenoid • ATF temperature sensor • Line pressure duty solenoid • Control valve • 2-4 brake • 2-4 brake timing solenoid
Shock occurs when select lever is moved from "3" to "2" range.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • ATF temperature sensor • Line pressure duty solenoid • Control valve • 2-4 brake duty solenoid • 2-4 brake • ATF deterioration • 2-4 brake timing solenoid
Shock occurs when select lever is moved from "D" to "1" range.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • ATF temperature sensor • Line pressure duty solenoid • Control valve • ATF deterioration • 2-4 brake duty solenoid • 2-4 brake timing solenoid • Low clutch timing solenoid

SYMPTOM RELATED DIAGNOSTIC

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

Symptom	Problem parts
Shock occurs when select lever is moved from "2" to "1" range.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • ATF temperature sensor • Line pressure duty solenoid • Control valve • Low & reverse clutch • ATF deterioration • 2-4 brake duty solenoid • 2-4 brake timing solenoid • Low clutch timing solenoid
Shock occurs when accelerator pedal is released at medium speeds.	<ul style="list-style-type: none"> • TCM • Throttle position sensor • ATF temperature sensor • Line pressure duty solenoid • Control valve • Lock-up damper • Engine performance • 2-4 brake duty solenoid • 2-4 brake timing solenoid • Low clutch timing solenoid
Vibration occurs during straight-forward operation.	<ul style="list-style-type: none"> • TCM • Lock-up duty solenoid • Lock-up facing • Lock-up damper
Vibration occurs during turns (tight corner "braking" phenomenon).	<ul style="list-style-type: none"> • TCM • Front vehicle speed sensor • Rear vehicle speed sensor • Throttle position sensor • ATF temperature sensor • Transfer clutch • Transfer valve • Transfer duty solenoid • ATF deterioration • Harness
Front wheel slippage occurs during standing starts.	<ul style="list-style-type: none"> • TCM • Front vehicle speed sensor • FWD switch • Throttle position sensor • ATF temperature sensor • Control valve • Transfer clutch • Transfer valve • Transfer pipe • Transfer duty solenoid
Vehicle is not set in FWD mode.	<ul style="list-style-type: none"> • TCM • FWD switch • Transfer clutch • Transfer valve • Transfer duty solenoid
Select lever is hard to move.	<ul style="list-style-type: none"> • Select cable • Select lever • Detente spring • Manual plate
Select lever is too high to move (unreasonable resistance).	<ul style="list-style-type: none"> • Detente spring • Manual plate
Select lever slips out of operation during acceleration or while driving on rough terrain.	<ul style="list-style-type: none"> • Select cable • Select lever • Detente spring • Manual plate