

8. Fuel Line

A: INSPECTION

The fuel line is located mostly internally, so check pipes, areas near pipes, and engine compartment piping for rust, hose damage, loose band, etc. If faulty parts are found, repair or replace them.

- 2.5 L non-turbo model

<Ref. to FU(H4SO)-56, Fuel Delivery and Evaporation Lines.>

- 2.5 L turbo model

<Ref. to FU(H4DOTC)-60, Fuel Delivery, Return and Evaporation Lines.>

- 3.0 L model

<Ref. to FU(H6DO)-56, Fuel Delivery, Return and Evaporation Lines.>