


Rear Oxygen Sensor

FUEL INJECTION (FUEL SYSTEMS)

18.Rear Oxygen Sensor

A: REMOVAL


- 1) Disconnect the ground cable from battery.



- 2) Lift-up the vehicle.
- 3) Disconnect the connector from the rear oxygen sensor.
- 4) Apply spray-type lubricant to the threaded portion of rear oxygen sensor, and leave it for one minute or more.
- 5) Remove the rear oxygen sensor.

CAUTION:

When removing the rear oxygen sensor, wait until exhaust pipe cools, otherwise it may damage the exhaust pipe.



B: INSTALLATION

- 1) Before installing rear oxygen sensor, apply the anti-seize compound only to the threaded portion of rear oxygen sensor to make the next removal easier.

Anti-seize compound:

NEVER-SEEZ NS-165 or the equivalent


CAUTION:

Never apply anti-seize compound to protector of rear oxygen sensor.

- 2) Install the rear oxygen sensor.

Tightening torque:

21 N·m (2.1 kgf-m, 15.2 ft-lb)



- 3) Connect the connector to rear oxygen sensor.
- 4) Lower the vehicle.
- 5) Connect the battery ground cable to the battery.

