

3. Ignition Coil

A: REMOVAL

Direct ignition type has been adopted. Refer to "Spark Plug" for removal procedure. <Ref. to IG(H6DO)-4, REMOVAL, Spark Plug.>

B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

16 N·m (1.6 kgf-m, 11.7 ft-lb)

C: INSPECTION

For inspection procedure, refer to "Diagnostics for Engine Starting Failure." <Ref. to EN(H6DO) (diag)-64, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>

Ignition Coil

IGNITION

IG(H6DO)-8

STARTING/CHARGING SYSTEMS

SC(H6DO)

	Page
1. General Description	2