

## 2. Wheel Alignment

### A: INSPECTION

NOTE:

Measure and adjust the front and rear wheel alignment at a time. Refer to "FS" section for measurement and adjustment of wheel alignment. <Ref. to FS-6, INSPECTION, Wheel Alignment.>