
7. Tire Pressure Monitoring System

A: REMOVAL

1. TRANSMITTER (TIRE PRESSURE SENSOR)

- 1) Remove the wheels from the vehicle. <Ref. to WT-6, REMOVAL, Steel Wheel.>
- 2) Bleed air from tire valve.
- 3) Remove the nut, and drop the transmitter in the tire.



- (1) Transmitter
- (2) Nut
- (3) Wheel
- (4) Tire
- (5) Push
- 4) Remove the tires from wheels.

CAUTION:

Use a tire changer when removing the tire from the wheel.


5) Remove the nut to take out transmitter.

NOTE:

Replace the grommet with a new part when reusing transmitter.

2. TIRE PRESSURE MONITORING CONTROL MODULE


- 1) Remove the driver's seat. <Ref. to SE-9, RE-MOVAL, Front Seat.>
- 2) Turn up the floor mat in the driver's seat area.
- 3) Remove the connector to remove tire pressure monitoring control module.



B: INSTALLATION

1. TRANSMITTER (TIRE PRESSURE SENSOR)

1) Install the transmitter to the wheel by aligning it with valve hole, and then tighten with nuts.




- (1) Transmitter
- (2) Grommet
- (3) Nut
- (4) Wheel

Tightening torque: 7.5 N⋅m (0.76 kgf-m, 5.53 ft-lb)

2) Install the tires to wheels.

CAUTION:

- Use a tire changer when installing tire to wheel.
- To prevent damaging the transmitter, set the tire changer boom in the position as shown in the figure.



- (1) Transmitter
- (2) Direction of turn table rotation
- (3) 90°
- (4) Tire changer boom
- 3) Install the wheels to vehicle. <Ref. to WT-6, IN-STALLATION, Steel Wheel.>
- 4) Register the transmitter ID to the tire pressure monitoring control module. <Ref. to TPM(diag)-9, REGISTER TRANSMITTER ID, OPERATION, Subaru Select Monitor.>

2. TIRE PRESSURE MONITORING CONTROL MODULE

Install in the reverse order of removal.

Tightening torque:

8 N·m (0.8 kgf-m, 5.8 ft-lb)

C: ADJUSTMENT

Re-register the transmitter ID when transmitter has been replaced or tires have been rotated. <Ref. to TPM(diag)-9, REGISTER TRANSMITTER ID, OP-ERATION, Subaru Select Monitor.>