1. Basic Diagnostic Procedure

A: PROCEDURE

	Step	Check	Yes	No
2	 CHECK SECURITY INDICATOR LIGHT. 1) Turn the ignition switch to "OFF" or "ACC". 2) Wait at least 60 seconds. CHECK KEY SWITCH. Remove the key from ignition switch. 	Does the security indicator light blink? Does the security indicator light blink within 1 second after removing the key?	Go to step 2.	Check the secu- rity indicator light circuit. <ref. to<br="">IM(diag)-10, CHECK SECU- RITY INDICATOR LIGHT CIRCUIT, INSPECTION, Diagnostics Chart for Security Indica- tor Light.> Check the key switch circuit. <ref. im(diag)-<br="" to="">12, CHECK KEY SWITCH CIR- CUIT, INSPEC-</ref.></ref.>
				TION, Diagnostics Chart for Security Indicator Light.>
3	CHECK SECURITY INDICATOR LIGHT. Turn the ignition switch to ON.	Does the security indicator light go off?	Go to step 5.	Go to step 4 .
4	CHECK ENGINE START. Turn the ignition switch to START.	Does the starter operate?	Check the LAN communication cir- cuit. <ref. to<br="">LAN(diag)-2, Basic Diagnostic Proce- dure.></ref.>	Check the DTC display (body inte- grated unit). Go to step 7 .
5	CHECK ENGINE START. Turn the ignition switch to START.	Does the starter operate?	Go to step 6.	Check the LAN communication cir- cuit. <ref. to<br="">LAN(diag)-2, Basic Diagnostic Proce- dure.></ref.>
6	CHECK ENGINE START. Turn the ignition switch to START.	Does the engine start?	Immobilizer sys- tem is normal.	Check the DTC display (ECM). Go to step 7 .
7	 CHECK ANY OTHER DTC ON DISPLAY. 1) Turn the ignition switch to OFF. 2) Connect the Subaru Select Monitor to the data link connector. <ref. im(diag)-7,="" monitor.="" select="" subaru="" to=""></ref.> 3) Turn the ignition switch and Subaru Select Monitor switch to ON. 4) Read DTC's on the display. 	Is the DTC displayed on screen?	Go to step 8.	Repair the related parts.
8	 PERFORM DIAGNOSIS. 1) Inspect using the "Diagnostic Procedure with Diagnostic Trouble Code (DTC)." <ref. (dtc).="" code="" diagnostic="" im(diag)-16,="" procedure="" to="" trouble="" with=""></ref.> 2) Repair the trouble cause. 3) Perform the Clear Memory Mode. 4) Read DTC's again. 	Is the DTC displayed on screen?	Inspect using the "Diagnostic Proce- dure with Diagnos- tic Trouble Code (DTC)." <ref. to<br="">IM(diag)-16, Diag- nostic Procedure with Diagnostic Trouble Code (DTC).></ref.>	Finish the diagno- sis.