# 9. List of Diagnostic Trouble Code (DTC)

# A: LIST

### 1. ECM

DTC	Item	Contents of diagnosis	Index No.
P0513	Incorrect Immobilizer Key	Incorrect immobilizer key (Use of unregistered key in body integrated unit)	<ref. (dtc).="" code="" diagnostic="" dtc="" im(diag)-16,="" immobilizer="" incorrect="" key,="" p0513="" procedure="" to="" trouble="" with=""></ref.>
P1570	Antenna	Faulty antenna	<ref. (dtc).="" antenna,="" code="" diagnostic="" dtc="" im(diag)-17,="" p1570="" procedure="" to="" trouble="" with=""></ref.>
P1571	Reference Code Incompatibility	Reference code incompatibility between body integrated unit and ECM	<ref. dtc="" im(diag)-19,="" p1571="" reference<br="" to="">CODE INCOMPATIBILITY, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
P1572	EGI — Immobilizer Communication (Excluding Antenna Circuit)	Communication failure between body integrated unit and ECM	<ref. (dtc).="" (except="" antenna="" circuit="" circuit),="" code="" diagnostic="" dtc="" failure="" im(diag)-20,="" imm="" p1572="" procedure="" to="" trouble="" with=""></ref.>
P1574	Key — Immobilizer Communication	Failure of body integrated unit to verify key (transponder) ID code	<ref. com-<br="" dtc="" im(diag)-22,="" key="" p1574="" to="">MUNICATION FAILURE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>
P1576	EGI Control Module EEPROM	ECM malfunctioning	<ref. (dtc).="" code="" control="" diagnostic="" dtc="" eeprom,="" egi="" im(diag)-23,="" module="" p1576="" procedure="" to="" trouble="" with=""></ref.>
P1577	IMM Control Module EEPROM	Body integrated unit malfunctioning	<ref. con-<br="" dtc="" im(diag)-24,="" imm="" p1577="" to="">TROL MODULE EEPROM, Diagnostic Proce- dure with Diagnostic Trouble Code (DTC).&gt;</ref.>
P1578	Meter Failure	Reference code incompatibility between body integrated unit and combination meter	<ref. dtc="" fail-<br="" im(diag)-24,="" meter="" p1578="" to="">URE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>

### NOTE:

Perform diagnosis of engine DTC when a DTC other than an immobilizer DTC is detected. <Ref. to EN(H4DOTC)(diag)-68, List of Diagnostic Trouble Code (DTC).> <Ref. to EN(H6DO) (diag)-70, List of Diagnostic Trouble Code (DTC).>

## **List of Diagnostic Trouble Code (DTC)**

#### 2. BODY INTEGRATED UNIT

DTC	Item	Contents of diagnosis	Index No.	Relation between ECM and DTC
B0401	M Collation NG	Reference code incompatibility between body integrated unit and combination meter	<ref. (dtc).="" code="" diagnostic="" dtc="" failure,="" im(diag)-24,="" meter="" p1578="" procedure="" to="" trouble="" with=""></ref.>	P1578
B0402	Immobilizer Key Collation NG	Incorrect immobilizer key (Use of unregistered key in body integrated unit)     Faulty antenna	<ref. (dtc).="" code="" diagnostic="" dtc="" im(diag)-16,="" immobilizer="" incor-rect="" key,="" p0513="" procedure="" to="" trouble="" with=""> <ref. (dtc).="" antenna,="" code="" diagnostic="" dtc="" im(diag)-17,="" p1570="" procedure="" to="" trouble="" with="">or <ref. (dtc).="" code="" communication="" diagnostic="" dtc="" failure,="" im(diag)-22,="" key="" p1574="" procedure="" to="" trouble="" with=""></ref.></ref.></ref.>	• P0513 • P1570 • P1574
B0403	E/G Request NG	Communication failure between body integrated unit and ECM	<ref. dtc="" im(diag)-20,="" imm<br="" p1572="" to="">CIRCUIT FAILURE (EXCEPT ANTENNA CIRCUIT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).&gt;</ref.>	P1572

#### NOTE:

- In immobilizer system, performing the starter relay control. When the body integrated unit detect the inconformity of reference code, immediately out put the starter relay cut signal to ECM, and then ECM stop the starter relay operation. In this case, engine does not start, and DTC is not recorded in ECM. Check that the engine does not start on the DTC of body integrated unit.
- DTC B0401 and B0402 are recorded as freeze frame data when the ignition switch becomes OFF. Therefore, if the engine is attempted to be started with an immobilizer key that is not registed, the DTC will not appear in the Subaru Select Monitor immediately. Turn the ignition switch to OFF, and turn it back to ON to check the DTC. At this time (when turning the ignition switch to ON again), note that the DTC is displayed as freeze frame data even when using a registered immobilizer key.