

13. General Diagnostic Table

A: INSPECTION

Read the DTC or inspect and diagnose the following data in the current data display using Subaru Select Monitor.

1. LAN SYSTEM

Item	Operation	Specifications		Note
		YES	NO	
Diagnostic code	DTC is not displayed when inspecting all DTCs.	DTC is not displayed.	Perform the diagnosis according to DTC.	—
Engine coolant temperature	Check the current data display of ECM, TCM and body integrated unit. Three data value are the same.	Same values	Inspect LAN system.	If engine coolant temperature sensor is not OK, inspect the sensor circuit.
R defogger SW	It turns to ON when pressing switch. (Low-speed CAN is OK)	Turns to ON.	Inspect rear defogger switch.	Rear defogger switch is connected with Low-speed CAN.
R defogger output	When switch input, it is output.	Output	Replace the body integrated unit.	If not operating with output, check the rear defogger relay.
Door lock SW	When locked with door lock switch, it turns to ON.	Turns to ON.	Inspect door lock switch.	The door lock switch is connected to the Low-speed CAN.
Door lock actuator	When locked with door lock switch, it is output.	Output	Replace the body integrated unit.	—

General Diagnostic Table

LAN SYSTEM (DIAGNOSTICS)

2. BODY INTEGRATED UNIT

Item	Operation	Specifications		Note
		YES	NO	
Illumination VR power supply	Operate the illumination volume, illumination light is controlled according to the change of voltage on data display.	Illumination light is controlled with changing of data.	Inspect the illumination volume.	—
Fuel level resistance	Check the fuel level resistance and fuel level resistance 2. Both resistances are same.	Same values	Inspect the body integrated unit.	Compare the input and output values of body integrated unit.
R wiper SW input	When rear wiper SW to ON, data display turns to ON.	Turns to ON.	Inspect the rear wiper switch.	—
R wiper output	When rear wiper switch to ON, output signal turns to ON.	Turns to ON.	Replace the body integrated unit.	If not operate with output turned to ON, check the rear wiper motor.
Keyless Entry	Keyless entry LOCK/UNLOCK the doors.	Operate	Inspect the keyless antenna.	If the antenna is OK, replace the body integrated unit.
Brake Switch	When brake pedal is depressed, it turns to ON.	Turns to ON.	Inspect the brake switch.	—
Shift Lock Solenoid	The shift lock releases when depressing the brake pedal.	Released	Inspect the shift lock.	—
Body integrated unit registration function setting	Does Vehicle equipment correspond to setting values?	Correspondence	Reconfigure the values according to vehicle equipment.	—
Customize	When changing customize setting, the registration completes correctly.	Registered	Inspect the body integrated unit.	—
Manual mode	Switch the shift (UP/DOWN) on Manual mode. Indicator is changed in 1 — 2.	Change	Inspect the shift lever.	—
Function check	Each checking item operate correctly. (Except for not equipped)	Operate	Inspect for non-functional actuator.	—
Security	After locking with keyless entry system and open the door, the security system operates and the horn sounds.	Horn sounds. (Security system operates.)	Inspect the security system.	—

WIRING SYSTEM SECTION

WIRING SYSTEM

WI

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

WIRING SYSTEM



	Page
1. Basic Diagnostic Procedure	3
2. Working Precautions	14
3. Power Supply Circuit	15
4. Ground Circuit	22
5. Engine Electrical System	32
6. Radiator Fan System	73
7. Charging System	75
8. Starter System	76
9. AT Control System	78
10. AT Shift Lock Control System	94
11. Anti-lock Brake System	95
12. Vehicle Dynamics Control System	97
13. TPM Control System	100
14. Air Conditioning System	101
15. Power Seat System	108
16. Airbag System	109
17. Seat Belt Warning System	113
18. Occupant Detection System	114
19. Seat Heater System	115
20. Headlight System	116
21. Front Fog Light System	119
22. Back-up Light System	120
23. Stop Light System	121
24. Clearance Light and Illumination Light System	122
25. Turn Signal Light and Hazard Light System	127
26. Interior Light System	129
27. Front Wiper and Washer System	133
28. Rear Wiper and Washer System	134
29. Wiper Deicer System	135
30. Audio System	136
31. Front Accessory Power Supply Socket System	138
32. Rear Accessory Power Supply Socket System	139
33. Navigation System	140
34. OP Connector System	142
35. Horn System	143
36. Power Window System	144
37. Remote Control Mirror System	148
38. Rear Defogger System	149
39. Combination Meter System	150
40. Speedmeter System	154
41. Clock System	155
42. Fuel Gauge System	156
43. Coolant Temperature System	157

44.	Oil Pressure Warning Light System	158
45.	Parking Brake / Brake Fluid Level Warning Light System	159
46.	Sunroof Control System	160
47.	Security System	162
48.	Immobilizer System	165
49.	Keyless Entry System	166
50.	Cruise Control System	170
51.	CAN Communication System	176
52.	Harness Components Location	178
53.	Front Wiring Harness	180
54.	Bulkhead Wiring Harness (In Engine Compartment)	182
55.	Bulkhead Wiring Harness (In Compartment)	184
56.	Engine Wiring Harness and Transmission Cord	187
57.	Instrument Panel Wiring Harness	193
58.	Rear Wiring Harness	195
59.	Door Cord	201
60.	Rear Wiring Harness and Trunk Lid Cord	203
61.	Rear Wiring Harness and Rear Gate Cord	205
62.	Harness Repair Kit	207