2. Door Lock System

No.	Trouble	Possible cause	Remedy
1	Door cannot be opened by outer handle. (Door can be opened by inner handle.)	Disconnect outer handle rod.	Connect firmly.
2	Door cannot be opened by inner handle. (Door can be opened by outer handle.)	a. Joint of upper rod is disconnected.b. Rear door child lock lever is set to lock side.	Connect firmly. Functionally normal.
3	Door does not open when outer or inner handle is oper- ated with inner lock knob set to unlock position.	a. Joint of lower rod is disconnected.b. Lock is not released due to improper adjustment of lower rod.	Connect firmly. Remove rod from latch. Adjust rod so that lock knob is set in "lock" position is locked.
4	Door opens even when inner lock knob is set to lock posi- tion. (Keyless locking is impossible.)	a. Lower rod joint is separated.b. Door is not locked due to improperly adjusted lower rod.	Same as a in No. 3. Same as a in No. 3.
5	Child lock lever will not come up.	a. Inner handle fails to return completely.b. Joint of upper rod is disconnected.	Refer to No. 6.
6	Inner handle stops halfway.	Contact of upper rod with inner handle mounting case.	Eliminate contact by bending upper rod properly.
7	Door cannot be locked or unlocked by key.	Joint of key lock rod is disconnected.	Connect firmly.
8	Auto door-lock switch does not act when inner lock knob is pushed.	Auto door-lock switch does not act due to improperly adjusted lower rod.	Same as a in No. 3.

3. Power Window

	Symptom				
	All windows do not move.	The window of driver side does not move.	The window of driver side does not move "AUTO" down.	The window of each passenger sides does not move.	
Battery	(1)				
Fuse in fuse box	(2)				
Circuit breaker and relay	(3)				
Main switch	(4)	(1)	(1)	(1)	
Sub switch of each passenger sides				(2)	
Motor of driver side		(2)	(2)		
Motor of each passenger sides				(3)	
Regulator assembly of each windows				(4)	
Power supply line of main switch	(5)	(3)	(3)		
Ground line	(6)				
Haness and connector	(7)	(4)	(4)	(5)	
		(): Figures in a par	enthesis refer to dia	gnostics procedures	

MEMO: