


COMPONENT PARTS

1. Intake Manifold



- | | | |
|--------------------------------------|---|--|
| (1) Intake manifold gasket LH | (17) Nipple (Equipped cruise control model) | (33) Pressure sensor |
| (2) Intake manifold gasket RH | (18) Plug | (34) Pressure sources switching solenoid valve |
| (3) Fuel injector pipe insulator | (19) PCV valve | (35) Vacuum hose A |
| (4) Fuel injector pipe | (20) Purge control solenoid valve | (36) Vacuum hose B |
| (5) O-ring A | (21) Nipple | (37) Bracket (Except Canada spec. vehicles) |
| (6) O-ring B | (22) BPT | (38) Bracket (For Canada spec. vehicles) |
| (7) Fuel injector | (23) BPT holder bracket | (39) Collar |
| (8) Insulator | (24) Back pressure hose | (40) Intake manifold |
| (9) Fuel injector cap | (25) EGR vacuum hose A | |
| (10) Plate | (26) EGR vacuum pipe | |
| (11) Sealing | (27) EGR vacuum hose C | |
| (12) Gasket | (28) EGR valve | |
| (13) Engine coolant hose B | (29) Gasket | |
| (14) Air by-pass hose | (30) EGR vacuum hose B | |
| (15) Idle air control solenoid valve | (31) EGR solenoid valve | |
| (16) Engine coolant hose A | (32) EGR pipe | |

Tightening torque: N·m (kg·m, ft·lb)

T1: 3.4 ± 0.5 (0.35 ± 0.05 , 2.5 ± 0.4)

T2: 4.9 ± 0.5 (0.5 ± 0.05 , 3.6 ± 0.4)

T3: 6.4 ± 0.5 (0.65 ± 0.05 , 4.7 ± 0.4)

T4: 16 ± 1.5 (1.6 ± 0.15 , 11.6 ± 1.1)

T5: 19 ± 1.5 (1.9 ± 0.15 , 13.7 ± 1.1)

T6: 19 ± 2 (1.9 ± 0.2 , 13.7 ± 1.4)

T7: 23 ± 3 (2.3 ± 0.3 , 16.6 ± 2.2)

T8: 25 ± 2 (2.5 ± 0.2 , 18.1 ± 1.4)

T9: 34 ± 2 (3.5 ± 0.2 , 25.3 ± 1.4)
