

## 1. Select Lever

| Symptom         | Possible cause   | Remedy  |
|-----------------|--|---|
| 1. Select lever | (1) Starter does not run.                                | Adjust select cable and inhibitor switch, or inspect circuit.               |
|                 | (2) Back-up light does not light up.                     | Adjust select cable and inhibitor switch, or inspect circuit.               |
|                 | (3) Select lever does not move from "P" to "R" position. | Adjust select cable and inhibitor switch, or inspect AT shift-lock circuit. |