#### **BODY SECTION**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)	AC
AIRBAG SYSTEM	АВ
SEAT BELT SYSTEM	SB
LIGHTING SYSTEM	LI
WIPER AND WASHER SYSTEMS	ww
ENTERTAINMENT	ET
COMMUNICATION SYSTEM	СОМ
GLASS/WINDOWS/MIRRORS	GW
BODY STRUCTURE	BS
BODY STRUCTURE  INSTRUMENTATION/DRIVER INFO	IDI
INSTRUMENTATION/DRIVER INFO	IDI
INSTRUMENTATION/DRIVER INFO SEATS	IDI SE
INSTRUMENTATION/DRIVER INFO SEATS SECURITY AND LOCKS SUNROOF/T-TOP/CONVERTIBLE TOP	IDI SE SL
INSTRUMENTATION/DRIVER INFO  SEATS  SECURITY AND LOCKS  SUNROOF/T-TOP/CONVERTIBLE TOP (SUNROOF)	IDI SE SL SR
INSTRUMENTATION/DRIVER INFO  SEATS  SECURITY AND LOCKS  SUNROOF/T-TOP/CONVERTIBLE TOP (SUNROOF)  EXTERIOR/INTERIOR TRIM	IDI SE SL SR

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**FUJI HEAVY INDUSTRIES LTD.** 

# **BODY STRUCTURE**

# BS

		Page
1.	General Description	2
	Datum Points	
3	Datum Dimensions	15

# 1. General Description S906001

## A: PREPARATION TOOL S906001A17

TOOL NAME	REMARKS
Tram tracking gauge	Used for measuring dimension.
Tape measure	Used for measuring dimension


## 2. Datum Points \$906540

#### A: LOCATION S906540A13

#### NOTE:

- Datum points are specified for body repair.
- Guide holes, locators, and indents are provided to facilitate panel replacement and to increase alignment accuracy.
- Both right and left reference points are symmetrical.

#### 1. ROOM SECTION S906540A1301




- Radiator panel (UPR) repair bolt hole M8 (Right)
- (2) Radiator panel (UPR) repair bolt hole M8 (Left)
- (3) Fender attaching bolt hole M6 (Symmetrical)
- (4) Repair locator 8 mm (0.31 in) dia. (Symmetrical)
- (5) Radiator panel side gauge hole 24 mm (0.94 in) dia. (Symmetrical)
- (6) Front bumper mounting hole 14  $\times$  16 mm (0.55  $\times$  0.63 in) dia. (Symmetrical)
- (7) Front crossmember attaching bolt hole 12.4 mm (0.488 in) dia. (Symmetrical)
- (8) Fender attaching bolt hole M6 (Symmetrical)
- (9) Front strut mounting hole 9.5 mm (0.374 in) dia. (Symmetrical)

- (10) Hood hinge attaching bolt hole M8 (Symmetrical)
- (11) Cowl panel mounting hole 6 mm (0.24 in) dia. (Symmetrical)
- (12) Roof inner trim attaching bolt hole 8 mm (0.31 in) dia.
- (13) Fender attaching bolt hole M6 (Symmetrical)
- (14) Front pillar gauge hole 20 mm (0.79 in) dia. (Symmetrical)
- (15) Wax coat hole 20 mm (0.79 in) dia. (Symmetrical)
- (16) Retainer attaching square hole 7 mm (0.28 in) (Symmetrical)
- (17) Sun visor attaching hole 17 mm (0.67 in) dia. (Symmetrical)
- (18) Retainer attaching square hole 7 mm (0.28 in) (Symmetrical)
- (19) Retainer attaching square hole 7 mm (0.28 in) (Symmetrical)

- (20) Center pillar gauge hole 12 mm (0.47 in) dia. (Symmetrical)
- (21) Belt anchor attaching bolt hole 11.1 mm (7/16 in) dia. (Symmetrical)
- (22) Wax coat hole, 20 mm (0.79 in) dia. (Symmetrical)
- (23) Rear door switch attaching hole 20 mm (0.79 in) dia. (Symmetrical)
- (24) Retainer attaching square hole 7 mm (0.28 in) (Symmetrical)
- (25) Spare tire attaching bolt hole M8
- (26) Air draw hole 7 mm (0.28 in) dia. (Symmetrical)
- (60) Fender attaching bolt hole M6 (Symmetrical)
- (64) Door switch attaching hole 13.5 mm (0.531 in) dia. (Symmetrical)
- (67) Front glass attaching hole Right 6.5 mm (0.256 in) dia. Left 6.5  $\times$  10 mm (0.256  $\times$  0.39 in) dia.

#### 2. REAR SECTION S906540A1302




- (27) Rear pillar (Inner) harness and hose clip attaching hole 7 mm (0.28 in) dia. (Symmetrical)
- (34) Rear skirt gauge hole 20 mm (0.79 in) dia. (Symmetrical)
- (36) Rear quarter bumper side gauge hole 20 mm (0.79 in) dia. (Left)
- (37) Rear quarter bumper side gauge hole 20 mm (0.79 in) dia. (Right)
- (38) Instrument panel attaching square hole  $22 \times 34.5$  mm (0.87  $\times$  1.358 in) (Right)
- (39) Steering support beam attaching bolt hole M8 (Symmetrical)
- (40) Front pillar (Inner) gauge hole 10 mm (0.39 in) dia. (Symmetrical)
- (41) Floor mat attaching clip hole 8 mm (0.31 in) dia. (Symmetrical)
- (42) Rear quarter glass attaching hole  $8 \times 15$  mm (0.31  $\times$  0.59 in) dia. (Symmetrical)


- (43) Pad attaching square hole 9 mm (0.35 in) dia. (Symmetrical)
- (44) Rear quarter glass attaching hole 8 mm (0.31 in) dia. (Symmetrical)
- (45) Rear locator hollow 4 mm (0.16 in) dia.
- (46) Rear strut mounting hole 10 mm (0.39 in) dia. (Symmetrical)
- (47) Rear gate stay attaching bolt hole M8 (Symmetrical)
- (48) Inner trim clip attaching hole  $8 \times 20$  mm (0.31  $\times$  0.79 in) dia. (Symmetrical)
- (49) Rear combination light mounting hole 8 mm (0.31 in) dia. (Symmetrical)
- (61) Side rail (Inner) gauge hole 10 mm (0.39 in) dia. (Symmetrical)
- (65) Repair location hole 12 mm (0.47 in) dia. (Symmetrical)

- (70) Buffer attaching hole M6 (Symmetrical)
- (71) Bumper face attaching square hole  $8 \times 9$  mm (0.31  $\times$  0.35 in)
- (72) Bumper face attaching square hole  $8 \times 9$  mm (0.31  $\times$  0.35 in) (Symmetrical)
- (73) Head console bracket gauge hole 8 mm (0.31 in) dia.
- (74) Inner system carrier attaching bolt hole 8 mm (0.31 in) (Symmetrical)
- (75) Inner system carrier attaching bolt hole 8 mm (0.31 in) (Symmetrical)
- (76) Head console bracket gauge hole 8 mm (0.31 in) dia.


#### 3. UNDERBODY SECTION S906540A1303





- (50) Radiator panel (LWR) frame gauge hole 15 mm (0.59 in) dia. (Symmetrical)
- (51) Front side frame gauge hole 20 mm (0.79 in) dia. (Symmetrical)
- (52) Front crossmember attaching hole 12.4 mm (0.488 in) dia. (Symmetrical)
- (53) Front suspension attaching bolt hole M14
- (54) Side frame gauge hole 20 mm (0.79 in) dia. (Symmetrical)
- (55) Repair location hole 12 mm (0.47 in) dia. (Symmetrical)
- (56) Side frame gauge hole 15 mm (0.59 in) dia. (Symmetrical)
- (57) Rear differential attaching bolt hole M12 (Symmetrical)
- (58) Rear suspension attaching bolt hole M12 (Symmetrical)
- (59) Rear side frame gauge hole 15 mm (0.59 in) dia. (Symmetrical)




#### **DATUM POINTS**












#### **DATUM POINTS**








#### 3. Datum Dimensions S906337

#### A: MEASUREMENT S906337A14


Refer to LOCATION for details on measurement points. <Ref. to BS-3, LOCATION, Datum Points.>

#### NOTE:


- Using a tram tracking gauge, measure all the dimensions.
- When using a tape measure, carefully measure dimensions without letting the tape measure sag or twist
- Measure the linear dimensions between CENTERS of holes.
- Suffixes "RH" and "LH" indicate right-hand and left-hand.



• Measure at the center of the circle around the outside of the body panel.




#### 1. FRONT STRUCTURE S906337A1401




			Unit: mm (in)
Point to point	Dimension	Point to point	Dimension
(11) R to (1)	852 (33.54)	(10) R to (8) R	390 (15.35)
(11) L to (1)	913 (35.94)	(10) L to (8) L	390 (15.35)
(11) R to (2)	960 (37.80)	(11) L to (9) R	659 (25.94)
(11) L to (2)	865 (34.06)	(11) R to (9) L	659 (25.94)
(11) R to (9) R	392 (15.43)	(9) R to (9) L	966 (38.03)
(11) L to (9) L	392 (15.43)	(11) L to (6) R	1,059 (41.69)
(11) R to (6) R	926 (36.46)	(11) R to (6) L	1,059 (41.69)
(11) L to (6) L	926 (36.46)	(6) R to (6) L	914 (35.98)
(11) R to (3) R	891 (35.08)	(6) R to (10) L	1,549 (60.98)
(11) L to (3) L	891 (35.08)	(6) L to (10) R	1,549 (60.98)
(10) R to (3) R	917 (36.10)	(8) R to (3) R	528 (20.79)
(10) L to (3) L	917 (36.10)	(8) L to (3) L	528 (20.79)
(10) R to (10) L	1,374 (54.09)	(10) L to (3) R	1,637 (64.45)
(3) R to (3) L	1,338 (52.68)	(8) R to (8) L	1,396 (54.96)
(5) R to (5) L	924 (36.38)	(8) R to (10) L	1,438 (56.61)
(4) R to (4) L	1,296 (51.02)	(8) L to (10) R	1,438 (56.61)
(5) R to (4) L	1,176 (46.30)	(3) R to (8) L	1,465 (57.68)
(5) L to (4) R	1,176 (46.30)	(3) L to (8) R	1,465 (57.68)
(60) R to (13) R	1,174 (46.22)	(7) R to (7) L	860 (33.86)
(60) L to (13) L	1,174 (46.22)	(7) R to (6) L	982 (38.66)
(60) R to (14) R	1,076 (42.36)	(7) L to (6) R	982 (38.66)
(60) L to (14) L	1,076 (42.36)	(7) R to (10) L	1,302 (51.26)
(10) R to (3) L	1,637 (64.45)	(7) L to (10) R	1,302 (51.26)

#### **DATUM DIMENSIONS**




			Unit: mm (in)
Point to point	Dimension	Point to point	Dimension
(11) to (A)	909.9 (35.82)	(11) to (C)	1,097.7 (43.22)
(11) to (B)	915 (36.02)	(11) to (D)	1,022 (40.24)

#### 2. CENTER STRUCTURE S906337A1402



S5M0138B


## 3. WINDSHIELD AND DOORS S906337A1403



#### **DATUM DIMENSIONS**

			Unit: mm (in)
Point to point	Dimension	Point to point	Dimension
(14) L to (18) L	1,453 (57.20)	(16) L to (64) L	859 (33.82)
(14) R to (18) R	1,453 (57.20)	(16) R to (64) R	859 (33.82)
(13) L to (64) L	944 (37.17)	(20) L to (23) L	845 (33.27)
(13) R to (64) R	944 (37.17)	(20) R to (23) R	845 (33.27)
(20) L to (24) L	947 (37.28)	(19) L to (23) L	885 (34.84)
(20) R to (24) R	947 (37.28)	(19) R to (23) R	885 (34.84)
(20) L to (36)	1,484 (58.43)	(11) L to (67) R	1,147 (45.16)
(20) R to (37)	1,488 (58.58)	(11) R to (67) L	1,147 (45.16)
(42) L to (44) L	769 (30.28)	(41) to (38)	1,157 (45.55)
(42) R to (44) R	769 (30.28)	(41) to (39) R	1,530 (60.24)
(11) R to (12)	918 (36.14)	(41) to (39) L	1,530 (60.24)
(11) L to (12)	918 (36.14)	(41) to (40) R	1,447 (56.97)
(67) R to (67) L	1,045 (41.14)	(41) to (40) L	1,447 (56.97)
(11) R to (67) R	1,006 (39.61)	(41) to (15) R	1,140 (44.88)
(11) L to (67) L	1,006 (39.61)	(41) to (15) L	1,140 (44.88)
(12) to (67) L	525 (20.67)	(41) to (22) R	733 (28.86)
(12) to (67) R	525 (20.67)	(41) to (22) L	733 (28.86)
(12) to (10) L	1,027 (40.43)	(41) to (26) R	1,568 (61.73)
(12) to (10) R	1,027 (40.43)	(41) to (26) L	1,568 (61.73)
(21) R to (21) L	1,322 (52.05)	(41) to (25)	1,212 (47.72)
(15) R to (15) L	1,453 (57.20)	(41) to (12)	1,298 (51.10)
(22) R to (22) L	1,453 (57.20)	(41) to (21) R	944 (37.17)
(39) R to (39) L	1,392 (54.80)	(41) to (21) L	944 (37.17)
(40) R to (40) L	1,402 (55.20)	(41) to (17) R	1,332 (52.44)
(11) L to (17) R	1,168 (45.98)	(41) to (17) L	1,332 (52.44)
(11) R to (17) L	1,168 (45.98)		

#### 4. COMPARTMENT \$906337A1404



			Unit: mm (in)
Point to point	Dimension	Point to point	Dimension
(45) to (48) L	862 (33.94)	(41) to (65) R	1,131 (44.53)
(45) to (48) R	862 (33.94)	(41) to (65)L	1,131 (44.53)
(45) to (47) L	876 (34.49)	(41) to (45)	1,569 (61.77)
(45) to (47) R	876 (34.49)	(41) to (43) R	1,435 (56.50)
(47) R to (47) L	1,426 (56.14)	(41) to (43) L	1,435 (56.50)
(49)R to (49) L	1,479 (58.23)	(41) to (48) L	1,576 (62.05)
(34) R to (34) L	945 (37.20)	(41) to (48) R	1,576 (62.05)
(48) R to (46) R	992 (39.06)	(65) R to (65) L	1,267 (49.88)
(48) L to (46) L	992 (39.06)	(17) R to (76)	627 (24.68)
(70) R to (70) L	1,218 (47.95)	(17) L to (76)	680 (26.77)
(61) R to (75) R	447 (17.60)	(72) R to (72) L	1,111 (43.74)
(61) L to (75) L	447 (17.60)	(74) R to (75) R	480 (18.90)
(17) R to (75) R	1,137 (44.76)	(74) L to (75) L	480 (18.90)
(17) L to (75) L	1,137 (44.76)	(17) R to (73)	518 (20.39)
(45) to (71)	913 (35.94)	(17) L to (73)	476 (18.74)

#### **DATUM DIMENSIONS**

Body	Structure
------	-----------

MEMO: