

# BULKHEAD WIRING HARNESS (IN COMPARTMENT)

WIRING SYSTEM

## 49. Bulkhead Wiring Harness (In Compartment)

### A: LOCATION

#### • Bulkhead Wiring Harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B30	25	★	C-1	D1	Front door cord LH
B31	6	Yellow	D-1		Airbag wiring harness
B32	3	Black	B-3		Turn & hazard module
B36	24	★	C-1	i1	Instrument panel wiring harness
B38	32	★	B-1	i3	
B40	16	Black	C-2		Data link connector
B41	2	★	C-1		Power window circuit breaker
B46	4	Green	B-5		Fuel pump relay
B47	6	Brown	B-5		Main relay
B50	4	★	C-1		Blower fan relay
B51	8	Blue	C-1		Fuse & relay box (F/B)
B52	7	★	C-1		
B54	17	★	B-2		Transmission control module (Turbo model)
	24	★	B-2		Transmission control module (Non-turbo model)
B55	24	Gray	B-2		Transmission control module (Non-turbo model)
	24	★	B-2		Transmission control module (Turbo model)
B56	24	★	B-2		Transmission control module (Turbo model)
B59	6	★	B-2		Interrupt relay (Security)
B61	6	★	B-1	F44	Front wiring harness
B62	16	★	B-2	F45	
B64	2	Black	B-2		Stop light switch
B65	4	Black	B-2		Stop & brake switch
B69	4	★	B-3		Combination switch
B70	18	★	B-3		
B71	17	★	B-3		
B72	4	Blue	C-3		Ignition switch
B73	2	★	C-3		Key lock solenoid (AT model)
B74	2	Black	C-3		Key warning switch
B75	2	Green	C-2	B76	Test mode connector
B76	2	Green	C-2	B75	
B77	10	Brown	B-3		Mode actuator (Auto A/C)
B79	14	Gray	C-2		Check connector
B81	1×2	★	C-2		Diagnosis terminal (Ground)
B82	6	Black	C-2		Diagnosis connector

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B83	8	★	C-4		Shield joint connector (Turbo model)
B86	6	Black	B-4		Blower motor resistor
B87	2	★	B-4		Blower motor (Manual A/C)
	6	★	B-4		Blower motor (Auto A/C)
B90	8	★	B-5	R50	Roof cord
B91	4	★	B-4		F/REC actuator
B93	18	★	B-4		Security control module
B94	20	Black	B-4		Cruise control module (Non-turbo model)
B95	2	Brown	B-4		Diode (Daytime running light)
B96	10	★	B-4		Daytime running light control module
B100	20	Blue	B-2	F2	Front wiring harness
B101	25	★	B-5	D11	Front door cord RH
B102	5	Black	B-5		Daytime running light relay
B103	5	Blue	B-5		High-beam relay (Daytime running light)
B104	4	Red	C-1		Luggage room power supply relay
B106	2	★	B-2		Clutch switch (MT model)
B107	2	Blue	B-2		Clutch switch (Model with cruise control)
B108	2	Black	B-1	F46	Front wiring harness
B112	2	Black	B-3		Diode (Front fog light)
	4	Brown	B-3		Diode (Front fog light) (Turbo AT model)
B117	6	★	C-4		AT select lever
B119	4	★	C-4		Front accessory power supply socket
B122	22	★	C-4		Shield joint connector
B134	35	Gray	C-4		Engine control module (Non-turbo model)
	34	★	C-4		Engine control module (Turbo model)
B135	28	Gray	B-4		Engine control module (Non-turbo model)
	35	★	B-4		Engine control module (Turbo model)
B136	26	Gray	B-4		Engine control module (Non-turbo model)
	35	★	B-4		Engine control module (Turbo model)
B137	20	Gray	B-4		Engine control module (Non-turbo model)
	31	★	B-4		Engine control module (Turbo model)
B152	12	★	C-1		Fuse & relay box (F/B)

# BULKHEAD WIRING HARNESS (IN COMPARTMENT)

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B153	8	★	B-2		Shield joint connector
B158	10	Gray	C-1		Fuse & relay box (F/B)
B160	6	Gray	C-2		Front fog light switch
B161	6	Brown	C-2		Cruise control switch
B173	1	★	C-1		IG power supply connector
B176	18	★	B-5		Keyless entry control module
B177	2	★	B-5		Wiper deicer
B183	1	★	C-1		Joint connector (Keyless entry)
B184	1	★	C-1		
B193	8	Black	C-2		Wiper deicer switch
B198	1	★	B-3		Ground joint connector
B199	1	★	B-3		
B200	24	Black	B-2	F74	Front wiring harness
B201	24	Black	C-4	i40	Instrument panel wiring harness
B202	24	★	C-4	i41	Instrument panel wiring harness (Auto A/C)
	20	★	C-4	i41	Instrument panel wiring harness (Manual A/C)
B224	2	★	C-3		Key illumination light (Turbo model)
B225	8	Black	C-2		Fuse (Relay block)
	5	Black	C-2		Ignition relay (Relay block)
	5	Black	C-2		Power window relay (Relay block)
	5	Black	C-2		Front fog light relay (Relay block)
	5	Black	C-2		Starter interlock relay (Relay block)
	5	Black	C-2		Wiper deicer & mirror heater relay (Relay block)
B225	5	Black	C-2		Seat heater relay (Relay block)
B236	5	Black	C-3		Steering roll connector
B243	6	★	B-2		Security horn relay
B256	3	★	B-4		Evaporator thermo switch
B271	12	Blue	C-1		Fuse & Relay Box F/B
B280	16	Blue	C-3		Body integrated unit
B281	20	Gray	C-3		
B292	3	★	C-4		ABS G sensor
B300	6	★	C-2		Line end check connector
B309	4	Black	B-5		Electric control throttle relay
B315	6	Black	B-3		Accelerator position sensor

★: Non-colored

# BULKHEAD WIRING HARNESS (IN COMPARTMENT)

## WIRING SYSTEM

---

### • Airbag Wiring Harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
AB1	6	Yellow	D-1	B31	Bulkhead wiring harness
AB2	2	Yellow	C-3		Inflator (Driver's seat)
AB3	28	Yellow	C-4		Airbag control module
AB4	4	Yellow	B-5		Inflator (Passenger's seat)
AB13	2	Yellow	C-1	AB14	Front sub sensor harness
AB21	2	Yellow	C-3	AB26	Airbag wiring harness
AB26	2	Yellow	C-3	AB21	Airbag wiring harness

