4. Remote Control Mirror System

A: WIRING DIAGRAM

1. REMOTE CONTROL MIRROR

<Ref. to WI-134, WIRING DIAGRAM, Remote Control Mirror System.>

B: INSPECTION

Symptom	Repair order
All function does not operate.	1. Fuse (F/B No. 4) (F/B No. 13) (F/B No. 17) (F/B No. 18)
	2. Mirror switch
	3. Wiring harness
One side of the mirror motor does not operate.	1. Mirror switch
	2. Mirror motor
	3. Wiring harness
Mirror heater does not operate.	1. Mirror switch
	2. Mirror heater
	3. Wiring harness