


### 3. Electrical Component Location

#### A: LOCATION



IM-00118

- |   |                                     |                 |
|---|-------------------------------------|-----------------|
| (1) Antenna                             | (3) Immobilizer control module (IMM | (4) Transponder |
| (2) Security indicator light (LED bulb) | ECM)                                |                 |