


Electrical Component Location

OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)


3. Electrical Component Location

A: LOCATION




OD-00057

- (1) Occupant detection control module
- (2) Occupant detection sensor
- (3) Seat belt tension sensor
- (4) Buckle switch (Passenger's seat)



Electrical Component Location

OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)



(A) For North America model

(B) For Canada model

(1) Passenger's airbag OFF indicator light

(2) Passenger's airbag ON indicator light