Clear Memory Mode

AUTOMATIC TRANSMISSION (DIAGNOSTICS)

9. Clear Memory Mode

A: OPERATION

Refer to "Subaru Select Monitor" for information about how to clear a DTC. <Ref. to 4AT(D)(diag)-15, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>