



# Starter System

WIRING SYSTEM

## 17. Starter System

### A: WIRING DIAGRAM

#### 1. MT MODEL



WI-15028



# Starter System

WIRING SYSTEM

## 2. AT NON-TURBO MODEL

ST(AT/NA)-01

ST(AT/NA)-01




WI-15029

# Starter System

## WIRING SYSTEM

### 3. AT TURBO MODEL



WI-15030