


### 4. Datum Points and Dimensions Concerning On-Board Aiming Adjustment

If headlight aiming is misaligned due to damaged body panel, repair headlight mating surface using body and headlight datum points as a guide.



Unit: mm (in)

⑪	—	Ⓐ <sub>L</sub>	}	:	993 (39.09)	⑪	—	Ⓑ <sub>L</sub>	}	:	1,048 (41.26)
⑪	—	Ⓐ <sub>R</sub>				⑪	—	Ⓑ <sub>R</sub>			