


1. Front Hood and Hood Lock



- ① Front hood
- ② Hinge (RH, LH)
- ③ Hood hinge cover (RH, LH)
- ④ Lever ASSY
- ⑤ Cable
- ⑥ Stopper

- ⑦ Hood lock ASSY
- ⑧ Striker
- ⑨ Front hood stay
- ⑩ Seal (Front hood) SD
- ⑪ Seal (Front hood) CTR

Tightening torque: N-m (kg-m, ft-lb)
T1: 9 — 19
(0.9 — 1.9, 6.5 — 13.7)
T2: 31 — 33 (3.2 — 3.4, 23 — 25)