


**1. Starter**



G6M0026

- ① Sleeve bearing
- ② Front bracket
- ③ Lever set
- ④ Magnet switch Assy
- ⑤ Yoke
- ⑥ Gear ASSY

- ⑦ Shaft ASSY
- ⑧ Internal gear ASSY
- ⑨ Over running clutch
- ⑩ Stopper set
- ⑪ Packing

- ⑫ Ball
- ⑬ Armature
- ⑭ Brush holder
- ⑮ Bearing
- ⑯ Rear bracket