

BULKHEAD WIRING HARNESS (IN COMPARTMENT)

WIRING SYSTEM

52. Bulkhead Wiring Harness (In Compartment)

A: LOCATION

• Bulkhead Wiring Harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B30	25	★	C-1	D1	Front door cord LH
B31	6	Yellow	D-1		SRS (Airbag) harness
B32	3	Black	B-1		Turn & hazard module
B36	24	Brown	B-3	i1	Instrument panel wiring harness
B37	24	★	B-3	i2	
B40	16	★	C-3		Data link connector
B41	2	★	C-1		Power window circuit breaker
B42	5	★	A-1		Power window relay (Relay block)
B46	4	Green	B-5		Fuel pump relay
B47	4	Brown	B-5		Main relay
B50	4	★	C-1		Blower fan relay
B51	8	Blue	C-1		Fuse & relay box (F/B)
B52	7	★	C-1		
B53	12	★	C-2		Shield joint connector (AT turbo model)
	8	★	C-2		Shield joint connector (AT non-turbo model)
B54	24	★	B-2		Transmission control module
B55	24	Gray	B-2		
B56	24	Green	B-2		Transmission control module (Turbo engine model)
B59	6	★	B-3		Interrupt relay (Security)
B61	8	★	B-2	F44	Front wiring harness
B62	24	★	B-2	F45	
B65	5	Black	B-2		Stop & brake switch
B68	5	Black	C-3		Cruise control sub switch & horn switch (Roll connector)
B69	4	★	C-3		Combination switch
B70	18	★	C-3		
B71	17	★	C-3		
B72	4	Blue	B-3		Ignition switch
B73	2	★	B-3		Key lock solenoid
B74	2	Black	C-3		Key warning switch
B75	2	Green	C-2	B76	Test mode connector
B76	2	Green	C-2	B75	
B77	3	★	B-4		Mode actuator
B79	14	Gray	C-3		Check connector
B81	1×2	★	C-2		Diagnosis terminal (Ground)
B82	6	Black	C-2		Diagnosis connector

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B83	8	★	C-5		Shield & sensor ground joint connector (Turbo engine model)
	6	★	C-5		Shield & sensor ground joint connector (Non-turbo engine model)
B84	31	★	B-4		Engine control module (Turbo engine model)
B86	4	Brown	B-4		Blower motor resistor
B87	2	★	B-4		Blower motor
B88	4	Brown	B-4		Evaporation thermostat
B90	6	★	B-5	R50	Roof cord
B93	18	★	B-4		Security control module
B94	20	Black	C-4		Cruise control module
B95	2	★	B-4		Diode (Daytime running light)
B96	10	★	B-5		Daytime running light control module
B100	24	Black	B-1	F2	Front wiring harness
B101	25	★	B-5	D11	Front door cord RH
B102	5	★	B-5		Daytime running light relay
B103	5	★	B-5		High-beam relay (Daytime running light)
B106	2	★	B-2		Clutch switch (MT model)
B107	2	Blue	B-2		Clutch switch (Cruise control)
B108	2	Black	B-1	F96	Front wiring harness
B112	2	★	B-3		Diode (Front fog light)
B117	6	★	C-4		AT select lever
B118	2	★	B-4		CD player illumination light
B119	4	★	C-4		Front accessory power supply socket
B120	14	★	B-4		Radio
B121	1	Black	B-4		Audio bracket ground
B122	6	★	C-5		Joint connector (STi model)
B125	1	Green	B-5	B126	Line end connector
B126	1	Green	B-5	B125	
B132	8	★	C-1		Headlight leveler switch

BULKHEAD WIRING HARNESS (IN COMPARTMENT)

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B134	22	★	B-4		Engine control module (Turbo engine model)
	28	★	C-4		Engine control module (Non-turbo engine model)
	34	★	C-4		Engine control module (STi model)
B135	28	★	B-4		Engine control module (Turbo engine model)
	20	★	B-4		Engine control module (Non-turbo engine model)
	35	★	B-4		Engine control module (STi model)
B136	17	★	B-4		Engine control module (Turbo engine model)
	26	★	B-4		Engine control module (Non-turbo engine model)
	35	★	B-4		Engine control module (STi model)
B137	24	★	C-4		Engine control module (Turbo engine model)
	35	★	B-4		Engine control module (Non-turbo engine model)
	31	★	B-4		Engine control module (STi model)
B152	12	★	C-1		Fuse & relay box (F/B)
B158	10	Gray	C-1		
B160	6	Gray	C-1		Front fog light switch
B161	6	Brown	C-1		Cruise control switch
B168	10	★	C-4		Mode control panel
B169	6	★	C-4		Blower fan switch
B176	18	★	C-1		Keyless entry control module
B177	2	Brown	B-1		Wiper deicer
B183	1	★	D-1		Joint connector (Keyless entry)
B184	1	★	D-1		
B191	4	Blue	B-5		Wiper deicer relay
B192	4	★	B-5		Wiper deicer timer
B193	6	★	C-1		Wiper deicer switch
B198	5	★	C-5		Ground joint connector
B200	16	Blue	B-2	F74	Front wiring harness (Except for STi model)
	20	Blue	B-2	F74	Front wiring harness (STi model)
B208	2	Black	B-5		Glove box light
B224	2	★	B-3		Key illumination light (Turbo engine model)

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B225	8	Black	C-2		Fuse (Relay block)
	5	Black	C-2		Ignition relay (Relay block)
	5	Black	C-2		Power window relay (Relay block)
	5	Black	C-2		Front fog light relay (Relay block)
	5	Black	C-2		Starter interlock relay (Relay block)
	5	Black	C-2		Mirror heater relay (Relay block)
	5	Black	C-2		Rear 12 V accessory relay (Relay block)
	5	★	C-2		HID relay (Relay block)
B243	6	★	B-3		Security horn relay
B256	2	★	B-4		Evaporator sensor
B257	3	★	C-5		ABS lateral G sensor (STi model)
B258	3	★	D-4		Driver's control center differential switch
B261	6	★	C-5		Shield joint connector (STi model)
B264	4	Red	C-1		ABS relay
B271	12	Blue	C-1		F/B
B275	4	★	B-4		Fan control amplifier
B280	16	Blue	C-3		Integrated module
B281	20	Gray	C-3		
B282	16	Gray	C-4		Auto A/C control module
B283	20	Gray	C-4		
B284	10	★	D-5		Remote control rear view mirror switch
B286	4	★	B-5		Intercooler water spray timer
B288	4	Blue	C-1		Driver's control center differential relay
B289	40	★	B-3		Driver's control center differential control unit
B292	3	★	D-5		ABS G sensor
B293	3	Gray	B-4		Air mix actuator
B294	6	★	C-1		Intercooler water spray switch
B300	6	★	C-2		Line end check connector
B304	2	★	B-5		ABS condenser
B309	4	Black	B-5		Electric control throttle relay
B315	6	★	B-3		Accelerator position sensor
B338	3	★	C-5		Driver's control center differential G sensor
B339	6	Blue	C-4		Auto/manual switch

★: Non-colored

