


# TRANSMISSION MOUNTING

MANUAL TRANSMISSION AND DIFFERENTIAL

## 4. Transmission Mounting



MT-00334

(1) Pitching stopper

(2) Cushion rubber

(3) Cross member

5MT-15

## TRANSMISSION MOUNTING

MANUAL TRANSMISSION AND DIFFERENTIAL

---

**MEMO**

**5MT-16**